

INSTRUCTIONS

for
the Installation, Care and Operation
of Circuit Breakers and Accessories

TYPE 2500 VALVE PORTION

MA-2500-10/2500

MAGNETIC

POWER CIRCUIT BREAKER

AND ACCESSORY EQUIPMENT

(ELECTRIC OPERATOR)

6657-1

These instructions are not intended to cover all details or variations that may be encountered in connection with the installation, operation, and maintenance of this equipment. Should additional information be desired contact the Allis-Chalmers Company.

ALLIS-CHALMERS MFG. CO.
BOSTON WORKS • BOSTON • MASS.

ALLIS-CHALMERS MANUFACTURING COMPANY

THIS IS THE
MANUAL FOR THE
MODEL 657

CONTENTS

Caution

Part 1 - Introduction

General
Proper Care is Essential to Service
Inspection and Shipping
Receipt
Storage
Remove Shipping Supports
Handling
Pre-Installation Service

SECTION NO.

Special - 8

1.1

1.2

1.3

1.4

1.5

1.6

1.7

1.8

Part 2 - Installation

General
Remove Shipping Braces
Prepare Breaker for Installation
Inspect and Check Breaker
Insertion Mechanism
Mechanical Interlock Switch
Grounding Contacts
Mechanical Interlocks
Position in Cubicle
Operate in Test Position

2.1

2.2

2.3

2.4

2.5

2.6

2.7

2.8

2.9

2.10

Part 3 - Breaker Operation

Description of Operator
Charging Springs
Closing Breaker
Opening Breaker
Manually Slow-Closing Breaker

3.1

3.2

3.3

3.4

3.5

Part 4 - Adjustments

General
Motor Coast
Closing Latch
Trip Latch
Closing Solenoid
Trip Solenoid
Spring Position Switch
Latch Check Switch
Auxiliary Switch
Interlock Plunger

4.1

4.2

4.3

4.4

4.5

4.6

4.7

4.8

4.9

4.10

ALLIS-CHALMERS MANUFACTURING COMPA

CONTENTS

SECTION NO.

Arcing Contact Hinge Joint	4.11
Contact Breakage of Hinge	4.12
Contact Alignment	4.13
Contact Lead	4.14
Contact Stroke	4.15

Part 5 - Maintenance

General	5.1
Contacts	5.2
Barrier Stacks	5.3
Breaker Timing	5.4
Lubrication	5.5
Maintenance Guide	5.6

Part 6 - Replacement Parts

How to Order	6.1
Recommend Spare Parts List	6.2
Replacing Parts	6.3
Phase Barriers	6.3a
Tilting Arc Chutes	6.3b
Barrier Stacks	6.3c

Schedule of Checks & Adjustments

Appendix A

ALLIS-CHALMERS MANUFACTURING COMPANY

ELECTRIC MOTOR MAGNETIC BREAKER AND AUXILIARY COOLING

FIG. NO.

DESCRIPTION

1

MAGNETIC BREAKER

2

ARC-GRUTE

3

STUD AND STUD

4

OPERATOR

11

AUXILIARY COOLING

**CAUTIONS TO BE OBSERVED IN THE
INSTALLATION, OPERATION, AND MAINTENANCE**

AIR MAGNETIC CIRCUIT BREAKERS

1. Examine breaker when delivered and report any shipping damage.
2. Breaker shipped **YIELD** in **CLOSE** position.
3. Remove **SHIPPING BRACES** and **FASTENINGS**.
4. Hoist breaker only with **SPRINGS** and **SHOCK** **STOP**.
5. Store to keep breaker and **INSULATION** **CLEAN** and **DRY**.
6. Operating power **LEADS** must be large enough to avoid **VOLTAGE DROP**.
7. Before adjusting or repairing, disconnect breaker from all sources of **POWER** and see that breaker is **OPEN** and **SPRINGS** are **DISCHARGED**.
8. Unbait **WLOW-OUT COILS** AND **ARC** **SUPPOTS** before tilting or chutes.
9. Avoid **CLEANING FLUIDS** detrimental to **INSULATION** or **WELDS**.
10. Keep **GRAPHITE** off **INSULATION** and **WELDS** of **INSULATION**.
11. Do not drop **Silver Contact** **Surfaces**.
12. During **SLOW-CLOSE** operation, prevent jamming mechanism by **PULLING LANYARD** when lead is picked up.
13. Reconnect **WLOW-OUT COILS** AND **ARC** **SUPPOTS** before **ENERGIZING** breaker.
14. Remove **SPRING CHARGING HANDLE** before energizing breaker control bus.
15. Remove **MECHANISM LOCKING PIN** before energizing breaker control bus.

PART I - INTRODUCTION

GENERAL

Alis-Chalmers power circuit breakers are the products of advanced research design. They are precision electrical equipment, tested to current ASA, IEEE, and NEMA Standards, and manufactured in accordance with highest standards.

PROPER CARE IS ESSENTIAL TO SUCCESSFUL OPERATION

Successful operation of this circuit breaker depends on proper installation, maintenance as a complement to quality design and construction.

The information and instructions contained in this book are to aid you in installing and maintaining this equipment so that you will obtain the highly satisfactory service of which they are capable.

The following numbering system has been adopted for ready reference in this instruction book:

1.2 -- Refers to Section 1.2 of Part I.

4-220 -- Refers to Item #220 of Illustration marked Figure 4.

Please pass this information along to your engineers, erection personnel, and servicemen who will then be better equipped to obtain maximum service from this equipment.

INSPECTION AND SHIPPING

After assembly and when circuit breakers are completed, they are subjected to a series of tests and inspections. Special care is especially taken to assure maximum protection during shipment.

RECEIPT

On receipt of the circuit breaker remove all packing braces and examine breaker and auxiliary equipment carefully to see that no damage has occurred during transit. If any injury is discovered, a claim for damages should be filed at once with the transportation company and the Alis-Chalmers Manufacturing Company notified.

STORAGE

As the breaker cannot be set up immediately in its permanent location, and it is necessary to store the equipment, it should be kept in a clean dry place protected from dust, the action of corrosive gases, from coal combustion products, etc., and from mechanical injury.

1.6 REMOVE SHIPPING SUPPORTS

This circuit breaker has been shipped locked in the closed position. Working braces that were installed to hold moving parts stationary in transit, must be removed. Fastenings installed to hold moving components of auxiliary in closed position during transit must be removed.

1.7 HANDLING

In moving a circuit breaker after shipping crates or supports have been removed, and in handling the breaker with a crane or hoist, hooks should be attached only to special supports provided for the purpose and a spreader used where necessary to prevent distortion of frame members. Avoid short catches which would place too much strain on parts of the breaker such as bushings, insulating parts, fittings, etc., which are not designed primarily for structural strength.

1.8 PRE-INSTALLATION SERVICE

Circuit breakers are completely assembled, adjusted, and tested at the factory. However, since there are possibilities that loose nuts or fastenings may have become loosened during shipping, and since the breaker, after installation, they should be checked thoroughly and any necessary adjustments made hereinafter before energization. The breaker should be operated several times manually at first, and then electrically, before and after installation in position before the breaker is ready for service.

Bushings and other insulating parts should be clean and dry. All contact surfaces should be inspected to see if they are clean and smooth. (Do not dress silver surfaces.)

PART 2 - INSTALLATION

2.1 GENERAL

Although the circuit breaker was carefully adjusted, tested and packed for maximum protection in transit, it is necessary that adequate steps be taken to prepare the unit for installation.

REMOVE SHIPPING BRACES

Breaker is shipped in closed position. Remove all shipping braces and fastenings used to hold trip latch (see Section 4.1) and other moving parts of breaker auxiliaries.

PREPARE BREAKER FOR INSPECTION

Prepare breaker for installation inspection and servicing outside of cubicle. Move phase barriers (see Section 6.1a & b) and tilt back arc chutes to expose interior of breaker (see Section 5.1).

INSPECT AND CHECK BREAKER

Examine for any moisture, dirt and other foreign material, which could impair optimum breaker performance.

Manually slow-close the breaker (see Section 3.5). Carefully watch the operation of the operator linkage and contacts. Contacts should mate properly but need not make at the end of travel on all phases.

Operate breaker several times slowly to check for smooth operation and to check adjustment of motor motor switch. (See Section 4.2).

Put arc chutes back in upright position (see Section 6.1c) and replace barriers (see Section 6.1a & b). Make certain all hardware is securely fastened, especially the six blower air connections.

INSERTION MECHANISM

Breaker insertion mechanism should be checked and lubricated if necessary for proper operation to prevent jamming during insertion. The breaker should be moved into position so that it can be rolled straight into the cubicle with minimum of friction on the wheels and guides in the cubicle. (See Section 2.6)

MECHANICAL INTERLOCK SWITCH

Mechanical interlock switch opens the spring charging motor circuit before breaker can be moved within the cubicle. Barrow (1-9) must be rotated one quarter turn allowing the switch lever to open. This action removes the under foot lever (1-40) permitting it to be depressed in order to move the breaker in the cubicle.

Switch must be locked in the closed position before operating the breaker electrically.

Wiring system is explained in Section 1.2

2.7 GROUNDING CONTACTS

Check to see that grounding fingers on the bottom of breaker will make proper contact with stationary contact in cubicle. Check for proper grounding contact when breaker is closed into cubicle.

2.8 MECHANICAL INTERLOCKS

Test mechanical interlock plunger (1-11) and make sure that it operates freely and has no binds nor interference. Plunger (1-9) must be rotated to allow switch (1-24) to open before (1-20) can be depressed.

2.9 POSITION IN CUBICLE

Move the breaker into each of its three positions in the cubicle: disconnected position, test position, and operating position. Test to make sure that breaker can be closed electrically only in its test position and in its operating position. Note that switch (1-24) must be in its closed position to energize the meter circuit. When switch (1-24) is open, none of this type of the same size and rating of circuit breaker, each of which should be tried in each of the three positions in several cubicles to ensure interchangeability.

2.10 OPERATE IN TEST POSITION

The breaker should be operated into its test position. Check to see that all parts work correctly. Make sure that secondary contacts of breaker are in alignment with secondary contacts in the cubicle.

Move the breaker slowly to its operating position. Check alignment of all breaker contacts for proper engagement with the cubicle primary studs. Alignment of breaker and cubicle primary contacts should be close enough that the contact fingers on the breaker will mesh with the studs in the cubicle without jamming. Check to see that all secondary fingers are making contact with the secondary bus.

PART 3 - BREAKER OPERATION

3.1 DESCRIPTION OF OPERATOR (Fig. 4)

The stored energy operator consists of three systems: (a) the driving system, (b) the spring linkage, and (c) the closing linkage. The systems are disengaged from each other except when performing their specific functions; thus, the driving system, the spring linkage and closing linkage are absolutely free of each other except when the spring linkage is reset and ready to be charged. Similarly, the spring linkage and closing linkage are free of each other except during a closing operation.

3.1a DRIVING SYSTEM

The driving system consists of a motor driving a pulley (4-2) which, in turn, drives the spur gears (4-3). A crank-worm gear (4-4) is mounted on each spur gear shaft; it is driven by a pin (4-5) fastened to the spur gear; and it drives the spring linkage.

3.1b SPRING LINKAGE

This system consists of four closing springs (4-6), two links (4-7), two links (4-9), one link (4-10), two links (4-11) and crank (4-12).

When the linkage is reset, the action of the driving pulley (4-2) driving the rolls (4-26) fastened to the shafts (4-23 & 4-24) go over a toggle. At the start of this operation, link (4-7) is in tension, allowing a gap between latch (4-13) and the roll (4-19). Following part way through the charging operation, as the linkage arm being charged, the action of roll (4-19) moving against latch (4-13) will be heard. The action of links (4-9 & 4-10) going over toggle will be heard at the end of the charging operation.

Releasing closing latch (4-13) allows the closing springs to drive the breaker closing linkage (see below). During this operation, the spring charging linkage remains over toggle until the end of its stroke when the toggle is broken by crank (4-12) striking the kick-off screw (4-32). The spring linkage immediately resets allowing the breaker closing linkage room to reset when tripped.

3.1c BREAKER CLOSING LINKAGE

This system consists of two links (4-21) and arm (4-22). It is always free to operate in any of its positions as it is not secured to the spring charging linkage.

In the closing operation the spring closing linkage drives toggle roll (4-15) over toggle against stop (4-39) thereby closing the breaker through arm (4-23). Depressing latch (4-27) during a closing operation prevents the breaker from closing, thereby making it trip free.

3.2 CHARGING SPRINGS

The closing springs (4-6) will charge as soon as the breaker control bus is energized. Should the springs not charge, check the motor cutoff adjustment (see Section 4.2).

The springs can be manually charged by turning the charging handle down guide tube (1-27) to engage the gearmotor. Rotate the handle in the direction shown until the spring linkage is locked in the over toggle (see Section 3.1b).

REMOVE CHARGING HANDLE FROM GUIDE TUBE BEFORE ENERGIZING BREAKER CONTROL CIRCUIT.

3.3 CLOSING BREAKER

When the springs are fully charged, the breaker can be closed manually by pulling lanyard (1-26) or electrically by energizing the closing circuit. This rotates latch (4-13) allowing the linkage (4-5) to close the breaker.

3.4 OPENING BREAKER

The breaker can be tripped manually by depressing trip bar (1-43) or electrically by energizing the trip circuit. This rotates latch (4-27) allowing the opening linkage to operate and reset.

The tripping action described above can occur at any time during a closing operation, either manual or electrical, and regardless of whether or not the armature is energized. The mechanism is electrically and mechanically trip free in any position.

3.5 MANUALLY SLOW CLOSING BREAKER

In order to check and make adjustments, the breaker can be closed slowly and mechanically held in any position of the closing stroke. The following procedure should be followed:

- a.) Remove breaker from service and all are charges back.
- b.) Be certain that control circuit is open and closing springs are discharged.
- c.) Insert mechanical locking pin into hole (1-25). It will be necessary to rotate lever (1-29) to allow pin to pass through hole. The pin will pass behind crank (1-30) and through hole in opposite side of operator frame.
- d.) Insert spring charging handle into guide tube (1-27) and engage with gearmotor. Turn handle in direction opposite to direction indicated on shield until resistance is felt. Pull manual closing lanyard (1-26) and continue turning handle. The breaker contacts will slowly close.

3.5 MANUALLY SLOW-CLOSING BREAKER (Continued)

CAUTION: As the contacts approach the breaker closed position, observe the position of cranks (4-4) on rolls (4-24). Care should be taken that the cranks do not pass by the rolls, which will cause the contacts to snap open.

Since the motor gears are self-locking, the contacts can be cranked to any position and held for adjustment checks.

a) To prepare for normal operation

1. Trip breaker open.

2. Remove spring charging lever.

3. Remove mechanism locking pin.

PART 4. ADJUSTMENTS

4.1 GENERAL

The breaker has been completely assembled and tested at the factory. However, adjustments or fasteners may be changed or become loosened during shipment, storage, or installation. It should be checked and corrected, if necessary, before breaker is operated. Manual operation of breaker should be used for preliminary operation to see that all parts are free and work smoothly. The bushings and other insulating parts should be clean and dry. All contact surfaces should be inspected to see that they are clean and smooth. (Do not drop all the phases). Removal of all phase barriers and removal or raising of terminal assemblies gives access to breaker for checking adjustments.

The paragraphs immediately following give the proper adjustments and methods of making same on the Allis-Chalmers Model A-1 Magnetic Power Circuit Breaker. Adjustment values are all tabulated in Appendix B attached.

4.2 MOTOR COAST (Fig. 4)

The motor cut-off switch (4-12) should open the motor circuit to allow the driving cranks (4-4) to coast after the motor has stopped. Adjustment is made by means of screw (4-13). Turn screw clockwise, adjust screw to just touch switch roll.

4.3 CLOSING LATCH (Fig. 4)

The closing latch (4-13) should engage its roll (4-14) approximately $5/32$ above the lower edge of the latch face. Adjustment is made by screw (4-26). If unstable increase bite. If hard to close decrease bite.

4.4 TRIP LATCH (Fig. 4)

The trip latch (4-27) should engage its roll (4-14) approximately $5/32$ above the lower edge of the latch face. Adjustment is made by screw (4-65).

When the breaker is "open", the trip latch (4-27) should clear its latch roll (4-14) by $1/32 \pm 1/64$. Adjustment is made by screw (4-75).

4.5 CLOSING SOLENOID (4-37)

The armature should move freely and have no binds. There should be clearance between the trip pin and latch when the solenoid is de-energized. The travel of the armature should be such that manual actuation will trip the latch and have a $1/8$ to $3/16$ after travel. Adjustment is made by shimming the solenoid.

4.6 TRIP SOLENOID (4-36)

Action and adjustment are identical to closing solenoid (see Section 4.5).

4.7 SPRING POSITION SWITCH (4-34)

The spring position switch (4-34), which is mounted on top of the operator frame, indicates when the springs are charged. Its contacts should close just before the springs are completely charged. Adjustment is made by screw (4-35).

4.8 LATCH CHECK SWITCH (4-1)

The latch check switch, which is mounted on the front of the operator, opens the closing circuit when the trip latch is not set. Proper adjustment has been made and should require no change.

4.9 AUXILIARY SWITCH (Fig. 5)

The auxiliary switch (11-15) has been adjusted at the factory and should normally not require further adjustment. However, before the breaker is placed in service a check should be made to see that the break arm (11-10) throws approximately equal distances on either side of a vertical center line. The adjustment for throw of break arm is made by positioning the clevis on the auxiliary switch connecting rod. After correct adjustment is made, make sure all fastenings and locknuts are secure. Each rotor (11-3) can be adjusted individually in steps of 1 degree merely by pressing the contact to one side against the spring and rotating it within its insulated rotor housing until it snaps into the desired position.

4.10 INTERLOCK PLUNGER (Fig. 1)

The foot lever (1-20) operates the interlock plunger (1-18) as well as the trip latch. Depressing the lever will raise the interlock plunger (1-18) sufficiently to release the breaker plunger if it is not down in the suble. The interlock is in proper adjustment when the plunger (1-18) is positioned to $1\frac{3}{4} \pm \frac{1}{16}$ above the floor line, and causes tripping of breaker contacts when it is raised to a level not more than $2\frac{1}{16}$ above the floor line. The latch tripping rod associated with the foot lever should be clear of the trip latch (4-27).

4.11 ARCING CONTACT HINGE JOINT (Fig. 3)

The arcing contact joint is in proper adjustment when each spring washer is deflected approximately 0.015 inches.

This adjustment is obtained by tightening nut (3-4) until all parts are snug fit; then tighten the nut $\frac{3}{4}$ to 1 turn more.

4.12 CONTACT PRESSURE OF HINGE JOINT (Fig. 3)

When the hinge joint contact is in proper adjustment, a pull of from 7 to 9 lbs is required to move the contact toward the open position. This pull is measured as follows:

Remove pin (1-46) and detach link (1-47) from the disconnect arms (3-18) and (3-19). Move the disconnect to a position just short of "contact make".

Attach a spring scale to the disconnect eight inches above screw (3-24) and in a direction perpendicular to the longest edge of the disconnect arm. A pull of from 7 to 9 lbs should be applied to move the disconnect toward the open position.

Adjustment is made by tightening screw (3-22) but (3-20).

Before attaching link (1-47) to disconnect arms (3-18) and (3-19), check contact alignment (Section 4.13) and (3-20) (Section 4.14).

4.13 CONTACT ALIGNMENT (Fig. 3)

The horizontal pairs of main contacts (3-9) should "make" with the moving contact simultaneously. (Note: Contacts on different phases should not necessarily "make" simultaneously.)

On MA-75/150B Breakers: - If not already detached, remove pin (1-46) and detach link (1-47) from disconnect arms (3-18) and (3-19). Detach arcing contact (3-10) from yoke (3-2) by removing pin (3-26). Move the disconnect toward the closed position until it just touches a main contact finger. (See Fig. 3, View A-A, main contacts opening). Dimension g should then be no greater than .020 inches.

On MA-250B Breakers: - Remove pin (1-46) and detach link (1-47) from disconnect arms (3-18) and (3-19) of two phases. With the main contact closing device move the disconnects of the remaining two phases toward the closed position until a main contact finger is touched. Dimension g should then be no greater than .020 inches.

Adjustment is made by loosening screw (3-22) and rotating the contact assembly. Alignment (dimension g) should be checked after tightening nuts (3-22).

Alignment is checked and adjusted on each phase separately. Be sure there are no binds between contacts (3-1) preventing proper wiping action with the disconnect arms.

Attach arcing contact (3-10) to yoke (3-2), but check contact lead (Section 4.14), before attaching link (1-47) to disconnect arms (3-18) and (3-19).

4.14 CONTACT LEAD (Fig. 3)

Contact lead should be checked and adjusted only when the contacts are in alignment (see Section 4.13).

The arcing contacts (3-9, 10, 21, 22) should "make" before the main contacts. Measure and adjust each phase as follows:

If not already detached, remove pin (1-46) to detach link (1-47) from disconnect arms (3-18) and (3-19). Move the disconnect toward the closed position until the arcing contacts just touch (See Fig. 3, View A-A, arcing contacts engaged).

The shortest gap between the bottom arcing fingers (3-11) and the disconnect arms (3-18) and (3-19) should be $1/16$ inch plus $0, \pm 1/32$. (Dimension b in View A-A of Fig. 3). Adjustment is made by loosening or tightening nut (3-1).

Reconnect link (1-47) to disconnect arms (3-18) and (3-19) using pin (1-46).

4.15 CONTACT STROKE (Fig. 3)

Contact stroke should be checked and adjusted only when the contacts are in proper alignment. (See Section 4.13).

In order to insure proper wiping action and prevent arcing, the stroke of the disconnect must be maintained in proper alignment. Check and adjust as follows:

With breaker in closed position, dimension g (View A-A of Fig. 3) on the top pair of fingers should be $1/16$ inch plus $0, \pm 1/32$. Adjustment is made with the breaker in the open position by increasing or decreasing the effective length of link (1-47) by means of nuts (1-40). Each phase is adjusted individually.

After making the above adjustments on all three phases, trip the breaker open and check to see that dimension g is $1/16$ inch plus $0, \pm 1/32$ on all three phases. (On breakers with more than four contacts per phase, dimension g is still measured to the second from top contact.)

Adjustment for dimension d is made by first removing pin (1-33) on each puffer. After loosening nut (1-42), increase (or decrease) effective length of red end (1-40) by turning (or unturning) it into pin (1-41). Adjust red ends (1-40) on both puffers the same amount. Tighten nuts (1-42), replace pin (1-33), and check dimension d.

PART 3 - MAINTENANCE

3.1 GENERAL

Safety of the operator and continuity of electric service of loads connected to circuit breakers are dependent upon proper operation of the breakers. In order to keep circuit breakers in proper order, it is recommended that a routine service inspection should be made at six month or 1000 operation intervals, whichever comes first. The actual service interval and the amount of servicing required will usually be determined by the particular conditions at the installation and will be influenced by such things as the number of operations, number of fault interruptions, cleanliness of the equipment and past experience with the equipment.

Servicing is usually extended to cover lubricating, cleaning, lubricating, tightening, inspection, tests, etc. A permanent record is usually desirable and should list for each serial number, the date, operation counter reading, general condition of equipment, and remarks by serviceman.

Be sure that the breaker and its mechanism is disconnected from all electric power and that the breaker is in the open position before any maintenance is attempted.

3.2 CONTACTS

Inspect all contacts frequently. Replace worn contacts with new ones. Replace badly pitted or burned contacts with new ones. Do not attempt to clean contacts as to cause improper operation of the breaker.

3.3 BARRIER STACKS

The barrier stacks are fragile and should be handled carefully. The barrier stacks should be inspected for erosion of the plates in the areas of the slots. The stacks should be replaced when a hole is observed on the full length of the edges of most of the slots. They should be likewise replaced if plates are broken or cracked. When cleaning the breaker and subcircuit, inspect for pieces of barrier stack or foreign material which would obviously indicate breakage.

3.4 BREAKER TIMING

Check the contact adjustment and timing, also check adjustments of auxiliary equipment and see that it is properly adjusted. A comparison of breaker timing at any period of maintenance with that taken when the breaker was new will immediately indicate a condition of misadjustment or friction should the timing vary more than 2 cycles on opening or 3 cycles on closing with the same coils.

5.5 LUBRICATION

Lubrication is of the utmost importance and a special effort should be made to assure that all moving parts are kept clean and properly lubricated at all times. The disconnect hinge and the wheel armature are lubricated with microfine dry graphite. Graphite should be rubbed in well and all excess carefully removed.

CAUTION: GRAPHITE MUST BE KEPT OFF OF SKIN UNDER PENALTY OF REPLACEMENT, AS IT CANNOT BE EASILY REMOVED.

Bearing Pins and other moving parts will be lightly lubricated with a light film of Beasox P-290 or equal. Ball bearings will in general not require frequent lubrication, but they should be taken to prevent entrance of dirt and foreign matter. Mating surfaces of main and arcing contacts will not be lubricated.

5.6 MAINTENANCE OUTLINE

Refer to the attached "Operation, Maintenance and Lubrication", Appendix A, for a digest of pertinent instructions. As additional information, a guide to simple and convenient maintenance procedures.

PART 4 - REPLACEMENT PARTS

6.1 HOW TO ORDER

When ordering replacement parts, it is very important to give complete information. This information should include:

- (1) Breaker serial number
- (2) Number of pieces required
- (3) Reference number
- (4) Instruction book number
- (5) Description of part (See instruction book descriptions where possible)
- (6) Rated voltage of all circuit breakers, and coils ordered
- (7) Rated amperes of all circuit breakers, and coils ordered
- (8) Rated voltage of breaker
- (9) Rated amperes of breaker

The breaker serial number is necessary in obtaining the correct identity of a part; without this serial number, All American Mfg. Co. cannot be sure of the correct identity of the desired part.

If any doubt exists as to the instructions or references in the description, a dimensional sketch of the desired part will help to properly identify it.

6.3 REPLACING PARTS

Before removing any part, observe its location and adjustment. By so doing, it is usually possible to avoid any appreciable amount of adjustment work after the installation of the replacement part.

CAUTION: BEFORE REMOVING ANY PART, MAKE SURE THAT THE BREAKER AND ITS OPERATING MECHANISM IS DISCONNECTED FROM ALL ELECTRIC POWER AND THAT THIS BREAKER IS IN THE OPEN POSITION.

6.3a PHASE BARRIERS (Fig. 1)

Lift wires of panel spring assembly out of slots (1-14) to release panel (1-32). Lift and remove panel. Remove center phase screw (1-23). The phase barrier assemblies (1-19) can now be lifted and removed from the breaker. Note: On Model 100, remove screw (1-17) and remove barrier (1-25) prior to above operation.

6.3b TILTING AND CHUTES (Fig. 1)

Remove phase barriers (see Section 6.3a). Remove screws (1-23), (1-37) of each phase. Remove screws (1-25) and (1-17) to remove barriers (1-19) and (1-22). With arc chutes supported in place, tilt back the arc chutes.

After tilting arc chutes upright, and replacing barriers, be sure screws (1-17) (1-23), (1-37), and (1-39) are tightened securely on all three phases.

6.3c BARRIER STACKS (Fig. 1)

Tilt back arc chutes (See Section 6.3b). Remove four screws (2-2), barrier (2-1), from each arc chute. Slide barrier stack (2-23) through top of arc chute.

When sliding a barrier stack into the chute, care should be taken to see that the end containing the two copper pins goes in first.

APPENDIX A

SCHEDULE OF CHECKS AND ADJUSTMENTS

This tabulation is intended to serve as a ready reference for servicing of this equipment. Other items may be added as experience dictates. For a thorough understanding of the breaker, it is recommended that the instruction book be studied.

- 1- Breaker should be prepared for service outside of its cubicle. Breaker must be in the open position and disconnected from electric power. Remove phase barriers (Section 6.3a) and tilt the breaker to expose breaker interior (Section 6.3b). Remove screws (1-23), (1-27), and (1-39), and Barrier (1-32) prior to raising arc chutes.
- 2- Operate breaker manually to check for full operation and freedom of movement.
- 3- Visually inspect all parts during all phases of servicing.
- 4- If a travel recording device is available, it will furnish an excellent indication of the mechanical operation of the breaker. Refer to Section 5.4.
- 5- Clean all parts of breaker. An air blower is useful in removing dust from generally inaccessible places.
- 6- Check meter current per Section 4.2.
- 7- Check trip latch (1-27) adjustment per Section 4.4.
- 8- Check latch roll stop screw (1-7) adjustment per Section 4.4.
- 9- Check closing latch (1-13) adjustment per Section 4.3.
- 10- Check trip solenoid (1-36) adjustment per Section 4.5.
- 11- Check closing solenoid (1-37) adjustment per Section 4.3.
- 12- Check control relay for proper action.
- 13- Operation counter is actuated by a spring which should be adjusted for minimum force by positioning of the control arm. Record counter reading.
- 14- Check trip interlock plunger (1-18) per Section 4.10.
- 15- Check all wiring for frayed or broken wires, tighten all terminals.
- 16- Check all hardware for tightness. Note that Stever locknuts are used in many places. These nuts may be identified by the slightly egg-shaped hole on one end and the parallel grooves on the corresponding face of the nut.
- 17- Operate breaker manually and electrically. Check operation at minimum close and trip voltage if possible.
- 18- Check spring position switch for proper action per Section 4.7.

19- Remove disconnect arms as a unit by removing screw (3-24) and nut (3-14). Refer to Fig. 3. Carefully inspect all contact surfaces in hinge joint. Silver washer (3-25) and adjacent surfaces should be clean and free of roughness or galling. Lubricate silver washer and contact surfaces by rubbing in microfine dry graphite used sparingly. Reassemble disconnect arms. Tighten hinge joint per Section 4.12.

20- Check arcing contact hinge joint.

21- Inspect condition of auxiliary switch contacts.

22- Inspect condition of control relay contacts.

23- Check contact alignment per Section 4.12.

24- Check contact lead per Section 4.12.

25- Check contact stroke per Section 4.12.

26- Check for barrier stack condition per Section 4.12.

27- Check condition of contacts.


28- Reassemble breaker. Be sure screws (1-47) and (1-39) are secured in each phase.

29- Check breaker in subside. Check for proper operation of trip interlock plunger in test position and fully inserted position. Check secondary wiring fingers for good contact. Check grounding contact for good contact.

30- GENERAL

The above points will provide a quick reference for maintenance procedures. Other items may be added as experience dictates. For a thorough understanding of the equipment, the instruction book should be studied. Refer to Part 5 for general comments on maintenance and lubrication.

ALLIS-CHALMERS MANUFACTURING COMPANY



STAY WITH US: TV, IDA!

ALLIS-CHALMERS MANUFACTURING COMPANY





FIG 2

ALLIS-CHALMERS MANUFACTURING COMPANY



ALLIS-CHALMERS MANUFACTURING COMPANY




FIG. 4

ALLIS-CHALMERS MANUFACTURING COMPANY




FIG. 11

TYPICAL AUXILIARY SWITCH