

INSTRUCTIONS

GEI-88765
Supersedes GEI-88765

To: R. BISSER

From: S. RICHTER

OK 1-1-1976

OK

9-4-76


MAGNE-BLAST CIRCUIT BREAKER

TYPES

- AM 13.8-750-2C
- AM 13.8-750-2CB
- AM 13.8-750-2H
- AM 13.8-750-2HB
- AM 13.8-750-3C
- AM 13.8-750-3CB
- AM 13.8-750-3H
- AM 13.8-750-3HB

CONTENTS

Introduction.....	1
Receiving, Handling and Storage.....	2
Installation.....	2
Description of Operation.....	4
Adjustments.....	6
General Maintenance.....	12
Renewal Parts.....	30



SWITCHGEAR DEPARTMENT

GENERAL  ELECTRIC

PHILADELPHIA, PA.

www.ElectricalPartManuals.com

MAGNE-BLAST CIRCUIT BREAKER

AM-13.8-750-2 (Δ) and AM-13.8-750-3 (Δ)

Δ Letter Designation B, C, and H, used immediately following the model number indicates basic design features.

INTRODUCTION

The magne-blast circuit breaker is the removable interrupting element for use in vertical-lift metal-clad switchgear, to provide reliable control and protection of power systems. Among the many advantages of metal-clad switchgear are added protection to equipment and personnel, compactness, simplified installation and reduced maintenance. In keeping with these features the magne-blast breakers are designed for interchangeability and maneuverability, together with reliability and low maintenance requirements.

The magne-blast circuit breaker operates on the principle that an arc can be interrupted in air by sufficiently elongating and cooling it. This is accomplished by means of a strong magnetic field that lengthens the arc and forces it into intimate contact with cool dielectric material. A sturdy, reliable operating mechanism assures low maintenance and long life.

The AM-13.8 magne-blast breaker is available in a number of current ratings. Refer to the breaker nameplate for the complete rating information of any particular breaker. The short circuit conditions to be imposed on the breaker must not exceed its rating, nor should it be called upon to operate at voltages or currents greater than those given on the nameplate. Since this book is written to cover several ratings of breakers that are of the same general design, all instructions will be of a general character and all illustrations will be typical, unless otherwise specified.

PROPER INSTALLATION AND MAINTENANCE ARE NECESSARY TO INSURE CONTINUED SATISFACTORY OPERATION OF THE BREAKER. The following instructions will provide complete information for placing magne-blast breakers in service and for maintaining satisfactory operation.

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

www.ElectricalPartManuals.com

Spring Charging

The mechanism consists of a high speed gear motor that compresses a set of closing springs through the action of a simple eccentric, ratchet, and pawl assembly. The rotary action of the motor (2) Fig. 4 is converted to a short straight stroke pumping action through the eccentric (6) and a lever that carries a spring loaded driving pawl (5).

The pawl advances the ratchet wheel (3) Fig. 3 only a few degrees each stroke where it is held in position by the latching pawls (1). When the ratchet wheel has been rotated approximately 180 degrees the closing springs (6) will be fully compressed. As the ratchet wheel continues to rotate, the spring load will shift over center and attempt to discharge. After only a few degrees of rotation, the closing roller (10) Fig. 1 will engage the closing latch (11) and the compressed springs will be held in repose until a closing operation is required. During the last few degrees of the ratchet wheel rotation the motor and interlock switches (6) are released and the driving pawl is raised from the ratchet wheel surface. This allows the motor and driving mechanism to coast to a natural stop expending all residual energy.

During the time the springs are being compressed a relay (6) Fig. 6 locks the closing power circuits open and the relay will remain energized until the springs are fully charged and the control contacts are re-set.

The closing springs may be charged manually if control voltage is lost. A 5/8" ratchet wrench can be used to rotate the eccentric in a counter clockwise direction until the indicator reads "CHARGED" and the driving pawl no longer engages the ratchet wheel. The use of the ratchet wrench provides for maximum safety in the event that control power is suddenly restored without warning. In this event, the motor drive will take over again and continues to charge the springs.

Closing Operation

Closing the breaker is accomplished by energizing the closing solenoid or by manually pressing the close button. In either case, the closing latch is removed from the spring blocking location allowing the springs to discharge. The energy of the springs is applied to the rotation of a cam (16) Fig. 5 that closes the breaker through a simple linkage that remains trip free at all times. A monitoring switch (11) Fig. 6 on the closing latch will start the spring charging motor after it is fully reset.

Opening Operation

An electrical opening operation is initiated by energizing the trip coil. This is accomplished either by actuating the opening control switch on the metal-clad unit or by a combination of relays and current devices used to detect a fault on the load side of the breaker. By energizing the trip coil, the trip plunger rotates the trip latch (7), Fig. 5, causing the operating mechanism linkage to collapse. The

www.ElectricalPartManuals.com

energy stored in the opening springs is thus released, opening the breaker. During this operation, the trip coil circuit is deenergized, and upon completion of the opening operation, the operating mechanism is returned to its normal position, ready for closing.

As the breaker opens, the main contacts part first, shunting the current through the arcing contacts. An arc forms as the arcing contacts part. See Fig. 7. As the movable arcing contact (27) is withdrawn from the area of the arc runner, the upper end of the arc is transferred to the upper arc runner (4). To assist the interruption at this point, a stream of air is emitted from the booster tube (28) and forces the arc onto the lower arc runner (10). Establishment of the arc on the runners automatically inserts the blowout coils into the circuit, introducing a magnetic field between the pole pieces which tends to draw the arc away from the arcing contacts. The interrupter contains four upper blowout coils and four lower blowout coils each individually connected in series with its respective section of arc runner. As the arc is forced outward along the diverging arc runners, the magnetic field is progressively increased with the addition of each coil in the circuit.

At the same time, the arc is being forced into the arc chute (8) which is composed of a series of gradually interleaving insulating fins. These fins, which project alternately from the two opposite surfaces of the chute, elongate the arc into a gradually decreasing serpentine path, so that the electrical resistance in the path of the arc is rapidly increased and the heat from the arc is absorbed. The increased resistance reduces both the magnitude and the phase angle of the current, and at an early current-zero the arc path is so long and the gases produced by the arc so cooled that the arc cannot reestablish itself. Interruption occurs.

Manual tripping follows the same procedure except that instead of energizing the trip circuit, the manual trip (11) Fig. 2 is used.

Trip Free Operation

If the trip coil circuit is energized while the breaker is closing, the trip plunger will force the trip latch (8) Fig. 5 away from the trip roller (9) causing the mechanism linkage to collapse and the breaker to re-open. The closing cam (16) will complete its closing stroke and the springs will re-charge as in a normal closing operation.

ADJUSTMENTS

All adjustments should be checked during periodic inspections and whenever it becomes necessary to repair or replace parts that have become worn or defective while in service. The following adjustments are listed in the order in which they are to be checked. First, however, remove the breaker from the metal-clad unit and remove the box barriers and front cover.

www.ElectricalPartManuals.com

"DO NOT WORK ON EITHER THE BREAKER OR MECHANISM UNLESS THE CLOSING SPRINGS ARE BLOCKED AND THE OPENING SPRINGS HAVE BEEN TRIPPED OPEN OR MECHANICALLY BLOCKED. THIS MEASURE IS REQUIRED TO PREVENT ACCIDENTAL CLOSING OR TRIPPING."

Primary Contact Wipe

When the breaker is closed, as shown in Fig. 8, the stationary primary contacts (1) should rise to a dimension of $5/16" + 0 - 1/16$. Before checking this dimension be sure the mechanism is re-set so that the prop pin (13) Fig. 5 is resting on the prop. To obtain the proper contact adjustment, open the breaker and, referring to Fig. 9, loosen the check nut (4) and turn the adjusting nut (3). Screwing up on the adjusting nut will decrease the primary contact wipe, down will increase it. Tighten the check nut, close the breaker and recheck the wipe. With the primary contact wipe correctly adjusted, the clearance between the contact arm (6) and the buffer block should be $1/16"$ or greater (as shown in Fig. 8) when the breaker is fully closed.

Arcing Contact Wipe

Refer to Fig. 8. Close the breaker until the arcing contacts just touch. This can be determined with the use of a circuit continuity tester such as a light indicator or bell set. In this position, the gap between the stationary primary contacts (1) and the movable primary contact (2) should be $5/16"$ or greater. This setting has been made at the factory and no adjustment is provided. A wipe of less than $5/16"$ is usually an indication that the arcing contacts need to be replaced. When making this check, also be sure that the movable arcing contact (5) does not touch the upper bumper.

Primary Contact Gap

Refer to Fig. 9. With the breaker closed, press the manual trip button allowing the breaker to trip open normally. Do not force the contacts open wider by hand. The gap between the stationary primary contacts (5) and the movable primary contact (6) should be $5-1/4" + 5/16" - 1/8"$. To change this gap, loosen the check nut (17), Fig. 5 and turn the adjusting nut (18) on stud (19). Screwing the adjusting nut down will decrease the primary contact gap. Tighten the check nut and re-measure the contact gap (close and trip the breaker before checking the measurement).

Trip Latch Wipe

Refer to Fig. 5. The wipe of the trip latch (8) on the trip roller (9) should be from $3/16"$ to $1/4"$. This can be measured by putting a film of grease on the latch (8), closing the breaker part way, and tripping. The mechanism has the proper trip latch wipe when the latch rests against the stop pin (23). No adjustment is provided and a visual

www.ElectricalPartManuals.com

GEI-88765

Inspection is usually all that is required. If this setting is not correct, look for insufficient travel of the trip shaft (7).

WHEN WORKING ON THE MECHANISM IN THE CLOSED POSITION, KEEP FINGERS CLEAR OF THE LINKAGE, AS ACCIDENTAL TRIPPING CAN CAUSE SEVERE INJURY.

Trip Latch Clearance

Refer to Fig. 5. With the breaker in the tripped position and the closing springs charged, check the clearance between the trip latch (8) and the trip roller (9). It should measure $1/32"$ to $1/16"$.

Prop Clearance

Refer to Fig. 5. With the breaker closed as far as possible, that is, with the springs blocked and the cam (16) rotated so that the prop pin (13) is at its maximum height over the prop (14), the clearance between the prop and prop pin should be $1/16"$ to $5/32"$. No adjustment is provided and a visual inspection is usually all that is required.

Release Latch Wipe

Refer to Fig. 6. The wipe between the release latch (3) and roller (2) should be $3/16"$ to $1/4"$. If re-setting is required, loosen, set, and re-tighten adjustment nut and screw (4).

Release Latch Monitoring Switch

The release latch must be fully re-set and the monitoring switch operated before the motor will start. The switch should be wiped by the striker so that the clearance between the striker and switch mounting bracket (20) Fig. 6 is $1/32"$ or less. To obtain this adjustment bend the switch striker. Be sure the latch is fully re-set before making any adjustments.

Motor and Relay Switches

With the closing springs blocked rotate the switch cam (1) Fig. 6 until the switch striker (8) has traveled the maximum amount (about 180 degrees rotation of cam). Loosen mounting bolt (14) and rotate switch support (15) until the gap between the striker (8) and support (15) is $1/32"$ or less.

Interlock Switch Wipe

Refer to Fig. 10. Rotate the interlock shaft (1) manually clockwise to release the interlock switch arm (2). The point at which the contacts make can be determined with a circuit continuity tester such as a light indicator or bell set. To obtain adjustment on the interlock switch (3), bend the interlock switch arm (2) until there is a maximum of $1/32"$ clearance to the switch mounting plate (4).

www.ElectricalPartManuals.com

Plunger Interlock

Refer to Fig. 13. With the breaker in the close position, the vertical distance "A" from the top of the interlock bolt (1) to the bottom of the elevating bar (3) should be $11-9/32$ " plus or minus $1/16$ ". To change this adjustment, add or remove washers (2).

Spring Release Interlock

A spring release interlock shown in Fig. (6A) will assure that the breaker contacts are open and the closing springs discharged when inserting or removing the breaker from the metal-clad unit. If the closing springs are charged and/or the breaker is in the closed position when being inserted or withdrawn from the metal-clad unit, the release interlock will trip the breaker open and hold the mechanism in a trip-free position while discharging the closing springs.

Auxiliary Fuses

Refer to Fig. 15. On breakers with "C" suffixes, a set of protecting fuses (4) are mounted on the front of the breaker. These fuses will be the primary protection devices for the closing control circuits on those breakers that are used in metal-clad units designed for sole-mold operated breakers.

Inspection and Test

1. For ease in reviewing the adjustments, the following are recapitulated:
 - a. Primary contact wipe: $3/16$ " +0 - $1/16$ "
 - b. Arcing contact wipe: $3/16$ " or greater (gap at primary contacts)
 - c. Primary contact gap: $5-1/4$ " + $5/16$ " - $1/8$ "
 - d. Trip latch wipe: $3/16$ " to $1/4$ " with trip latch resting against stop pin.
 - e. Trip latch clearance: $1/32$ " to $1/16$ "
 - f. Prop clearance: $1/16$ " to $5/32$ "
 - g. Release latch wipe: $3/16$ " to $1/4$ "
 - h. Release latch monitoring switch: maximum clearance $1/32$ "
 - i. Motor and relay switch: maximum clearance $1/32$ "
 - j. Interlock switch: maximum clearance $1/32$ "
 - k. Auxiliary switch: contacts are closed when breaker primary contact gap is 1" or greater.
 - l. Driving and latching pawl: minimum clearance to ratchet teeth .015"
 - m. Latch checking switch contacts make when the gap between the trip latch and the stop pin is $1/16$ "
 - n. Plunger interlock: $11-9/32$ " plus or minus $1/16$ "
2. Check all nuts, washers, bolts, cotter pins, and terminal connections for tightness.

www.ElectricalPartManuals.com

3. Inspect all wiring to make sure that no damage has resulted during installation, and test for possible grounds or short circuits.
4. See that all bearing surfaces of the mechanism have been lubricated. Refer to the section on LUBRICATION.
5. Operate the breaker slowly with the manual charging wrench and note that there is no excessive binding or friction and that the breaker can be moved to the fully opened and fully closed positions.
6. See that any place where the surface of the paint has been damaged is repainted immediately.
7. Check the trip coil plunger and the release coil plunger to see that they move freely.

Opening and Closing Speeds

The closing speed of the arcing contact of the breaker should be a minimum of 11 feet per second. This represents the average speed of the movable arcing contact from a point 1" before the tip is tangent to the lower surface of the upper arc runner to the tangent position.

The opening speed of the arcing contact should be a minimum of 15 feet per second. This represents the average speed over 3" from the point when the tip on the movable contact is tangent to the lower surface of the upper runner.

Control Power Check

After the mechanism has been closed and opened slowly several times with the maintenance closing wrench and the mechanism adjustments are checked as described, the operating voltages should be checked at the release coil, trip coil, and motor terminals. For electrical operation of the mechanism, the control power may be either an alternating or direct current source. The operating ranges for the closing and tripping voltages are given on the breaker nameplate. The following ranges are standard:

Nominal Voltage	Closing Range		Tripping Range	
	Min.	Max.	Min.	Max.
48v d-c	34	- 50v d-c	28	- 60v d-c
110v d-c	80	- 115v d-c	60	- 125v d-c
125v d-c	90	- 130v d-c	70	- 140v d-c
220v d-c	160	- 230v d-c	120	- 250v d-c
250v d-c	180	- 260v d-c	140	- 280v d-c
115v a-c	95	- 125v a-c	95	- 125v a-c
230v a-c	190	- 250v a-c	190	- 250v a-c

www.ElectricalPartManuals.com

GEI-88765

If the closed circuit voltage at the terminals of the coil or motor does not fall in the specified range, check the voltage at the source of power and line drop between the power source and breaker.

When two or more breakers operating from the same control power source are required to close simultaneously, the closed circuit voltage at the closing coil or motor of each breaker must fall within the specified limits.

Electrical closing or opening is accomplished by merely energizing the closing or trip coil circuit. Control switches are provided for this purpose on the metal-clad unit. It is also possible to trip or close the breaker manually by pressing the manual trip lever (11) Fig. 2 or the manual close button (7).

Before the breaker is finally raised into position in the metal-clad unit, rub a small amount of G-E contact lubricant D50H47 on the silvered portion of the breaker studs to form a thin coating for contacting purposes.

GENERAL MAINTENANCE

Dependable service and safer power equipment are contingent upon the unflinching performance of the power circuit breaker. To maintain such service, it is recommended that a definite inspection and maintenance schedule be set up and followed, as serious shutdowns can often be avoided by locating potential sources of trouble in an early stage. A periodic lubrication of parts subject to wear is also vitally important for the successful operation of the breaker.

BEFORE ANY MAINTENANCE WORK IS PERFORMED, MAKE CERTAIN THAT ALL CONTROL CIRCUITS ARE OPENED AND THAT THE BREAKER IS REMOVED FROM THE METAL-CLAD UNIT. DO NOT WORK ON THE BREAKER OR MECHANISM WHILE IN THE CLOSED POSITION UNLESS THE PROP AND TRIP LATCH HAVE BEEN SECURELY WIRED OR BLOCKED TO PREVENT ACCIDENTAL TRIPPING. DO NOT WORK ON THE BREAKER OR MECHANISM WHILE THE SPRINGS ARE CHARGED UNLESS THEY ARE SECURED IN THAT POSITION BY THE MAINTENANCE SPRING BLOCKING DEVICE.

Periodic Inspection

The frequency of periodic inspection should be determined by each operating company on the basis of the number of operations (including switching), the magnitude of currents interrupted, and any unusual operations which occur from time to time. Operating experience will soon establish a maintenance schedule which will give assurance of proper breaker condition. On installations where a combination of fault duty and repetitive operation is encountered, an inspection is recommended after any severe fault operation. The following instructions list the main points to be included in an inspection and, a number of general recommendations.

www.ElectricalPartManuals.com

Arc Chutes

It is not necessary to inspect the arc chutes unless there is evidence of damage or if the arc chutes are removed for any reason. When inspecting an arc chute, it should be disassembled and the following points noted:

1. Scale formed over the surface of the arc chute must not be removed, but loose particles collected in the chute should be blown out.
2. Cracks which have formed in the fins of the arc chute are to be expected in ceramic materials of this type when subjected to the severe heat of an arc. These cracks do not interfere with the operation of the device in any way and should be disregarded.
3. If the arc chute has suffered any mechanical injury due to dropping or accidental striking, resulting in the actual breaking off of fins, replacement of the chute will be necessary. Small broken corners on the exhaust end of the chute will not interfere with its performance and can also be disregarded.
4. The plastisol flexible covering for the pole pieces (3 & 4) Fig. 16 and the upper mounting support (13) Fig. 16 should be inspected for breaks in the insulation. If there are holes or breaks in the insulation they should be repaired or the part replaced.

Arc Chute Removal

The arc chutes of the 13.8 KV breakers require a mechanical aid to remove and replace them at general maintenance periods. This can be accomplished by an overhead crane, a portable hoist, or by an arc chute lifter especially designed for this purpose.

The arc chute lifter (16) Fig. 19 bolts on the top plate of the breaker, in line with the chute to be removed, and will lift, transport, and release the chute as necessary.

To use the Arc Chute Lifter proceed as follows:

1. Remove box barrier (7) Fig. 7.
2. Bolt angle support (20) Fig. 19 in place on top of breaker.
3. Place the arc chute lifter over the rear bushing and into the proper slots.
4. Lower grappling hooks (17) by turning handle (14) clockwise until hooks can be placed over lifting bolts (18) in arc chute.
5. Turn handle counter clockwise until hooks begin to lift arc chute.
6. Loosen the two upper supporting bolts (2) Fig. 19 and the one lower supporting bolt (9) Fig. 19 using a 3/4" wrench.
7. Turn handle of arc chute lifter counter clockwise and move chute gently from side to side until both upper and lower supports are clear.
8. Move trolley (15) Fig. 19 of the arc chute lifter to the rear.
9. Turn handle of arc chute lifter clockwise until arc chute is resting on the floor and hooks can be removed.

www.ElectricalPartManuals.com

GEI-88765

Breaker Contacts

By removing the box barrier the movable and stationary primary contacts and the movable arcing contacts can be inspected. The stationary arcing contacts can be inspected only after removing the arc chute assembly, as explained under REPAIR AND REPLACEMENT. If the contacts are burned or pitted, they should be made smooth with a fine file.

After completing inspection of the contacts, check the contact adjustments as specified under ADJUSTMENTS.

Mechanism

A careful inspection should be made to check for loose nuts or bolts and broken retaining rings. All cam, roller, and latch surfaces should be inspected for any evidence of damage or excessive wear. Lubricate the mechanism as outlined below, then, using the manual charging wrench, open and close the breaker several times to make certain that the mechanism operates freely throughout its entire stroke. Check the mechanism adjustments as specified under ADJUSTMENTS. Check all terminal connections.

Bushings and Insulation

The surface of the bushings should be kept clean and unmarred to prevent moisture absorption. If the insulation surface should become damaged, it should be sanded and cleaned, and should be refinished with either clear varnish or clear resin. Allow to dry smooth and hard.

All other insulation parts on the breaker should be kept clean and dry. Smoke or dust collected between inspection periods should be wiped off, and if dampness is apparent, heaters should be installed to insure dryness.

Insulation Test

When insulation has been repaired or replaced, or when breaker has been stored under adverse conditions, it is recommended that the insulation be checked before the breaker is placed in service. A standard 60 cycle high potential test at 27,000 volts RMS will normally indicate whether the breaker is satisfactory for service. With the breaker contacts in the fully open position, apply the high potential to each terminal of the breaker individually for one minute with all other terminals and the breaker frame grounded. After high potential tests are made on organic insulating materials, these materials should be inspected for visible leakage current paths, and necessary action must be taken to replace insulation that may have been affected by moisture absorption.

www.ElectricalPartManuals.com

If the breaker secondary wiring is to be given a hi-potential test at 1500 volts, remove both of the motor leads from the terminal boards. Failure to disconnect the motor from the circuit may cause damage to the winding insulation.

LUBRICATION

In order to maintain reliable operation, it is important that all circuit breakers be properly lubricated at all times. Most of the bearings and rolling surfaces utilize a new type of dry lubrication that will require no maintenance and will last the life of the equipment. Only few bearings and surfaces listed in the chart, Fig. 20, require lubrication. These have been properly lubricated, during assembly at the factory, using the finest grades of lubricants available. However, even the finest oils and greases have a tendency to oxidize with age, as evidenced by hardening and darkening in color. Elimination of the hardened lubricant is essential for the proper operation of circuit breakers. Also frequent operation of the breaker causes the lubricant to be forced out from between the bearing surfaces. A simple lubrication will often clear up minor disturbances which might be mistaken for more serious trouble.

A definite lubrication schedule should be set up taking into consideration the frequency of operation of the breaker and local conditions. Until such a schedule is worked out, the breaker should be lubricated at each periodic inspection and also whenever it is overhauled, in accordance with the lubrication chart, Fig. 20. It is also recommended that all circuit breakers be operated at regular intervals to insure the user that the equipment is operating freely.

The lubrication chart, Fig. 20, is divided into two methods of lubrication. The first method outlines the maintenance lubrication which should be performed at the time of periodic maintenance, and requires no disassembly. The second method outlines a lubrication procedure similar to that performed on the breaker at the factory, but should be used only in case of a general overhaul or disassembly for other reasons, or if the operation of the breaker becomes slower.

General Electric Lubricants D50H15 and D50H47 are available in 1/4# collapsible tubes. It is so packaged to insure cleanliness and to prevent oxidation.

Method of Cleaning Bearings

Whenever cleaning is required, as indicated in the lubrication chart, the following procedures are recommended:

www.ElectricalPartManuals.com

Sleeve Bearings

The sleeve bearings used throughout the linkage utilize Teflon surfaces and do not require lubrication. After a number of operations, the surface will acquire a thin black film. Do not remove this film unless there is evidence of outside contaminants, such as dry or hardened grease. If contaminants are present they should be removed by immersing the link and bearing in clean petroleum solvent or similar cleaner and using a stiff brush. Do not remove the bearings from the links. DO NOT USE CARBON TETRACHLORIDE.

The hinge of the primary contact arm (24) Fig. 7 should be disassembled, cleaned, and lubricated with G-E D50H47 lubricant at general overhaul periods.

The main shaft bearings (24) Fig. 5 and the driving pawl lever bearing should be removed, cleaned, and lubricated with G-E D50H15 lubricant at general overhaul periods.

Roller & Needle Bearings

The cam follower bearings (6) Fig. 5, latch roller bearing (9), and cam shaft bearings (25) Fig. 5 should be first removed from the mechanism and the inner race disassembled. They should then be placed in a container of clean petroleum solvent or similar cleaner. DO NOT USE CARBON TETRACHLORIDE. If the grease in the bearings has become badly oxidized, it may be necessary to use alcohol (type used for thinning shellac) to remove it. Ordinarily, by agitating the bearings in the cleaning solution, and using a stiff brush to remove the solid particles, the bearings can be satisfactorily cleaned. Do not handle the bearings with bare hands as deposits from the skin onto the bearings are inductive to corrosion. If the bearings are touched, the contamination can be removed by washing in alcohol. After the bearings have been thoroughly cleaned, spin them in clean new light machine oil until the cleaner or solvent is entirely removed. Allow this oil to drain off and then repack them immediately with G-E lubricant D50H15 being sure all metal parts are greased. The removable seals should then be replaced.

NOTE: If it becomes necessary to clean the bearings in alcohol (shellac thinner), be sure the alcohol is perfectly clean, and do not allow the bearings to remain in the alcohol more than a few hours. If it is desirable to leave the bearings in the alcohol for a longer time, an inhibited alcohol such as is used for anti-freeze should be used. Even then the bearings should be removed from the alcohol within twenty-four hours. Esso Anti-Freeze and Du Pont Zerone are satisfactory for this purpose. Precautions against the toxic effects of the alcohol must be exercised by wearing rubber gloves and by using the alcohol in a well ventilated room; excessive exposure to the fumes is sometimes unpleasant to personnel. Washing the bearings in the light oil and draining should follow immediately, then apply the lubricant.

www.ElectricalPartManuals.com

GEI-88765

Bearings that are pressed into the frame or other members such as the eccentric drive bearings (7) Fig. 15 should not be removed. After removing the shaft and inner race the bearing can usually be cleaned satisfactorily with petroleum solvent or a similar cleaner and a stiff brush. Follow the procedure outlined above using a light machine oil and G-E lubricant D50H15 before reassembling the inner race and shaft.

Rolling Surfaces

A number of rolling and rubbing surfaces in the mechanism have been lubricated with a baked-on, dry, molybdenum disulfide coating. This requires no maintenance and should last the life of the breaker.

RECOMMENDED MAINTENANCE FOR MAGNE-BLAST BREAKERS APPLIED TO REPETITIVE SWITCHING DUTY.

1. Magne-blast breakers applied to repetitive operation such as switching arc furnaces and motors should be serviced and maintained according to the following schedule:
 - A. Every 2000 Operation, or Every Six Months - Whichever Comes First
 1. Remove the box barriers.
 2. Wipe all insulating parts clean of smoke deposit and dust with a clean dry cloth, including the bushings, and the inside of the box barriers.
 3. All areas in the throat area of the arc chute should be thoroughly cleaned by using sandpaper. This cleaning should be performed any time the arc chute is removed. The arc chute fins should not be cleaned. Whenever the arc chute is removed, loose dust and dirt should be blown out before replacing arc chutes.
 4. Primary Contacts - Inspect the condition of the stationary contact fingers and movable contact blocks. Badly pitted or burned contacts should be replaced. (Note: Burned primary contacts indicate the probable need for arcing contact replacement). If the contact surfaces are only roughened or galled, they should be smoothed with crocus cloth or draw filed. After contact dressing the primary contacts should be greased lightly with D50H47.

www.ElectricalPartManuals.com

5. Arcing Contacts - When the arcing contact wipe is less than the minimum specified under ADJUSTMENTS, the contacts should be replaced. The contacts should be inspected for uneven wear and/or damage using a mirror to inspect the stationary contacts. Normally it will not be necessary to remove the arc chutes for this 2000 operation servicing unless inadequate wipe or contact condition indicate a need for replacement. When the arc chutes are removed, the contact braids, coil protectors, and other parts subject to arcing should be checked for possible cleaning or replacement. Do not grease the arcing contacts under any circumstances.
6. Check the breaker and mechanism adjustments as summarized under INSPECTION AND TEST. The necessary readjustments should be made as described under ADJUSTMENTS.
7. The breaker and operating mechanism should be carefully inspected for loose nuts, bolts, retaining rings, etc.. all cam, latch and roller surfaces should be inspected for damage or excessive wear. The buffer blocks and their retainers on the bottom of the stationary contact support should be inspected for possible need of replacement.
8. The contacts of the control relay should be inspected for wear and cleaned if necessary.
9. Lubricate the breaker operating mechanism in accordance with the table under LUBRICATION.
10. Inspect all wiring for tightness of connections and possible damage to insulation.
11. After the breaker has been serviced, it should be slowly closed and opened, as described in INSTALLATION, to be sure there is no binding or friction and that the breaker contacts can move to the fully opened and fully closed positions. Its electrical operation should then be checked using either the test cabinet or the test couplers.

B. After Every 5,000 Operations

1. In addition to the servicing done each 2,000 operations, the arc chutes should be removed from the breaker and disassembled to permit a detailed inspection of insulation, blow-out coils, arc runners and assemblies which can become contaminated by arc products.

www.ElectricalPartManuals.com

2. The blow-out coils should be carefully examined and if the insulation has been cracked, shrunk or eroded from arc action and heat so that the turns of the coils are not fully insulated from each other, the coils should be replaced. All connections should be checked for tightness.
3. The arc runners should be inspected and replaced when any part of their area has been reduced to 25% of the original metal thickness as a result of arc erosion.
4. Check the stationary arc contacts to assure that the arcing contacts are in good condition and that their connections are tight.
5. Insulating material that is carbonized and cannot be satisfactorily cleaned should be replaced.
6. Any parts damaged or severely burned and/or eroded from arc action should be replaced.

NOTE: Fine cracks may develop in the fins of the arc chute sides. This is to be expected with ceramic materials when subjected to the high heat of an arc and may be disregarded unless they are long and present a possibility of fin sections breaking completely off. Small broken corners on the exhaust end of the arc chute will not interfere with its performance and can also be disregarded.

7. The cup bearing and the contact ring at the hinge point of the contact blade should be disassembled, inspected, cleaned, and relubricated with G-E contact lubricant D50H47. The contact ring should be inspected for wear and replaced when reduced in thickness to less than 1/32".

C. Every 10,000 Operations or Approximately Every Five Years - Whichever Comes First.

1. At this time the breaker should be given a general overhaul and all excessively worn parts in both the mechanism and breaker replaced. Such wear will usually be indicated when the breaker cannot be adjusted to instruction book tolerances. This overhaul and inspection is more detailed and will require disassembly of mechanism and breaker operating parts.
2. All roller and needle bearings in the operating mechanism should be disassembled, cleaned, and repacked with G.E. lubricant D50H15 as described under LUBRICATION.

www.ElectricalPartManuals.com

GEI-88765

3. The stationary primary contact fingers should be disassembled and the silver-plated pivot area of the contact and contact support cleaned and lubricated with G-E lubricant D50H47.
 4. The breaker and operating mechanism should be serviced as described for every 2,000 operations and properly adjusted before being put back into service.
2. Magne-blast breakers applied to repetitive operation such as capacitor switching should be serviced and maintained according to the preceding recommendations, and in addition, should have items 1A1, 1A2, and 1A3, repeated at 500 operation intervals.

TROUBLE SHOOTING

Failure of a breaker to operate properly will generally fall within four general classes; failure to trip, failure to close or latch closed, closing springs will not recharge, and overheating. The following is a brief outline showing particular types of distress that might be encountered, together with suggestions for remedying the trouble:

Failure to Trip

1. Mechanism binding or sticking caused by lack of lubrication.
REMEDY: Lubricate complete mechanism.
2. Mechanism binding or sticking caused by being out of adjustment.
REMEDY: Check all mechanism adjustments, latches, stops, auxiliary devices, etc., in accordance with section on ADJUSTMENTS. Examine latch and roller surfaces for corrosion.
3. Damaged trip coil.
REMEDY: Replace damaged coil.
4. Blown fuse in trip circuit.
REMEDY: Replace blown fuse after determining cause of failure.
5. Faulty connections in trip circuit.
REMEDY: Repair broken or loose wires and see that all binding screws are tight.
6. Damaged or dirty contacts in trip circuit.
REMEDY: Recondition or replace contacts.

Failure to Close or Latch Closed

1. Mechanism binding or sticking caused by lack of lubrication.
REMEDY: Lubricate complete mechanism.
2. Damaged or dirty contacts in control circuit.
REMEDY: Recondition or replace contacts.

www.ElectricalPartManuals.com

GEI-88765

- 3.. Blown fuse in closing circuit.
REMEDY: Replace blown fuse after determining cause of failure.
4. Faulty connection in charging circuit.
REMEDY: Repair broken or loose wires and see that all binding screws are tight.

Overheating

1. Poor condition of contacts due to lack of attention after severe duty or too frequent operation.
REMEDY: Recondition or replace burned and pitted contacts. (Contacts should be reconditioned very carefully and only when absolutely necessary.)
2. Contacts not properly aligned or adjusted.
REMEDY: Check all adjustments in accordance with section on ADJUSTMENTS.
3. Breaker kept closed or open for too long a period.
REMEDY: Operate breaker more often to wipe contacts clean. Replace contacts if necessary.
4. Overloading.
REMEDY: Replace breaker with one of adequate rating for present or future load, or re-arrange circuits so as to remove excess load.
5. Primary connections of inadequate capacity.
REMEDY: Increase size or number of conductors or remove excess current.
6. Loose connections or terminal connectors.
REMEDY: Tighten.
7. Ambient temperature too high.
REMEDY: Relocate in a cooler place or arrange some means of cooling.

REPAIR AND REPLACEMENT

The following information covers in detail the proper method of removing various parts of the breaker in order to make any necessary repairs. This section includes only those repairs that can be made at the installation on parts of the breaker that are most subject to damage or wear. IMPORTANT: UPON COMPLETION OF ANY REPAIR WORK, ALL BREAKER AND MECHANISM ADJUSTMENTS MUST BE CHECKED. Refer to the section on INSTALLATION, paying particular attention to ADJUSTMENTS and FINAL INSPECTION.

www.ElectricalPartManuals.com

GEI-88765

Arc Chute (To inspect or replace blow-out coils)

To remove an arc chute, first open the breaker and remove the box barrier (7), Fig. 7. Loosen the two upper supporting bolts (2) Fig. 19 and the one lower support bolt (9) using a 3/4" wrench. By raising the complete arc chute assembly about 3/8" and sliding it toward the rear of the breaker, it can be removed as shown in Fig. 19.

To disassemble the arc chute after it has been removed from the breaker, proceed as follows:

1. Remove the assembly bolts (2,6,7,9,10,12, and 15), Fig. 16.
2. Remove the side brace (14), and rear brace (5), the upper pole pieces (3), and the lower pole pieces (4), Fig. 16.
3. To remove the upper mounting support (13), Fig. 16 remove the assembly bolts (1 and 11), and the upper connection bolt (8) Fig. 18.
4. Remove the assembly bolt (18) to remove the lower brace (8) Fig. 16.
5. Remove the lower mounting support (16) by removing the assembly bolts (17) Fig. 16 and the connection nut (7) Fig. 18.
6. At this point, the fiber side shields (4), Fig. 18 and the upper arc runner assembly (2) can be removed.
7. Further disassembly of both the upper and lower arc runner assemblies can be done by removing the various screws and 1/4" assembly bolts (not illustrated) as shown in Fig. 17.
8. The arc chute sides (6) Fig. 17 can also be separated for inspection.

Reassemble the arc chute in the reverse order. The following items should be noted during reassembly:

1. Equally space the fins of the arc chute sides before bolting together.
2. The gap between the fins at the rear of the arc chute should be 3/64" to 3/32" measured at least 1" in from the back end of the arc chute (see Fig. 21).
3. Check to insure that electrical connections to the blowout coils are tight.
4. When reassembling the arc runner assemblies, check that the spacers (1 and 10), Fig. 17, are correctly installed.

www.ElectricalPartManuals.com

5. Before bolting the upper mounting support in place, make certain that the upper arc runner assembly is tight against the arc chute side so that the gap between the upper insulation (7), Fig. 17 and the arc chute side (6) is a minimum.
6. Make certain that the electrical connections are tight.

To reassemble the arc chute to the breaker, proceed as follows:

1. Rest the lower mounting support (8) on the arc chute mounting bracket (7) as shown in Fig. 19.
2. Slide the arc chute forward and lift it slightly to engage the supporting bolts (2), Fig. 19, in the slots of the upper mounting support (3).
3. Check the spring baffle (11), Fig. 22, to assure that it closes the gap between upper insulation (19), Fig. 16 and the back of the contact support (4), Fig. 22.
4. Tighten the supporting bolts (2 and 9) Fig. 19. These bolts serve as both the electrical and mechanical connections between the bushing and the arc runners.
5. Check that the movable arcing contact (4), Fig. 19, has clearance to the upper arc runner (2) Fig. 17 without touching.

Contacts

Open the breaker and remove the box barrier and arc chute as previously described. To remove the contacts, proceed as follows:

A. Stationary Arcing Contacts (10), Fig. 22.

1. Disconnect the contact braids from the contact fingers by removing two bolts (8), Fig. 22.
2. Grasp the lower end of the contact fingers with pliers and pull contact assembly downward to remove from stud assembly.
3. To disassemble braids from stud assembly, remove one bolt (5).
4. To disassemble stud assembly from contact support, remove two bolts (6).
5. Reassemble in the reverse order.

www.ElectricalPartManuals.com

GEI-88765

B. Stationary Primary Contacts (9), Fig. 23

1. Compress the contact spring (6).
2. Remove spring and spring guide (1).
3. Raise the contact finger to clear the primary contact stop plate (8) and lift the finger out of contact support (7). Remove one contact finger at a time.

To replace the Stationary Primary Contacts:

1. Apply a thin coating of D50H47 grease on the hinged edge of the finger (9) then place it on the contact support (7) so that it is retained by stop plate (8).
2. Open spring compressor (3) and assemble spring guide, spring and spring compressor (Fig. 23A).
3. Turn nut (2) in clockwise direction to compress contact spring (Fig. 23B). Hold spring firmly in place on spring compressor to prevent spring from slipping out of the compressor.
4. Place washer (not shown) on guide on top of spring, place top of guide into hole in spring retainer (4) and the round end of spring guide in cutout in primary finger (Fig. 23C).
5. Hold spring assembly firmly in place and remove spring compressor.

C. Movable Arcing Contact (7), Fig. 24.

1. Remove the assembly bolts (8).
2. Reassemble in reverse order.

D. Movable Primary Contacts (5), Fig. 24 (1200 Amp. Breaker)

1. Remove the nuts from assembly bolts (6).
2. Remove the primary contacts.
3. Reassemble in reverse order.

(2000 Amp. Breaker)

1. Remove the nuts from assembly bolts (6).
2. Remove the connection bar (9).
3. Remove the cup bearing (3).

www.ElectricalPartManuals.com

GEI-88765

4. Spread the contact arms (4) and remove the primary contacts (5).
5. Reassemble in the reverse order.

E. Contact Blade Assembly (4, 5, 7) Fig. 24

1. Remove the connection bar (9).
2. Remove the cup bearing (3) and the pin (11).
3. When reassembling, first insert the piston assembly (10), into the booster cylinder and reassemble the cup bearing (3).
4. Replace pin (11), and connection bar (9).

F. After disassembly and reassembly of any contacts, check all contact adjustments as described under ADJUSTMENTS.

Bushings

IMPORTANT: DO NOT REMOVE ALL SIX BUSHINGS AT ONCE. The bushings have been carefully aligned with the breaker frame, during assembly at the factory, and it is important that this alignment be maintained to facilitate installation of the breaker in the metal-clad unit. It is, therefore, recommended that the bushings be removed and reassembled one at a time. Also, before removing any one bushing, measure the distance from that particular bushing to adjacent bushings in both directions, so that it may be reinstalled in the same location.

It is also possible to remove and reassemble three bushings at one time. If this is preferred, alignment of the bushings may be accomplished by placing the breaker in a de-energized spare metal-clad unit before tightening the bushing mounting bolts. This must be done before the arc chutes are reinstalled.

To replace the bushing, proceed as follows:

Rear Bushing

1. Open the breaker and remove the box barrier and arc chutes as already described.
2. Remove the upper and lower horizontal barriers (18 and 20), Fig. 7.
3. Remove the four bolts at the mounting flange of the rear bushing being removed and lower the bushing assembly.
4. Referring to Fig. 23, disassemble the primary contact springs (6) as previously described.
5. Disassemble the spring retainer (4) by removing mounting bolts (5).

www.ElectricalPartManuals.com

GEI-88765

6. Referring to Fig. 22, disassemble the contact support (4) and arc chute mounting bracket (2) by removing two bolts (3).
7. Reassemble in the reverse order. The arc chute mounting bracket (2) is not symmetrical and must be assembled correctly to orient the chute properly on the breaker. The longest projection of the bracket should be toward the lower end of the bushing.

Front Bushing

1. Open the breaker and remove the box barrier and arc chutes as already described.
2. Remove the upper and lower horizontal barriers (18 and 20) Fig. 7.
3. Remove the connection bar (9), Fig. 24, cup bearing (3), and pin (11).
4. Remove the four bolts at the mounting flange of the front bushing being removed, and lower the bushing.
5. When reassembling, first mount the bushing and assemble the cup bearing (3) contact arm (4), and replace pin (11). The contact surfaces at the hinge point of the contact blade and bushing should have a thin coating of D50HM7 grease.
6. Check all contact adjustments as outlined under ADJUSTMENTS.

INTERLOCK SWITCH

To remove the interlock switch (3), Fig. 10 remove the two mounting screws and disconnect the lead wires. Reassemble in the reverse order and check the switch adjustments as explained under ADJUSTMENTS.

LATCH CHECKING SWITCH

To remove the latch checking switch (7), Fig. 10 (when furnished), remove the two mounting screws and disconnect the lead wires. Reassemble in the reverse order and check the switch adjustments as explained under ADJUSTMENTS.

MOTOR, RELAY AND LIGHT SWITCHES

The three switches are mounted in tandem as shown in Fig. 6.

1. Remove the opening spring per instructions below.
2. Remove (2) mounting bolts (14) from switch bracket (15).
3. Remove the (2) mounting screws of the lower switch.
4. Remove the (2) mounting screws of the center switch.

www.ElectricalPartManuals.com

GEI-88765

5. Remove the (2) mounting screws of the upper switch.
6. Disconnect the lead wires of switch to be replaced.
7. Reassemble in the reverse order and check switch adjustments as described under ADJUSTMENTS.

TRIP SHAFT AND LATCH

1. Remove latch checking switch arm (10) Fig. 11 (when supplied).
2. Remove cotter pins on both ends of the shaft (12).
3. Remove set screw in latch (11).
4. Remove trip coil linkage bolt (6).
5. Place a block between the latch and frame (either side) and drive shaft until the latch is free of the key.
6. Remove key and all burrs that may be raised around the keyway on the shaft. Burrs will scar or shave the Teflon bearing surfaces if they are not removed.
7. Reassemble the parts in the reverse order. Be sure the latch spring is properly installed and the latch is aligned in the center of the latch roller. Check latch adjustment as described under ADJUSTMENTS.

TRIP LATCH ROLLER BEARING

1. Remove (2) cotter pins at ends of shaft (8) Fig. 12.
2. Partially remove shaft out right side of frame until latch roller (6) is free.
3. Reassemble in reverse order with proper spacing of washers. Be sure latch roller rotates freely.

CLOSING LATCH.

1. Remove cotter pins at both ends of latch shaft (19) Fig. 6.
2. Remove spring and paddle (16) Fig. 6.
3. Remove set screws from latch (3) Fig. 6.
4. Move shaft (14) to left (away from frame) by tapping lightly on the inside end of shaft. Rotate shaft and continue tapping until shaft is free. Shaft will push outside needle bearing from housing.

www.ElectricalPartManuals.com

GEI-88765

5. Reassemble in reverse order putting bearing into frame last. Use a small piece of tubing or pipe when inserting bearing to assure proper alignment.
6. Check latch adjustments as described under ADJUSTMENTS.

MOTOR SUPPORT

1. To remove motor support (8) Fig. 15, first remove the latch spring. (16) Fig. 6.
2. Remove the retaining ring (9) Fig. 15 and link (10).
3. Remove motor leads from the terminal board.
4. Remove six 3/8" bolts (1) Fig. 15 on bottom and one 3/8" bolt on the right side (not shown).
5. Remove four mounting bolts from motor (not shown).
6. Remove the retaining ring (7) from the eccentric (2) Fig. 15.
7. Reassemble all parts of the motor support in the reverse order and re-align it properly as described under DRIVING PAWL ADJUSTMENTS.

CAM

1. Remove 2 set screws from ratchet wheel (3) Fig. 3 and remove wheel from main shaft (8).
2. Remove 2 set screws from cam (12) Fig. 1.
3. Remove prop reset spring (10) Fig. 2.
4. Remove 2 set screws from cam (16), Fig. 5, and move cam to the right on the shaft as far as it will go. Slide the shaft to the left until key is fully exposed. Remove key and check shaft for burrs.
5. Remove shaft out left side of frame.
6. Reassemble in reverse order using the correct number of washers and spacers to properly locate the parts.
7. Rotate the mechanism through a closing operation using the manual charging wrench. Check the location of the cam follower (6), Fig. 5, on the cam (16). If necessary, move the cam to correct the alignment. Complete the closing operation and check the location of the prop pin (13), Fig. 5 on the prop (14). It should be approximately centered.

www.ElectricalPartManuals.com

TRIP COIL

To replace the potential trip coil (2), Fig. 11 proceed as follows:

1. With the breaker in the open position, remove the two mounting bolts (3).
2. Remove upper support (1) and spacers.
3. Cut wires at the butt connectors and remove coil.
4. When replacing the coil be sure to assemble the correct fiber spacers at the ends before bolting support (1).
5. Adjust coil location to allow approximately 1/4" of armature travel before latch starts to move.
6. Butt connect wires and check operation of solenoid electrically and mechanically.

SPRING RELEASE COIL

To remove the spring release coil (5), Fig. 6 proceed as follows:

1. Block the closing springs as described in INSTALLATION.
2. Remove the left hand closing spring as described in CLOSING SPRINGS below.
3. Remove two mounting bolts (17), coil support (18), and spacers.
4. Cut wires at the butt connectors and remove coil.
5. Replace the coil and the correct number of fiber spacers before bolting support.
6. Butt connect wires and check that the armature is not binding. Check coil for electrical operation.

CLOSING SPRINGS

The closing springs (6) Fig. 3 can be removed as follows:

1. Charge the springs with the manual charging wrench and apply the spring blocking device as described in INSTALLATION.
2. Discharge springs by pushing manual close button (7) Fig. 2.

www.ElectricalPartManuals.com

GEI-88765

3. Rotate cam shaft (8) Fig. 3 by using the manual charging wrench until the gap between the spring (6) and the bearing block (10) is 2 inches or more.
4. Lift both springs until they clear the lower supports, then pull forward and down until the top supports are free.
5. Either discharge the opening springs by pushing the manual trip lever or block the opening springs with a suitable blocking device.

OPENING SPRINGS

To remove the opening springs (9) Fig. 3 proceed as follows:

1. Charge and block the closing springs as described under INSTALLATION.
2. Push manual trip lever (11) Fig. 2 to be sure the opening springs are fully discharged.
3. Remove upper pin (12) Fig. 3 and lower pin (11).
4. After reassembling springs check the primary opening as described under PRIMARY CONTACT GAP.

OPENING BUFFER BLOCK

The opening buffer block is essentially to limit the travel of the contact arm. To remove the buffer block assembly remove bolt (16) Fig. 14. To disassemble the buffer block (18) remove the two bolts (17). If it is necessary to remove the buffer block on the supporting members the block will have to be adjusted as follows. Remove operating rod pin (11) Fig. 14, and place contact arm so that the primary gap is at the maximum setting. Add or remove shims (19) to allow 1/16" to 3/16" clearance between the buffer and the contact arm. Lower contact arm to rest against the buffer block and check the clearance from the movable arcing contact (7) to the booster cylinder. There should be a minimum of 1/4" clearance at the top and side. Re-assemble pin in contact arm after adjustments are made.

RENEWAL PARTS

It is recommended that sufficient renewal parts be carried in stock to enable the prompt replacement of any worn, broken, or damaged parts. A stock of such parts minimize service interrupting caused by breakdowns, and saves time and expense. When continuous operation is a primary consideration, more renewal parts should be carried, the amount depending upon the severity of the service and the time required to secure replacements.

www.ElectricalPartManuals.com

Renewal parts which are furnished may not be identical to the original parts, since improvements are made from time to time. The parts which are furnished, however, will be interchangeable.

The Renewal Parts List covers the following types of breakers.

AM-13.8-750-2C	1200A & 2000A
AM-13.8-750-2CR	1200A & 2000A
AM-13.8-750-2CB	1200A & 2000A
AM-13.8-750-2CBR	1200A & 2000A
AM-13.8-750-2H	1200A & 2000A
AM-13.8-750-2HR	1200A & 2000A
AM-13.8-750-2HB	1200A & 2000A
AM-13.8-750-2HBR	1200A & 2000A
AM-13.8-750-3C	1200A & 2000A
AM-13.8-750-3CR	1200A & 2000A
AM-13.8-750-3CB	1200A & 2000A
AM-13.8-750-3CBR	1200A & 2000A
AM-13.8-750-3H	1200A & 2000A
AM-13.8-750-3HR	1200A & 2000A
AM-13.8-750-3HB	1200A & 2000A
AM-13.8-750-3HBR	1200A & 2000A

NOTE: The listed terms "Right" and "Left" apply when facing the mechanism end of the breaker.

ORDERING INSTRUCTIONS

1. Always specify the complete nameplate data of both the breaker and the mechanism.
2. Specify the quantity, catalog number (if listed), reference number (if listed), and description of each part ordered, and this bulletin number.
3. Standard hardware, such as screws, bolts, nuts, washers, etc., is not listed in this bulletin. Such items should be purchased locally.
4. For prices, refer to the nearest office of the General Electric Company.

www.ElectricalPartManuals.com

GEI-88765

PARTS RECOMMENDED FOR NORMAL MAINTENANCE

In the tabulation below are listed the parts of those breakers which are usually recommended for stock for normal maintenance.

Fig. No.	Ref. No.	Type	Catalog No. for Type AM-13.8-750-		No. Req'd.	Description
			-2 Design	-3 Design		
7	21	*	0281B0708G001	0281B0708G001	3	Operating Rod
7	21	B	0281B0708G007	0281B0708G007	3	Operating Rod
7	30	All	0263B0292P002	0263B0292P002	3	Booster Cylinder
7	7	All	0898B0275G002	0898B0275G002	3	Throat Insulation (Left)
7	7	All	0898B0275G001	0898B0275G001	3	Throat Insulation (Right)
7	12	All	0456A0336P001	0456A0336P001	6	Lower Hanger Insulation
17	13	All	0414A0195P002	0414A0195P002	6	Lower Shield
18	2	All	0414A0116P088	0414A0116P088	3	Insulation Plate
22	7	All	0898B0224G005	0236C0791G004	3	Flexible Connector (Left)
22	7	All	0898B0224G004	0236C0791G001	3	Flexible Connector (Right)
22	10	All	0836C0132G004	0236C0790G009	3	Arcing Contact Assembly
24	1	*	006509787P001	006509787P001	24	Primary Contact Finger Springs
24	1	B	0121A5904P001	0121A5904P001	24	Primary Contact Finger Springs
24	2	All	0236C0791P008	0236C0791P008	24	Primary Contact Finger
24	5	All	0067A7574P007	0137A9164P003	6	Movable Primary Contact
24	5	All	0067A7574P008	0137A9164P004	6	Movable Primary Contact
24	7	*	0836C0135G004	0802B0742G007	3	Movable Arcing Contact
24	7	B	0836C0135G005	0802B0742G004	3	Movable Arcing Contact
24	10	All	0213X0343G049	0213X0343G046	3	Tube and Piston Assembly
6	12	All	0105C9393P001	0105C9393P001	1	Motor - 48 V-dc
6	12	All	0105C9393P002	0105C9393P002	1	Motor - 110 & 125 V-dc & 115 V-ac
6	18	All	0105C9393P003	0105C9393P003	1	Motor - 220 & 230 V-dc & 230 V-ac
6	6	All	0137A7575P004	0137A7575P004	Δ 1	Relay - 48 V-dc
6	6	All	0137A7575P001	0137A7575P001	Δ 1	Relay - 110 & 125 V-dc
6	6	All	0109B1978G001	0109B1978G001	Δ 1	Relay - 220 & 230 V-dc
6	6	All	0137A7575P005	0137A7575P005	Δ 1	Relay - 115 V-ac
6	6	All	0137A7575P002	0137A7575P002	Δ 1	Relay - 230 V-ac
11	2	All	006174582G001	006174582G001	1	Potential Trip Coil - 110 & 125 V-dc
11	2	All	006174582G015	006174582G015	1	Potential Trip Coil - 220 V-dc
11	2	All	006174582G002	006174582G002	1	Potential Trip Coil - 250 V-dc
11	2	All	006174582G010	006174582G010	1	Potential Trip Coil - 115 V-ac
11	2	All	006174582G014	006174582G014	1	Potential Trip Coil - 230 V-ac
11	2	All	006275070G001	006275070G001	1	Potential Trip Coil - 24 V-dc
11	2	All	006275070G002	006275070G002	1	Potential Trip Coil - 48 V-dc
6	5	All	006174582G001	006174582G001	1	Spring Release Coil - 110 & 125 V-dc
6	5	All	006174582G015	006174582G015	1	Spring Release Coil - 220 V-dc
6	5	All	006174582G002	006174582G002	1	Spring Release Coil - 250 V-dc
6	5	All	006174582G010	006174582G010	1	Spring Release Coil - 115 V-ac
6	5	All	006174582G014	006174582G014	1	Spring Release Coil - 230 V-ac
6	5	All	006275070G002	006275070G002	1	Spring Release Coil - 48 V-dc
6	10	All	0456A0866P005	0456A0866P005	5	Switch, Normally Open
6	10	All	0456A0866P006	0456A0866P006	5	Switch, Normally Closed
6	13	All	0137A9192G003	0137A9192G003	1	Auxiliary Switch
6	13	All	0161A4231P001	0161A4231P001	1	Closing Latch Spring
6	13	All	0137A9252P001	0137A9252P001	1	Prop Spring
6	5	All	0161A4241P001	0161A4241P001	1	Driving Pawl Spring
6	1	All	0161A5909P001	0161A5909P001	2	Latching Pawl Spring

* All except breakers with "B" suffix.

Δ Quan. (2) relays required on special control circuits. Check breaker and connection diagram.

www.ElectricalPartManuals.com

GEI-88765




Fig. 1 Left Side View ML-13
Operating Mechanism

1. Secondary Coupler
2. Interlock Switches
3. Auxiliary Switch
4. Latch Checking Switch
5. Charge-Discharge Indicator
6. Power Switches
7. Closing Springs
8. Motor
9. Fuses
10. Closing Latch Roller
11. Closing Latch
12. Switch Cam




Fig. 2 Front View ML-13
Operating Mechanism

1. Trip Coil
2. Open - Close Indicator
3. Auxiliary Switch
4. Counter
5. Trip Latch
6. Charge-Discharge Indicator
7. Close Button
8. Motor
9. Fuse
10. Prop Spring
11. Trip Lever

FIG. 1 8034473

FIG. 2 8034471

www.ElectricalPartManuals.com

Fig. 4 801 75




Fig. 3 Right Side View ML-13

1. Latching Pawls
2. Positive Interlock Roller
3. Ratchet Wheel
4. Eccentric
5. Fuse
6. Closing Spring
7. Main Shaft bearing
8. Cam Shaft
9. Opening Spring
10. Guide Block
11. Lower Spring Pin
12. Upper Spring Pin




Fig. 4 Spring Blocking Device

1. Close Button
2. Motor
3. Fuse
4. Spring Blocking Device
5. Driving Pawl
6. Eccentric
7. Closing Spring
8. Manual Charging Wrench
9. Support Bolts
10. Charge-Discharge Indicator

www.ElectricalPartManuals.com




Fig. 5 Sectional View of Mechanism


1. Handle
2. Trip Coil Support
3. Trip Coil
4. Trip Armature
5. Prop Reset Spring
6. Cam Follower Roller
7. Trip Shaft
8. Trip Latch
9. Trip Latch Roller

10. Trip Latch Roller Support
11. Crank Shaft
12. Cranks
13. Prop Pin
14. Prop
15. Drive Shaft
16. Cam
17. Check Nut

Opening Spring


18. Stop Plate
19. Spring Rod
20. Spring
21. Spring
22. Spring Guide
23. Stop Pin
24. Main Shaft Bearing
25. Cam Shaft Bearing

www.ElectricalPartManuals.com



1. Switch Cam
2. Closing Latch Roller
3. Closing Latch
4. Latch Adjusting Screw
5. Spring Release Solenoid
6. Control Relay
7. Latch Checking Switch
8. Switch Striker
9. Charge-Discharge Indicator
10. Power Switches
11. Latch Monitoring Switch
12. Motor
13. Fuse
14. Switch Support Bolts
15. Switch Support
16. Closing Latch Spring
17. Release Coil Bolts
18. Release Coil Support
19. Closing Latch Shaft
20. Switch Mounting Bracket

Fig. 5 Control Mechanism



1. Actuating Crank
2. Link
3. Tripping Crank
4. Turnbuckle
5. Spring Release Crank

Fig. 6A Spring Release Interlock


www.ElectricalPartManuals.com

FIG. 23A 8034465


FIG. 23B 8034465

FIG. 23C 8034465


FIG. 23D 8034465




A



B



C



D

Fig. 23 Method of Installing Primary Contact Springs
Using a Spring Compressor

1. Spring Guide
2. Compressor Nut
3. Spring Compressor
4. Spring Retainer
5. Assembly Bolts

6. Spring
7. Contact Support
8. Stationary Primary Finger

www.ElectricalPartManuals.com




Fig. 23 Rear Bushing Assembly

1. Rear Bushing
2. Guide and Support for Arc Chute
3. Bolts for Contact Support
4. Contact Support
5. Bolt for Flexible Braid
6. Mounting Bolt
7. Flexible Braid
8. Connection Bolt
9. Stud for Mounting Arcing Fingers
10. Stationary Arcing Contact Assembly
11. Spring Baffle




Fig. 24 Removal of Contacts

1. Contact Springs
2. Stationary Primary Contacts
3. Cup Bearing
4. Contact Arm
5. Movable Primary Contacts
6. Assembly Bolts
7. Movable Arcing Contact
8. Assembly Bolts
9. Connection Bar
10. Piston Assembly
11. Pin
12. Buffer

www.ElectricalPartManuals.com

coating on the ball contact.

7. Refer to metal-clad instruction book GEH-1802 for final instructions before inserting the breaker into the metal-clad unit.

DESCRIPTION OF OPERATION

The magne-blast breaker is composed of two major parts, the breaker element and the operating mechanism. The breaker element comprises three similar pole units, each pole unit consisting of main and arcing contacts, an interrupter, and an enclosing box barrier that segregates the interrupting units from each other to provide insulation between phases as well as from each phase to ground. The primary connections to the associated metal-clad equipment are made through the primary disconnect studs.

The ML-13 operating mechanism shown in Figures 1, 2, and 3 is of the stored energy type designed to give high speed closing and opening. The mechanism will operate on a-c or d-c voltage as indicated on the breaker name plate. Closing and opening operations are controlled electrically by the metal-clad or remote relaying, and mechanically by the manual close and trip levers on the breaker. All secondary connections from the breaker to the metal-clad unit are made through the coupler (1) Fig. 1.

A positive interlock (2) Fig. 3 and interlock switch (2) Fig. 1 are provided between the breaker and metal-clad unit to prevent raising or lowering of the breaker in the unit while in a closed position and to prevent a closing operation when the breaker is not in either the fully raised or lowered position. A plunger can also be provided to operate an additional auxiliary switch mounted in the metal-clad unit.

When the breaker is interchangeable with MS-13 solenoid operated breakers in M-36 metal-clad units, motor circuit fuses are mounted on the breaker for protection. These breakers are identified by the "C" suffix in the breaker nomenclature.

In case when breakers with ML-13 operating mechanisms must mesh and line up with breakers having ML-11 mechanisms the spring charging circuit should be fused with Fuss Company Fusetrons as follows:

Control Voltage	Fuse Size	Cat. No.
48v - d-c	10A	FRN 10
110v - d-c	4A	FRN 4
125v - d-c	4A	FRN 4
115v - a-c	4A	FRN 4
220v - d-c	2.5A	FRN 2.5
250v - d-c	2.5A	FRN 2.5
230v - a-c	2.5A	FRN 2.5

www.ElectricalPartManuals.com

GEI-88765




FIG. 7 265C198

Fig. 7 Cross Section of Breaker Pole Unit

- | | |
|------------------------------|----------------------------------|
| 1. Box Barrier Retainer | 17. Operating Crank |
| 2. Blow-out Core | 18. Upper Horizontal Barrier |
| 3. Blow-out Coil | 19. Spring Retainer |
| 4. Arc Runner | 20. Lower Horizontal Barrier |
| 5. Pole Pieces | 21. Operating Rod |
| 6. Stationary Arcing Contact | 22. Stationary Primary Contacts |
| 7. Box Barrier | 23. Movable Primary Contacts |
| 8. Arc Chute | 24. Cup Bearing |
| 9. Pole Pieces | 25. Yoke |
| 10. Arc Runner | 26. Movable Contact Arm Assembly |
| 11. Blow-out Coil | 27. Movable Arcing Contact |
| 12. Blow-out Core | 28. Booster Tube |
| 13. Muffler | 29. Connection Bar |
| 14. Front Bushings | 30. Booster Cylinder and Piston |
| 15. Rear Bushings | 31. Bottom Barrier |
| 16. Frame | |

www.ElectricalPartManuals.com

Primary Contact Wipe
"-2" Design

B
Arcing Contact Wipe
"-2" Design

Primary Contact Wipe
"-3" Design

D
Arcing Contact Wipe
"-3" Design

- | | |
|--------------------------------|-------------------------------|
| 1. Stationary Primary Contacts | 4. Stationary Arcing Contacts |
| 2. Movable Primary Contacts | 5. Movable Arcing Contacts |
| 3. Buffer Block | 6. Contact Arm |

www.ElectricalPartManuals.com

GEI-88765




Fig. 9 Adjustable Coupling for Making
Primary Contact Wipe Adjustments

- | | |
|----------------------|--------------------------------|
| 1. Operating Rod | 5. Stationary Primary Contacts |
| 2. Operating Rod Pin | 6. Movable Primary Contacts |
| 3. Adjusting Nut | 7. Contact Arm |
| 4. Check Nut | 8. Yoke |




Fig. 10 Positive Interlock Switch

- | | |
|-----------------------------|--------------------------|
| 1. Positive Interlock Shaft | 6. Switch Support |
| 2. Switch Arm | 7. Latch Checking Switch |
| 3. Interlock Switch | 8. Switch Arm |
| 4. Switch Support | 9. Trip Shaft |
| 5. Auxiliary Switch | |

Fig. 9 8018500

Fig. 10 8034474

www.ElectricalPartManuals.com

1. Trip Coil Support
2. Trip Coil
3. Mounting Bolts
4. Counter
5. Trip Latch
6. Trip Arm Screw
7. Manual Trip Lever
8. Open-Close Indicator
9. Auxiliary Switch
10. Switch Arm
11. Latch Set Screw
12. Cotter Pin
13. Prop Spring




Fig. 11 Auxiliary Switch and Trip Coil

1. Switch Support
2. Latch Checking Switch
3. Switch Arm
4. Trip Latch
5. Reset Pin Stop
6. Latch Roller
7. Latch Roller Link
8. Latch Roller Pin





Fig. 12 Latch Checking Switch

www.ElectricalPartManuals.com


GEI-88765



1. Plunger Bolt
2. Washer
3. Breaker Lifting Rail

FIG. 13 8034464

Fig. 13 Plunger Interlock



1. Contact Springs
2. Stationary Primary Contacts
3. Cup Bearing
4. Contact Arm
5. Movable Primary Contact
6. Assembly Bolts
7. Movable Arcing Contacts
8. Assembly Bolts
9. Connection Bar
10. Piston Assembly
11. Pin
12. Spring Retainer
13. Assembly Bolts
14. Stationary Contact Support
15. Arc Chute Connection
16. Buffer Assembly Bolt
17. Assembly Bolts
18. Buffer Block
19. Shims

FIG. 14 8026375

Fig. 14 Opening Buffer

www.ElectricalPartManuals.com





Fig. 15 Driving Elements

- | | |
|------------------------|-------------------|
| 1. Mounting Bolts | 6. Motor |
| 2. Eccentric | 7. Retaining Ring |
| 3. Box Charging Stud | 8. Motor Support |
| 4. Fuse | 9. Retaining Ring |
| 5. Manual Close Button | 10. Driving Link |



- | |
|----------------------------|
| 1. Assembly Bolts |
| 2. Assembly Bolt |
| 3. Upper Pole Piece |
| 4. Lower Pole Piece |
| 5. Rear Brace |
| 6. Assembly Bolt |
| 7. Assembly Bolt |
| 8. Lower Brace |
| 9. Assembly Bolts |
| 10. Assembly Bolts |
| 11. Assembly Bolt |
| 12. Assembly Bolts |
| 13. Upper Mounting Support |
| 14. Side Brace |
| 15. Assembly Bolts |
| 16. Lower Mounting Support |
| 17. Assembly Bolts |
| 18. Assembly Bolt |
| 19. Upper Insulation |
| 20. Rear Support |

Fig. 16 Arc Chute Assembly

www.ElectricalPartManuals.com

GPR-33765




FIG. 17 Arc Chute Assembly
With Side Removed

1. Upper Arc Runner Spacers
2. Upper Arc Runner Assembly
3. Blowout Core
4. Blowout Coil
5. Upper Arc Runner
6. Arc Chute Side
7. Upper Insulation
8. Lower Arc Runner
9. Lower Arc Runner Assembly
10. Lower Arc Runner Spacers
11. Lower Coil Connection
12. Lower Insulation
13. Lower Insulation




FIG. 18 Front View
Arc Chute Assembly

1. Upper Mounting Support
2. Upper Arc Runner Assembly
3. Upper Arc Runner
4. Side Shield
5. Lower Arc Runner Assembly
6. Lower Coil Connection
7. Connection Nut
8. Upper Coil Connection

FIG. 17 0023202

FIG. 18 0023211

www.ElectricalPartManuals.com

Fig. 19 8034810




Fig. 19 Arc Chute Assembly, Removed Showing Accessibility of Stationary Contacts

1. Rear Bushing
2. Supporting Bolt
3. Upper Arc Chute Support
4. Movable Arcing Contact
5. Mounting Bolt
6. Arc Chute Frame
7. Support Bracket
8. Lower Arc Chute Support
9. Lower Supporting Bolt
10. Upper Horizontal Bar
11. Lower Horizontal Bar
12. Stationary Arcing Contact
13. Arc Chute Lifter Bolt
14. Handle
15. Trolley
16. Arc Chute Lifter
17. Grappling Hook
18. Lifting Bolt
19. Arc Chute
20. Angle Support




Fig. 21 Arc Chute Fin Spacing

www.ElectricalPartManuals.com

PART	LUBRICATION AT MAINTENANCE PERIOD	ALTERED LUBRICATION (REQUIRED IN DISASSEMBLY)
Sleeve Bearings - links, trip shaft, etc. (Teflon coated bearings)	No lubrication required.	No lubrication required.
Sleeve Bearings - main crank shaft, driving pawl lever. (Bronze or cast iron)	Light application of machine oil SAE 20 or SAE 30.	Remove bearings or links, clean per instructions and apply D50H15 lubricant liberally.
Contact Arm Hinge Assembly, Cup Bearing Loose rings between bushing and contact arm.	No lubrication required.	Wipe clean and apply D50H15.
Roller Bearings	Light application of machine oil SAE 20 or SAE 30.	Wipe clean and apply D50H15.
Roller Bearings	No lubrication required.	No lubrication required.
Roller Bearings	Light application of machine oil SAE 20 or SAE 30.	Wipe clean and apply D50H15 lubricant.
Silver plated contacts and primary disconnect studs.	Wipe clean and apply D50H47.	Wipe clean and apply D50H47.
Booster Cylinders	Do not lubricate.	Do not lubricate.
Argon Cylinders	Do not lubricate.	Do not lubricate.

Fig. 20 LUBRICATION CHART

www.ElectricalPartManuals.com