


SIEMENS

Model 95 Motor Control Centers

Instructions

Installation
Operation
Maintenance

MCC3318-01





DANGER

Hazardous voltages are present in the equipment which will cause death, serious personal injury or equipment damage. Always de-energize and ground the equipment before maintenance. Maintenance should be performed only by qualified personnel.* The use of unauthorized parts in the repair of the equipment or tampering by unqualified personnel will result in dangerous conditions which can cause severe personal injury or equipment damage. Follow all safety instructions contained herein.

IMPORTANT

The information contained herein is general in nature and not intended for specific application purposes. It does not relieve the user of responsibility to use sound practices in application, installation, operation, and maintenance of the equipment purchased. Siemens reserves the right to make changes in the specifications shown herein or to make improvements at any time without notice or obligations. Should a conflict arise between the general information contained in this publication and the contents of drawings or supplementary material or both, the latter shall take precedence.

NOTE

***Authorized and qualified personnel—**

For the purpose of this manual a qualified person is one who is familiar with the installation, construction or operation of the equipment and the hazards involved. In addition, he has the following qualifications:

- (a) **is trained and authorized** to de-energize, clear, ground, and tag circuits and equipment in accordance with established safety practices.
- (b) **is trained** in the proper care and use of protective equipment such as rubber gloves, hard hat, safety glasses or face shields, flash clothing, etc., in accordance with established safety practices.
- (c) **is trained** in rendering first aid.

SUMMARY

These instructions do not purport to cover all details or variations in equipment, nor to provide for every possible contingency to be met in connection with installation, operation, or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the local sales office.

The contents of this instruction manual should not become part of or modify any prior or existing agreement, commitment or relationship. The sales contract contains the entire obligation of Siemens Energy & Automation, Inc. The warranty contained in the contract between the parties is the sole warranty of Siemens Energy & Automation, Inc. Any statements contained herein do not create new warranties or modify the existing warranty.

Model 95 Motor Control Centers

Table of Contents

General Information	2	Permissible Loading of Motor Control Centers	22
An Overview	2	Maintenance	23
Qualified Person	2	General Inspection of the MCC	23
Signal Words	2	Periodic Cleaning	24
Siemens Advanced Motor Master System (SAMMS)	4	Stab Fingers and Vertical Bus	24
Receiving and Handling	6	Recommended Tightening Torques	24
Receiving	6	Circuit Breaker Disconnect Operator	24
Handling	6	Adjustment Notes	25
Skid Removal	8	Mechanical Interlock Adjustment	26
Storage	8	Maintenance After a Fault Has Occurred	26
Installation	9	Bus	26
Operating Environment	9	Enclosure	26
Site Preparation	9	Disconnecting Means	26
Mounting	10	Terminals and Internal Conductors	27
Top and Bottom Covers	10	Motor Starter	27
Installation of Seismic Qualified Structures	12	Adjustment of Sentron™ Type ETI Instantaneous Trip Motor Circuit Interrupter (1A-125A)	27
Joining Shipping Sections	12	Adjustment of Circuit Breakers with Adjustable Instantaneous Trip (125A-1200A)	28
Ground Bus	12	Field Testing of the Circuit Breakers	28
Incoming Power Connections	14	Overload Relays	29
Incoming Cable Spaces, Wiring Troughs and Terminations	14	Overload Relay	29
Main Lugs at Top with Top Cable Entry	15	Single Phasing Protection	29
Main Lugs at Top with Bottom Cable Entry	15	Manual or Automatic Reset	29
Main Lugs at Bottom with Bottom Cable Entry	15	3UA Overload Relay Selection and Adjustment	29
Main Lugs at Top with Top or Bottom Cable Entry	15	Procedure for Checking Nuisance Overload Tripping	29
Main Disconnect with Top Cable Entry	16	Field Testing	30
Load and Control Wiring	16	SA Overload Relays	31
NEMA Type A Wiring	16	SA Overload Heater Selection	31
NEMA Type B Wiring	16	Procedure for Checking Nuisance Overload Tripping	31
NEMA Type C Wiring	16	3SB0 Pilot Devices	33
Field Additions	17	Technical Data	33
Drawout Unit Removal	18	3TF Contactor	34
Drawout Unit Addition	19	Technical Data	35
Operation	21	Troubleshooting	37
Pre-Energization Checks	21		
Energizing Equipment	22		

General Information

An Overview

Introduction - The most effective means for grouping low voltage motor starters, associated control, and distribution equipment is through the use of motor control centers. A concept introduced almost 50 years ago, MCC's provide a means of grouping motor starter units, feeder tap units, and auxiliary controls in a common sheet steel enclosure. Motor starters through NEMA Size 4 and all feeder disconnects through 225 amperes are normally supplied with drawout construction. Most devices within the MCC are powered from a common horizontal bus and three phase bus risers. Large starters and certain special units may have cable connections to the horizontal bus in lieu of a vertical bus. Once installed in its centralized operating plant location, supervision and monitoring can be performed safely and by a minimum number of personnel.

Compact Components - Space-saving size of Siemens components results in spacious unit layouts for ease of installation, inspection and maintenance. Compactness also provides an advantage for adding auxiliary devices.

Electrical and Mechanical Life - Contactor life expectancies are among the longest in the industry and low coil power consumption promises operating cost savings in all contactor sizes.

NEMA Class 10 and Single Phase Protection - A unique overload relay designed to trip in 10 seconds or less under locked rotor conditions and less than 30 seconds under single phase conditions is offered as standard.

NEMA Class 20 - A Class 20 overload relay with interchangeable heater elements is offered as an alternative.




Figure 1: The Siemens Motor Control Center


I-T-E® Electrical Products Molded Case Circuit Breakers - State of the art "ETI" Circuit Breakers provide reliable protection with combination interrupting ratings up to 100,000 amperes - and without the use of fuses.

Spacious Wireway - A 40 square inch vertical wireway is one of the largest in the industry; provides room for a large number of control and power circuits. Horizontal wiring is accomplished through two oversize horizontal wireways. This design makes cable routing, inspection and clamp-on current measurements easier.

Precision Stab Design - Assures proper alignment and extended life operation.

Tubular Vertical Bus - Greater structural strength and increased heat dissipation for longer life.

UL Listed Starters - Widest range of UL listing in the industry—from NEMA Size 1 through NEMA Size 7.

	⚠ DANGER
	<p>Hazardous Voltage. Will cause severe personal injury, death or property damage. Only qualified personnel should work on or around this equipment after becoming thoroughly familiar with these publications and all information contained in this instruction manual.</p> <p>Turn off power supplying this equipment before any adjustments, servicing, wiring, parts replacement, or before any act requiring physical contact with electrical working components of this equipment is performed.</p>

Qualified Person

A "Qualified Person" is familiar with the installation, construction and operation of this equipment. In addition, this person has the following qualifications:

- Training and authorization to energize, de-energize, clear, ground and tag circuits and equipment in accordance with established safety practices.
- Training in the proper care and use of protective equipment such as rubber gloves, hard hat, safety glasses, face shields, flash clothing, etc., in accordance with established safety procedures.

Signal Words

The signal words "**Danger**", "**Warning**" and "**Caution**" used in this manual indicate the degree of hazard that may be encountered by the user. These words are defined as:

Danger ≈ Indicates death, severe personal injury or property damage *will* result if proper precautions are not taken.

Warning ≈ Indicates death, severe personal injury or property damage *can* result if proper precautions are not taken.

Caution ≈ Indicates some personal injury or property damage may result if proper precautions are not taken.

General Information




Figure 2: Typical Structural Components

General Information

Siemens Advanced Motor Master System (SAMMS[®])

The Siemens Advanced Motor Master System (SAMMS) is a programmable electronic device which replaces conventional control relays and timers, push buttons, pilot lights and overload relays. It consists of a controller which mounts in the MCC unit, plus a hand-held communicator.

The SAMMS controller mounts in the MCC unit in the location normally occupied by the pilot device panel. A three-phase current transformer, usually located between the branch circuit protective device and the contactor, is used to monitor motor current. The control power transformer supplied with SAMMS-equipped starters contains an extra 12 volt secondary winding to supply power to the SAMMS.

The SAMMS was designed specifically for use in motor control centers and similar applications and can be applied in NEMA Size 1 through Size 6 starters. It can be programmed to control all common starter types, including across-the-line, reversing, reduced voltage autotransformer, reduced voltage reactor, two-speed, wye delta and part-winding. Programming of the SAMMS control circuit logic is normally done at the factory to the customer's specifications, but can be accomplished by the user using an optional IBM PC-compatible software package.

The SAMMS front panel includes a keypad and indicating lights which provide the user with local control and visual status indication.

Overload protection provided by the SAMMS is based on an advanced motor model which continuously calculates the motor winding temperature as a function of the motor RMS current. The motor model compares the calculated temperature against maximum permissible temperature, and trips the motor off line if this value is exceeded. Selection of one of twenty-two overload trip classes allows (for SAMMS 3) customized motor stall protection.

By utilizing the SAMMS hand-held communicator which includes a keypad, four digit numeric display and a cable which plugs into a receptacle on the front of the SAMMS, local display of motor and control circuit data and setting of certain operating parameters are possible. The number of features which can be accessed by the hand-held communicator depends on the SAMMS model furnished.

SAMMS-1, designed for applications where trained maintenance personnel are not available, or where motor loads are of a non-critical nature, allows access to the following functions using the hand-held communicator:

Function F-1. Displays the code number of the ladder diagram of the control circuit currently programmed into the SAMMS memory.

Function F-2. Displays the NEMA size of the starter.

Function F-3. Displays the NEMA size of the low speed contactor in the case of a two-speed starter.

Function F-4. Allows the user to input the full load amps of the motor, or the full load amps of the high speed winding in the case of a two speed motor.

Function F-5. Allows the user to input the full load amps of the low speed winding in the case of a two speed motor.

Function F-6. Allows the user to input the service factor of the motor.

Function F-7. Allows the user to select Class 10 or Class 20 overload protection.

Function F-8. Allows the user to enable or disable automatic reset after an overload trip.

Function F-9. Allows the user to enable or disable trip on phase current unbalance.

Function F-10. Displays the time in seconds until reset is allowed after overload trip occurs.

Function F-11. Allows the user to override the inhibit start feature in the case of an emergency.

General Information

SAMMS-2, designed for applications where trained maintenance personnel are available to service the motors and driven equipment, provides functions F-1 through F-11, plus the following additional functions:

Function F-7. Provides selection between four overload trip classes: 5, 10, 15 and 20.

Function F-12. Ground fault on-off (optional on all three SAMMS models).

Function F-13. Displays the selected value of a built-in start delay timer.

Function F-14. Displays the selected value of a second built-in timer. The function of the second timer is defined by the control circuit programmed into the SAMMS. For example, it can provide time delay for switching between high and low speed for two speed controllers.

Function F-15. Displays the average phase current.

Function F-16. Displays the current in amps seen by the motor at the last trip.

Function F-17. Displays the unbalance current as a percent of the full load current.

Function F-18. Displays the total elapsed running time on the motor in tens of hours.

Function F-19. Displays total number of motor starts in tens of starts.

Function F-20. Displays the total number of overload trips which have occurred.

Function F-21. Resets functions F-18, F-19 and F-20 to zero.




Figure 3: SAMMS Unit

SAMMS-3 is designed for use in critical process environments where down time can result in great losses of production time and/or process material. It provides all the functions of SAMMS-1 and SAMMS-2, plus the following:

Function F-7. Provides selection between twenty-two overload trip classes, from 2 through 23.

Function F-16. Displays each of the individual phase currents, as well as the highest phase current.

Function F-22. Allows the user to select a process current warning which will flash a warning if the motor current varies from a preset level. The current level at which the warning is given is adjustable from 0 to 100% of the motor full load amps.

Function F-23. Allows the user to enable or disable motor jam protection.

Function F-24. Allows the user to choose either loss of load warning or protection. Depending on the setting, the SAMMS will either flash a warning or trip the motor off line if a sudden loss of load occurs.

Function F-25. Displays the ratio of the calculated motor winding insulation temperature to the normal motor winding insulation temperature at full load current.

For additional information on operation and maintenance of the SAMMS, refer to the SAMMS instruction manual.



Figure 4: The SAMMS Hand Held Communicator.

Receiving and Handling

Receiving


Upon receipt of the motor control center, an immediate inspection should be made for any damage which may have occurred during shipment. The inspection should begin with the packaging material and proceed to the equipment within. Be sure to look for concealed damage and do not discard the packaging material. If damage is found, note damage on "Bill of Lading" prior to accepting receipt of the shipment, if possible.

Note: The way visible shipping damage is treated by the consignee prior to signing the delivery receipt can determine the outcome of the damage claim to be filed. Notification to the carrier within the 15 day limit on concealed damage is essential if loss resulting from unsettled claims is to be eliminated or minimized.

A claim should be immediately filed with the carrier, and the Siemens sales office should be notified if damage or loss is discovered. A description of the damage and as much identification information as possible should accompany the claim.

Handling

The motor control centers are shipped in groups of one to four vertical frames which are mounted on wooden shipping skids. When single frames are shipped individually, each is additionally mounted on a special pallet for further stability. Lifting brackets are supplied for each shipping section. If the brackets are shipped loose, assemble the brackets to the top structural members of the control center as shown in **Figure 5**. One bolt attaches the bracket to a 16 inch deep frame. The 20 inch deep frames require two bolts per bracket. Tighten 3/8" hardware to 20 - 30 ft. lbs.



⚠ WARNING

Heavy Equipment. Can result in death, severe personal injury and/or substantial property damage. Exercise extreme care when handling the motor control center. A crane or hoist should be used if at all possible.

Exercise all safety precautions outlined in the following discussion.

The following precautions must be taken whenever moving an MCC:

1. Handle the motor control center with care to avoid damage to components and to the frame or its finish.
2. Handle the motor control center in an upright position only. Motor control centers are normally front heavy and frequently top heavy. Balance the load carefully and steady the motor control center, as necessary, while moving. Some motor control center interiors may contain heavy equipment, such as transformers mounted within, that could be adversely affected by tilting.

3. Know the capabilities of the moving means available to handle the weight of the motor control center. Adequate handling facilities should be available. The following table gives the approximate weights of single vertical frames and will be helpful in determining the required capacity of the handling means. If a vertical frame contains power factor correction capacitors, reactors, or a large transformer, sufficient additional weight handling capacity must be allowed.

Table 1

FRAME	WEIGHT
20" W x 16" D Front Only	550 lb.
20" W x 20" D Front Only	600 lb.
20" W x 20" D Back-to-Back	850 lb.
30" W x 20" D Front Only	850 lb.

4. It is recommended that a crane or hoist be used to handle the MCC if at all possible. If a crane or hoist is not available and other handling means are necessary, extreme care must be exercised to insure that the equipment is secured during the movement and placement operations to prevent tipping and falling. Jacks, prybars, dollies, roller lifts, and similar devices all require supplemental blocking beneath the MCC and restraints to prevent tipping. These devices are not recommended due to the hazards implicit in their use.

The following precautions should be taken when moving an MCC with a crane or hoist:

1. Select rigging lengths to compensate for any unequal weight distribution and to maintain the motor control center in an upright position.
2. Do not allow the angle between the lifting cables and vertical to exceed 45° as shown in **Figure 5**.
3. Do not pass ropes or cables through lifting brackets. Use only slings with safety hooks or shackles.
4. Never lift an MCC above an area where personnel are located.

The following precautions should be taken when moving an MCC with a forklift:

1. Make sure the load is properly balanced on the forks.
2. Place protective material between the MCC and forklift to prevent bending and scratching.
3. Securely strap the MCC to the forklift to prevent shifting or tipping.
4. Excessive speeds and sudden starts, stops, and turns must be avoided when handling the MCC.
5. Lift the MCC only high enough to clear obstructions on the floor.
6. Take care to avoid collisions with structures, other equipment, or personnel when moving the MCC.
7. Never lift an MCC above an area where personnel are located.

Receiving and Handling




Figure 5: Motor Control Center, Sling, Roller, and Forklift Handling

Receiving and Handling

The following precautions should be taken when moving an MCC by rolling on pipes:

1. Use enough people and restraining devices to prevent tipping.
2. The surface over which the MCC is rolled must be level, clean and free of obstructions. **NEVER ROLL AN MCC ON AN INCLINED SURFACE.**
3. It should be recognized that rolling an MCC is especially hazardous to fingers, hands, and feet and is susceptible to tipping. Measures should be taken to eliminate these hazards.
4. All pipes must be the same outside diameter and should have no flat spots. Only steel pipe should be used for this purpose.

Skid Removal

Skid removal should be performed just prior to final placement of the control center and is achieved by first removing the bottom horizontal wire space covers which allows access to the skid lag bolts. Install the lifting brackets (see **Figure 5**) to the top of the MCC (torque bolts to 20-30 ft. lbs.) and attach the crane rigging to these brackets. Apply sufficient tension on the rigging to remove all slack without lifting the equipment. This is a recommended safety measure to reduce the possibility of tipping. The lag bolts may now be removed, the MCC lifted, the skids removed, the MCC lowered into place, and the anchor bolts secured. The last operation should be performed with adequate rigging tension to prevent tipping. After all additional shipping sections are secured in a similar manner, sections and bus bars should be joined in accordance with the instructions in the Installation section of this manual. Close doors and reinstall covers as soon as possible to eliminate intrusion of dirt and foreign materials into the MCC enclosure.

Storage

An indoor motor control center or separate unit, which is not installed and energized immediately, should be stored in a clean dry space where a uniform temperature prevents condensation. Preferably, it should be stored in a heated building, with adequate air circulation and protected from dirt and water. Motor control centers and units should be stored where they are not subject to mechanical damage.

If the motor control center is to be stored for any length of time, prior to installation, restore the packing for protection during that period. Where conditions permit, leave the packing intact until the motor control center or sections are at their final installation position. If the packing is removed, cover the top and openings of the equipment during the construction period to protect them against dust and debris.

An indoor motor control center that must be stored outdoors should be securely covered for protection from weather conditions and dirt. Temporary electrical heating should be installed to prevent condensation; approximately 150 watts per section is adequate for the average motor control center's size and environment. All loose packing or flammable materials should be removed before energizing space heaters.

An unenergized outdoor motor control center should be kept dry internally by installing temporary heating (see above), or by energizing optional self-contained space heaters.

Any scratches or gouges suffered from shipping or handling should be touched up with a can of spray paint to prevent rusting.

Installation

Operating Environment

The motor control center conforms with the provisions of NEMA Standard ICS1 - 108, Altitude Class 2KM which defines the usual service condition for electromagnetic control. It is designed for indoor use where the temperature inside the control center is higher than the ambient temperature. The control center is capable of carrying its rated load when the ambient temperature does not exceed 40° C and the altitude does not exceed 6600 feet above sea level. Where unusual service conditions exist or where temperature or altitude limitations are exceeded, the control center construction, ratings, or protection may require alteration. Some examples of unusual service conditions are excessive moisture, vibration, or dust.

Site Preparation

Installation shall be in accordance with the National Electrical Code, ANSI and NFPA 70 Standards. Unless the motor control center has been designed for unusual service conditions, it

should not be located where it will be exposed to ambient temperatures above 40° C (104° F), corrosive or explosive fumes, dust, vapors, dripping or standing water, abnormal vibration, shock or tilting, or other unusual operating conditions.

The motor control center should be installed in a clean dry heated place with good ventilation and it should be readily accessible for scheduled maintenance. A flat, level concrete surface should be prepared for the mounting site. If the mounting site is not flat and level, the motor control center must be shimmed where necessary to prevent distortion of the structure.

All conduit entering from the bottom should be in place and stubbed up about two inches above the finished floor level before installing the control center. Refer to the MCC lead sheet plan view located in the information packet for specific conduit area dimensions.




Figure 6: MCC Anchor Bolt Location (without sill channels)

Installation

Mounting

Motor control centers may be mounted by many different fastening systems including true drop in, cast in place, powder actuated, or threaded insert fasteners. See **Figures 6 and 7** for anchor bolt locations. The bolt pattern is dependent on frame width, depth, location in the line-up and whether or not sill channels are furnished. A floor plan drawing located in the print pocket details the anchor bolt locations. The coordination between bolts and the MCC should be verified prior to attempting installation. Expandable inserts in predrilled holes or imbedded "L" bolts are recommended. Wooden plugs driven into holes in masonry or concrete are not recommended for anchoring inserts and should never be used. The bolt size must be 3/8".

Welding the steel base or sill channels to a steel floor plate is an alternate mounting method especially recommended in areas subject to seismic activity. See **Figure 8** for details.

Grouting the sill channels as indicated in **Figure 9** is another method of fastening. This method requires the foundation to be

grooved as shown to accept the sill channels. The sill end covers must be removed prior to placing the MCC into the grooves. The actual groove dimensions must be coordinated with the floor plan layout on the lead sheet included in the motor control center information packet.

If the control center is located on structural steel platforms over grids, it is recommended that the center be modified with bottom plates. Channel sill end covers are supplied with those control centers which employ sill channels to cover the openings at the ends of the center if the channels are above grade.

Top and Bottom Covers

Top covers are provided on all motor control centers as an integral part of the enclosure. Bottom covers are supplied on certain types of construction such as NEMA 12. These covers should be removed only for the purpose of piercing holes for conduit or wire entry and must be immediately replaced to reduce the possibility that falling material, tools, or personnel could unintentionally contact the bus system or other live parts.




Figure 7: MCC Anchor Bolt Location (with sill channels)

Installation




Figure 8: Welded Installation




Figure 9: Grouting Method of Fastening Motor Control Center

Installation

Installation of Seismic Qualified Structures

Special installation arrangements are required for seismic qualified structures. Specific mounting procedures specified on the contract drawings or motor control center lead sheet must be explicitly followed to maintain the seismic withstand rating. Removal or rearrangement of frames may void the control center seismic qualification.

Joining Shipping Sections

Shipping sections consist of up to four vertical frames shipped as a single unit. It is often necessary to join two or more shipping sections at the job site. All necessary electrical and structural joining components are provided and the following procedures are recommended.

1. Position the first shipping section into place on the foundation and level.
2. Remove the front horizontal bus barrier and the side sheet from the end(s) to be joined. If the rear is accessible, the back cover plates should be removed from the two mating frames.
3. Position the second shipping section on the foundation adjacent to the first and level it. The horizontal bus should be inspected for proper positioning and alignment at this time.
4. Connect the shipping sections together by positioning the structure joining clips over the adjacent corner posts above and below the interframe barrier as shown in **Figure 10A**. Secure each clip with four self tapping screws, two on each side.

NOTE: CLIPS ARE ABOVE AND BELOW THE INTER-UNIT BARRIER IF USED, THE BARRIER IS 69 INCHES HIGH.




Figure 10A: Structural Joining of Shipping Sections

5. Assemble the bus bar links to join the horizontal power bus and neutral bus, if supplied, in the two shipping sections as shown in **Figure 10C**. The horizontal and neutral buses may differ in size, material, or plating, therefore, the links must be matched to the proper bars. All links and associated mounting hardware are provided with the motor control center.
6. Torque all bus connections to 40-50 ft. lbs.
7. If the motor control center has interwiring, connect the inter-unit wiring terminal blocks between shipping sections.
8. Join the ground bus between the two adjacent sections, if supplied. The Ground Bus Section in this manual details this procedure.
9. If there are other shipping sections to be joined, repeat steps 1 through 8 above.
10. Secure the motor control center to the foundation.
11. NEMA 3R enclosure sections should be securely joined and sealed to prohibit intrusion of dust and moisture.

Ground Bus

All hardware and links are supplied for joining the ground bus between two shipping sections. This joining may be accomplished by loosening the screw securing the connection link so that the link pivots freely. Remove the screw securing the ground bus in the adjacent frame to which the link will attach. Pivot the free end of the link such that the hole is aligned with the bolt, then reassemble the screw and link assembly. Tighten hardware. See **Figure 10B**.




Figure 10B: Joining Shipping Sections, Ground Bus

Installation




Figure 10C: Joining Shipping Sections, Horizontal Power Bus

Installation

Main Disconnect with Bottom Cable Entry




Figure 15

Main Disconnect with Top Cable Entry




Figure 16

Load and Control Wiring

All interconnections between devices within each control unit are prewired at the factory. Field wiring to each control unit should be made in accordance with the wiring diagram indicated on the lead sheet for that particular unit. The lead sheet and wiring diagrams are included in the information packet. When wiring or performing any maintenance on drawout units, disengage the stabs by withdrawing the unit. Refer to pages 18 and 19, "Drawout Unit Removal", Steps 1 through 10. Wiring done with the pan in this position will ensure adequate cable slack to allow unit withdrawal to the same position when future maintenance is required. Always use stranded wire.

The vertical wiring between control units or between a control unit and conduit should be pulled through the wiring space on the right side of the frame. These wires should then be tied or

laced together and the resulting bundle then securely fastened to the wire supports. Connections between a front mounted control unit and a rear mounted control unit in a back-to-back control center should be made at the bottom of the frame. Interconnecting wiring between control units mounted on the same side of the MCC should be routed through the top horizontal wire space.

Installation and wiring must be in accordance with NFPA-70, ANSI, the National Electrical Code and any other applicable regional codes or regulations.

NEMA Type A Wiring

Motor control centers with NEMA Type A wiring do not include terminal blocks. See **Figure 17**. All field wiring, both power and control, should be connected directly to the individual components.

NEMA Type B Wiring

Motor control center units with NEMA Type B wiring are equipped with control terminal blocks to which the factory wiring is connected. **Figure 18** depicts this wiring which adds terminal blocks mounted on the pan top for outgoing connections.

NEMA Type C Wiring

Figure 19 shows a motor control center equipped with NEMA Type C wiring which includes all the features described for NEMA Type B wiring in addition to master terminal blocks located at either the top or bottom of the vertical frames. Motor control center units are factory wired to their master terminal blocks.

The motor control center lead sheet, located in the information packet, indicates the type of wiring provided for this installation.

NOTE: Six 12 inch drawout assembly module spaces per frame are available in the front, five in the rear, with the rear side tracks set an inch higher than the front to prevent stab assembly interference on the vertical bus. Drawout assemblies may be mounted on either the front or rear, but there will be a phase reversal when mounted on the rear. This should be taken into consideration when terminating motor cables.




Figure 17: NEMA Class 1, Type A Wired Unit

Installation

Field Additions

Field additions may be made to the control center if the current rating of the main or vertical bus is not exceeded. The preparation of the floor and conduit is the same as in a new installation. Any new shipping section will contain all of the necessary hardware and bus connecting links. De-energize the existing motor control center and remove the end side sheet from the new and existing vertical frames which are to be joined. After joining the structures per the instructions in the installation section of this manual, perform the pre-energization checks outlined in the operation section of this instruction manual.

Additions to motor control centers fall into two general categories: additions of frames and additions or replacement of drawout units. The addition of frames is similar to the installation of control centers which have been shipped in several sections. When mounting methods or models of new and existing sections differ, care must be exercised to ensure proper alignment of horizontal bus. The new frames are then treated the same as in a new installation. This is discussed in detail in the Joining Shipping Sections portion of this manual.

A special splice bar is provided for the ground bus when connecting to a ValueLine motor control center. See **Figure 20** for details.




Figure 18: NEMA Class 1, Type B Wired Unit




Figure 19: NEMA Class 1, Type C Motor Control Center




Figure 20: Ground Bus Splicing of New Motor Control Center to ValueLine Mark 2 (Model A).

Installation

Drawout Unit Removal

The following sequences should be followed when removing a drawout unit:

1. Turn unit off using STOP button or selector switch (if supplied).
2. Push the disconnect operating handle down to the OFF position.
3. Turn the quarter turn door fasteners 90° with a screwdriver and open the door.
4. Grasp the handle on the racking cam located on the top of the unit and pull out, rotating the cam until it stops (approximately 90°). This will withdraw the unit far enough to separate the stabs from the vertical bus (**Figure 21A**).
5. Grasp the racking cam handle and pull the unit out approximately 1 more inches. Now push the handle back toward the unit until it stops. The unit may be locked out in this position by inserting a padlock in the handle as shown in **Figure 21B**.




Figure 21A: Draw-Out Unit (Pan Assembly) Removal





Figure 21B: Operating Handle in the "OFF" Position

	⚠ DANGER
	<p>Hazardous Voltage. Will cause death, serious personal injury, or property damage.</p> <p>Energized vertical bus may be partially exposed through the access hole in the barrier when the unit is not fully inserted. Use extreme caution when performing any wiring or maintenance with the unit withdrawn.</p>

6. Separate pull apart terminals, or disconnect wires from terminal blocks. Tag and secure disconnected wires within the motor control center wireway. To separate pull apart terminal blocks, insert a flat head screw driver under locking tab and push non-stationary portion of the terminal block toward the rear as shown in **Figure 22A**.
7. Lift and hold non-stationary portion of terminal blocks up and over fixed portion, as shown in **Figure 22B**.
8. The drawout unit may now be easily pulled from the frame.




Figure 22A: Separate Pull Apart Terminal Blocks




Figure 22B: Move Non-Stationary Portion Over Fixed Portion.

Installation

9. If so equipped, the drawout unit pilot device panel (or SAMMS panel) may be released by loosening the captive screw a few turns, then swinging the panel to the right to gain access to components mounted behind it. Once the panel is opened to approximately 135°, a detent will hold it in position. To release the detent, lift the panel slightly allowing it to reclose.
10. The drawout unit should be protected from abuse, dust, and moisture while it is out of the motor control center.

Drawout Unit Addition

Drawout units may easily be added to the Siemens Motor Control Center to fill blank spaces. Each unit comes complete with horizontal support barrier, door, and hinges. The following is the installation procedure for these units.

1. Remove the cover(s) over the blank section(s) equal to the drawout unit height. (Steps A and B, **Figure 23**).
2. Horizontal drawout unit barriers are installed by sliding the rear tabs into mating slots in the vertical barriers and fastening the front into place with two self-tapping screws in the predrilled vertical channels (see **Figure 2**). (Step C, **Figure 23**).
3. Use the new door as a template to locate the positions of the hinges. Self-tapping screws in predrilled holes are used to bolt the hinges to the left hand corner channels. Remove or relocate any excess hinges left from the removal of the covers performed in Step 1 above. (Step D, **Figure 23**).
4. Remove the vertical bus barrier insert at the appropriate location for stab engagement.
5. Push the disconnecting means operating handle to the OFF position.
6. Close the racking handle and install the drawout unit onto the slide rails and push in until it stops. The unit may then be padlocked in this disengaged position.
7. Connect all power cables and control wires in agreement with unit wiring diagram and the instructions detailed in the Incoming Power and Load and Control Wiring sections of this manual.
8. Perform pre-energization checks outlined in Operation section of this manual.
9. Remove the padlock installed in Step 6 above. Pull the racking handle out until it stops, then push the unit inward until it engages the pin located on the underside of the horizontal unit barrier.
10. Rack the unit onto the vertical bus by pushing the racking handle to the left and inward as far as it will go.
11. Close the door and secure it with the quarter turn fasteners.
12. Move the handle to the ON position. The control unit is now ready for operation.
13. Repeat Steps 1 through 12 for each additional new drawout unit to be added.



⚠ DANGER

Hazardous Voltage. Will cause death, serious personal injury, or property damage.

Energized vertical bus may be partially exposed through the access hole in the barrier when the unit is not fully inserted. Use extreme caution when performing any wiring or maintenance with the unit withdrawn.

Installation





Figure 23: Draw-Out Unit Addition

Operation


Pre-Energization Checks

After installation, field addition, or maintenance, perform the following checks before energizing equipment:

1. Compare all circuits for agreement with the wiring diagrams which are provided with the motor control center. Be sure that each motor is connected to its intended starter.
2. Check all connections for proper torque and be sure that inserts or automatic shutters are installed in all exposed openings in the vertical bus barriers.
3. Inspect the motor control center for accumulation of dust or dirt. If required, clean the MCC as explained in the Maintenance section of this manual.
4. Test the motor control center power circuit for possible short circuits and grounds. A dielectric test at 2 times the nominal system voltage plus 1000 volts applied for one minute between phases and from all phases to ground is the preferred method. The maximum allowable leakage current is 1.5mA per 1000 test volts applied. If a high-pot tester is not available, then a megger test using a 500 or 1000 volt megger is a suitable second choice. The minimum allowable resistance measured from phase to phase and from phase to ground is one megohm. Be sure to disconnect any control devices, control power transformer, etc., from the circuit which could be damaged by the test voltage.


	<p>⚠ DANGER</p> <p>Hazardous Voltage. Will cause death, serious personal injury, or property damage.</p> <p>Dielectric or megger testing should only be conducted by qualified personnel. Refer to test device instructions for safety instructions.</p>
---	--

5. Manually exercise all switches, circuit breakers, contactors, magnetic devices, and other operating mechanisms several times to make certain they are properly aligned and operate freely. Some contactors are shipped with taped arc chutes or restraining devices to minimize vibration effects during shipment. Be sure that all such restraints have been removed. None of these devices must ever be blocked in the ON position. Check all electrical interlocks for proper contact operation. Check all mechanical interlocks for proper freedom and operation.
6. Some arc chutes are shipped separately packaged to reduce shipping damage. Make sure that all arc chutes are properly installed and secured on all contactors, relays or switches.

	<p>⚠ DANGER</p> <p>Hazardous Voltage. Will cause death, serious personal injury, or property damage.</p> <p>Never operate any contactor, relay or switch unless its arc chute or cover is properly installed and secured and undamaged.</p>
---	---

7. Check all timers for proper interval setting and contact operation.

8. Check overload relay trip setting and or heater size and verify that they are adjusted per the instructions given for the overload relay in this instruction manual.
9. Check all power circuit fuses and control fuses to verify that they are sized in accordance with the National Electrical Code application requirements. Class K-9 and H fuses are not recommended.
10. Current transformers to which customer devices will be connected, are shipped with their secondaries shorted. All

	<p>⚠ DANGER</p> <p>Explosive Hazard. Installation of fuses of insufficient interruption rating will cause death, serious personal injury or property damage.</p> <p>To ensure proper coordination and sufficient capacity to interrupt the available fault current, always install replacement fuses with UL class, continuous current rating, type, and interrupting capacity identical to the original. NEVER defeat rejection mechanisms which are provided to prevent the installation of the wrong type of fuses.</p>
--	--


shorting devices should be removed when the secondary connections to these transformers are completed. Make sure that the current transformer secondary is complete. Current transformers must not be energized with their secondaries open circuited.

11. Check all devices for missing or broken parts, proper spring tension, free movement, rusting or corrosion, dirt, and excessive wear. Make all necessary repairs.
12. Check all electrical relays, meters, and instruments to verify that connections are made properly and that the devices function properly. Verify that adjustable voltage and current trip mechanisms are set to the proper values.
13. Make sure that no fuses, overload relays, incomplete sequence relays, shunt trips, ground fault protection assemblies, electrical interlocks, or trip contacts from any of these devices are strapped, bypassed, or defeated in any manner.
14. Turn all circuit breakers and fusible switches to the OFF position.
15. Make sure that all barriers, braces, and shields are installed in the equipment as intended. If vertical bus isolation barriers are supplied, make sure that they are all properly seated between the vertical bus supports.
16. Check the integrity of all bus mounting means and cable connections to the bus. Make certain that field wiring is clear of line bus and physically secured to withstand the effects of the largest fault current which the supply system is capable of delivering. Make sure that control wires or power cables are not touching the power bus.
17. Verify that all ground connections have been properly made. The sections of the motor control center which were shipped separately must be connected in such a way to assure a continuous grounding path.


Operation

18. Install covers, install units, close and secure doors, make certain that no wires are pinched and that all enclosure parts are properly aligned and secured.
19. Make sure the door interlocks on all disconnect operators are properly adjusted and secured. If adjustment is required, use the procedure explained in the Maintenance section of this instruction manual.
20. Disconnect any safety grounds which have been connected to the power bus.

Energizing Equipment

	⚠ WARNING
	<p>Hazardous Voltage. Failure to check out this equipment prior to energization can cause death, serious personal injury or equipment damage.</p> <p>All pre-energized checks outlined in this instruction manual must be performed before the equipment is energized. This equipment should be energized by QUALIFIED PERSONNEL only.</p>

1. In order to minimize risk of injury or damage, or both, there should be no load on the motor control center when it is energized. Turn off all of the downstream loads, including those such as distribution equipment and other devices which are remote from the motor control center.
 2. The equipment should be energized in sequence by starting at the source end of the system and working towards the load end. In other words, energize the main devices, then the feeder devices, and then the branch-circuit devices. With barriers (if applicable) in place, and unit doors closed and latched, turn the devices on with a firm positive motion. Protective devices that are not quick-acting should not be "teased" into the closed position.
 3. After all disconnect devices have been closed, loads such as lighting circuits, starters, contactors, heaters, and motors, may be turned on to verify that the system operates as intended.
- ### Permissible Loading of Motor Control Centers
1. For motor control centers without main overcurrent protective devices, the total continuous load current through the horizontal bus should not exceed the current rating of the motor control center.
 2. For motor control centers with a single main overcurrent protective device, the total continuous load current on the protective device should not exceed 80 percent of its ampere rating unless the device is rated to carry 100 percent of its ampere rating, in an enclosure.
 3. For motor control centers with multiple main overcurrent protective devices, the total continuous current through the horizontal bus should not exceed the current rating of the motor control center. The total continuous load current on each overcurrent protective device should not exceed 80 percent of its ampere rating unless the device is rated to carry 100 percent of its ampere rating, in an enclosure.
 4. For branch-circuit overcurrent protective devices in a motor control center, the total continuous load current on the protective device should not exceed 80 percent of its ampere rating unless the device is rated to carry 100 percent of its ampere rating, in an enclosure.
 5. Unless a current limiting means is used in a series combination, the maximum short-circuit current rating of the entire motor control center is the smallest of the following:
 - a. the rating of the bus structure, or
 - b. the lowest rating of the motor control units, or
 - c. the lowest rating of the feeder units.
- This motor control center rating is clearly indicated on the lead sheet located in the information packet.

	⚠ DANGER
	<p>Hazardous Voltage. Will cause death, serious personal injury or equipment damage.</p> <ol style="list-style-type: none">1) Disconnect and lock-out incoming power and control voltage sources before beginning work on this or any other electrical equipment.2) Check all power and control circuit terminals with a voltmeter to make certain that the equipment is totally de-energized.3) Ensure that only QUALIFIED PERSONNEL be instructed and authorized to use the defeater mechanism to gain access to an energized compartment.4) Never attempt to withdraw a drawout unit or disconnect any terminations when the defeater mechanism has been used to open a compartment door. <p>It is recommended that a safety ground be connected to the power bus after the system has been de-energized, and prior to working on the equipment. Follow the procedure outlined in the PRE-ENERGIZATION CHECK section of this manual before power is restored.</p>

For the safety of maintenance personnel as well as others who might be exposed to hazards associated with maintenance activities, the safety related work practices of NFPA 70E, part 11, should always be followed when working on electrical equipment. Maintenance personnel should be trained in the safety practices, procedures and requirements that pertain to their respective job assignments. This manual should be reviewed and retained in a location readily accessible for reference during maintenance of this equipment.

The customer must establish a periodic maintenance program to ensure trouble-free and safe operation. The frequency of inspection, periodic cleaning, and preventive maintenance schedule will depend upon the operation conditions. NFPA Publication 70B, "Electrical Equipment Maintenance" may be used as a guide to establish such a program. **A preventive maintenance program is not intended to cover reconditioning or major repair, but should be designed to reveal, if possible, the need for such actions in time to prevent malfunctions during operation.** The following items should be included in any maintenance checklist. For more details read the succeeding pages.

- General Inspection of the MCC
- Periodic Cleaning
- Tightening Torques
- Stab Fingers and Vertical Bus
- Circuit Breaker/Disconnect Operator
- Mechanical Interlocks

A specific checklist of routine preventative maintenance requirements is recommended for each item of equipment, as well as a log book to record the maintenance history.

General Inspection of the MCC

1. Carefully inspect the doors, enclosure sides and deadfront surfaces over all units for excessive heat. As a general rule, temperature which the palm of the hand cannot stand for about 3 seconds may indicate trouble. Infra-red heat detectors are available for the purpose of detecting heat problems.
2. Inspect the motor control center a minimum of once each year, or more often as deemed necessary. Look for any moisture or signs of previous wetness or dripping inside the MCC. Look for any accumulation of dust or dirt. Clean as explained in the Periodic Cleaning section.
3. Loose electrical connections can cause overheating that can lead to equipment malfunction or failure. Loose bonding or grounding can compromise safety and/or function. Terminal screws, lugs, bus connections, bonding and grounding connections should be inspected for tightness and retightened securely as required. Recommended tightening torques are shown in the Recommended Tightening Torque section of this manual. Fuse clips should be checked for signs of overheating, looseness, or inadequate spring pressure, and replaced if necessary. All terminals, connections, and conductors should be examined for evidence of overheating, corrosion, or pitting. Any parts found to be damaged should be replaced, using parts supplied or recommended by Siemens. Evidence of overheating may include discolored conductors, terminals or parts; or melted, charred or burned insulation.
4. Examine insulation on conductors for overheating or chafing against metal edges that could progress into an insulation failure. Any damaged conductors should be replaced. Replacement conductors should be rerouted, braced or shielded if needed to avoid similar damage in future operation. Temporary wiring should be removed or replaced by permanent wiring.
5. Operate each switch or circuit breaker several times to insure that all mechanisms are free and in proper working order. Check the operation of the mechanical safety interlocks provided with the operator (see section on Circuit Breaker/Disconnect Operator). Never attempt to operate a switch or circuit breaker by use of excessive force.
6. Visually inspect instruments and pilot lights. Replace defective pilot lights. Check instrument calibrations.
7. Check all devices for missing or broken parts, proper spring tension, free movement, rusting or corrosion, dirt, and excessive wear. Perform periodic maintenance on components as detailed in the component instruction books.

Maintenance

Periodic Cleaning

Accumulation of dust and foreign material such as coal dust, cement dust, or lampblack must be removed from all control equipment and all surfaces must be wiped clean at regular intervals. Dirty, wet, or contaminated parts should be replaced unless they can be cleaned effectively. Dust can collect moisture, causing voltage breakdown and it can reduce the effectiveness of heat sinks.

Control equipment parts should be cleaned by vacuuming or wiping with a dry cloth or soft brush. Use care to avoid damaging delicate parts. Liquid cleaners, including spray cleaners, are not recommended due to the possibility of residues. Compressed air is not recommended for cleaning because it will only redistribute contaminants on other surfaces, and may damage delicate parts. The inside bottom of the motor control center should also be cleaned, including removal of any hardware or debris, so that any new or unusual wear or loss of parts occurring after the inspection may be more readily detected during subsequent maintenance. Inspect the motor control center for any signs of previous wetness or dripping inside the controller.

Condensation in conduits or dripping from an outside source is a common cause of failure. Seal off any conduits that have dripped condensate, and provide an alternative means for the conduit to drain. Seal off any cracks or openings which have allowed moisture to enter the enclosure. Eliminate the source of any dripping on the enclosure and any other source of moisture. Replace and thoroughly dry and clean any accumulation of deposited material from previous wettings.

Stab Fingers and Vertical Bus

Look for wear of the tin or silver (optional) plating where the unit stab fingers engage the vertical bus. The plating is part of the environmental protection system. Oxide and/or other films can form on exposed bus resulting in a poor contact.

These parts must be replaced when the plating is worn to the point where copper can be seen because contact resistance becomes higher, increasing the heat generated at the contact point.

Lubricate the stab fingers with a light coating of Siemens contact lubricant number 15-171-370-002 before replacing drawout assemblies.

Recommended Tightening Torques

When making bolted assemblies, the following considerations should be generally followed. The tightening torques are determined by the size of hardware used.

1. **Metal-to-Metal** - Apply standard tightening torque as listed:

Table 3
Recommended Tightening Torques

Thread Size	Torque (lb.-in.)
8-32	14-20
10-32	20-30
1/4-20	40-60
5/16-18	168-228
3/8-16	240-360
1/2-13	480-600

2. **Metal-to-Insert Molded in Compound Part** - Apply 2/3 of standard tightening torque.
3. **Compound-to-Insert Molded in Compound Part** - Apply 1/2 of standard tightening torque.
4. **Compound-to-Compound** - Apply 1/2 of standard tightening torque.

Circuit Breaker Disconnect Operator

Operator mechanisms for circuit breakers through 125A and disconnect switches through 200A are hinged from the side of the unit and secured in place by a single captive screw. They may be swung open to access the protective device by loosening the captive screw a few turns to release it from the unit top brace. The linear motion Operator mechanism shown in **Figure 24** mounts directly to the face of the circuit disconnecting device and the plastic handle extends through the unit door to allow the device to be safely operated. The operator is provided with three mechanical safety interlocks to perform the following functions:

1. **Operator-Unit Interlock:** The operator-to-drawout unit interlock prevents withdrawal or insertion of the control unit with the handle in the "ON" position. When the handle is in the "ON" position, the operator driver (**Figure 24**, Item 1), extends into the racking handle assembly (**Figure 25**, Item 1). This also prevents movement of the latching mechanism (**Figure 25**, Item 2), locking the unit so that it may neither be inserted or withdrawn. When the handle is in the "OFF" position, the racking handle is free to move, thus allowing easy withdrawal and insertion of the drawout unit.
2. **Padlocking:** The handle may be locked in the "OFF" position (**Figure 26**) by installing one to four padlocks in the locations shown. With one or more padlocks installed, the handle is prevented from moving to the "ON" position by interference between the padlock and the handle.




Figure 24: Linear Motion Operator Mechanism

Maintenance

3. **Door-Operator Interlock:** The door-to-operator interlock prohibits closing or opening the control unit door except when the handle is in the "OFF" position. As the handle moves to the "ON" position, the interlock lever (**Figure 24**, Item 2) pivots behind the door mounted "J" shaped bracket thus preventing opening of the control unit door.

A provision is made for QUALIFIED PERSONS to defeat the door-operator interlock when the handle is in the "ON" position. This is accomplished by turning the defeater screw (**Figure 24**, Item 5) counterclockwise approximately 1/8 turn until the door is released. To reclose the door, gently hold the door closed while turning the defeater screw counterclockwise until the door is felt to close against the structure frame. Release the defeater screw and secure the 1/4 turn door fasteners.

This safety interlock also serves to prevent inadvertent closing of the protector when the door is open. Authorized personnel may defeat the interlock in this situation by pushing and holding the exposed upper portion of the interlock arm to the left. This releases the interlock so that the protective device may be turned "ON".

Adjustment Notes

No field adjustment to the door interlock mechanism should be necessary under normal operating conditions. However, should adjustment become necessary as a result of mechanical damage or wear, the following procedure is recommended.




Figure 25: Padlocking the Pan Brace Assembly

1. With the protector in the "OFF" position, the latching mechanism (**Figure 25**, Item 2) fully extended, and the unit door open, defeat the interlock by pushing the top of the lever (**Figure 24**, Item 2) to the left and turn breaker "ON" and "OFF" several times. If the protector fails to turn "ON" or if excessive operating resistance is experienced, turn protector "OFF". Withdraw the unit and inspect for misalignment of the operator extension(s) or the driver (**Figure 24**, Item 1) and the racking handle assembly (**Figure 25**, Item 1). Make necessary adjustments to correct any misalignment.
2. With the drawout unit reinstalled in the motor control center, close and secure door. Turn protector "ON". If operating difficulty persists and protector fails to turn "ON", open unit door. Inspect the door mounted portion of the interlock assembly for damage or distortion. Inspect the interlock lever (**Figure 24**, Item 2) mounted on the right side of the operator for damage, freedom of movement, and its ability to rest firmly against the boss on the plastic handle without assistance. If damage or unusual wear are detected, all affected parts must be replaced.
3. If operating difficulty persists, unlatch the 1/4 turn fasteners and open the door, then slowly close it observing the point of contact between the interlock lever on the operator (**Figure 24**, Item 2) and the door mounted portion of the interlock. The ramp on the "J" shaped bracket mounted on the door should first engage the movable interlock lever on the operator at a point approximately 1/16" below the top right corner of the interlock lever. If the point of engagement does not occur at this point, gently bend the pointed extension of the door mounted portion up or down slightly to the proper position. Before making this adjustment, make sure the plastic handle is centered in the door cut-out when the door is closed.




Figure 26: Padlocking the Handle in the "OFF" Position

Maintenance

Mechanical Interlock Adjustment

Siemens motor control centers which contain reversing, multi-speed or reduced voltage motor starters may employ mechanical interlocking between contactors in the starter units. Two contactors of the same size or two contactors of different sizes may be mechanically interlocked depending on the type of motor starter. The combinations of interlocked contactors which can be supplied is shown in **Table 4**. Mechanical interlocking is accomplished with the interlock mechanisms shown in **Figure 27** which mounts between two adjacent contactors. Dimension "X" shown in the figure is factory set to the dimension shown in **Table 4**. The contactors and mechanical interlock mechanism should be checked periodically and adjusted if necessary to ensure that the mechanical interlock functions properly. This procedure should be performed as outlined in the following steps (refer to **Figure 27**).

Table 4
Combinations of Mechanical Interlocks

1st Contactor Catalog No.	2nd Contactor Catalog No.	Dimension "X" (mm)
3TF44	3TF44	0
3TF44	3TF46	0
3TF46	3TF46	0
3TF46	3TF48	8
3TF48	3TF48	8
3TF48	3TF52	16
3TF52	3TF52	16
3TF52	3TF56	16
3TF56	3TF56	0

1. Disconnect and lock out all incoming power and control voltage sources to the unit which contains the mechanical interlock assembly to be adjusted.
2. Remove the screws which secure legs "F" to the baseplate.
3. Set dimension "X" of legs to the dimension shown in **Table 4**.




Figure 27: Mechanical Interlock

4. Re-attach legs "F" to the baseplate using the screws removed in Step 2.
5. Turn both of the screw spindles "E" until they are flush to .016" below the surface of the interlock case.
6. Check the function of the mechanical interlock by pushing on the screw spindles "E". You should not be able to push both spindles down at the same time.

Maintenance After a Fault Has Occurred

The excessive currents occurring during a fault may result in component or bus damage due to mechanical distortion, thermal damage, metal deposits, or smoke. After a fault, repair the cause of the fault, inspect all equipment per NEMA Standards Publication No. ICS 2-1987 Part ICS 2-302 and make any necessary repairs or replacements prior to placing the equipment into service again. The following procedure is recommended for this inspection.

Bus - Retighten all bus connections. Replace burnt or melted bus or bus with melted, worn or damaged plating. Replace all insulators showing deterioration or deposits.

Enclosure - Inspect the enclosure and doors for evidence of damage such as deformation, displacement of parts or burning. Extensive damage will require replacement of the entire controller.

Disconnecting Means

1. **Circuit Breakers:** Examine the circuit breaker for evidence of possible damage. If there is no apparent evidence of damage, the breaker may be reset and turned "ON". If it is suspected that the circuit breaker has opened several short circuits or if there are signs of possible deterioration, replace the breaker or subject it to the test described in Para. AB1-2.38 of the NEMA Standards Publication for "Molded Case Circuit Breakers" before restoring it to service.
2. **Disconnect Switch:** The external operating handle must be capable of opening the switch after a fault. Replace the switch if the external operating handle fails to open it or if visual inspection after opening indicates deterioration beyond normal wear, such as overheating, contact blade or jaw pitting, charring, or insulation breakage.




Figure 28: The Stab Assembly

Maintenance

3. **Fuse Holders:** Replace fuse holders if the insulating mounts, barriers, or fuse clips show signs of deterioration, heating, distortion, or looseness.
4. **Operating Handle:** The disconnecting means must be replaced if the operating handle fails to open and close. The door interlock must be inspected and its proper function verified prior to restoring the controller to service.
5. **Stab Fingers:** (Figure 28) Inspect stab fingers as instructed under Stab Fingers Section and Vertical Bus Section and replace if necessary.

Terminals and Internal Conductors

Replace all damaged parts which show evidence of discoloration, melting or arcing damage.

Motor Starter


1. **Contactors:** Replace the contacts and contact springs if the contacts are welded or show heat damage, displacement of metal, evidence of binding in the guides, or wear in excess of wear allowance. If deterioration extends beyond the contacts, replace the contactor. Examples of such deterioration include evidence of arcing on the contactor moldings and insulation damage. Arc chutes must be in place and secured prior to operating contactor.
2. **Overload Relays:** a) Any indication of an arc striking or burning the overload relay may require replacement. b) Contact operation must be verified by electrically or mechanically tripping and resetting the relay even if there is no visual indication of damage that would require replacement.
3. **Fuses:** Always replace all three fuses even though only one or two are open circuited since internal damage suffered by fuses not replaced could result in nuisance shut down later.
NOTE: (For fuses mounted on pan sides only) To replace side-mounted fuses supplied with 30 and 60 amp fusible disconnects, a special fuse removal tool is provided. Re-

move the three fuses in sequence starting with the front (A phase) fuse. Pry out the bottom of the fuse by inserting the tool between the fuse barrel and the left hand unit side and moving the tool handle to the left. Then complete fuse removal by grasping the fuse and pulling it out of the upper clip. Repeat for the second and third fuses.

4. Perform the Pre-Energization Checks procedures detailed on Page 21 and 22 herein, before restoring the equipment to service.

Adjustment of Sentron™ Type ETI Instantaneous Trip Motor Circuit Interrupter (1A-125A)

ETI instantaneous trip motor circuit interrupters are supplied as standard with Size 1 through Size 3 motor starters. The motor circuit interrupter continuous current rating should not be less than 115% of motor full load current (MFLC). The MFLC is obtained from the motor nameplate or from Table 430-150 of the NEC (1987). Use the following procedure to adjust the instantaneous trip setting.

	⚠ WARNING
	Hazardous Voltage. Can cause death, serious personal injury or property damage. Disconnect and lock-out all power and control voltage sources supplying the motor circuit interrupter before adjusting trip setting or performing any other maintenance operations.

1. Turn the operating handle to the "OFF" position and open the unit door.
2. Loosen the captive screw which secures the operator mechanism to the unit top brace and swing the operator out of the way, exposing the adjustment dial on the motor circuit interrupter.
3. The instantaneous setting is determined by multiplying MFLC by 13. Select the closest setting to (13 times MFLC) which does not exceed (13 times MFLC). The label on the face of the circuit breaker shows the continuous rating and adjustment points for the installed breaker.
4. Adjust the trip setting by rotating the adjustment dial to the position selected in step 3 above.
5. Making sure that both the motor circuit interrupter and the operator are in the "OFF" position, swing the operator back into position over the front of the interrupter. Be sure that the toggle on the interrupter engages the opening in the driver plate on the operator. Secure by tightening the captive screw.




Figure 29: Operator Hinge Open to Expose Adjustment on ETI Motor Circuit Interrupter

Maintenance

Adjustment of Circuit Breakers with Adjustable Instantaneous Trip (125A-1200A)

These circuit breakers are supplied with Size 4 and Size 5 motor starters. Use the following procedure to adjust the instantaneous trip setting:

1. Turn the operating handle to the "OFF" position and open the unit door.
2. If a linear operator is provided, remove the four screws which mount the operator to the two steel brackets on the face of the circuit breaker. Slip the operating handle assembly forward off the face of the circuit breaker. This exposes one adjustment dial per phase.
3. Select the required trip setting from the label on the operator for the particular circuit breaker based on 13 times MFLC as explained in adjustment Step 3 for the motor circuit interrupter.
4. Set all three adjustment dials to the trip setting selected in Step 3.
5. Re-install the operator handle assembly to the circuit breaker using the reverse procedure to the procedure explained in Step 2.

Field Testing of the Circuit Breakers

A test can be performed using the procedure outlined in the following discussion to verify that a circuit breaker trip mechanism is functioning.

1. Wire the three circuit breaker poles in series.
2. Connect the series combination of breaker poles to a variable low voltage high current power source.
3. Gradually increase the current from "0" until the circuit breaker trips. If the circuit breaker fails to trip when the test current reaches 150% of the largest trip setting, the trip unit is not functioning properly and the circuit breaker requires replacement.

Overload Relays

Overload Relay

For proper overload relay coordination, the cables on the load side of the overload relay should be sized in accordance with the tables in Article 310 of the National Electrical Code. The wire for motors with full load currents of 100 amperes or less may be selected from the 60° C or 75° C column. Select wire from the 75° C column when the motor current is greater than 100 amperes. When conditions dictate the use of cables larger than these, the relay tripping time may be affected. Another condition which may affect tripping is a long acceleration time such as that caused by a motor driving a high inertia load. If either of these conditions exists, consult Siemens for overload relay application instructions.

3UA Overload Relays

The 3UA three phase thermal overload relay is a NEMA Class 10, directly heated, front adjustable, ambient temperature compensating, bimetallic device. The relay is supplied with one normally closed contact (Form B) for opening the control circuit in case of thermal trip and one normally open contact (Form A) for wiring to an alarm or other device.

The relay for NEMA size 1 through size 4 starters mounts directly to the contactor. The relay for NEMA size 5, 6, and 7 starters is separately mounted and directly heated from the secondary of current transformers.

Single Phasing Protection - In addition to motor overload protection, the internal trip mechanism provides motor single phase protection. Referring to **Figure 30**, Curve 3 shows the normal three phase time-current tripping relationship. The relay senses a loss of phase condition and shifts the time-current tripping response curve to the left as shown by Curve 2. As a result of this curve shift and the higher single phase current, the tripping time of the overload relay will be reduced.

Manual or Automatic Reset - The 3UA overload relay is set for HAND reset operation when shipped from the factory. The relay may be set for AUTO operation by depressing and turning the blue reset button counterclockwise to the position marked "A" (see **Figure 31**).





Figure 30: 3UA Overload Relay Time-Current Tripping Curves



⚠ WARNING

Automatic Reset. Can cause death, serious personal injury or property damage.

Do not use automatic reset with two wire control or any other application where automatic reset restores power to the motor endangering either personnel or equipment.

3UA Overload Relay Selection and Adjustment - The 3UA overload relays for use in Siemens Motor Control Centers may be selected from **Tables 5, 6, 7, and 8**. The following information must be known before the selection can be made.

1. Starter size (NEMA size 1, 2, 3, 4, 5, 6 or 7).
2. Motor nameplate full load current (FLC).
3. Motor nameplate service factor and temperature rise.

Markings on the adjustment dial denote current in amperes. The dial should be set at the actual motor full load current marked on the motor nameplate (FLC), if the motor nameplate is marked with a service factor of not less than 1.15 or with a temperature rise not greater than 40° C. For all other motors, the dial setting should be .92 times FLC (see **Table 9**). Where these settings are not adequate to start the motor or carry the load, the National Electrical Code allows the setting of the 3UA overload to be increased 1.12 times FLC for motors marked with service factors not less than 1.15 or with a temperature rise not greater than 40° C; the setting for all other motors may be increased to 1.04 times FLC (see **Table 10**).

Procedure for Checking Nuisance Overload Tripping - The following steps need to be taken when the overload relay consistently trips with the motor running.

1. Make sure that all connections to the overload relay are tight. Check for and correct any phase unbalance of motor currents.
2. Verify the dial adjustment (see **Figure 31**). The setting should NOT be greater than the value shown in **Table 9**.




Figure 31: 3UA Overload Relay

Overload Relays

3. Verify that the proper overload relay has been selected per ACTUAL motor running current. See the overload relay selection tables. If the actual motor running current is larger than the motor nameplate marking, the motor is overloaded. For a motor with a service factor greater than 1.0, multiply the rated motor full load current by the service factor to determine if the motor is overloaded.
4. Adjust the overload dial to a higher setting until tripping ceases. This setting is not to exceed the value shown in **Table 10**.

Table 5

NEMA Starter Sizes 1, 2, 3 and 4			
Lead Sheet Designation	Relay Range	Catalog Number	Used with Contactor
3A0A	.10 - .16	3UA55 00 - 0A	3TF44 SIZE 1
3A0C	.16 - .25	3UA55 00 - 0C	
3A0E	.25 - .40	3UA55 00 - 0E	
3A0G	.40 - .63	3UA55 00 - 0G	
3A0J	.63 - 1.00	3UA55 00 - 0J	
3A0K	.80 - 1.25	3UA55 00 - 0K	
3A1A	1.00 - 1.60	3UA55 00 - 1A	
3A1B	1.25 - 2.00	3UA55 00 - 1B	
3A1C	1.60 - 2.50	3UA55 00 - 1C	
3A1D	2.00 - 3.20	3UA55 00 - 1D	
3A1E	2.50 - 4.00	3UA55 00 - 1E	
3A1F	3.20 - 5.00	3UA55 00 - 1F	
3A1G	4.00 - 6.30	3UA54 00 - 1G	
3A1H	5.00 - 8.00	3UA55 00 - 1H	
3A1J	6.30 - 10.0	3UA54 00 - 1J	
3A1K	8.00 - 12.5	3UA55 00 - 1K	
3A2A	10.0 - 16.0	3UA55 00 - 2A	
3A2B	12.5 - 20.0	3UA55 00 - 2B	
3A2C	16.0 - 25.0	3UA55 00 - 2C	3TF46 SIZE 2
3A2D	20.0 - 32.0	3UA55 00 - 2D	
3C2L	16 - 25	3UA58 00 - 2C	
3C2M	20 - 32	3UA58 00 - 2D	
3C2E	25 - 40	3UA58 00 - 2E	
3C2F	32 - 50	3UA58 00 - 2F	3TF48 SIZE 3
3C2T	40 - 57	3UA58 00 - 2T	
3C2P	50 - 63	3UA58 00 - 2P	
3C2V	57 - 70	3UA58 00 - 2V	
3C2U	63 - 80	3UA58 00 - 2U	
3C2H	55 - 80	3UA62 00 - 2H	3TF52 SIZE 4
3C2W	63 - 90	3UA62 00 - 2W	
3C2X	80 - 110	3UA62 00 - 2X	
3C3H	90 - 120	3UA62 00 - 3H	
3C3J	110 - 135	3UA62 00 - 3J	
3C3K	120 - 150	3UA62 00 - 3K	

5. The overload relay should be replaced if it still trips after Steps 1 through 4 have been completed. If the value in **Table 10** was not attainable with the replaced relay, the next higher trip range of the same frame size should be installed.

Field Testing - 3UA overload relays are subjected to 100% calibration testing at the factory. If tests are to be performed on an overload relay in the field, use the following procedure:

1. Connect 4 feet of wire to each field wiring terminal of the overload relay. The wire should be the smallest size having

Table 6

NEMA Starter Sizes 5 (With 300:5 Current Transformer)		
Lead Sheet Designation	Full Load Current of Motor (FLC)	Catalog Number
3B1A	60.0 - 96.0	3UA59 00 - 1A
3B1B	75.0 - 120.0	3UA59 00 - 1B
1B1C	96.0 - 150.0	3UA59 00 - 1C
3B1D	120.0 - 192.0	3UA59 00 - 1D
3B1E	162.0 - 258.0	3UA59 00 - 1E
3B1F	210.0 - 270.0	3UA59 00 - 1F

Table 7

NEMA Starter Sizes 6 (With 600:5 Current Transformer)		
Lead Sheet Designation	Full Load Current of Motor (FLC)	Catalog Number
3B1A	120.0 - 192.0	3UA59 00 - 1A
3B1B	150.0 - 240.0	3UA59 00 - 1B
1B1C	192.0 - 300.0	3UA59 00 - 1C
3B1D	240.0 - 384.0	3UA59 00 - 1D
3B1E	324.0 - 516.0	3UA59 00 - 1E
3B1F	420.0 - 540.0	3UA59 00 - 1F

Table 8

NEMA Starter Sizes 7 (With 1000:5 Current Transformer)		
Lead Sheet Designation	Full Load Current of Motor (FLC)	Catalog Number
3B1A	200.0 - 320.0	3UA59 00 - 1A
3B1B	250.0 - 400.0	3UA59 00 - 1B
1B1C	320.0 - 500.0	3UA59 00 - 1C
3B1D	400.0 - 640.0	3UA59 00 - 1D
3B1E	500.0 - 800.0	3UA59 00 - 1E
3B1F	640.0 - 810.0	3UA59 00 - 1F

Overload Relays

an ampacity of at least 125% of the maximum current element rating. The maximum current element rating is equal to 125% of the maximum overload trip setting.

2. Connect the overload relay to a 3 phase variable current test power source. If a 3 phase test source is not available, wire the three overload phases in series and use a single phase test power source.
3. The overload relay must be tested at an ambient temperature between -20° C and 55° C (-5° F to 131° F).
4. Energize the relay with test current between 125% and 1000% of the overload relay trip setting and measure the time to trip. The test trip time should be approximately equal to the average tripping time shown on curve 3 in **Figure 30**.
5. A short cooldown time must be allowed before the overload relay can be reset and further tests performed.
6. The overload relay may be tested with single phase test current applied to individual poles. In this case, test tripping time should be approximately equal to the average tripping time shown on curve 2 in **Figure 30**.
7. A test push-button is provided on each overload relay. Depressing this push-button (red in color) causes the overload relay contacts to change state, the extra N. O. alarm contact will close.

Table 9

Maximum Settings of Overload Relays	
	Maximum Setting Multiply Motor FLC by:
Motor service factor equal to or greater than 1.15	1.00
Motor temperature rise less than or equal to 40° C.	1.00
All other motors	0.92

Table 10

Maximum Settings of Overload Relays	
When the Values Indicated in Table 9 are Insufficient to Start	
	Maximum Setting Multiply Motor FLC by:
Motor service factor equal to or greater than 1.15	1.12
Motor temperature rise less than or equal to 40° C.	1.12
All other motors	1.04

SA Overload Relays

The SA single or three phase thermal overload relay is a NEMA Class 20 bimetal, ambient compensated device. Heater elements are interchangeable from the front. The bimetal elements are operated by calibrated heaters. Upon a substantial level of abnormal current flow the deflection becomes great enough to open a snap-action output contact. The relay features a test trip device for weld check. Trip indication is on the front of the relay. The SA overload relay always requires manual reset.

SA Overload Heater Selection - The overload heaters may be selected from **Tables 11, 12 and 13**. Heaters should be selected on the basis of the actual full load current and service factor as shown on the motor nameplate or in the manufacturer's published literature. When the service factor of the motor is 1.15 and 1.25, select heaters from the heater application table. If the service factor of the motor is 1.0, or there is no service factor shown, or a maximum of 115% protection is desired, select one size smaller heater than indicated.

Warning: TO PROVIDE CONTINUED PROTECTION AGAINST FIRE AND SHOCK HAZARD, THE COMPLETE OVERLOAD RELAY MUST BE REPLACED IF BURNOUT OF THE CURRENT ELEMENT OCCURS.

Procedure for Checking Nuisance Overload Tripping - The following steps need to be taken when the overload relay consistently trips with the motor running:

1. Make sure all connections to the overload and heaters are tight. Check for and correct any phase unbalance of motor current.
2. Verify that the proper heater elements are installed.
3. Replace all three heater elements with new ones.
4. Measure ACTUAL motor current, then refer to **Tables 11, 12 and 13** to insure that the proper overload relay heaters are installed.
5. Finally, replace the relay if steps 1 through 4 do not solve nuisance tripping problem.

Overload Relays

Table 11

For Ambient Compensated Overload Relays Size 1 and 2 Starters			
Starter Size	FLC of Motor 40° C ° C Amb		Heater Catalog Number ^①
	Block Type Overload Using 3 Heaters	Single Pole Type Overload	
Size 1	.25 - .27	.29 - .31	SFH03
	.28 - .31	.32 - .35	SFH04
	.32 - .34	.36 - .39	SFH05
	.35 - .38	.40 - .43	SFH06
	.39 - .42	.44 - .48	SFH07
	.43 - .46	.49 - .53	SFH08
	.47 - .50	.54 - .58	SFH09
	.51 - .55	.59 - .64	SFH10
	.56 - .62	.65 - .71	SFH11
	.63 - .68	.72 - .79	SFH12
	.69 - .75	.80 - .87	SFH13
	.76 - .83	.88 - .96	SFH14
	.84 - .91	.97 - 1.06	SFH15
	.92 - 1.00	1.07 - 1.16	SFH16
	1.01 - 1.11	1.17 - 1.28	SFH17
	1.12 - 1.22	1.29 - 1.41	SFH18
	1.23 - 1.34	1.42 - 1.55	SFH19
	1.35 - 1.47	1.56 - 1.71	SFH20
	1.48 - 1.62	1.72 - 1.87	SFH21
	1.63 - 1.78	1.88 - 2.06	SFH22
Size 2	1.79 - 1.95	2.07 - 2.26	SFH23
	1.96 - 2.15	2.27 - 2.48	SFH24
	2.16 - 2.35	2.49 - 2.72	SFH25
	2.36 - 2.58	2.73 - 2.99	SFH26
	2.59 - 2.83	3.00 - 3.28	SFH27
	2.84 - 3.11	3.29 - 3.60	SFH28
	3.12 - 3.42	3.61 - 3.95	SFH29
	3.43 - 3.73	3.96 - 4.31	SFH30
	3.74 - 4.07	4.32 - 4.71	SFH31
	4.08 - 4.39	4.72 - 5.14	SFH32
	4.40 - 4.87	5.15 - 5.6	SFH33
	4.88 - 5.3	5.7 - 6.2	SFH34
	5.4 - 5.9	6.3 - 6.8	SFH35
	6.0 - 6.4	6.9 - 7.5	SFH36
	6.5 - 7.1	7.6 - 8.2	SFH37
	7.2 - 7.8	8.3 - 9.0	SFH38
	7.9 - 8.5	9.1 - 9.9	SFH39
	8.6 - 9.4	10.0 - 10.8	SFH40
	9.5 - 10.3	10.9 - 11.9	SFH41
	10.4 - 11.3	12.0 - 13.1	SFH42
	11.4 - 12.4	13.2 - 14.3	SFH43
	12.5 - 13.5	14.4 - 15.7	SFH44
	13.6 - 14.9	15.8 - 17.2	SFH45
	15.0 - 16.3	17.3 - 18.9	SFH46
	16.4 - 18.0	19.0 - 20.8	SFH47
	18.1 - 19.8	20.9 - 22.9	SFH48
	19.9 - 21.7	23.0 - 25.2	SFH49
	21.8 - 23.9	25.3 - 27.6	SFH50
	24.0 - 26.2	27.7 - 30.3	SFH51
	26.3 - 28.7	30.4 - 33.3	SFH52
	28.8 - 31.4	33.4 - 36.4	SFH53
	31.5 - 34.5	36.5 - 39.9	SFH54
	34.6 - 37.9	40.0 - 43.9	SFH55
	38.0 - 41.5		SFH56
	41.6 - 45.0		SFH57

① 'S' may be omitted from heater catalog number.

Table 12

For Ambient Compensated Overload Relays Size 3 and 4 Starters		
Starter Size	FLC of Motor 40° C ° C Amb	Heater Catalog Number ^①
Size 3	19.0 - 20.8	SFH72
	20.9 - 22.9	SFH73
	23.0 - 25.2	SFH74
	25.3 - 27.8	SFH75
	27.9 - 30.6	SFH76
	30.7 - 33.5	SFH77
	33.6 - 37.5	SFH78
	37.6 - 41.5	SFH79
	41.6 - 46.3	SFH80
	46.4 - 50	SFH81
Size 4	51 - 55	SFH82
	56 - 61	SFH83
	62 - 66	SFH84
	67 - 73	SFH85
	74 - 78	SFH86
	79 - 84	SFH87
	85 - 92	SFH88
	93 - 101	SFH89
	102 - 110	SFH90
	111 - 122	SFH91
	123 - 129	SFH92
	130 - 133	SFH93
	...	SFH94

① 'S' may be omitted from heater catalog number.

Table 13

For Ambient Compensated Overload Relays Size 5, 6 and 7 Starters	
FLC of Motor 40° C ° C Amb	Heater Catalog Number ^①
Size 5 (With 300:5 Current Transformers)	
...	SFH23
118 - 129	SFH24
130 - 141	SFH25
142 - 155	SFH26
156 - 170	SFH27
171 - 187	SFH28
188 - 205	SFH29
206 - 224	SFH30
225 - 244	SFH31
245 - 263	SFH32
264 - 292	SFH33
Size 6 (With 600:5 Current Transformers)	
...	SFH23
236 - 259	SFH24
260 - 283	SFH25
284 - 310	SFH26
311 - 340	SFH27
341 - 374	SFH28
375 - 411	SFH29
412 - 448	SFH30
449 - 489	SFH31
490 - 527	SFH32
528 - 540	SFH33
Size 7 (With 1000:5 Current Transformers)	
432 - 470	SFH25
471 - 516	SFH26
517 - 566	SFH27
567 - 622	SFH28
623 - 684	SFH29
685 - 746	SFH30
747 - 814	SFH31

① 'S' may be omitted from heater catalog number.

3SB0 Pilot Devices

Pilot Device Options

The 3SB0 pilot devices are available in two basic forms, completely assembled for the most frequently used configurations, or subassemblies for greater flexibility.

Application

The 3SB0 pilot devices are of the heavy duty oiltight, watertight and dust-tight (NEMA Type 4, 4X, 13, IP65) design. They are used in industrial control applications where control circuits are 600V or less. The 3SB0 pilot devices are available in two mounting diameters. 22mm and 30mm.

Design

22mm Mounting - The actuator is inserted into the hole in the panel from the front and secured to the contact block holder. The unit is then fixed from behind by means of two set screws which are located in the contact block holder. This method prevents the unit from working loose or twisting.

30mm Mounting - The holder is an integral part of the actuator. It is inserted into the hole in the panel from the rear and secured from the front by means of a locking ring. With the use of a legend plate or the thrust and trim washers, the unit becomes stationary and will not twist or work loose.

Front Rings

The 22mm and 30mm units are supplied as standard with metal chrome plated front rings. Black plastic or anodized aluminum rings are optional at no additional cost. The plastic rings are recommended for use where the atmosphere may be corrosive.

Indicator Lights Using LED's

LED's have a definite advantage over incandescent lamps. LED's are a current device, incandescent lamps are power devices, therefore the power consumption of LED's is much lower. The life span for LED's is generally 10 to 20 times longer than that of incandescent lamps and they provide a greater resistance to shock and vibration. This makes the LED indicator light ideal where lamp integrity and low maintenance is crucial.

Contact Blocks

The 3SB0 contact blocks incorporate parallel double-break contact. This insures a high degree of reliability and therefore makes them suitable for use with solid state control equipment. The terminals are clearly marked to simplify wiring. The snap on type contact blocks, along with wire funnels, screwdriver guide holes and open captive spring steel washers permit a time saving installation. The contact block holder is available as a 3 or 5 unit holder. If a 5 unit holder is required, the fifth digit of the catalog number can be changed to reflect this.

Technical Data						
UL and CSA ratings Rated voltage for 1 NO + 1 NC, 2 NO, 2 NC for 1 NC or 1 NO Lamp holder Voltage reducer Lamp holder with 60 Hz transformer Continuous current Switching capacity	AC 600 V max., above AC 300 V same polarity AC 600 V max. for lamps with a BA 9s base, max. 125 V; 2.5 W for max. AC 240 V 120, 480, 575 V / 6 V, 60 Hz, 1 VA 10 A 10 A, heavy duty					
	Insulation rating U_i for 1 NO + 1 NC, 2 NO, 2 NC (screw terminals) for 1 NO or 1 NC (screw terminals) for 1 NO + 1 NC (plug-in terminal) for 1 NO or 1 NC (plug-in terminal) for BA 9s lamp holder					
Insulation group Rated operating voltage U_o Continuous current, rated operational currents switching capacity	VDE 0110, Group C all contact blocks with: screw terminals, AC 660 V plug-in terminals, AC 380 V					
	AC 40 to 60 Hz $I_n/AC-1$ A	U_o AC V	$I_n/AC-11$ A	DC U_o DC V	$I_n/DC-1$ A	$I_n/DC-11$ A
Short-circuit protection DIAZED fuse links Miniature circuit-breaker with G characteristic	10	-	-	24	10	10
		-	-	48	8	4
Mechanical endurance pushbutton units illuminated pushbutton units rotary and latching actuators		220/230	6	110	3.5	1.2
		380/400	4	220	1	0.4
Contact endurance Frequency of operation Ambient temperature range		500	2.5	440	0.5	0.2
		660	1.2	-	-	-
Conductor sizes Mounting position Terminal marking	10 A TDz, 16 A Dz 10 A					
	10 million make-break operations 3 million make-break operations 300 thousand make-break operations					
Device designation Lamp holder Incandescent lamp Glow lamp LED	10 million make-break operations with 3TH8, 3TB40 to 3TB44 contactors					
	1000 make-break operations per hour -25 to +60°C -25 to +40°C (housing fitted with indicator lights or illuminated pushbutton units with incandescent lamps)					
Safety measures	(2) #4-12 AWG (2) 1 to 2.5 mm ² , 1 X 4 mm ² any according to DIN EN 50 013 identification number on the holder, function number on the contact block					
	Marking tag					
Actuating force	Clip-on for illuminated pushbutton units or indicator lights for BA 9s lamps (10 mm X 28 mm bulb) 6, 12, 24, 42, and 60 V; 2 W 120 V; 2.5 W for operating voltages between 220 and 240 V, use a 130 V incandescent lamp with a voltage reducer AC 110V AC 6V AC/DC 24					
	Safety requirements are met automatically when the actuators and lens assemblies are mounted on metal front plates. When mounted in insulated housings, the "protective insulation" safety requirement is met. Metal enclosures can be made to meet these requirements when the earthing terminal inside the housing is used.					
	Number of contact blocks	0	1	2	3	
	Pushbutton unit NC opens unit NO closes	-	4.5 N 6.0 N	6.5 N 9.5 N	8.5 N 13.0 N	
	Latching mushroom pushbutton unit for EMERGENCY STOP	10 N	14.0 N	18.0 N	22.0 N	

3TF Contactor

Specifications

3TF contactors meet or exceed the requirements of NEMA, EEMAC, UL, CSA, IEC, VDE and other international standards.

Mounting

The permissible mounting positions for the contactors on a vertical mounting surface are shown in the drawings below.

The 3TF44 to 3TF56 contactors can be mounted without a lateral clearance.

30mm minimum clearance should be kept between the contactors for the exchange of the auxiliary contacts. The following data reductions must be observed with installations where current paths run one upon the other horizontally (90° rotation):

Switching frequency	
3TF52 and 3TF54 3TF56	to 80% of the normal values to 50% of the normal values
Mechanical endurance	
3TF50 to 3TF56	8 million make-break operations

Auxiliary Contacts

They provide high contact reliability at low voltages and currents by means of double-break moving contacts.

The terminal designations comply with DIN EN 50012.

When the contacts are energized, the NC contacts open before the NO contacts close.

Control Circuit

Protection of circuits against surges:

The coils of the 3TF44 to 3TF56 contactors can be subsequently equipped with varistors.

Contact Life

The graph depicts the expected contact life of 3TF contactors as a function of the breaking current in AC applications. For normal applications the motor interrupts the motor full load current (MFLC). In plugging and jogging applications the contactor interrupts the Locked Rotor Current (LRC). If the LRC is not known assume 6 times the marked MFLC.

To obtain the contactor's approximate electrical contact life, determine breaking current and find value on the horizontal axis. Move upward and locate intersection with black line of appropriate contactor. Read expected life on left or right side of graph.

The lines apply to standard 480 V motors when interrupting MFLC. If mixed applications are involved, such as normal switching (breaking MFLC) with intermittent jogging/plugging (breaking LRC), the contact life can be calculated with the following formula:

$$X = \frac{A}{1 + \frac{C}{100} \left(\frac{A}{B} - 1 \right)}$$

Legend

- X Contact life for mixed applications
- A Contact life from chart for normal applications-breaking MFLC
- B Contact life from chart for plugging/jogging applications-breaking LRC
- C Percentage of plugging/jogging operation to total operation
- HP Rated output of motor




Figure 32







Figure 33

3TF Contactor

Technical Data										
Contactors	Type		3TF46	3TF47	3TF48	3TF50	3TF52	3TF54	3TF56	3TF68
Mechanical life	make/break operations	Mill.	10	10	10	10	10	10	10	10
Insulation rating		V	1000	1000	1000	1000	1000	1000	1000	1000
Permitted ambient temperature range	without overload relay attached when stored	°C	- 25 to + 55							
		°C	- 50 to + 80							
Coil ratings (cold coil, 1.0 X U _c)			50 Hz	60 Hz	50 Hz	60 Hz	50 Hz	60 Hz	50 Hz	60 Hz
AC operation	closing	VA	183	233	183	233	330	410	590	730
	p.f.		0.6	0.54	0.6	0.54	0.5	0.4	0.45	0.39
	closing delay	VA	17	21	17	21	32	39	51	61
	p.f.		0.29	0.29	0.29	0.29	0.23	0.24	0.26	0.25
	opening delay									
Coil voltage tolerances	AC		0.85 to 1.1 times rated control voltage							
Operating times (valid for 20% undervoltage and 10% overvoltage, cold or warm coil)										
Total break time = opening delay + arcing time		ms	15-40	15-40	20-50	20-50	20-50	20-50	17-65	93-270
AC operation	closing delay	ms	5-25	5-25	5-30	8-30	10-30	10-30	8-20	8-20
	opening delay	ms	10-15	10-15	10-15	10-15	10-15	10-15	10-15	10-15
Operating times at 1 X U_c										
AC operation	closing delay	ms	17-30	17-30	22-35	22-37	25-40	25-40	25-40	(56-118)
	opening delay	ms	5-25	5-25	5-30	8-30	10-30	10-30	8-20	100-200
Resistance to shock (rectangular pulse)		g/ms	9.2/5 5.4/10	9.2/5 5.4/10	8.6/5 4.8/10	9.4/5 5.2/10	10.4/5 5.8/10	9.7/5 5.3/10	8.8/5 4.9/10	6.7/5 3.6/10
Conductor sizes (USA)										
For contactors without overload relay										
main conductor: solid or stranded	AWG	(2)10-4	(2)10-4	8-1	3-2/0	1/0-250 MCM	2/0-500 MCM	2/0-500 MCM	2/0-500 MCM	2/0-500 MCM
auxiliary conductor: solid or stranded	AWG	(2)14-12	(2)14-12	(2)14-12	(2)14-12	(2)14-12	(2)14-12	(2)14-12	(2)14-12	(2)14-12
Switching frequency in make/break operations per hour (1/h)										
Contactors without overload relay										
duty AC-1	1/h	1000	1000	900	800	800	800	700	700	
duty AC-2	1/h	600	400	400	400	300	300	200	200	
duty AC-3	1/h	1200	1000	1000	1000	700	700	500	500	
duty AC-4	1/h	400	300	300	300	200	200	150	150	
Contactors with overload relay (average value)	1/h	15	15	15	15	15	15	15	15	
Approved by	Contactors	Type	3TF46	3TF47	3TF48	3TF50	3TF52	3TF54	3TF56	3TF68
	Continuous current Rated output of three-phase motors at 60 Hz (enclosed)	open enclosed 115 V 230 V 460 V 575 V	A A hp hp hp hp							
	Prescribed short-circuit protection (approved) Fuses									
	Class	A								
	Circuit-breakers									
	EEMAC size									
	contactors	Size	2	-	3	-	4	-	5	6
	Starters (= contactors + overload relay enclosed)	Size	2	-	3	-	4	-	5	6
Auxiliary contacts										
 ratings for auxiliary contacts										
Contactors	AC 600 V max. NEMA A600 Switching capacity AC-11	A	24V	120V	240V	480V	600V			
3TF46										
3TF47			10 A	10 A	5.5 A	2.5 A	2.5 A			
3TF48										
3TF50										
3TF52	DC 600 V max. NEMA P600 Switching capacity DC-11	A	24V	150V	250V	300V	600V			
3TF54			10 A	1.6 A	0.8 A	0.5 A	0.18 A			
3TF56										
3TF68										

○ Values in parentheses are obtained when an internal control wire is cut.

3TF Contactor

Technical Data										
Contactors	Size Type		3TF46	3TF47	3TF48	3TF50	3TF52	3TF54	3TF56	3TF68
Load rating of triple-pole AC contactors										
AC1 duty, switching resistive load										
Rated operational current I_n / AC1 (at 55 °C)	A	80	80	100	160	200	300	400	630	
Ratings for three-phase loads ^① p.f. 0.95										
220 V	kW	30	30	38	61	76	114	152	240	
380 V	kW	52.5	52.5	66	105	132	195	262	415	
500 V	kW	67	67	86	138	173	260	345	545	
660 V	kW	91	91	114	183	228	340	457	720	
Min. conductor size at I_n	mm	25	25	35	70	95	165	240	2 X 185	
AC2 and AC3 duty										
Slip ring or squirrel-cage motors										
220 V	kW	15	18.5	22.2	37	55	78	125	191	
380 V	kW	22.5	31.5	38.5	58	90	135	215	330	
500 V	kW	30	41.4	50.7	76.3	118	178	284	434	
660 V	kW	39	54.7	66.9	100	156	235	375	573	
AC4 duty (contact life of approx. 200,000 make/break operations is designed for normal applications)										
Rated operational current I_n	A	24	28	34	54	75	110	150	200	
Rated powers of squirrel cage motors at 50 Hz and $I_n \leq 6 \times I_n$										
220 V	kW	6.9	8.1	9.8	15.6	22	34	47	62	
380 V	kW	12	14	17	27	38	58	81	107	
500 V	kW	15.8	18.4	22.4	35	50	76	107	140	
660 V	kW	20.8	24.3	29.5	46.9	66	100	140	186	
Max. perm. rated operational current I_n / AC4 at	A	45	63	75	110	170	250	400	630	
Used as stator contactors for intermittent duty (AC2 duty)										
Stator Current duty factor ^②										
20%	A	103	103	153	245	308	462	617	975	
40%	A	98	122	195	245	367	490	775		
60%	A	87	87	109	176	218	327	436	690	
80%	A	80	80	100	160	200	300	400	630	
Used as rotor contactors for intermittent duty										
Rotor current duty factor ^②										
10%	A	163	163	293	395	560	769	1075	1820	
20%	A	163	163	242	388	487	730	975	1540	
40%	A	155	155	193	308	387	580	775	1225	
60%	A	138	138	173	275	345	517	689	1090	
80%	A	127	127	158	252	316	474	632	995	
Used as rotor contactors for continuous duty										
Locked-rotor voltages										
starting	V	1500	1500	2000	2000	2000	2000	2000	2000	
variable speed	V	750	750	1000	1000	1000	1000	1000	1000	
plugging	V	750	750	1000	1000	1000	1000	1000	1000	
Permitted ratings of the contacts with DC										
DC1 duty, switching resistive load ($\frac{t}{A} \leq 1$ ms)										
Rated operational current I_n (at 55 °C)										
1 pole assembly										
24 V	A	80	80	100	160	200	300	400		
60 V	A	30	30	80	80	80	300	330		
110 V	A	6	6	12	18	18	33	33		
220 V	A	1.2	1.2	2.5	3.4	3.4	3.8	3.8		
440 V	A	0.48	0.48	0.8	0.8	0.8	0.9	0.9		
600 V	A	0.35	0.35	0.48	0.5	0.5	0.6	0.6		
3 pole assemblies in series										
24 V	A	80	80	100	160	200	300	400		
60 V	A	80	80	100	160	200	300	400		
110 V	A	80	80	100	160	200	300	400		
220 V	A	80	80	100	160	200	300	400		
440 V	A	3	3	6	11.5	11.5	11	11		
600 V	A	1	1	3.4	4	4	5.2	5.2		
DC2 to DC5 duty, shunt and series motors ($\frac{t}{A} \leq 15$ ms)										
Rated operational current I_n (at 55 °C)										
1 pole assembly										
24 V	A	5	5	6	16	16	35	35		
60 V	A	2	2	3	7.5	7.2	11	11		
110 V	A	0.75	0.75	1.25	2.5	2.5	3	3		
220 V	A	0.2	0.2	0.35	0.6	0.6	0.6	0.6		
440 V	A	0.1	0.1	0.15	0.17	0.17	0.18	0.18		
600 V	A	0.08	0.08	0.1	0.12	0.12	0.125	0.125		
3 pole assemblies in series										
24 V	A	80	80	100	160	200	300	400		
60 V	A	80	80	100	160	200	300	400		
110 V	A	80	80	100	160	200	300	400		
220 V	A	3.5	3.5	4	160	200	300	400		
440 V	A	0.6	0.6	0.8	1.4	1.4	1.4	1.4		
600 V	A	0.35	0.35	0.45	0.75	0.75	0.75	0.75		
Permitted ratings of the contactors when switching low-inductance (MKV) three-phase capacitors *										
Ratings of single capacitors at 50 Hz and										
Derate 20% for 400 Hz applications.										
220/230 V	kvar	17	24	24	35	58	87	115	175	
380/400 V	kvar	30	40	40	60	100	150	200	300	
500 V	kvar	35	50	50	80	130	190	265	400	
660 V	kvar	30	40	40	60	100	150	200	300	
Ratings of capacitor banks (6 μ H min. inductance between parallel capacitors) at 50 Hz and										
220/230 V	kvar	17	24	24	30	40	66	85	145	
380/400 V	kvar	30	40	40	50	70	115	150	250	
500 V	kvar	35	50	50	66	90	145	195	333	
660 V	kvar	30	40	40	50	70	115	150	250	

* Contact life 0.1 million make/break operations

① Industrial furnaces and electric heaters with resistance heating for example (higher current during heat-up allowed for). The values given apply to contactors without overload relays.

② Duty factor in % =

$$\frac{\text{On time}}{\text{Cycle time}} \times 100; \text{ cycle times up to 10 minutes.}$$

Troubleshooting

In the unlikely event that operating problems are encountered, use the following troubleshooting chart to isolate the cause of the problem and find the remedy. If the corrective action given in the chart fails to correct the difficulty, consult your field sales representative.

The following information is required if it is necessary to write Siemens relative to the equipment problem.

1. Manufacturer's order number and part number, if available.
2. Nameplate data on contactor or controller.

3. Duty cycle and any details of operation.
4. Length of time in service and approximate total number of operations.
5. Voltage, current and frequency.
6. Description of any problem.
7. Any other pertinent information, such as drawing, layout and schematic number.

Problem	Probable Causes	Corrective Action
Doors will not close or are out of alignment.	Enclosure is not bolted down tightly on perfectly level surface.	Using level, add shims as necessary and tighten anchoring bolts.
	Enclosure sprung out of shape.	Straighten or repair cubicle.
	Door hinges not properly adjusted.	Remove door hinges. Add or subtract shims as necessary.
Contactor will not close.	Control circuit or power fuse blown or circuit breaker tripped.	Inspect fuses, replace if blown. Reset circuit breaker.
	Incoming power line not energized.	Close feeder circuit breakers or tie switch.
	Magnet coil defective.	Check magnet operation, replace coil as necessary.
	*Master relay (MR) defective.	Check and replace if defective.
	Control power transformer defective.	Check and replace if necessary.
	Overload relay tripped or defective.	Check and replace if necessary.
	Missing jumpers, loose connections, remote connections, etc.	Check wiring diagram carefully to make sure that all external or alternate connections have been made satisfactorily. This is especially true where remote protective or control devices are used.
Contactor chatter or hum.	Loose connection in control circuit.	Tighten connections in control circuit.
	*Defective master relay.	Check relay, replace if necessary.
	Defective coil.	Check main coil, replace if necessary.
	Low control voltage.	Check line voltage.
	Corroded or dirty magnet pole faces.	Clean or replace magnet assembly.
Contacts overheating.	Loose connections.	Tighten connections.
	Contacts not mating firmly.	Check for weak or deformed contact spring, replace if necessary.
	Dirt or foreign matter on contact surface.	Clean contacts.
	Contact tip eroded.	Replace contacts.

*Not supplied on all starters.

Troubleshooting

Problem	Probable Causes	Corrective Action
Overload relays trip during starting or soon after motor is up to speed.	<p>Motor overloaded.</p> <p>Motor being started too frequently at close intervals.</p> <p>Excessive motor acceleration time.</p> <p>Low line voltage.</p>	<p>Limit starting load and running load to motor capabilities.</p> <p>Jogging and starting operations must be limited to capabilities of the motor and control. Check starting limitations in motor instruction manual before repeated starts.</p> <p>The starting of high inertia loads may not permit the use of standard overload relay application. Where accelerating time approaches 12 seconds or more, special overload relay bypass devices and circuits would usually be required. Contact Siemens regarding such problems and supply complete data on locked-rotor starting current and total accelerating time under maximum load conditions.</p> <p>Line voltage should be maintained between +10% of motor nameplate voltage.</p>
Overload relay trips during motor operation.	<p>Motor being overloaded.</p> <p>Overload relay not adjusted to motor capabilities or sized properly.</p> <p>Incorrect relay/heater selection.</p>	<p>Reduce load or correct conditions causing overload.</p> <p>Adjust relay setting in accordance with instructions for the overload relay. Adjustment should correspond to thermal rating of the motor, including temperature rise, duty and service factor. Replace overload if not sized properly.</p> <p>Select relay/heater in accordance with instructions for overload relays. Replace if necessary.</p>
Overload relay fails to trip on overload current.	<p>Relay tripping mechanism jammed.</p> <p>Incorrect relay or relay set incorrectly.</p> <p>*Current transformers with improper ratio or with short-circuited secondary terminals.</p>	<p>Replace relay.</p> <p>Check relay selection and adjustment per overload relay instructions.</p> <p>Current transformers must have a step-down ratio to correspond to full load motor current and relay selection. Protective jumpers may be provided at current transformer secondary terminals or on terminal block connections to guard against open transformer secondary circuit, and jumpers must be removed before placing equipment in operation.</p>
Blowing of motor power fuses.	<p>Short circuit on the load side of the motor fuses.</p>	<p>Use megger and other test instruments to locate fault and correct.</p>

*Not supplied on all starters.

Troubleshooting

Problem	Probable Causes	Corrective Action
Blowing of motor power fuses. (<i>cont.</i>)	Jogging or too frequent starting.	On frequent starting, fuses accumulate abnormal heat and cool more slowly than do overload relays. Since fuses more closely follow cooling and heating of motor windings, successive starting operations must be limited to the safe capacity of the motor to prevent fuse blowing from this cause. Check size rating on fuse against motor full load currents and service factor.
	Fuses internally damaged because of improper handling.	Motor power fuses may be damaged, dropped or roughly handled. Replace with fuse of same type, rating and voltage.
Blowing of primary control transformer fuses.	Shorted primary winding in control transformer.	Replace or repair transformer.
	Fuse may be "open" due to rough handling before installing.	Replace with fuse of same type, rating, and voltage.
	Secondary fuses not properly coordinated.	Melting characteristics of secondary fuse should not intersect melting characteristic of primary fuse. Rating of standard NEC fuse should not exceed twice the secondary current rating.
Blowing of secondary control transformer fuses.	Abnormal current or short circuit in control.	Check for faulty operation of long wipe economizing contacts, if supplied, shorted magnet coils, shorted rectifiers, if supplied, grounds, loose or bent connections, mechanical binding in relay and contactor mechanisms, excessive operations and incorrect secondary terminal connections.

SIEMENS

Siemens Energy
& Automation, Inc.
Electrical Apparatus
Division
P.O. Box 29503
Raleigh, NC 27626-0503


SIEMENS

Model 95 Motor Control Centers

Instructions

Installation
Operation
Maintenance

MCC3318-02





DANGER

Hazardous voltages.

Will cause death, serious personal injury or equipment damage.

Always de-energize and ground the equipment before maintenance.

Maintenance should be performed only by qualified personnel. The use of unauthorized parts in the repair of the equipment or tampering by unqualified personnel will result in dangerous conditions which will cause severe personal injury or equipment damage. Follow all safety instructions contained herein.

IMPORTANT

The information contained herein is general in nature and not intended for specific application purposes. It does not relieve the user of responsibility to use sound practices in application, installation, operation, and maintenance of the equipment purchased. Siemens reserves the right to make changes in the specifications shown herein or to make improvements at any time without notice or obligations. Should a conflict arise between the general information contained in this publication and the contents of drawings or supplementary material or both, the latter shall take precedence.

QUALIFIED PERSON

For the purpose of this manual a qualified person is one who is familiar with the installation, construction or operation of the equipment and the hazards involved. In addition, this person has the following qualifications:

- (a) **is trained and authorized** to de-energize, clear, ground, and tag circuits and equipment in accordance with established safety practices.
- (b) **is trained** in the proper care and use of protective equipment such as rubber gloves, hard hat, safety glasses or face shields, flash clothing, etc., in accordance with established safety practices.
- (c) **is trained** in rendering first aid.

SUMMARY

These instructions do not purport to cover all details or variations in equipment, nor to provide for every possible contingency to be met in connection with installation, operation, or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the local sales office, listed on back of this instruction guide.

The contents of this instruction manual shall not become part of or modify any prior or existing agreement commitment or relationship. The sales contract contains the entire obligation of Siemens Energy & Automation, Inc. The warranty contained in the contract between the parties is the sole warranty of Siemens Energy & Automation, Inc. Any statements contained herein do not create new warranties or modify the existing warranty.

Model 95 Motor Control Centers

Table of Contents

General Information	2	Permissible Loading of Motor Control Centers	22
An Overview	2	Maintenance	23
Qualified Person	2	General Inspection of the MCC	23
Signal Words	2	Periodic Cleaning	24
Siemens Advanced Motor Master System (SAMMS)	4	Stab Fingers and Vertical Bus	24
Receiving and Handling	6	Recommended Tightening Torques	24
Receiving	6	Circuit Breaker Disconnect Operator	24
Handling	6	Adjustment Notes	25
Skid Removal	8	Mechanical Interlock Adjustment	26
Storage	8	Maintenance After a Fault Has Occurred	26
Installation	9	Bus	26
Operating Environment	9	Enclosure	26
Site Preparation	9	Disconnecting Means	26
Mounting	10	Terminals and Internal Conductors	27
Top and Bottom Covers	10	Motor Starter	27
Installation of Seismic Qualified Structures	12	Adjustment of Sentron™ Type ETI Instantaneous Trip Motor Circuit Interrupter (1A-125A)	27
Joining Shipping Sections	12	Adjustment of Circuit Breakers with Adjustable Instantaneous Trip (125A-1200A)	28
Ground Bus	12	Field Testing of the Circuit Breakers	28
Incoming Power Connections	14	Overload Relays	29
Incoming Cable Spaces, Wiring Troughs and Terminations	14	Overload Relay	29
Main Lugs at Top with Top Cable Entry	15	Single Phasing Protection	29
Main Lugs at Top with Bottom Cable Entry	15	Manual or Automatic Reset	29
Main Lugs at Bottom with Bottom Cable Entry	15	3UA Overload Relay Selection and Adjustment	29
Main Lugs at Top with Top or Bottom Cable Entry	15	Procedure for Checking Nuisance Overload Tripping	29
Main Disconnect with Top Cable Entry	16	Field Testing	30
Load and Control Wiring	16	SA Overload Relays	31
NEMA Type A Wiring	16	SA Overload Heater Selection	31
NEMA Type B Wiring	16	Procedure for Checking Nuisance Overload Tripping	31
NEMA Type C Wiring	16	3SB0 Pilot Devices	33
Field Additions	17	Technical Data	33
Drawout Unit Removal	18	3TF Contactor	34
Drawout Unit Addition	19	Technical Data	35
Operation	21	Troubleshooting	37
Pre-Energization Checks	21		
Energizing Equipment	22		

General Information

An Overview

Introduction - The most effective means for grouping low voltage motor starters, associated control, and distribution equipment is through the use of motor control centers. A concept introduced almost 50 years ago, MCC's provide a means of grouping motor starter units, feeder tap units, and auxiliary controls in a common sheet steel enclosure. Motor starters through NEMA Size 4 and all feeder disconnects through 225 amperes are normally supplied with drawout construction. Most devices within the MCC are powered from a common horizontal bus and three phase bus risers. Large starters and certain special units may have cable connections to the horizontal bus in lieu of a vertical bus. Once installed in its centralized operating plant location, supervision and monitoring can be performed safely and by a minimum number of personnel.

Compact Components - Space-saving size of Siemens components results in spacious unit layouts for ease of installation, inspection and maintenance. Compactness also provides an advantage for adding auxiliary devices.

Electrical and Mechanical Life - Contactor life expectancies are among the longest in the industry and low coil power consumption promises operating cost savings in all contactor sizes.

NEMA Class 10 and Single Phase Protection - A unique overload relay designed to trip in 10 seconds or less under locked rotor conditions and less than 30 seconds under single phase conditions is offered as standard.

NEMA Class 20 - A Class 20 overload relay with interchangeable heater elements is offered as an alternative.




Figure 1: The Siemens Motor Control Center

I-T-E® Electrical Products Molded Case Circuit Breakers - State of the art "ETI" Circuit Breakers provide reliable protection with combination interrupting ratings up to 100,000 amperes - and without the use of fuses.

Spacious Wireway - A 40 square inch vertical wireway is one of the largest in the industry; provides room for a large number of control and power circuits. Horizontal wiring is accomplished through two oversize horizontal wireways. This design makes cable routing, inspection and clamp-on current measurements easier.

Precision Stab Design - Assures proper alignment and extended life operation.

Tubular Vertical Bus - Greater structural strength and increased heat dissipation for longer life.

UL Listed Starters - Widest range of UL listing in the industry—from NEMA Size 1 through NEMA Size 7.

	⚠ DANGER
	<p>Hazardous Voltage. Will cause severe personal injury, death or property damage. Only qualified personnel should work on or around this equipment after becoming thoroughly familiar with these publications and all information contained in this instruction manual.</p> <p>Turn off power supplying this equipment before any adjustments, servicing, wiring, parts replacement, or before any act requiring physical contact with electrical working components of this equipment is performed.</p>

Qualified Person

A "Qualified Person" is familiar with the installation, construction and operation of this equipment. In addition, this person has the following qualifications:

- Training and authorization to energize, de-energize, clear, ground and tag circuits and equipment in accordance with established safety practices.
- Training in the proper care and use of protective equipment such as rubber gloves, hard hat, safety glasses, face shields, flash clothing, etc., in accordance with established safety procedures.

Signal Words

The signal words "**Danger**", "**Warning**" and "**Caution**" used in this manual indicate the degree of hazard that may be encountered by the user. These words are defined as:

Danger ≈ Indicates death, severe personal injury or property damage *will* result if proper precautions are not taken.

Warning ≈ Indicates death, severe personal injury or property damage *can* result if proper precautions are not taken.

Caution ≈ Indicates some personal injury or property damage may result if proper precautions are not taken.

General Information




Figure 2: Typical Structural Components

General Information

Siemens Advanced Motor Master System (SAMMS[†])

The Siemens Advanced Motor Master System (SAMMS) is a programmable electronic device which replaces conventional control relays and timers, push buttons, pilot lights and overload relays. It consists of a controller which mounts in the MCC unit, plus a hand-held communicator.

The SAMMS controller mounts in the MCC unit in the location normally occupied by the pilot device panel. A three-phase current transformer, usually located between the branch circuit protective device and the contactor, is used to monitor motor current. The control power transformer supplied with SAMMS-equipped starters contains an extra 12 volt secondary winding to supply power to the SAMMS.

The SAMMS was designed specifically for use in motor control centers and similar applications and can be applied in NEMA Size 1 through Size 6 starters. It can be programmed to control all common starter types, including across-the-line, reversing, reduced voltage autotransformer, reduced voltage reactor, two-speed, wye delta and part-winding. Programming of the SAMMS control circuit logic is normally done at the factory to the customer's specifications, but can be accomplished by the user using an optional IBM PC-compatible software package.

The SAMMS front panel includes a keypad and indicating lights which provide the user with local control and visual status indication.

Overload protection provided by the SAMMS is based on an advanced motor model which continuously calculates the motor winding temperature as a function of the motor RMS current. The motor model compares the calculated temperature against maximum permissible temperature, and trips the motor off line if this value is exceeded. Selection of one of twenty-two overload trip classes allows (for SAMMS3) customized motor stall protection.

By utilizing the SAMMS hand-held communicator which includes a keypad, four digit numeric display and a cable which plugs into a receptacle on the front of the SAMMS, local display of motor and control circuit data and setting of certain operating parameters are possible. The number of features which can be accessed by the hand-held communicator depends on the SAMMS model furnished.

SAMMS-1, designed for applications where trained maintenance personnel are not available, or where motor loads are of a non-critical nature, allows access to the following functions using the hand-held communicator:

Function F-1. Displays the code number of the ladder diagram of the control circuit currently programmed into the SAMMS memory.

Function F-2. Displays the NEMA size of the starter.

Function F-3. Displays the NEMA size of the low speed contactor in the case of a two-speed starter.

Function F-4. Allows the user to input the full load amps of the motor, or the full load amps of the high speed winding in the case of a two speed motor.

Function F-5. Allows the user to input the full load amps of the low speed winding in the case of a two speed motor.

Function F-6. Allows the user to input the service factor of the motor.

Function F-7. Allows the user to select Class 10 or Class 20 overload protection.

Function F-8. Allows the user to enable or disable automatic reset after an overload trip.

Function F-9. Allows the user to enable or disable trip on phase current unbalance.

Function F-10. Displays the time in seconds until reset is allowed after overload trip occurs.

Function F-11. Allows the user to override the inhibit start feature in the case of an emergency.

General Information

SAMMS-2, designed for applications where trained maintenance personnel are available to service the motors and driven equipment, provides functions F-1 through F-11, plus the following additional functions:

Function F-7. Provides selection between four overload trip classes: 5, 10, 15 and 20.

Function F-12. Ground fault on-off (optional on all three SAMMS models).

Function F-13. Displays the selected value of a built-in start delay timer.

Function F-14. Displays the selected value of a second built-in timer. The function of the second timer is defined by the control circuit programmed into the SAMMS. For example, it can provide time delay for switching between high and low speed for two speed controllers.

Function F-15. Displays the average phase current.

Function F-16. Displays the current in amps seen by the motor at the last trip.

Function F-17. Displays the unbalance current as a percent of the full load current.

Function F-18. Displays the total elapsed running time on the motor in tens of hours.

Function F-19. Displays total number of motor starts in tens of starts.

Function F-20. Displays the total number of overload trips which have occurred.

Function F-21. Resets functions F-18, F-19 and F-20 to zero.




Figure 3: SAMMS Unit

SAMMS-3 is designed for use in critical process environments where down time can result in great losses of production time and/or process material. It provides all the functions of SAMMS-1 and SAMMS-2, plus the following:

Function F-7. Provides selection between twenty-two overload trip classes, from 2 through 23.

Function F-16. Displays each of the individual phase currents, as well as the highest phase current.

Function F-22. Allows the user to select a process current warning which will flash a warning if the motor current varies from a preset level. The current level at which the warning is given is adjustable from 0 to 100% of the motor full load amps.

Function F-23. Allows the user to enable or disable motor jam protection.

Function F-24. Allows the user to choose either loss of load warning or protection. Depending on the setting, the SAMMS will either flash a warning or trip the motor off line if a sudden loss of load occurs.

Function F-25. Displays the ratio of the calculated motor winding insulation temperature to the normal motor winding insulation temperature at full load current.

For additional information on operation and maintenance of the SAMMS, refer to the SAMMS instruction manual.



Figure 4: The SAMMS Hand Held Communicator.

Receiving and Handling

Receiving


Upon receipt of the motor control center, an immediate inspection should be made for any damage which may have occurred during shipment. The inspection should begin with the packaging material and proceed to the equipment within. Be sure to look for concealed damage and do not discard the packaging material. If damage is found, note damage on "Bill of Lading" prior to accepting receipt of the shipment, if possible.

Note: The way visible shipping damage is treated by the consignee prior to signing the delivery receipt can determine the outcome of the damage claim to be filed. Notification to the carrier within the 15 day limit on concealed damage is essential if loss resulting from unsettled claims is to be eliminated or minimized.

A claim should be immediately filed with the carrier, and the Siemens sales office should be notified if damage or loss is discovered. A description of the damage and as much identification information as possible should accompany the claim.

Handling

The motor control centers are shipped in groups of one to four vertical frames which are mounted on wooden shipping skids. When single frames are shipped individually, each is additionally mounted on a special pallet for further stability. Lifting brackets are supplied for each shipping section. If the brackets are shipped loose, assemble the brackets to the top structural members of the control center as shown in **Figure 5**. One bolt attaches the bracket to a 16 inch deep frame. The 20 inch deep frames require two bolts per bracket. Tighten 3/8" hardware to 20 - 30 ft. lbs.



⚠ WARNING

Heavy Equipment. Can result in death, severe personal injury and/or substantial property damage. Exercise extreme care when handling the motor control center. A crane or hoist should be used if at all possible.

Exercise all safety precautions outlined in the following discussion.

The following precautions must be taken whenever moving an MCC:

1. Handle the motor control center with care to avoid damage to components and to the frame or its finish.
2. Handle the motor control center in an upright position only. Motor control centers are normally front heavy and frequently top heavy. Balance the load carefully and steady the motor control center, as necessary, while moving. Some motor control center interiors may contain heavy equipment, such as transformers mounted within, that could be adversely affected by tilting.

3. Know the capabilities of the moving means available to handle the weight of the motor control center. Adequate handling facilities should be available. The following table gives the approximate weights of single vertical frames and will be helpful in determining the required capacity of the handling means. If a vertical frame contains power factor correction capacitors, reactors, or a large transformer, sufficient additional weight handling capacity must be allowed.

Table 1

FRAME	WEIGHT
20" W x 16" D Front Only	550 lb.
20" W x 20" D Front Only	600 lb.
20" W x 20" D Back-to-Back	850 lb.
30" W x 20" D Front Only	850 lb.

4. It is recommended that a crane or hoist be used to handle the MCC if at all possible. If a crane or hoist is not available and other handling means are necessary, extreme care must be exercised to insure that the equipment is secured during the movement and placement operations to prevent tipping and falling. Jacks, prybars, dollies, roller lifts, and similar devices all require supplemental blocking beneath the MCC and restraints to prevent tipping. These devices are not recommended due to the hazards implicit in their use.

The following precautions should be taken when moving an MCC with a crane or hoist:

1. Select rigging lengths to compensate for any unequal weight distribution and to maintain the motor control center in an upright position.
2. Do not allow the angle between the lifting cables and vertical to exceed 45° as shown in **Figure 5**.
3. Do not pass ropes or cables through lifting brackets. Use only slings with safety hooks or shackles.
4. Never lift an MCC above an area where personnel are located.

The following precautions should be taken when moving an MCC with a forklift:

1. Make sure the load is properly balanced on the forks.
2. Place protective material between the MCC and forklift to prevent bending and scratching.
3. Securely strap the MCC to the forklift to prevent shifting or tipping.
4. Excessive speeds and sudden starts, stops, and turns must be avoided when handling the MCC.
5. Lift the MCC only high enough to clear obstructions on the floor.
6. Take care to avoid collisions with structures, other equipment, or personnel when moving the MCC.
7. Never lift an MCC above an area where personnel are located.

Receiving and Handling




Figure 5: Motor Control Center, Sling, Roller, and Forklift Handling

Receiving and Handling

The following precautions should be taken when moving an MCC by rolling on pipes:

1. Use enough people and restraining devices to prevent tipping.
2. The surface over which the MCC is rolled must be level, clean and free of obstructions. **NEVER ROLL AN MCC ON AN INCLINED SURFACE.**
3. It should be recognized that rolling an MCC is especially hazardous to fingers, hands, and feet and is susceptible to tipping. Measures should be taken to eliminate these hazards.
4. All pipes must be the same outside diameter and should have no flat spots. Only steel pipe should be used for this purpose.

Skid Removal

Skid removal should be performed just prior to final placement of the control center and is achieved by first removing the bottom horizontal wire space covers which allows access to the skid lag bolts. Install the lifting brackets (see **Figure 5**) to the top of the MCC (torque bolts to 20-30 ft. lbs.) and attach the crane rigging to these brackets. Apply sufficient tension on the rigging to remove all slack without lifting the equipment. This is a recommended safety measure to reduce the possibility of tipping. The lag bolts may now be removed, the MCC lifted, the skids removed, the MCC lowered into place, and the anchor bolts secured. The last operation should be performed with adequate rigging tension to prevent tipping. After all additional shipping sections are secured in a similar manner, sections and bus bars should be joined in accordance with the instructions in the Installation section of this manual. Close doors and reinstall covers as soon as possible to eliminate intrusion of dirt and foreign materials into the MCC enclosure.

Storage

An indoor motor control center or separate unit, which is not installed and energized immediately, should be stored in a clean dry space where a uniform temperature prevents condensation. Preferably, it should be stored in a heated building, with adequate air circulation and protected from dirt and water. Motor control centers and units should be stored where they are not subject to mechanical damage.

If the motor control center is to be stored for any length of time, prior to installation, restore the packing for protection during that period. Where conditions permit, leave the packing intact until the motor control center or sections are at their final installation position. If the packing is removed, cover the top and openings of the equipment during the construction period to protect them against dust and debris.

An indoor motor control center that must be stored outdoors should be securely covered for protection from weather conditions and dirt. Temporary electrical heating should be installed to prevent condensation; approximately 150 watts per section is adequate for the average motor control center's size and environment. All loose packing or flammable materials should be removed before energizing space heaters.

An unenergized outdoor motor control center should be kept dry internally by installing temporary heating (see above), or by energizing optional self-contained space heaters.

Any scratches or gouges suffered from shipping or handling should be touched up with a can of spray paint to prevent rusting.

Installation

Operating Environment

The motor control center conforms with the provisions of NEMA Standard ICS1 - 108, Altitude Class 2KM which defines the usual service condition for electromagnetic control. It is designed for indoor use where the temperature inside the control center is higher than the ambient temperature. The control center is capable of carrying its rated load when the ambient temperature does not exceed 40° C and the altitude does not exceed 6600 feet above sea level. Where unusual service conditions exist or where temperature or altitude limitations are exceeded, the control center construction, ratings, or protection may require alteration. Some examples of unusual service conditions are excessive moisture, vibration, or dust.

Site Preparation

Installation shall be in accordance with the National Electrical Code, ANSI and NFPA 70 Standards. Unless the motor control center has been designed for unusual service conditions, it

should not be located where it will be exposed to ambient temperatures above 40° C (104° F), corrosive or explosive fumes, dust, vapors, dripping or standing water, abnormal vibration, shock or tilting, or other unusual operating conditions.

The motor control center should be installed in a clean dry heated place with good ventilation and it should be readily accessible for scheduled maintenance. A flat, level concrete surface should be prepared for the mounting site. If the mounting site is not flat and level, the motor control center must be shimmed where necessary to prevent distortion of the structure.

All conduit entering from the bottom should be in place and stubbed up about two inches above the finished floor level before installing the control center. Refer to the MCC lead sheet plan view located in the information packet for specific conduit area dimensions.




Figure 6: MCC Anchor Bolt Location (**without** sill channels)

Installation

Mounting

Motor control centers may be mounted by many different fastening systems including true drop in, cast in place, powder actuated, or threaded insert fasteners. See **Figures 6 and 7** for anchor bolt locations. The bolt pattern is dependent on frame width, depth, location in the line-up and whether or not sill channels are furnished. A floor plan drawing located in the print pocket details the anchor bolt locations. The coordination between bolts and the MCC should be verified prior to attempting installation. Expandable inserts in predrilled holes or imbedded "L" bolts are recommended. Wooden plugs driven into holes in masonry or concrete are not recommended for anchoring inserts and should never be used. The bolt size must be 3/8".

Welding the steel base or sill channels to a steel floor plate is an alternate mounting method. See **Figure 8** for details. Consult factory for installations in areas subject to seismic activity. Grouting the sill channels as indicated in **Figure 9** is another method of fastening. This method requires the foundation to be grooved as shown to accept the sill channels.

The sill end covers must be removed prior to placing the MCC into the grooves. The actual groove dimensions must be coordinated with the floor plan layout on the lead sheet included in the motor control center information packet.

If the control center is located on structural steel platforms over grids, it is recommended that the center be modified with bottom plates. Channel sill end covers are supplied with those control centers which employ sill channels to cover the openings at the ends of the center if the channels are above grade.

Top and Bottom Covers

Top covers are provided on all motor control centers as integral part of the enclosure. Bottom covers are supplied on certain types of construction such as NEMA 12. These covers should be removed only for the purpose of piercing holes for conduit or wire entry and must be immediately replaced to reduce the possibility that falling material, tools, or personnel could unintentionally contact the bus system or other live parts.




Figure 7: MCC Anchor Bolt Location (with sill channels)

Installation




Figure 8: Welded Installation




Figure 9: Grouting Method of Fastening Motor Control Center

Installation

Installation of Seismic Qualified Structures

Special installation arrangements are required for seismic qualified structures. Specific mounting procedures specified on the contract drawings or motor control center lead sheet must be explicitly followed to maintain the seismic withstand rating. Removal or rearrangement of frames may void the control center seismic qualification.

Joining Shipping Sections

Shipping sections consist of up to four vertical frames shipped as a single unit. It is often necessary to join two or more shipping sections at the job site. All necessary electrical and structural joining components are provided and the following procedures are recommended.

1. Position the first shipping section into place on the foundation and level.
2. Remove the front horizontal bus barrier and the side sheet from the end(s) to be joined. If the rear is accessible, the back cover plates should be removed from the two mating frames.
3. Position the second shipping section on the foundation adjacent to the first and level it. The horizontal bus should be inspected for proper positioning and alignment at this time.
4. Connect the shipping sections together by positioning the structure joining clips over the adjacent corner posts above and below the interframe barrier as shown in **Figure 10A**. Secure each clip with four self tapping screws, two on each side.




Figure 10A: Structural Joining of Shipping Sections

5. Assemble the bus bar links to join the horizontal power bus and neutral bus, if supplied, in the two shipping sections as shown in **Figure 10C**. The horizontal and neutral buses may differ in size, material, or plating, therefore, the links must be matched to the proper bars. All links and associated mounting hardware are provided with the motor control center.
6. Torque all bus connections to 40-50 ft. lbs.
7. If the motor control center has interwiring, connect the inter-unit wiring terminal blocks between shipping sections.
8. Join the ground bus between the two adjacent sections, if supplied. The Ground Bus Section in this manual details this procedure.
9. If there are other shipping sections to be joined, repeat steps 1 through 8 above.
10. Secure the motor control center to the foundation.
11. NEMA 3R enclosure sections should be securely joined and sealed to prohibit intrusion of dust and moisture.

Ground Bus

All hardware and links are supplied for joining the ground bus between two shipping sections. This joining may be accomplished by loosening the screw securing the connection link so that the link pivots freely. Remove the screw securing the ground bus in the adjacent frame to which the link will attach. Pivot the free end of the link such that the hole is aligned with the bolt, then reassemble the screw and link assembly. Tighten hardware. See **Figure 10B**.




Figure 10B: Joining Shipping Sections, Ground Bus

Installation




Figure 10C: Joining Shipping Sections, Horizontal Power Bus

Installation

Incoming Power Connections

NOTE: Remove top covers before cutting holes for conduit to prevent metal chips from falling into the motor control center.

Conduits should be carefully installed to prevent moisture or water from entering and accumulating within the enclosure. All conduits (including stubs) should be bonded to the motor control center. After all shipping sections are in place, leveled and joined together into a single motor control center, cables may be pulled and top entry conduit may be installed. Bottom entry conduit will have been stubbed through the floor at the proper locations prior to placement of the motor control center. The incoming source cables may be connected at this time, however, the power source disconnecting means must remain open and locked out until all wiring is completed and the entire system has been checked out. Care must be exercised to make sure that the lugs which have been provided are suitable for use with the type of cables being installed in the motor control center. If crimp lugs are supplied, use only the

crimping tool recommended by the lug manufacturer. Care should be exercised in stripping insulation from the conductors to prevent nicking the conductor. For aluminum, clean all oxide from the stripped portion and apply inhibiting compound at once. Tighten all screw lugs and bolted electrical connections to the specified torque listed in the table in the maintenance section of this instruction manual.

To minimize the length of unsupported cable, the shortest, most direct routing should be chosen. However, the largest practical bending radii should be maintained to avoid damaging the insulation and to avoid causing terminals to loosen. All cables entering the motor control center must be adequately supported and restrained to withstand the maximum fault current capable of being delivered by the source. The recommended distances between straps for 80 pound rated strap is 6 inches for 25 KA bracing, 4 inches for 42 KA bracing and 3 inches for 65 KA bracing. Using a strap rated less than 80 pounds will require the spacing distances to be reduced. For 100 KA bracing, cables must be supported in accordance with the special instructions provided with the motor control center. Typical incoming line arrangements are shown in **Figures 11 through 16**.

Incoming Cable Spaces, Wiring Troughs and Wiring Terminations

The National Electrical Code establishes very specific guidelines for minimum cable bending space within motor control centers. In particular, Article 373-6 of the NEC details these requirements. **Figures 11 through 16** describe the most common arrangements for terminating main incoming power cables to the motor control center. Consult the factory for incoming line compartment braced for 100,000 amperes short circuit. The following table summarizes these and other standard termination schemes.

Table 2

Figure No.	Description of Incoming Service	Top or Bottom Incoming Section	Cable Entry	Space Requirements	Comments
14	≤ 350 MCM One per Phase	Top – Directly on Main Bus	Either	None	See Figure 14
11, 12	≤ 600 MCM One or Two per Phase	Top	Either	Top Wireway Plus 12" or 18"	See Figures 11 and 12
-	≤ 600 MCM Three or Four per Phase	Top	Either	Top Wireway Plus 12" or 18" X 2	Parallel Incoming Lines at Top of Adjacent Vertical Sections
-	750 MCM One or Two per Phase	Top	Either	Top Wireway Plus 36"	
13	≤ 500 MCM One or Two per Phase	Bottom	Bottom	Bottom Wireway plus 12"	600 A Maximum See Figure 13
	≤ 750 MCM One or Two per Phase	Bottom	Bottom	Bottom Wireway plus 24"	600 A Maximum See Figure 13
-	≤ 750 MCM	Top or Bottom	Either	Consult Factory	Consult Factory
15	≤ 500 MCM One or Two per Phase ≤ 750 MCM One per Phase to Main Breaker	Top	Top	See Breaker/Disconnect	See Figure 16
16	≤ 500 MCM One to Four per Phase ≤ 750 MCM One per Phase to Main Breaker	Top	Top	See Breaker/Disconnect	See Figure 16
-	Cable Feed to Incoming Line Reactor	Full Height	Either	Full Structure	30" Wide Structure
-	Busway	Top or Bottom	Either	Consult Factory	Consult Factory

Siemens Motor Control Centers are equipped with a 9" high, full-width horizontal wireway in both the top and bottom of each structure. A separate vertical wireway connects the top and bottom wiring areas in each vertical section. This wireway is 5" wide by 8" deep (40 square inches).

Installation

Main Lugs at Top with Top Cable Entry

Can accommodate up to two 600 MCM cables per phase when using Siemens' standard mechanical lugs. (Compression lugs require extra vertical space or the addition of a top nut). Requires a total height of 21" (9" top wireway, plus 12" of unit mounting space).




Figure 11

Main Lugs at Top with Bottom Cable Entry

Can accommodate up to two 250 MCM or one 500 MCM cable per phase in the standard 21" height (9" top wireway, plus 12" of unit mounting space). Can accommodate up to two 600 MCM cables per phase in a 27" high compartment (9" + 18").




Figure 12

Main Lugs at Bottom with Bottom Cable Entry

Lugs are bolted directly to the bottom of the vertical bus. Can accommodate up to two 500 MCM per phase in 21" high compartment (9" high bottom wireway plus 12" of unit mounting space). Can accommodate up to two 750 MCM per phase in 33" high compartment (9" + 24").




Figure 13

Main Lugs at Top with Top or Bottom Cable Entry

In this arrangement the lugs mount directly on the horizontal bus, thus eliminating the need to use unit mounting space. The limitation here is one 350 MCM cable per phase and rear or side accessibility.




Figure 14

Installation

Main Disconnect with Bottom Cable Entry




Figure 15

Main Disconnect with Top Cable Entry




Figure 16

Load and Control Wiring

All interconnections between devices within each control unit are prewired at the factory. Field wiring to each control unit should be made in accordance with the wiring diagram indicated on the lead sheet for that particular unit. The lead sheet and wiring diagrams are included in the information packet. When wiring or performing any maintenance on drawout units, disengage the stabs by withdrawing the unit. Refer to pages 18 and 19, "Drawout Unit Removal", Steps 1 through 10. Wiring done with the pan in this position will ensure adequate cable slack to allow unit withdrawal to the same position when future maintenance is required. Always use stranded wire.

The vertical wiring between control units or between a control unit and conduit should be pulled through the wiring space on the right side of the frame. These wires should then be tied or

laced together and the resulting bundle then securely fastened to the wire supports. Connections between a front mounted control unit and a rear mounted control unit in a back-to-back control center should be made at the bottom of the frame. Interconnecting wiring between control units mounted on the same side of the MCC should be routed through the top horizontal wire space.

Installation and wiring must be in accordance with NFPA-70, ANSI, the National Electrical Code and any other applicable regional codes or regulations.

NEMA Type A Wiring

Motor control centers with NEMA Type A wiring do not include terminal blocks. See **Figure 17**. All field wiring, both power and control, should be connected directly to the individual components.

NEMA Type B Wiring

Motor control center units with NEMA Type B wiring are equipped with control terminal blocks to which the factory wiring is connected. **Figure 18** depicts this wiring which adds terminal blocks mounted on the pan top for outgoing connections.

NEMA Type C Wiring

Figure 19 shows a motor control center equipped with NEMA Type C wiring which includes all the features described for NEMA Type B wiring in addition to master terminal blocks located at either the top or bottom of the vertical frames. Motor control center units are factory wired to their master terminal blocks.

The motor control center lead sheet, located in the information packet, indicates the type of wiring provided for this installation.

NOTE: Six 12 inch drawout assembly module spaces per frame are available in the front, five in the rear, with the rear side tracks set an inch higher than the front to prevent stab assembly interference on the vertical bus. Drawout assemblies may be mounted on either the front or rear, but there will be a phase reversal when mounted on the rear. This should be taken into consideration when terminating motor cables.




Figure 17: NEMA Class 1, Type A Wired Unit

Installation

Field Additions

Field additions may be made to the control center if the current rating of the main or vertical bus is not exceeded. The preparation of the floor and conduit is the same as in a new installation. Any new shipping section will contain all of the necessary hardware and bus connecting links. De-energize the existing motor control center and remove the end side sheet from the new and existing vertical frames which are to be joined. After joining the structures per the instructions in the installation section of this manual, perform the pre-energization checks outlined in the operation section of this instruction manual.

Additions to motor control centers fall into two general categories: additions of frames and additions or replacement of drawout units. The addition of frames is similar to the installation of control centers which have been shipped in several sections. When mounting methods or models of new and existing sections differ, care must be exercised to ensure proper alignment of horizontal bus. The new frames are then treated the same as in a new installation. This is discussed in detail in the Joining Shipping Sections portion of this manual.

A special splice bar is provided for the ground bus when connecting to a ValueLine motor control center. See **Figure 20** for details.




Figure 18: NEMA Class 1, Type B Wired Unit




Figure 19: NEMA Class 1, Type C Motor Control Center




Figure 20: Ground Bus Splicing of New Motor Control Center to ValueLine Mark 2 (Model A).

Installation

Drawout Unit Removal

The following sequences should be followed when removing a drawout unit:

1. Turn unit off using STOP button or selector switch (if supplied).
2. Push the disconnect operating handle down to the OFF position.
3. Turn the quarter turn door fasteners 90° with a screwdriver and open the door.
4. Grasp the handle on the racking cam located on the top of the unit and pull out, rotating the cam until it stops (approximately 90°). This will withdraw the unit far enough to separate the stabs from the vertical bus (**Figure 21A**).
5. Grasp the racking cam handle and pull the unit out approximately 1 more inches. Now push the handle back toward the unit until it stops. The unit may be locked out in this position by inserting a padlock in the handle as shown in **Figure 21B**.




Figure 21A: Draw-Out Unit (Pan Assembly) Removal





Figure 21B: Operating Handle in the "OFF" Position

	⚠ DANGER
	Hazardous Voltage. Will cause death, serious personal injury, or property damage.
	Energized vertical bus may be partially exposed through the access hole in the barrier when the unit is not fully inserted. Use extreme caution when performing any wiring or maintenance with the unit withdrawn.

6. Separate pull apart terminals, or disconnect wires from terminal blocks. Tag and secure disconnected wires within the motor control center wireway. To separate pull apart terminal blocks, insert a flat head screw driver under locking tab and push non-stationary portion of the terminal block toward the rear as shown in **Figure 22A**.
7. Lift and hold non-stationary portion of terminal blocks up and over fixed portion, as shown in **Figure 22B**.
8. The drawout unit may now be easily pulled from the frame.




Figure 22A: Separate Pull Apart Terminal Blocks




Figure 22B: Move Non-Stationary Portion Over Fixed Portion.

Installation

9. If so equipped, the drawout unit pilot device panel (or SAMMS panel) may be released by loosening the captive screw a few turns, then swinging the panel to the right to gain access to components mounted behind it. Once the panel is opened to approximately 135°, a detent will hold it in position. To release the detent, lift the panel slightly allowing it to reclose.
10. The drawout unit should be protected from abuse, dust, and moisture while it is out of the motor control center.

Drawout Unit Addition

Drawout units may easily be added to the Siemens Motor Control Center to fill blank spaces. Each unit comes complete with horizontal support barrier, door, and hinges. The following is the installation procedure for these units.

1. Remove the cover(s) over the blank section(s) equal to the drawout unit height. (Steps A and B, **Figure 23**).
2. Horizontal drawout unit barriers are installed by sliding the rear tabs into mating slots in the vertical barriers and fastening the front into place with two self-tapping screws in the predrilled vertical channels (see **Figure 2**). (Step C, **Figure 23**).
3. Use the new door as a template to locate the positions of the hinges. Self-tapping screws in predrilled holes are used to bolt the hinges to the left hand corner channels. Remove or relocate any excess hinges left from the removal of the covers performed in Step 1 above. (Step D, **Figure 23**).
4. Remove the vertical bus barrier insert at the appropriate location for stab engagement.
5. Push the disconnecting means operating handle to the OFF position.
6. Close the racking handle and install the drawout unit onto the slide rails and push in until it stops. The unit may then be padlocked in this disengaged position.
7. Connect all power cables and control wires in agreement with unit wiring diagram and the instructions detailed in the Incoming Power and Load and Control Wiring sections of this manual.
8. Perform pre-energization checks outlined in Operation section of this manual.
9. Remove the padlock installed in Step 6 above. Pull the racking handle out until it stops, then push the unit inward until it engages the pin located on the underside of the horizontal unit barrier.
10. Rack the unit onto the vertical bus by pushing the racking handle to the left and inward as far as it will go.
11. Close the door and secure it with the quarter turn fasteners.
12. Move the handle to the ON position. The control unit is now ready for operation.
13. Repeat Steps 1 through 12 for each additional new drawout unit to be added.



⚠ DANGER

Hazardous Voltage. Will cause death, serious personal injury, or property damage.

Energized vertical bus may be partially exposed through the access hole in the barrier when the unit is not fully inserted. Use extreme caution when performing any wiring or maintenance with the unit withdrawn.

Installation





Figure 23: Draw-Out Unit Addition

Operation


Pre-Energization Checks

After installation, field addition, or maintenance, perform the following checks before energizing equipment:

1. Compare all circuits for agreement with the wiring diagrams which are provided with the motor control center. Be sure that each motor is connected to its intended starter.
2. Check all connections for proper torque and be sure that inserts or automatic shutters are installed in all exposed openings in the vertical bus barriers.
3. Inspect the motor control center for accumulation of dust or dirt. If required, clean the MCC as explained in the Maintenance section of this manual.
4. Test the motor control center power circuit for possible short circuits and grounds. A dielectric test at 2 times the nominal system voltage plus 1000 volts applied for one minute between phases and from all phases to ground is the preferred method. The maximum allowable leakage current is 1.5mA per 1000 test volts applied. If a high-pot tester is not available, then a megger test using a 500 or 1000 volt megger is a suitable second choice. The minimum allowable resistance measured from phase to phase and from phase to ground is one megohm. Be sure to disconnect any control devices, control power transformer, etc., from the circuit which could be damaged by the test voltage.


	<p>⚠ DANGER</p> <p>Hazardous Voltage. Will cause death, serious personal injury, or property damage.</p> <p>Dielectric or megger testing should only be conducted by qualified personnel. Refer to test device instructions for safety instructions.</p>
---	--

5. Manually exercise all switches, circuit breakers, contactors, magnetic devices, and other operating mechanisms several times to make certain they are properly aligned and operate freely. Some contactors are shipped with taped arc chutes or restraining devices to minimize vibration effects during shipment. Be sure that all such restraints have been removed. None of these devices must ever be blocked in the ON position. Check all electrical interlocks for proper contact operation. Check all mechanical interlocks for proper freedom and operation.
6. Some arc chutes are shipped separately packaged to reduce shipping damage. Make sure that all arc chutes are properly installed and secured on all contactors, relays or switches.

	<p>⚠ DANGER</p> <p>Hazardous Voltage. Will cause death, serious personal injury, or property damage.</p> <p>Never operate any contactor, relay or switch unless its arc chute or cover is properly installed and secured and undamaged.</p>
---	---

7. Check all timers for proper interval setting and contact operation.

8. Check overload relay trip setting and or heater size and verify that they are adjusted per the instructions given for the overload relay in this instruction manual.
9. Check all power circuit fuses and control fuses to verify that they are sized in accordance with the National Electrical Code application requirements. Class K-9 and H fuses are not recommended.
10. Current transformers to which customer devices will be connected, are shipped with their secondaries shorted. All

	<p>⚠ DANGER</p> <p>Explosive Hazard. Installation of fuses of insufficient interruption rating will cause death, serious personal injury or property damage.</p> <p>To ensure proper coordination and sufficient capacity to interrupt the available fault current, always install replacement fuses with UL class, continuous current rating, type, and interrupting capacity identical to the original. NEVER defeat rejection mechanisms which are provided to prevent the installation of the wrong type of fuses.</p>
--	--


shorting devices should be removed when the secondary connections to these transformers are completed. Make sure that the current transformer secondary is complete. Current transformers must not be energized with their secondaries open circuited.

11. Check all devices for missing or broken parts, proper spring tension, free movement, rusting or corrosion, dirt, and excessive wear. Make all necessary repairs.
12. Check all electrical relays, meters, and instruments to verify that connections are made properly and that the devices function properly. Verify that adjustable voltage and current trip mechanisms are set to the proper values.
13. Make sure that no fuses, overload relays, incomplete sequence relays, shunt trips, ground fault protection assemblies, electrical interlocks, or trip contacts from any of these devices are strapped, bypassed, or defeated in any manner.
14. Turn all circuit breakers and fusible switches to the OFF position.
15. Make sure that all barriers, braces, and shields are installed in the equipment as intended. If vertical bus isolation barriers are supplied, make sure that they are all properly seated between the vertical bus supports.
16. Check the integrity of all bus mounting means and cable connections to the bus. Make certain that field wiring is clear of line bus and physically secured to withstand the effects of the largest fault current which the supply system is capable of delivering. Make sure that control wires or power cables are not touching the power bus.
17. Verify that all ground connections have been properly made. The sections of the motor control center which were shipped separately must be connected in such a way to assure a continuous grounding path.

Operation

18. Install covers, install units, close and secure doors, make certain that no wires are pinched and that all enclosure parts are properly aligned and secured.
19. Make sure the door interlocks on all disconnect operators are properly adjusted and secured. If adjustment is required, use the procedure explained in the Maintenance section of this instruction manual.
20. Disconnect any safety grounds which have been connected to the power bus.

Energizing Equipment

	⚠ WARNING
	<p>Hazardous Voltage. Failure to check out this equipment prior to energization can cause death, serious personal injury or equipment damage.</p> <p>All pre-energized checks outlined in this instruction manual must be performed before the equipment is energized. This equipment should be energized by QUALIFIED PERSONNEL only.</p>


1. In order to minimize risk of injury or damage, or both, there should be no load on the motor control center when it is energized. Turn off all of the downstream loads, including those such as distribution equipment and other devices which are remote from the motor control center.
2. The equipment should be energized in sequence by starting at the source end of the system and working towards the load end. In other words, energize the main devices, then the feeder devices, and then the branch-circuit devices. With barriers (if applicable) in place, and unit doors closed and latched, turn the devices on with a firm positive motion. Protective devices that are not quick-acting should not be "teased" into the closed position.
3. After all disconnect devices have been closed, loads such as lighting circuits, starters, contactors, heaters, and motors, may be turned on to verify that the system operates as intended.

Permissible Loading of Motor Control Centers

1. For motor control centers without main overcurrent protective devices, the total continuous load current through the horizontal bus should not exceed the current rating of the motor control center.
2. For motor control centers with a single main overcurrent protective device, the total continuous load current on the protective device should not exceed 80 percent of its ampere rating unless the device is rated to carry 100 percent of its ampere rating, in an enclosure.
3. For motor control centers with multiple main overcurrent protective devices, the total continuous current through the horizontal bus should not exceed the current rating of the motor control center. The total continuous load current on each overcurrent protective device should not exceed 80 percent of its ampere rating unless the device is rated to carry 100 percent of its ampere rating, in an enclosure.
4. For branch-circuit overcurrent protective devices in a motor control center, the total continuous load current on the protective device should not exceed 80 percent of its ampere rating unless the device is rated to carry 100 percent of its ampere rating, in an enclosure.
5. Unless a current limiting means is used in a series combination, the maximum short-circuit current rating of the entire motor control center is the smallest of the following:
 - a. the rating of the bus structure, or
 - b. the lowest rating of the motor control units, or
 - c. the lowest rating of the feeder units.

This motor control center rating is clearly indicated on the lead sheet located in the information packet.

Maintenance



⚠ DANGER

Hazardous Voltage. Will cause death, serious personal injury or equipment damage.

- 1) Disconnect and lock-out incoming power and control voltage sources before beginning work on this or any other electrical equipment.
- 2) Check all power and control circuit terminals with a voltmeter to make certain that the equipment is totally de-energized.
- 3) Ensure that only QUALIFIED PERSONNEL be instructed and authorized to use the defeater mechanism to gain access to an energized compartment.
- 4) Never attempt to withdraw a drawout unit or disconnect any terminations when the defeater mechanism has been used to open a compartment door.

It is recommended that a safety ground be connected to the power bus after the system has been de-energized, and prior to working on the equipment. Follow the procedure outlined in the PRE-ENERGIZATION CHECK section of this manual before power is restored.

For the safety of maintenance personnel as well as others who might be exposed to hazards associated with maintenance activities, the safety related work practices of NFPA 70E, part 11, should always be followed when working on electrical equipment. Maintenance personnel should be trained in the safety practices, procedures and requirements that pertain to their respective job assignments. This manual should be reviewed and retained in a location readily accessible for reference during maintenance of this equipment.

The customer must establish a periodic maintenance program to ensure trouble-free and safe operation. The frequency of inspection, periodic cleaning, and preventive maintenance schedule will depend upon the operation conditions. NFPA Publication 70B, "Electrical Equipment Maintenance" may be used as a guide to establish such a program. **A preventive maintenance program is not intended to cover reconditioning or major repair, but should be designed to reveal, if possible, the need for such actions in time to prevent malfunctions during operation.** The following items should be included in any maintenance checklist. For more details read the succeeding pages.

- General Inspection of the MCC
- Periodic Cleaning
- Tightening Torques
- Stab Fingers and Vertical Bus
- Circuit Breaker/Disconnect Operator
- Mechanical Interlocks

A specific checklist of routine preventative maintenance requirements is recommended for each item of equipment, as well as a log book to record the maintenance history.

General Inspection of the MCC

1. Carefully inspect the doors, enclosure sides and deadfront surfaces over all units for excessive heat. As a general rule, temperature which the palm of the hand cannot stand for about 3 seconds may indicate trouble. Infra-red heat detectors are available for the purpose of detecting heat problems.
2. Inspect the motor control center a minimum of once each year, or more often as deemed necessary. Look for any moisture or signs of previous wetness or dripping inside the MCC. Look for any accumulation of dust or dirt. Clean as explained in the Periodic Cleaning section.
3. Loose electrical connections can cause overheating that can lead to equipment malfunction or failure. Loose bonding or grounding can compromise safety and/or function. Terminal screws, lugs, bus connections, bonding and grounding connections should be inspected for tightness and retightened securely as required. Recommended tightening torques are shown in the Recommended Tightening Torque section of this manual. Fuse clips should be checked for signs of overheating, looseness, or inadequate spring pressure, and replaced if necessary. All terminals, connections, and conductors should be examined for evidence of overheating, corrosion, or pitting. Any parts found to be damaged should be replaced, using parts supplied or recommended by Siemens. Evidence of overheating may include discolored conductors, terminals or parts; or melted, charred or burned insulation.
4. Examine insulation on conductors for overheating or chafing against metal edges that could progress into an insulation failure. Any damaged conductors should be replaced. Replacement conductors should be rerouted, braced or shielded if needed to avoid similar damage in future operation. Temporary wiring should be removed or replaced by permanent wiring.
5. Operate each switch or circuit breaker several times to insure that all mechanisms are free and in proper working order. Check the operation of the mechanical safety interlocks provided with the operator (see section on Circuit Breaker/Disconnect Operator). Never attempt to operate a switch or circuit breaker by use of excessive force.
6. Visually inspect instruments and pilot lights. Replace defective pilot lights. Check instrument calibrations.
7. Check all devices for missing or broken parts, proper spring tension, free movement, rusting or corrosion, dirt, and excessive wear. Perform periodic maintenance on components as detailed in the component instruction books.

Maintenance

Periodic Cleaning

Accumulation of dust and foreign material such as coal dust, cement dust, or lampblack must be removed from all control equipment and all surfaces must be wiped clean at regular intervals. Dirty, wet, or contaminated parts should be replaced unless they can be cleaned effectively. Dust can collect moisture, causing voltage breakdown and it can reduce the effectiveness of heat sinks.

Control equipment parts should be cleaned by vacuuming or wiping with a dry cloth or soft brush. Use care to avoid damaging delicate parts. Liquid cleaners, including spray cleaners, are not recommended due to the possibility of residues. Compressed air is not recommended for cleaning because it will only redistribute contaminants on other surfaces, and may damage delicate parts. The inside bottom of the motor control center should also be cleaned, including removal of any hardware or debris, so that any new or unusual wear or loss of parts occurring after the inspection may be more readily detected during subsequent maintenance. Inspect the motor control center for any signs of previous wetness or dripping inside the controller.

Condensation in conduits or dripping from an outside source is a common cause of failure. Seal off any conduits that have dripped condensate, and provide an alternative means for the conduit to drain. Seal off any cracks or openings which have allowed moisture to enter the enclosure. Eliminate the source of any dripping on the enclosure and any other source of moisture. Replace and thoroughly dry and clean any accumulation of deposited material from previous wettings.

Stab Fingers and Vertical Bus

Look for wear of the tin or silver (optional) plating where the unit stab fingers engage the vertical bus. The plating is part of the environmental protection system. Oxide and/or other films can form on exposed bus resulting in a poor contact.

These parts must be replaced when the plating is worn to the point where copper can be seen because contact resistance becomes higher, increasing the heat generated at the contact point.

Lubricate the stab fingers with a light coating of Siemens contact lubricant number 15-171-370-002 before replacing drawout assemblies.

Recommended Tightening Torques

When making bolted assemblies, the following considerations should be generally followed. The tightening torques are determined by the size of hardware used.

1. **Metal-to-Metal** - Apply standard tightening torque as listed:

Table 3

Recommended Tightening Torques

Thread Size	Torque (lb.-in.)
8-32	14-20
10-32	20-30
1/4-20	40-60
5/16-18	168-228
3/8-16	240-360
1/2-13	480-600

2. **Metal-to-Insert Molded in Compound Part** - Apply 2/3 of standard tightening torque.
3. **Compound-to-Insert Molded in Compound Part** - Apply 1/2 of standard tightening torque.
4. **Compound-to-Compound** - Apply 1/2 of standard tightening torque.

Circuit Breaker Disconnect Operator

Operator mechanisms for circuit breakers through 125A and disconnect switches through 200A are hinged from the side of the unit and secured in place by a single captive screw. They may be swung open to access the protective device by loosening the captive screw a few turns to release it from the unit top brace. The linear motion Operator mechanism shown in **Figure 24** mounts directly to the face of the circuit disconnecting device and the plastic handle extends through the unit door to allow the device to be safely operated. The operator is provided with three mechanical safety interlocks to perform the following functions:

1. **Operator-Unit Interlock:** The operator-to-drawout unit interlock prevents withdrawal or insertion of the control unit with the handle in the "ON" position. When the handle is in the "ON" position, the operator driver (**Figure 24**, Item 1), extends into the racking handle assembly (**Figure 25**, Item 1). This also prevents movement of the latching mechanism (**Figure 25**, Item 2), locking the unit so that it may neither be inserted or withdrawn. When the handle is in the "OFF" position, the racking handle is free to move, thus allowing easy withdrawal and insertion of the drawout unit.
2. **Padlocking:** The handle may be locked in the "OFF" position (**Figure 26**) by installing one to four padlocks in the locations shown. With one or more padlocks installed, the handle is prevented from moving to the "ON" position by interference between the padlock and the handle.




Figure 24: Linear Motion Operator Mechanism

Maintenance

3. **Door-Operator Interlock:** The door-to-operator interlock prohibits closing or opening the control unit door except when the handle is in the "OFF" position. As the handle moves to the "ON" position, the interlock lever (**Figure 24**, Item 2) pivots behind the door mounted "J" shaped bracket thus preventing opening of the control unit door.

A provision is made for QUALIFIED PERSONS to defeat the door-operator interlock when the handle is in the "ON" position. This is accomplished by turning the defeater screw (**Figure 24**, Item 5) counterclockwise approximately 1/8 turn until the door is released. To reclose the door, gently hold the door closed while turning the defeater screw counterclockwise until the door is felt to close against the structure frame. Release the defeater screw and secure the 1/4 turn door fasteners.

This safety interlock also serves to prevent inadvertent closing of the protector when the door is open. Authorized personnel may defeat the interlock in this situation by pushing and holding the exposed upper portion of the interlock arm to the left. This releases the interlock so that the protective device may be turned "ON".

Adjustment Notes

No field adjustment to the door interlock mechanism should be necessary under normal operating conditions. However, should adjustment become necessary as a result of mechanical damage or wear, the following procedure is recommended.




Figure 25: Padlocking the Pan Brace Assembly

1. With the protector in the "OFF" position, the latching mechanism (**Figure 25**, Item 2) fully extended, and the unit door open, defeat the interlock by pushing the top of the lever (**Figure 24**, Item 2) to the left and turn breaker "ON" and "OFF" several times. If the protector fails to turn "ON" or if excessive operating resistance is experienced, turn protector "OFF". Withdraw the unit and inspect for misalignment of the operator extension(s) or the driver (**Figure 24**, Item 1) and the racking handle assembly (**Figure 25**, Item 1). Make necessary adjustments to correct any misalignment.
2. With the drawout unit reinstalled in the motor control center, close and secure door. Turn protector "ON". If operating difficulty persists and protector fails to turn "ON", open unit door. Inspect the door mounted portion of the interlock assembly for damage or distortion. Inspect the interlock lever (**Figure 24**, Item 2) mounted on the right side of the operator for damage, freedom of movement, and its ability to rest firmly against the boss on the plastic handle without assistance. If damage or unusual wear are detected, all affected parts must be replaced.
3. If operating difficulty persists, unlatch the 1/4 turn fasteners and open the door, then slowly close it observing the point of contact between the interlock lever on the operator (**Figure 24**, Item 2) and the door mounted portion of the interlock. The ramp on the "J" shaped bracket mounted on the door should first engage the movable interlock lever on the operator at a point approximately 1/16" below the top right corner of the interlock lever. If the point of engagement does not occur at this point, gently bend the pointed extension of the door mounted portion up or down slightly to the proper position. Before making this adjustment, make sure the plastic handle is centered in the door cut-out when the door is closed.




Figure 26: Padlocking the Handle in the "OFF" Position

Maintenance

Mechanical Interlock Adjustment

Siemens motor control centers which contain reversing, multi-speed or reduced voltage motor starters may employ mechanical interlocking between contactors in the starter units. Two contactors of the same size or two contactors of different sizes may be mechanically interlocked depending on the type of motor starter. The combinations of interlocked contactors which can be supplied is shown in **Table 4**. Mechanical interlocking is accomplished with the interlock mechanisms shown in **Figure 27** which mounts between two adjacent contactors. Dimension "X" shown in the figure is factory set to the dimension shown in **Table 4**. The contactors and mechanical interlock mechanism should be checked periodically and adjusted if necessary to ensure that the mechanical interlock functions properly. This procedure should be performed as outlined in the following steps (refer to **Figure 27**).

Table 4
Combinations of Mechanical Interlocks

1st Contactor Catalog No.	2nd Contactor Catalog No.	Dimension "X" (mm)
3TF44	3TF44	0
3TF44	3TF46	0
3TF46	3TF46	0
3TF46	3TF48	8
3TF48	3TF48	8
3TF48	3TF52	16
3TF52	3TF52	16
3TF52	3TF56	16
3TF56	3TF56	0

1. Disconnect and lock out all incoming power and control voltage sources to the unit which contains the mechanical interlock assembly to be adjusted.
2. Remove the screws which secure legs "F" to the baseplate.
3. Set dimension "X" of legs to the dimension shown in **Table 4**.




Figure 27: Mechanical Interlock

4. Re-attach legs "F" to the baseplate using the screws removed in Step 2.
5. Turn both of the screw spindles "E" until they are flush to .016" below the surface of the interlock case.
6. Check the function of the mechanical interlock by pushing on the screw spindles "E". You should not be able to push both spindles down at the same time.

Maintenance After a Fault Has Occurred

The excessive currents occurring during a fault may result in component or bus damage due to mechanical distortion, thermal damage, metal deposits, or smoke. After a fault, repair the cause of the fault, inspect all equipment per NEMA Standards Publication No. ICS 2-1987 Part ICS 2-302 and make any necessary repairs or replacements prior to placing the equipment into service again. The following procedure is recommended for this inspection.

Bus - Retighten all bus connections. Replace burnt or melted bus or bus with melted, worn or damaged plating. Replace all insulators showing deterioration or deposits.

Enclosure - Inspect the enclosure and doors for evidence of damage such as deformation, displacement of parts or burning. Extensive damage will require replacement of the entire controller.

Disconnecting Means

1. **Circuit Breakers**: Examine the circuit breaker for evidence of possible damage. If there is no apparent evidence of damage, the breaker may be reset and turned "ON". If it is suspected that the circuit breaker has opened several short circuits or if there are signs of possible deterioration, replace the breaker or subject it to the test described in Para. AB1-2.38 of the NEMA Standards Publication for "Molded Case Circuit Breakers" before restoring it to service.
2. **Disconnect Switch**: The external operating handle must be capable of opening the switch after a fault. Replace the switch if the external operating handle fails to open it or if visual inspection after opening indicates deterioration beyond normal wear, such as overheating, contact blade or jaw pitting, charring, or insulation breakage.




Figure 28: The Stab Assembly

Maintenance

3. **Fuse Holders:** Replace fuse holders if the insulating mounts, barriers, or fuse clips show signs of deterioration, heating, distortion, or looseness.
4. **Operating Handle:** The disconnecting means must be replaced if the operating handle fails to open and close. The door interlock must be inspected and its proper function verified prior to restoring the controller to service.
5. **Stab Fingers: (Figure 28)** Inspect stab fingers as instructed under Stab Fingers Section and Vertical Bus Section and replace if necessary.

Terminals and Internal Conductors

Replace all damaged parts which show evidence of discoloration, melting or arcing damage.

Motor Starter

1. **Contactors:** Replace the contacts and contact springs if the contacts are welded or show heat damage, displacement of metal, evidence of binding in the guides, or wear in excess of wear allowance. If deterioration extends beyond the contacts, replace the contactor. Examples of such deterioration include evidence of arcing on the contactor moldings and insulation damage. Arc chutes must be in place and secured prior to operating contactor.
2. **Overload Relays:** a) Any indication of an arc striking or burning the overload relay may require replacement. b) Contact operation must be verified by electrically or mechanically tripping and resetting the relay even if there is no visual indication of damage that would require replacement.
3. **Fuses:** Always replace all three fuses even though only one or two are open circuited since internal damage suffered by fuses not replaced could result in nuisance shut down later.
NOTE: (For fuses mounted on pan sides only) To replace side-mounted fuses supplied with 30 and 60 amp fusible disconnects, a special fuse removal tool is provided. Re-

move the three fuses in sequence starting with the front (A phase) fuse. Pry out the bottom of the fuse by inserting the tool between the fuse barrel and the left hand unit side and moving the tool handle to the left. Then complete fuse removal by grasping the fuse and pulling it out of the upper clip. Repeat for the second and third fuses.

4. Perform the Pre-Energization Checks procedures detailed on Page 21 and 22 herein, before restoring the equipment to service.

Adjustment of Sentron™ Type ETI Instantaneous Trip Motor Circuit Interrupter (1A-125A)

ETI instantaneous trip motor circuit interrupters are supplied as standard with Size 1 through Size 3 motor starters. The motor circuit interrupter continuous current rating should not be less than 115% of motor full load current (MFLC). The MFLC is obtained from the motor nameplate or from Table 430-150 of the NEC (1987). Use the following procedure to adjust the instantaneous trip setting.



⚠ WARNING

Hazardous Voltage. Can cause death, serious personal injury or property damage.

Disconnect and lock-out all power and control voltage sources supplying the motor circuit interrupter before adjusting trip setting or performing any other maintenance operations.

1. Turn the operating handle to the "OFF" position and open the unit door.
2. Loosen the captive screw which secures the operator mechanism to the unit top brace and swing the operator out of the way, exposing the adjustment dial on the motor circuit interrupter.
3. The instantaneous setting is determined by multiplying MFLC by 13. Select the closest setting to (13 times MFLC) which does not exceed (13 times MFLC). The label on the face of the circuit breaker shows the continuous rating and adjustment points for the installed breaker.
4. Adjust the trip setting by rotating the adjustment dial to the position selected in step 3 above.
5. Making sure that both the motor circuit interrupter and the operator are in the "OFF" position, swing the operator back into position over the front of the interrupter. Be sure that the toggle on the interrupter engages the opening in the driver plate on the operator. Secure by tightening the captive screw.




Figure 29: Operator Hinge Open to Expose Adjustment on ETI Motor Circuit Interrupter

Maintenance

Adjustment of Circuit Breakers with Adjustable Instantaneous Trip (125A-1200A)

These circuit breakers are supplied with Size 4 and Size 5 motor starters. Use the following procedure to adjust the instantaneous trip setting:

1. Turn the operating handle to the "OFF" position and open the unit door.
2. If a linear operator is provided, remove the four screws which mount the operator to the two steel brackets on the face of the circuit breaker. Slip the operating handle assembly forward off the face of the circuit breaker. This exposes one adjustment dial per phase.
3. Select the required trip setting from the label on the operator for the particular circuit breaker based on 13 times MFLC as explained in adjustment Step 3 for the motor circuit interrupter.
4. Set all three adjustment dials to the trip setting selected in Step 3.
5. Re-install the operator handle assembly to the circuit breaker using the reverse procedure to the procedure explained in Step 2.

Field Testing of the Circuit Breakers

A test can be performed using the procedure outlined in the following discussion to verify that a circuit breaker trip mechanism is functioning.

1. Wire the three circuit breaker poles in series.
2. Connect the series combination of breaker poles to a variable low voltage high current power source.
3. Gradually increase the current from "0" until the circuit breaker trips. If the circuit breaker fails to trip when the test current reaches 150% of the largest trip setting, the trip unit is not functioning properly and the circuit breaker requires replacement.

Overload Relays

Overload Relay

For proper overload relay coordination, the cables on the load side of the overload relay should be sized in accordance with the tables in Article 310 of the National Electrical Code. The wire for motors with full load currents of 100 amperes or less may be selected from the 60° C or 75° C column. Select wire from the 75° C column when the motor current is greater than 100 amperes. When conditions dictate the use of cables larger than these, the relay tripping time may be affected. Another condition which may affect tripping is a long acceleration time such as that caused by a motor driving a high inertia load. If either of these conditions exists, consult Siemens for overload relay application instructions.

3UA Overload Relays

The 3UA three phase thermal overload relay is a NEMA Class 10, directly heated, front adjustable, ambient temperature compensating, bimetallic device. The relay is supplied with one normally closed contact (Form B) for opening the control circuit in case of thermal trip and one normally open contact (Form A) for wiring to an alarm or other device.

The relay for NEMA size 1 through size 4 starters mounts directly to the contactor. The relay for NEMA size 5, 6, and 7 starters is separately mounted and directly heated from the secondary of current transformers.

Single Phasing Protection - In addition to motor overload protection, the internal trip mechanism provides motor single phase protection. Referring to **Figure 30**, Curve 3 shows the normal three phase time-current tripping relationship. The relay senses a loss of phase condition and shifts the time-current tripping response curve to the left as shown by Curve 2. As a result of this curve shift and the higher single phase current, the tripping time of the overload relay will be reduced.

Manual or Automatic Reset - The 3UA overload relay is set for HAND reset operation when shipped from the factory. The relay may be set for AUTO operation by depressing and turning the blue reset button counterclockwise to the position marked "A" (see **Figure 31**).





Figure 30: 3UA Overload Relay Time-Current Tripping Curves



⚠ WARNING

Automatic Reset. Can cause death, serious personal injury or property damage.

Do not use automatic reset with two wire control or any other application where automatic reset restores power to the motor endangering either personnel or equipment.

3UA Overload Relay Selection and Adjustment - The 3UA overload relays for use in Siemens Motor Control Centers may be selected from **Tables 5, 6, 7, and 8**. The following information must be known before the selection can be made.

1. Starter size (NEMA size 1, 2, 3, 4, 5, 6 or 7).
2. Motor nameplate full load current (FLC).
3. Motor nameplate service factor and temperature rise.

Markings on the adjustment dial denote current in amperes. The dial should be set at the actual motor full load current marked on the motor nameplate (FLC), if the motor nameplate is marked with a service factor of not less than 1.15 or with a temperature rise not greater than 40° C. For all other motors, the dial setting should be .92 times FLC (see **Table 9**). Where these settings are not adequate to start the motor or carry the load, the National Electrical Code allows the setting of the 3UA overload to be increased 1.12 times FLC for motors marked with service factors not less than 1.15 or with a temperature rise not greater than 40° C; the setting for all other motors may be increased to 1.04 times FLC (see **Table 10**).

Procedure for Checking Nuisance Overload Tripping - The following steps need to be taken when the overload relay consistently trips with the motor running.

1. Make sure that all connections to the overload relay are tight. Check for and correct any phase unbalance of motor currents.
2. Verify the dial adjustment (see **Figure 31**). The setting should NOT be greater than the value shown in **Table 9**.




Figure 31: 3UA Overload Relay

Overload Relays

3. Verify that the proper overload relay has been selected per ACTUAL motor running current. See the overload relay selection tables. If the actual motor running current is larger than the motor nameplate marking, the motor is overloaded. For a motor with a service factor greater than 1.0, multiply the rated motor full load current by the service factor to determine if the motor is overloaded.
4. Adjust the overload dial to a higher setting until tripping ceases. This setting is not to exceed the value shown in **Table 10**.

Table 5

NEMA Starter Sizes 1, 2, 3 and 4			
Lead Sheet Designation	Relay Range	Catalog Number	Used with Contactor
3A0A	.10 - .16	3UA55 00 - 0A	3TF44 SIZE 1
3A0C	.16 - .25	3UA55 00 - 0C	
3A0E	.25 - .40	3UA55 00 - 0E	
3A0G	.40 - .63	3UA55 00 - 0G	
3A0J	.63 - 1.00	3UA55 00 - 0J	
3A0K	.80 - 1.25	3UA55 00 - 0K	
3A1A	1.00 - 1.60	3UA55 00 - 1A	
3A1B	1.25 - 2.00	3UA55 00 - 1B	
3A1C	1.60 - 2.50	3UA55 00 - 1C	
3A1D	2.00 - 3.20	3UA55 00 - 1D	
3A1E	2.50 - 4.00	3UA55 00 - 1E	
3A1F	3.20 - 5.00	3UA55 00 - 1F	
3A1G	4.00 - 6.30	3UA55 00 - 1G	
3A1H	5.00 - 8.00	3UA55 00 - 1H	
3A1J	6.30 - 10.0	3UA55 00 - 1J	
3A1K	8.00 - 12.5	3UA55 00 - 1K	
3A2A	10.0 - 16.0	3UA55 00 - 2A	
3A2B	12.5 - 20.0	3UA55 00 - 2B	
3A2C	16.0 - 25.0	3UA55 00 - 2C	3TF46 SIZE 2
3A2D	20.0 - 32.0	3UA55 00 - 2D	
3C2L	16 - 25	3UA58 00 - 2C	
3C2M	20 - 32	3UA58 00 - 2D	
3C2E	25 - 40	3UA58 00 - 2E	
3C2F	32 - 50	3UA58 00 - 2F	
3C2T	40 - 57	3UA58 00 - 2T	3TF48 SIZE 3
3C2P	50 - 63	3UA58 00 - 2P	
3C2V	57 - 70	3UA58 00 - 2V	
3C2U	63 - 80	3UA58 00 - 2U	
3C2H	55 - 80	3UA62 00 - 2H	3TF52 SIZE 4
3C2W	63 - 90	3UA62 00 - 2W	
3C2X	80 - 110	3UA62 00 - 2X	
3C3H	90 - 120	3UA62 00 - 3H	
3C3J	110 - 135	3UA62 00 - 3J	
3C3K	120 - 150	3UA62 00 - 3K	

5. The overload relay should be replaced if it still trips after Steps 1 through 4 have been completed. If the value in **Table 10** was not attainable with the replaced relay, the next higher trip range of the same frame size should be installed.

Field Testing - 3UA overload relays are subjected to 100% calibration testing at the factory. If tests are to be performed on an overload relay in the field, use the following procedure:

1. Connect 4 feet of wire to each field wiring terminal of the overload relay. The wire should be the smallest size having

Table 6

NEMA Starter Sizes 5 (With 300:5 Current Transformer)		
Lead Sheet Designation	Full Load Current of Motor (FLC)	Catalog Number
3B1A	60.0 - 96.0	3UA59 00 - 1A
3B1B	75.0 - 120.0	3UA59 00 - 1B
1B1C	96.0 - 150.0	3UA59 00 - 1C
3B1D	120.0 - 192.0	3UA59 00 - 1D
3B1E	150.0 - 240.0	3UA59 00 - 1E
3B1F	192.0 - 300.0	3UA59 00 - 1F

Table 7

NEMA Starter Sizes 6 (With 600:5 Current Transformer)		
Lead Sheet Designation	Full Load Current of Motor (FLC)	Catalog Number
3B1A	120.0 - 192.0	3UA59 00 - 1A
3B1B	150.0 - 240.0	3UA59 00 - 1B
1B1C	192.0 - 300.0	3UA59 00 - 1C
3B1D	240.0 - 384.0	3UA59 00 - 1D
3B1E	300.0 - 480.0	3UA59 00 - 1E
3B1F	384.0 - 600.0	3UA59 00 - 1F

Table 8

NEMA Starter Sizes 7 (With 1000:5 Current Transformer)		
Lead Sheet Designation	Full Load Current of Motor (FLC)	Catalog Number
3B1A	200.0 - 320.0	3UA59 00 - 1A
3B1B	250.0 - 400.0	3UA59 00 - 1B
1B1C	320.0 - 500.0	3UA59 00 - 1C
3B1D	400.0 - 640.0	3UA59 00 - 1D
3B1E	500.0 - 800.0	3UA59 00 - 1E
3B1F	640.0 - 1000.0	3UA59 00 - 1F

Overload Relays

an ampacity of at least 125% of the maximum current element rating. The maximum current element rating is equal to 125% of the maximum overload trip setting.

2. Connect the overload relay to a 3 phase variable current test power source. If a 3 phase test source is not available, wire the three overload phases in series and use a single phase test power source.
3. The overload relay must be tested at an ambient temperature between -20° C and 55° C (-5° F to 131° F).
4. Energize the relay with test current between 125% and 1000% of the overload relay trip setting and measure the time to trip. The test trip time should be approximately equal to the average tripping time shown on curve 3 in **Figure 30**.
5. A short cooldown time must be allowed before the overload relay can be reset and further tests performed.
6. The overload relay may be tested with single phase test current applied to individual poles. In this case, test tripping time should be approximately equal to the average tripping time shown on curve 2 in **Figure 30**.
7. A test push-button is provided on each overload relay. Depressing this push-button (red in color) causes the overload relay contacts to change state, the extra N. O. alarm contact will close.

Table 9

Maximum Settings of Overload Relays	
	Maximum Setting Multiply Motor FLC by:
Motor service factor equal to or greater than 1.15	1.00
Motor temperature rise less than or equal to 40° C.	1.00
All other motors	0.92

Table 10

Maximum Settings of Overload Relays	
When the Values Indicated in Table 9 are Insufficient to Start	
	Maximum Setting Multiply Motor FLC by:
Motor service factor equal to or greater than 1.15	1.12
Motor temperature rise less than or equal to 40° C.	1.12
All other motors	1.04

SA Overload Relays

The SA single or three phase thermal overload relay is a NEMA Class 20 bimetal, ambient compensated device. Heater elements are interchangeable from the front. The bimetal elements are operated by calibrated heaters. Upon a substantial level of abnormal current flow the deflection becomes great enough to open a snap-action output contact. The relay features a test trip device for weld check. Trip indication is on the front of the relay. The SA overload relay always requires manual reset.

SA Overload Heater Selection - The overload heaters may be selected from **Tables 11, 12 and 13**. Heaters should be selected on the basis of the actual full load current and service factor as shown on the motor nameplate or in the manufacturer's published literature. When the service factor of the motor is 1.15 and 1.25, select heaters from the heater application table. If the service factor of the motor is 1.0, or there is no service factor shown, or a maximum of 115% protection is desired, select one size smaller heater than indicated.

Warning: TO PROVIDE CONTINUED PROTECTION AGAINST FIRE AND SHOCK HAZARD, THE COMPLETE OVERLOAD RELAY MUST BE REPLACED IF BURNOUT OF THE CURRENT ELEMENT OCCURS.

Procedure for Checking Nuisance Overload Tripping - The following steps need to be taken when the overload relay consistently trips with the motor running:

1. Make sure all connections to the overload and heaters are tight. Check for and correct any phase unbalance of motor current.
2. Verify that the proper heater elements are installed.
3. Replace all three heater elements with new ones.
4. Measure ACTUAL motor current, then refer to **Tables 11, 12 and 13** to insure that the proper overload relay heaters are installed.
5. Finally, replace the relay if steps 1 through 4 do not solve nuisance tripping problem.

Overload Relays

Table 11

For Ambient Compensated Overload Relays Size 1 and 2 Starters			
Starter Size	FLC of Motor 40° C ° C Amb		Heater Catalog Number ^①
	Block Type Overload Using 3 Heaters	Single Pole Type Overload	
Size 1	.25 - .27	.29 - .31	SFH03
	.28 - .31	.32 - .35	SFH04
	.32 - .34	.36 - .39	SFH05
	.35 - .38	.40 - .43	SFH06
	.39 - .42	.44 - .48	SFH07
	.43 - .46	.49 - .53	SFH08
	.47 - .50	.54 - .58	SFH09
	.51 - .55	.59 - .64	SFH10
	.56 - .62	.65 - .71	SFH11
	.63 - .68	.72 - .79	SFH12
	.69 - .75	.80 - .87	SFH13
	.76 - .83	.88 - .96	SFH14
	.84 - .91	.97 - 1.06	SFH15
	.92 - 1.00	1.07 - 1.16	SFH16
	1.01 - 1.11	1.17 - 1.28	SFH17
	1.12 - 1.22	1.29 - 1.41	SFH18
	1.23 - 1.34	1.42 - 1.55	SFH19
	1.35 - 1.47	1.56 - 1.71	SFH20
	1.48 - 1.62	1.72 - 1.87	SFH21
	1.63 - 1.78	1.88 - 2.06	SFH22
Size 2	1.79 - 1.95	2.07 - 2.26	SFH23
	1.96 - 2.15	2.27 - 2.48	SFH24
	2.16 - 2.35	2.49 - 2.72	SFH25
	2.36 - 2.58	2.73 - 2.99	SFH26
	2.59 - 2.83	3.00 - 3.28	SFH27
	2.84 - 3.11	3.29 - 3.60	SFH28
	3.12 - 3.42	3.61 - 3.95	SFH29
	3.43 - 3.73	3.96 - 4.31	SFH30
	3.74 - 4.07	4.32 - 4.71	SFH31
	4.08 - 4.39	4.72 - 5.14	SFH32
	4.40 - 4.87	5.15 - 5.6	SFH33
	4.88 - 5.3	5.7 - 6.2	SFH34
	5.4 - 5.9	6.3 - 6.8	SFH35
	6.0 - 6.4	6.9 - 7.5	SFH36
	6.5 - 7.1	7.6 - 8.2	SFH37
	7.2 - 7.8	8.3 - 9.0	SFH38
	7.9 - 8.5	9.1 - 9.9	SFH39
	8.6 - 9.4	10.0 - 10.8	SFH40
	9.5 - 10.3	10.9 - 11.9	SFH41
	10.4 - 11.3	12.0 - 13.1	SFH42
	11.4 - 12.4	13.2 - 14.3	SFH43
	12.5 - 13.5	14.4 - 15.7	SFH44
	13.6 - 14.9	15.8 - 17.2	SFH45
	15.0 - 16.3	17.3 - 18.9	SFH46
	16.4 - 18.0	19.0 - 20.8	SFH47
	18.1 - 19.8	20.9 - 22.9	SFH48
	19.9 - 21.7	23.0 - 25.2	SFH49
	21.8 - 23.9	25.3 - 27.6	SFH50
	24.0 - 26.2	27.7 - 30.3	SFH51
	26.3 - 28.7	30.4 - 33.3	SFH52
	28.8 - 31.4	33.4 - 36.4	SFH53
	31.5 - 34.5	36.5 - 39.9	SFH54
	34.6 - 37.9	40.0 - 43.9	SFH55
	38.0 - 41.5		SFH56
	41.6 - 45.0		SFH57

① "S" may be omitted from heater catalog number.

Table 12

For Ambient Compensated Overload Relays Size 3 and 4 Starters		
Starter Size	FLC of Motor 40° C ° C Amb	Heater Catalog Number ^①
Size 3	19.0 - 20.8	SFH72
	20.9 - 22.9	SFH73
	23.0 - 25.2	SFH74
	25.3 - 27.8	SFH75
	27.9 - 30.6	SFH76
	30.7 - 33.5	SFH77
	33.6 - 37.5	SFH78
	37.6 - 41.5	SFH79
	41.6 - 46.3	SFH80
	46.4 - 50	SFH81
	51 - 55	SFH82
	56 - 61	SFH83
	62 - 66	SFH84
	67 - 73	SFH85
	74 - 78	SFH86
Size 4	79 - 84	SFH87
	85 - 92	SFH88
	93 - 101	SFH89
	102 - 110	SFH90
	111 - 122	SFH91
	123 - 129	SFH92
	130 - 133	SFH93
	...	SFH94

① "S" may be omitted from heater catalog number.

Table 13

For Ambient Compensated Overload Relays Size 5, 6 and 7 Starters	
FLC of Motor 40° C ° C Amb	Heater Catalog Number ^①
Size 5 (With 300:5 Current Transformers)	
...	SFH23
118 - 129	SFH24
130 - 141	SFH25
142 - 155	SFH26
156 - 170	SFH27
171 - 187	SFH28
188 - 205	SFH29
206 - 224	SFH30
225 - 244	SFH31
245 - 263	SFH32
264 - 292	SFH33
Size 6 (With 600:5 Current Transformers)	
...	SFH23
236 - 259	SFH24
260 - 283	SFH25
284 - 310	SFH26
311 - 340	SFH27
341 - 374	SFH28
375 - 411	SFH29
412 - 448	SFH30
449 - 489	SFH31
490 - 527	SFH32
528 - 540	SFH33
Size 7 (With 1000:5 Current Transformers)	
432 - 470	SFH25
471 - 516	SFH26
517 - 566	SFH27
567 - 622	SFH28
623 - 684	SFH29
685 - 746	SFH30
747 - 814	SFH31

① "S" may be omitted from heater catalog number.

3SB0 Pilot Devices

Pilot Device Options

The 3SB0 pilot devices are available in two basic forms, completely assembled for the most frequently used configurations, or subassemblies for greater flexibility.

Application

The 3SB0 pilot devices are of the heavy duty oiltight, watertight and dust-tight (NEMA Type 4, 4X, 13, IP65) design. They are used in industrial control applications where control circuits are 600V or less. The 3SB0 pilot devices are available in two mounting diameters. 22mm and 30mm.

Design

22mm Mounting - The actuator is inserted into the hole in the panel from the front and secured to the contact block holder. The unit is then fixed from behind by means of two set screws which are located in the contact block holder. This method prevents the unit from working loose or twisting.

30mm Mounting - The holder is an integral part of the actuator. It is inserted into the hole in the panel from the rear and secured from the front by means of a locking ring. With the use of a legend plate or the thrust and trim washers, the unit becomes stationary and will not twist or work loose.

Front Rings

The 22mm and 30mm units are supplied as standard with metal chrome plated front rings. Black plastic or anodized aluminum rings are optional at no additional cost. The plastic rings are recommended for use where the atmosphere may be corrosive.

Indicator Lights Using LED's

LED's have a definite advantage over incandescent lamps. LED's are a current device, incandescent lamps are power devices, therefore the power consumption of LED's is much lower. The life span for LED's is generally 10 to 20 times longer than that of incandescent lamps and they provide a greater resistance to shock and vibration. This makes the LED indicator light ideal where lamp integrity and low maintenance is crucial.

Contact Blocks

The 3SB0 contact blocks incorporate parallel double-break contact. This insures a high degree of reliability and therefore makes them suitable for use with solid state control equipment. The terminals are clearly marked to simplify wiring. The snap on type contact blocks, along with wire funnels, screwdriver guide holes and open captive spring steel washers permit a time saving installation. The contact block holder is available as a 3 or 5 unit holder. If a 5 unit holder is required, the fifth digit of the catalog number can be changed to reflect this.

Technical Data						
Ⓢ and Ⓢ ratings Rated voltage for 1 NO + 1 NC, 2 NO, 2 NC for 1 NC or 1 NO Lamp holder Voltage reducer Lamp holder with 60 Hz transformer	AC 600 V max., above AC 300 V same polarity AC 600 V max. for lamps with a BA 9s base, max. 125 V; 2.5 W for max. AC 240 V 120, 480, 575 V / 6 V, 60 Hz, 1 VA					
	10 A 10 A, heavy duty					
Insulation rating U for 1 NO + 1 NC, 2 NO, 2 NC (screw terminals) for 1 NO or 1 NC (screw terminals) for 1 NO + 1 NC (plug-in terminal) for 1 NO or 1 NC (plug-in terminal) for BA 9s lamp holder	AC 660 V, DC 800 V AC 660 V, DC 800 V AC 380 V, DC 440 V AC 380 V, DC 440 V 250 V; 2.5 W					
	VDE 0110, Group C all contact blocks with: screw terminals, AC 660 V plug-in terminals, AC 380 V					
Continuous current, rated operational currents switching capacity	AC 40 to 60 Hz I / AC-1 A					
	10	U AC V	I / AC-1 A	DC U, DC V	I / DC-1 A	I / DC-11 A
Short-circuit protection Ⓢ DIAZED fuse links Miniature circuit-breaker with G characteristic	10 A TDz, 16 A Dz 10 A					
Mechanical endurance pushbutton units illuminated pushbutton units rotary and latching actuators	10 million make-break operations 3 million make-break operations 300 thousand make-break operations					
	10 million make-break operations with 3TH8, 3TB40 to 3TB44 contactors 1000 make-break operations per hour					
Contact endurance Frequency of operation Ambient temperature range	-25 to +60°C -25 to +40°C (housing fitted with indicator lights or illuminated pushbutton units with incandescent lamps)					
	(2) #4-12 AWG (2) 1 to 2.5 mm ² , 1 X 4 mm ²					
Conductor sizes Mounting position Terminal marking	any according to DIN EN 50 013 identification number on the holder, function number on the contact block					
	Marking tag					
Device designation Lamp holder	Clip-on for illuminated pushbutton units or indicator lights for BA 9s lamps (10 mm X 28 mm bulb)					
	6, 12, 24, 42, and 60 V; 2 W 120 V; 2.5 W for operating voltages between 220 and 240 V, use a 130 V incandescent lamp with a voltage reducer					
Incandescent lamp Glow lamp LED	AC 110V AC 6V AC/DC 24					
	Safety requirements are met automatically when the actuators and lens assemblies are mounted on metal front plates. When mounted in insulated housings, the "protective insulation" safety requirement is met. Metal enclosures can be made to meet these requirements when the earthing terminal inside the housing is used.					
Safety measures						
Actuating force	Number of contact blocks					
	0	1	2	3		
Pushbutton unit	NC opens	4.5 N	6.5 N	8.5 N		
	NO closes	6.0 N	9.5 N	13.0 N		
Latching mushroom pushbutton unit for EMERGENCY STOP	10 N	14.0 N	18.0 N	22.0 N		

3TF Contactor

Description

Design

3TF contactors are designed to handle loads up to 400 HP, 480 V. Contactors designed to meet NEMA, UL max. hp, and IEC ratings for maximum flexibility and worldwide applications. 3TF contactors meet or exceed the requirements of NEMA, EEMAC, UL, CSA, IEC and VDE.

Inrush capacity of 8.4 times rated FLC insures troublefree starting of high efficiency motors. Advanced materials and design maximize electrical and mechanical life.

Maximum Electrical and Mechanical Life

Contactors through 3TF50 have touch safe power and control terminals Sigut® or FAST terminals (Fast Accessible Safe Terminations) incorporate screwdrive guide holes, wire funnels, wire stops and captive hardware to speed wiring. All terminals are supplied with the terminals open ready for wire to speed installation.

Auxiliary contacts are double bridge type for maximum reliability and suitable for interface with electronic circuits. Auxiliary contacts install easily snapping to the sides of 3TF4 and 3TF5 contactors.

Technical Data

Contactor	NEMA Size Type		00 3TF40	3TF41	0 3TF42	3TF43	1 3TF44	3TF45
Mechanical life	make/break operations	Mil	15		15		10	
Insulation rating		V	690					
Ambient temperature range		°C	-25 to +55 in operation, -50 to +80 when stores					
Coil ratings (cold coil 1.0 x U _s)		Hz	50	60			50	60
AC operation	Inrush	VA	68	75			87	115
	p.f.		0.82	0.76			0.82	0.75
	Sealed	VA	10	9.4			13	13
	p.f.		0.29	0.29			0.27	0.27
DC operation	Inrush = Sealed	W	6.5				-	
Coil voltage range:	AC at DC 24V		0.8 to 1.1 x U _s 0.8 to 1.2 x U _s				0.8 top 1.1 x U _s -	
Operating times ① (Valid for 20% undervoltage to 10% overvoltage cold or warm coil)			(Values are applicable up to and including 20% undervoltage, 10% overvoltage as well as with the coil in cold state and operating temperature)					
AC operation	closing delay	ms	8- 35		10- 35		13-57	
	opening delay	ms	4- 18		5- 20		5-10	
DC operation	closing delay	ms	20-170		35-180		-	
	opening delay	ms	10- 25		10- 25		-	
Operating times (at 1.0 x U _s ³)								
AC operation	closing delay	ms	10- 35		10- 25		13-32	
	opening delay	ms	4- 18		5- 20		5-10	
DC operation	closing delay	ms	30- 70		40- 80		-	
	opening delay	ms	12- 20		10- 20		-	
Resistance to shock (rectangular pulse)	AC	g/ms	7.7/5	4.4/10	5.5/5	3.2/10	5.7/5; 9.5	3.3/10; 5.2/10
Conductor sizes								
For contactors without overload relay								
main conductor: solid or stranded			AWG	(2) 18-12	(2) 18-12	(2) 14-10	(2) 14-10	max. 6
auxiliary conductor: solid or stranded			AWG	(2) 18-12	(2) 18-12	(2) 18-12	(2) 18-12	(2) 18-12
Switching frequency in make/break operations/hr								
Contactors without overload relay								
	to AC-1	ops./h	1500		1500		1200	1200
	to AC-2	ops./h	1000		750		750	600
	to AC-3	ops./h	1000		750		750	600
	to AC-4	ops./h	250		250		250	200
Contactor with overload relay (avg. value)			1/h	15	15		15	15
Auxiliary contacts								
Ⓛ, Ⓜ and Ⓢ ratings for auxiliary contacts								
3TF40 thru 3TF68	Rated voltage switching capacity	AC 600 V max. NEMA A600 Make Break	A A	24V	120V	240V	480V	600V
				60 6	60 6	30 3	15 1.5	12 1.2
		DC 600 V max. NEMA P600 Make Break	A A	24V	150V	250V	300V	600V
				1.1 1.1	1.1 1.1	.55 .55	.20 .20	.20 .20

① The opening delay can increase if the coils have voltage spike protection. Diodes may only be attached to contactors up to 3TF44.

3TF Contactor

Technical Data

Contactor	NEMA Size Type		2 3TF46	3TF47	3 3TF48	3TF49	3TF50	3TF51	4 3TF52	3TF53
Mechanical life	make/break operations	Mil	10	10	10	10	10	10	10	10
Insulation rating		V	1000	1000	1000	1000	1000	1000	1000	1000
Ambient temperature range		°C	-25 to +55 in operation		-50 to +80 when stored					
Coil ratings (cold coil, 1.0 x U _c)		Hz	50	60	50	60	50	60	50	60
AC operation	Inrush	VA	183	185	345	360	550	570	1015	1005
	p.f.		0.6	0.54	0.5	0.4	0.45	0.4	0.38	0.31
	Sealed	VA	17	15	35	31	39	35	71	62
	p.f.		0.29	0.29	0.23	0.24	0.24	0.25	0.26	0.28
Coil voltage range	AC		0.85 to 1.1 x U _s							
Operating times (valid for 20% undervoltage to 10% overvoltage, cold or warm coil) Total break time = opening delay + arcing time										
AC operation	closing delay	ms	15–40		20–50		20–50		20–50	
	opening delay ①	ms	5–25		5–30		8–30		10–30	
	arcing time	ms	10–15		10–15		10–15		10–15	
Operating times at 1 x U _s										
AC operation	closing delay	ms	17–30		22–35		22–37		25–40	
	opening delay ①	ms	5–25		5–30		8–30		10–30	
Resistance to shock (rectangular pulse)		g/ms	9.2/5	5.4/10	8.6/5	4.8/10	9.4/5 and 5.2/10		10.4/5 and 5.8/10	
Conductor sizes										
For contactors without overload relay										
main conductor: solid or stranded		AWG	max. 1/0		max. 1/0		max. 2/0		1/0 to 250 mcm	
auxiliary conductor: solid or stranded		AWG	2 x (18 to 12)		2 x (18 to 12)		2 x (18 to 12)		2 x (18 to 12)	
Switching frequency in make/break operations per hour (1/h)										
Contactors without overload relay										
	duty AC-1	1/h	1000	1000	900	900	800	800	800	750
	duty AC-2	1/h	600	400	400	350	400	300	300	250
	duty AC-3	1/h	1200	1000	1000	850	1000	750	700	500
	duty AC-4	1/h	400	300	300	250	500	200	200	130
Contactors with overload relay (average value)		1/h	15	15	15	15	15	15	15	15

Technical Data

Contactor	NEMA Size Type		3TF54	3TF55	5 3TF56	3TF57	6 3TF68
Mechanical life	make/break operations	Mil	10	10	10	10	10
Insulation rating		V	1000	1000	1000	1000	1000
Ambient temperature range		°C	-25 to +55 in operation -50 to +80 when stored				
Coil ratings (cold coil, 1.0 x U _c)		Hz	50	60	50 60	50 60	50 60
AC operation	Inrush	VA	1690	1590	2450 2760	— —	— —
	p.f.		0.34	0.26	0.21 0.18	— —	— —
	Sealed	VA	101	94	115 132	— —	— —
	p.f.		0.24	0.27	0.33 0.33	— —	— —
Coil voltage range	AC		0.85 to 1.1 x U _s				
Operating times (valid for 20% undervoltage to 10% overvoltage, cold or warm coil) Total break time = opening delay + arcing time							
AC operation	closing delay	ms	20–50		17–65	40–110	135–315
	opening delay ①	ms	10–30		8–20	70–110	8–20
	arcing time	ms	10–15		10–15	15–25	10–15
Operating times at 1 x U _s							
AC operation	closing delay	ms	25–40		25–40	48–70	100–200
	opening delay ①	ms	10–30		8–20	80–100	8–20
Resistance to shock (rectangular pulse)		g/ms	9.9/5 and 5.3/10		8.8/5 and 4.9/10	8.5/5 and 4.7/10	6.7/5 and 3.6/10
Conductor sizes							
For contactors without overload relay							
main conductor: solid or stranded		AWG	2/0 to 500 mcm		2/0 to 500 mcm	2/0 to 500 mcm	2/0 to 500 mcm
auxiliary conductor: solid or stranded		AWG	2 x (18 to 12)		2 x (18 to 12)	2 x (18 to 12)	2 x (18 to 12)
Switching frequency in make/break operations per hour (1/h)							
Contactors without overload relay							
	duty AC-1	1/h	800	750	700	500	700
	duty AC-2	1/h	300	250	200	170	200
	duty AC-3	1/h	700	500	500	420	500
	duty AC-4	1/h	200	130	150	150	150
Contactors with overload relay (average value)		1/h	15	15	15	15	15

① Values in parentheses are obtained when an internal control wire is cut.

3TF Contactor

Contactor Selection – Life Curves

Specifications

3TF contactors meet or exceed the requirements of NEMA, EEMAC, UL, CSA, IEC, VDE and other international standards.

Contact Life

The graph depicts the expected contact life of 3TF contactors as a function of the breaking current in AC applications. For normal applications the contactor interrupts the motor full load current (FLA). In plugging and jogging applications the contactor interrupts the Locked rotor current (LRA). If the LRA is not known assume 6 times the marked FLA.


To obtain the contactor's approximate electrical contact life, determine breaking current and find value on the horizontal axis. Move upward and locate intersection with black line of appropriate contactor. Read expected life on left or right side of graph.

The lines apply to standard 480V motors when interrupting FLA. If mixed applications are involved, such as normal switching (breaking FLA) with intermittent jogging/plugging (breaking LRA), the contact life can be calculated with the following formula:

$$X = \frac{A}{1 + \frac{C}{100} \left(\frac{A}{B} - 1 \right)}$$

Legend

- X Contact life for mixed applications
- A Contact life from chart for normal applications – breaking FLA
- B Contact life from chart for plugging/jogging application – breaking LRA
- C Percentage of plugging/jogging operation to total operation
- HP Rated output of motor



Troubleshooting

In the unlikely event that operating problems are encountered, use the following troubleshooting chart to isolate the cause of the problem and find the remedy. If the corrective action given in the chart fails to correct the difficulty, consult your field sales representative.

The following information is required if it is necessary to write Siemens relative to the equipment problem.

1. Manufacturer's order number and part number, if available.
2. Nameplate data on contactor or controller.

3. Duty cycle and any details of operation.
4. Length of time in service and approximate total number of operations.
5. Voltage, current and frequency.
6. Description of any problem.
7. Any other pertinent information, such as drawing, layout and schematic number.

Problem	Probable Causes	Corrective Action
Doors will not close or are out of alignment.	Enclosure is not bolted down tightly on perfectly level surface.	Using level, add shims as necessary and tighten anchoring bolts.
	Enclosure sprung out of shape.	Straighten or repair cubicle.
	Door hinges not properly adjusted.	Remove door hinges. Add or subtract shims as necessary.
Contactor will not close.	Control circuit or power fuse blown or circuit breaker tripped.	Inspect fuses, replace if blown. Reset circuit breaker.
	Incoming power line not energized.	Close feeder circuit breakers or tie switch.
	Magnet coil defective.	Check magnet operation, replace coil as necessary.
	*Master relay (MR) defective.	Check and replace if defective.
	Control power transformer defective.	Check and replace if necessary.
	Overload relay tripped or defective.	Check and replace if necessary.
	Missing jumpers, loose connections, remote connections, etc.	Check wiring diagram carefully to make sure that all external or alternate connections have been made satisfactorily. This is especially true where remote protective or control devices are used.
Contactor chatter or hum.	Loose connection in control circuit.	Tighten connections in control circuit.
	*Defective master relay.	Check relay, replace if necessary.
	Defective coil.	Check main coil, replace if necessary.
	Low control voltage.	Check line voltage.
	Corroded or dirty magnet pole faces.	Clean or replace magnet assembly.
Contacts overheating.	Loose connections.	Tighten connections.
	Contacts not mating firmly.	Check for weak or deformed contact spring, replace if necessary.
	Dirt or foreign matter on contact surface.	Clean contacts.
	Contact tip eroded.	Replace contacts.

*Not supplied on all starters.

Troubleshooting

Problem	Probable Causes	Corrective Action
Overload relays trip during starting or soon after motor is up to speed.	<p>Motor overloaded.</p> <p>Motor being started too frequently at close intervals.</p> <p>Excessive motor acceleration time.</p>	<p>Limit starting load and running load to motor capabilities.</p> <p>Jogging and starting operations must be limited to capabilities of the motor and control. Check starting limitations in motor instruction manual before repeated starts.</p> <p>The starting of high inertia loads may not permit the use of standard overload relay application. Where accelerating time approaches 12 seconds or more, special overload relay bypass devices and circuits would usually be required. Contact Siemens regarding such problems and supply complete data on locked-rotor starting current and total accelerating time under maximum load conditions.</p>
Overload relay trips during motor operation.	<p>Low line voltage.</p> <p>Motor being overloaded.</p> <p>Overload relay not adjusted to motor capabilities or sized properly.</p>	<p>Line voltage should be maintained between +10% of motor nameplate voltage.</p> <p>Reduce load or correct conditions causing overload.</p>
Overload relay fails to trip on overload current.	<p>Incorrect relay/heater selection.</p> <p>Relay tripping mechanism jammed.</p> <p>Incorrect relay or relay set incorrectly.</p> <p>*Current transformers with improper ratio or with short-circuited secondary terminals.</p>	<p>Adjust relay setting in accordance with instructions for the overload relay. Adjustment should correspond to thermal rating of the motor, including temperature rise, duty and service factor. Replace overload if not sized properly.</p> <p>Select relay/heater in accordance with instructions for overload relays. Replace if necessary.</p> <p>Replace relay.</p> <p>Check relay selection and adjustment per overload relay instructions.</p> <p>Current transformers must have a step-down ratio to correspond to full load motor current and relay selection. Protective jumpers may be provided at current transformer secondary terminals or on terminal block connections to guard against open transformer secondary circuit, and jumpers must be removed before placing equipment in operation.</p>
Blowing of motor power fuses.	<p>Short circuit on the load side of the motor fuses.</p>	<p>Use megger and other test instruments to locate fault and correct.</p>

*Not supplied on all starters.

Troubleshooting

Problem	Probable Causes	Corrective Action
Blowing of motor power fuses. (<i>cont.</i>)	Jogging or too frequent starting.	On frequent starting, fuses accumulate abnormal heat and cool more slowly than do overload relays. Since fuses more closely follow cooling and heating of motor windings, successive starting operations must be limited to the safe capacity of the motor to prevent fuse blowing from this cause. Check size rating on fuse against motor full load currents and service factor.
	Fuses internally damaged because of improper handling.	Motor power fuses may be damaged, dropped or roughly handled. Replace with fuse of same type, rating and voltage.
Blowing of primary control transformer fuses.	Shorted primary winding in control transformer.	Replace or repair transformer.
	Fuse may be "open" due to rough handling before installing.	Replace with fuse of same type, rating, and voltage.
	Secondary fuses not properly coordinated.	Melting characteristics of secondary fuse should not intersect melting characteristic of primary fuse. Rating of standard NEC fuse should not exceed twice the secondary current rating.
Blowing of secondary control transformer fuses.	Abnormal current or short circuit in control.	Check for faulty operation of long wipe economizing contacts, if supplied, shorted magnet coils, shorted rectifiers, if supplied, grounds, loose or bent connections, mechanical binding in relay and contactor mechanisms, excessive operations and incorrect secondary terminal connections.



SIEMENS

Siemens Energy
& Automation, Inc.
Electrical Apparatus
Division
P.O. Box 29503
Raleigh, NC 27626-0503

