

Instructions for A202 60, 100 or 200 Ampere 2, 3, 4 or 5 Pole Lighting Contactor

I.L. 16966

Model J




Fig. 1 60 and 100 Ampere Lighting Contactors

THE CONTACTOR

The A202 lighting contactors when wired as shown in Figure 6 will control tungsten, fluorescent or metal vapor lamp loads. The contactor and its associated load should be protected against short circuits by a suitable branch circuit protective device selected in accordance with the National Electrical Code (NEC).

CONTACTOR RATINGS	
Current Ratings	
Contactor Size	Continuous Current Per Pole, Enclosed
60 Ampere	60A
100 Ampere	100A
200 Ampere	200A
Voltage Ratings	
Incandescent Lamp Control	
Maximum, Line-to-Line	480VAC
Maximum, Line-to-Neutral	277VAC
Electric-Discharge Lamp Control	600VAC
General Use Switch	600VAC




Fig. 2 Dimension Drawing, 60 Ampere




Fig. 3 Dimension Drawing, 100 & 200 Ampere

This industrial type control is designed to be installed, operated, and maintained by adequately trained workmen. These instructions do not cover all details, variations, or combinations of the equipment, its storage, delivery, installation, check out, safe operation, or maintenance. Care must be exercised to comply with local, state, and national regulations, as well as safety practices, for this class of equipment.

A202, 60, 100, OR 200 AMPERE CONTACTOR

I.L. 16966

COIL

A202 lighting contactors are available with a single or dual voltage coil. When equipped with a single voltage coil, the contactor is wired as shown in Figure 6. A connection diagram for a dual voltage coil is shown in Figure 4. When supplied with a dual voltage coil, the motor controller is normally wired for the high voltage connection. The wiring may be changed to the low voltage connection by removing and reconnecting the jumpers as illustrated below.




Fig. 4 Dual Voltage Coil Connections

REPLACEMENT COIL: ORDER BY PART NUMBER, VOLTAGE, AND FREQUENCY

AC OPERATING COILS FOR 60 AMPERE CONTACTORS

Voltage	Freq.	Part Number	
		2, 3 Pole	4, 5 Pole
24	60	505C806G16	Not Available
120/110	60/50	505C806G01	505C818G01
208	60	505C806G02	505C818G02
240	60	505C806G12	505C818G12
277	60	505C806G18	505C818G16
380	50	505C806G07	505C818G07
480/440	60/50	505C806G13	505C818G13
600	60	505C806G05	505C818G09
120/240*	60/60	505C806G10	505C818G10
240/480*	60/60	505C806G03	505C818G03

*Dual Voltage Coil. Use only on contactors originally supplied with a dual voltage coil.

AC OPERATING COILS FOR 100 AND 200 AMPERE CONTACTORS

Voltage	Freq.	Part Number	
		2-3 Pole	4-5 Pole
24	60	505C633G34	Not Available
120/110	60/50	505C633G01	505C635G01
208	60	505C633G02	505C635G02
240	60	505C633G12	505C635G12
277	60	505C633G14	505C635G15
380	50	505C633G07	505C635G07
480/440	60/50	505C633G13	505C635G13
600	60	505C633G05	505C635G05
120/240*	60/60	505C633G10	505C635G10
240/480*	60/60	505C633G03	505C635G03

*Dual Voltage Coil. Use only on contactors originally supplied with a dual voltage coil.

AC COIL DATA — TYPICAL VALUES

Contactor	Poles	Inrush VA	Sealed VA	Sealed Watts
60A	2-3	160	25	7.8
60A	4-5	200	30	9.5
100A	2-3	625	50	18
100A	4-5	825	75	28
200A	2-3	625	50	18
200A	4-5	825	75	28

OPERATING TIME IN MILLISECONDS (TYPICAL)

Contactor	Pickup	Dropout
60A	14—32	12—16
100A	33—41	12—16
200A	33—41	12—16

POWER CIRCUIT TERMINALS

Wire with copper conductors only unless terminals are marked as suitable for aluminum conductors.

Range of Conductor Sizes

Contactor Rating	CU Only Terminals	CU/AL Terminals
60A	#10 - 3 AWG	#14-4 AWG
100A	#8 - 2/0 AWG	#0-0000 AWG
200A	#6 - 4/0 AWG	#4-300 MCM

AUXILIARY CONTACTS — L56 (RATED B600)

A maximum of four auxiliary units can be installed in the recesses of each contactor. These may be mounted with the terminals in line with the power poles or may be mounted with the terminals in a right angle relationship to the power poles. They mount by means of a spring clip which snaps into locations provided in the contactor. To remove the L56 disengage the top spring clip, by pressing on the extended tab, and withdraw the unit.

L56 AUXILIARY CONTACTS

Contact Type	Catalog No.
1 Normally Closed	L56E
1 Normally Open	L56D
2 Normally Closed	L56C
2 Normally Open	L56B
1 Normally Open and 1 Normally Closed	L56

L56 CONTACT RATINGS (B600)

AC Volts	Make	Break
24-120	30A	3A
120-600	3600VA	360VA

TABLE I — ACCESSORIES

Fuse Block Kits — Meet requirements of NEC concerning common control fusing.


Order Cat. No.	Qty.	Description
F56	2	Contactor mounted Fuse Holder for 1 600 volt Bussman KTK Fuse
FKR	1	Panel mounted Fuse Holder for 2 Class CC (Bussman KTKR) Fuses*

*Use when available fault current exceeds 10,000 amperes.

Order Fuses Separately By Ampere Rating.


Contactor Size	Minimum Wire Size in Control Circuit	Suggested Fuse Size†
60, 100, 200	#16 AWG	10 AMP

† - When using a control transformer, select fuse size per the National Electrical Code.


Fig. 5 Control Station Connection Diagram
REPLACEMENT CONTACT KITS

Contactor Rating and Pole Combination	Part Number
60 Amp 2 Pole	373B331G11
60 Amp 3 Pole	373B331G12
60 Amp 4 Pole	373B331G13
100 Amp 2 Pole	373B331G20
100 Amp 3 Pole	373B331G21
100 Amp 4 Pole	373B331G22
200 Amp 2 Pole	672B788G06
200 Amp 3 Pole	672B788G07
200 Amp 4 Pole	672B788G08

For each 5 pole device order one 2 pole kit and one 3 pole kit.


Fig. 6 Connection Diagram
TABLE II — RECOMMENDED DRIVING TORQUE

Location (Qty.)	Driving Torque (lb.-in.)	Fig. 7 Item
60 Ampere Contactors		
Cover Screw (2)	9— 12	7
Coil Wire Connector (2)	9— 12	13
Stationary Contact Screw (2/pole)	14— 16	11
Main Power Connector (2/pole)	40— 50	4
100 and 200A Contactors		
Cover Screw (2)	18— 21	7
Coil Wire Connector (2)	9— 12	13
Stationary Contact Screw (2/pole)	25— 30	11
Main Power Connector (2/pole)	75—100	4




Fig. 7 200 Ampere, A202 Contactor (Exploded View)

MAINTENANCE — First Turn Off Power

To Inspect Contacts

Refer to Figure 7. Loosen the two arc box assembly screws (7) located immediately above and below the nameplate and remove the arc box (8). Contacts (5) are visible. Retighten the screws per Table II.

To Replace Contacts

After removing the arc box and with replacement contacts at hand, compress the overtravel spring (12) and remove the moving contact (5) from the crossbar (6). Remove the retaining screws (11) and lift out the stationary contact carriers (14).

To replace contacts, reverse the above procedure, making sure that stationary contacts are secure, (see Table II) moving contacts are free to move, overtravel springs are seated and the crossbar moves freely when the arc box is in position.

The silver cadmium oxide contact buttons need **NO** dressing or lubricant throughout their life.

Important — Replace all contacts and springs as a group to avoid misalignment.

To Replace The Coil

Refer to Figure 7. Loosen the assembly screws (10) located to the immediate left and right of the arc box. Pull the loosened upper base structure (9) forward. Pull the coil (1) from the upper base, plug in a new coil, replace the upper base structure and check the auxiliary contacts for secureness when repositioning the upper base. Tighten the assembly screws referring to Table II.

Magnet — Armature Assembly

Self alignment and permanent air gap features of the magnet armature make replacement unnecessary. Mating pole face surfaces should be kept clean.

Arc box must be in place when the contactor interrupts a circuit.