

**SIEMENS-ALLIS**

**JFR DISTRIBUTION  
VOLTAGE REGULATORS**



**USERS MANUAL**

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# SIEMENS-ALLIS

## JFR DISTRIBUTION VOLTAGE REGULATORS

### CONTENTS

SUBJECT	Page	SUBJECT	Page
<b>SUMMARY OF PROCEDURES</b> .....	3	Setting Line Drop Compensator .....	14
Placing Regulator in Service .....	3	Load Center Method .....	14
Checking Regulator Accu/Stat Control .....	3	Average Increase Method .....	14,15
Removing Regulator from Service .....	3	Test for Determining Leading and Lagging Regulator (Open Delta) .....	16
<b>WARRANTY</b> .....	3	Further Results of Test .....	16
<b>INTRODUCTION</b> .....	4	Setting Compensator with Capacitors on the Line .....	16
Inspection for Damage in Shipping .....	4	Table I Distribution Line Resistance and Reactance .....	17
Storage .....	4	Table II Compensator Multiplier Table .....	17
Protective Measures .....	4	Table III Line Drop Compensator Settings For Regulators Connected in Delta .....	18
Location .....	5	<b>MAINTENANCE</b> .....	
<b>INSTALLATION DIAGRAMS</b> .....	5	Periodic Inspection .....	19
<b>CONNECTION DIAGRAMS</b> .....		Accu/Stat Control Maintenance .....	19
Straight Design .....	6	Removing Regulator From Service .....	19
Inverted Design .....	7	Untanking .....	19
Series Transformer Design .....	8	Overloading Regulator .....	19
<b>PLACING REGULATOR IN SERVICE</b> .....		<b>SPECIAL FEATURES</b> .....	
Before Connecting .....	9	Polarized Jack Plug and Hinged Panel .....	20
Energizing and Checking Control Operation .....	9	Vari-Amp Position Indicator, Mounting .....	20
Switching the Regulator "On the Line" .....	9	Operation at Less Than Rated Voltage .....	20
Checking Mechanism Operation .....	9	Unidirectional Breather .....	21
Set Vari-Amp Limits .....	9	Reset Drag Hand .....	21
Energizing and Checking the Control Panel .....	9	Table IV System Operating Voltages .....	21
External Power Supply .....	9	Table V Regulating Ranges and Current Capacities .....	21
Bandwidth Check .....	10	<b>OPTIONAL FEATURES</b> .....	
Voltage Level Check .....	10	Forced Air Cooling .....	22
<b>CONTROL DIAGRAMS</b> .....		Remote Mounting of Control Compartment .....	22
IJ-2 Control - Wiring Diagram .....	11	Installation of the Remote Mounting Kit .....	22
IJ-2 Control - Schematic Diagram .....	11	Meter Sockets .....	23
IJ-2A Control - Wiring Diagram .....	12	<b>PARTS LIST</b> .....	
IJ-2A Control - Schematic Diagram .....	12	Major Components .....	24
IJ-2 Control Circuit - Schematic Diagram .....	13	Instructions for Ordering Parts .....	24
IJ-2A Control Circuit - Schematic Diagram .....	13	Accu/Stat Control Panel-Types IJ-2, IJ2A .....	24,25
<b>SETTING THE Accu/Stat CONTROLS</b> .....		Dial Switch - Type TLG .....	26
Introduction .....	14	Quick Break Mechanism - Type TLG .....	27
Voltage Level .....	14	Dial Switch - Type TLF .....	28
Band Width .....	14	Quick Break Mechanism - Type TLF .....	29
Time Delay .....	14	Bushings and By-Pass Arresters .....	30,31

## USERS MANUAL

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

## PLACING REGULATOR IN SERVICE

(without interrupting the load)

For detailed instructions see page 9.

1. The by-pass switch 1, Fig. (7, 10, 13), is in series with the line and will of course, be closed if the line is carrying load. Close the disconnect switch 2, Fig. (7, 10, 13), on the source side of the regulator. This excites the regulator to full line voltage.
2. Run the tap changer to "Neutral" position.
3. Turn transfer switch and voltage source switch to "off".
4. Remove both fuses on front of control panel.
5. Close the disconnect switch 3, Fig (7, 10, 13), on the load side of the regulator.
6. Open the by-pass switch 1. The regulator then carries load.
7. Replace fuses on front of control panel.
8. Set voltage source switch to "Normal".
9. Adjust the control (see Page 13) and set the transfer switch to "automatic" position.

### CAUTION

Source (S), load (L) and neutral (SL) designation of bushings stamped on cover. Check before connecting to line.

## CHECKING REGULATOR ACCU/STAT CONTROL

For detailed instructions to check band width and voltage see page 10.

1. Move transfer switch from "automatic" to "raise" position and allow regulator to operate about five steps.
2. Return the transfer switch to "automatic" operation. After a short time delay the regulator will operate, and come to rest.
3. Check the regulator operation in the "lower" direction in the same manner.
4. If the control operation is satisfactory, return the transfer switch to the "automatic" position.

## REMOVING REGULATOR FROM SERVICE

(without interrupting service)

1. Run the regulator to the "Neutral" position.
2. Turn transfer switch and voltage source switch to "off".
3. Remove both fuses on front of the control panel so the regulator cannot operate.
4. Close the by-pass switch 1, Fig. (7, 10, 13), thus shunting the regulator.
5. Open disconnect switch 3, Fig. (7, 10, 13), on load side.
6. Open disconnect switch 2, Fig. (7, 10, 13), on source side.

### CAUTION

When removing the regulator from service, never open the neutral disconnect switch until the source disconnect switch has been opened. Failure to observe this rule may cause a high enough voltage to be induced in the windings to damage the insulation.

**NOTE:** Above instructions and those on Page 9 based on using individual switches for source, load and by-pass. If combination type regulator by-pass switch is used, the by-pass switch No. 1, Fig. (7, 10, 13) is the by-pass element of the combination switch. The source and load switches, No. 2 and 3, are the source and load blades of the combination switch.

## WARRANTY

Company warrants title to the product(s) and, except as noted below with respect to items not of Company's manufacture, also warrants the product(s) on date of shipment to Purchaser, to be of the kind and quality described herein, merchantable, and free of defects in workmanship and material.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS, AND CONSTITUTES THE ONLY WARRANTY OF COMPANY WITH RESPECT TO THE PRODUCT(S).

If within one year from date of initial operation, but not more than eighteen months from date of shipment by Company of any item of product(s), Purchaser discovers that such item was not as warranted above and promptly notifies Company in writing thereof, Company shall remedy such nonconformance by, at Company's option, adjustment or repair or replacement of the item and any affected part of the product(s). Purchaser shall assume all responsibility and expense for removal, re-installation, and freight in connection with the foregoing

remedies. The same obligations and conditions shall extend to replacement parts furnished by Company hereunder. Company shall have the right of disposal of parts replaced by it.

ANY SEPARATELY LISTED ITEM OF THE PRODUCT(S) WHICH IS NOT MANUFACTURED BY THE COMPANY IS NOT WARRANTED BY COMPANY and shall be covered only by the express warranty, if any, of the manufacturer thereof.

THIS STATES PURCHASER'S EXCLUSIVE REMEDY AGAINST COMPANY AND ITS SUPPLIERS RELATING TO THE PRODUCT(S) WHETHER IN CONTRACT OR IN TORT OR UNDER ANY OTHER LEGAL THEORY, AND WHETHER ARISING OUT OF WARRANTIES, REPRESENTATIONS, INSTRUCTIONS, INSTALLATIONS OR DEFECTS FROM ANY CAUSE. Company and its suppliers shall have no obligation as to any product which has been improperly stored or handled, or which has not been operated or maintained according to instructions in Company or supplier furnished manuals.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

Type JFR regulators are designed to give dependable on-the-line service and to make installation, operation and maintenance as simple as possible.

High quality materials and careful workmanship have been combined to give you the best regulator available. Your regulator has been carefully inspected and adjusted at the factory. However, successful operation depends on proper installation and care.

The manual has been written to help you obtain long and economical service from your regulator. If you follow these instructions carefully, your unit will give the best in regulating service. *Read this manual before installing or operating your regulator.*

### INSPECTION FOR DAMAGE IN SHIPPING

As soon as the regulator arrives, check each item with the shipping manifest. Should any shortage or damage be found, call the local freight agent of the carrier over which the shipment arrived, and make proper notation on the freight bill. Claim should be made immediately with the carrier, and Siemens-Allis should be notified.

### STORAGE

If the regulator is not to be put into immediate use, it can be stored inside or outside without any particular precautions, provided the control compartment is tightly closed and the breather plugs are removed to allow normal breathing.

Oil may splash into the lower breather pipe during transit, so a container should be placed under the opening when the plug is removed. About a quart of oil may be drained out.

### PROTECTIVE MEASURES

**By-Pass Arresters:** All standard regulators are equipped with by-pass arresters which should be mounted on the bushings and connected across the series winding. By-pass arresters limit the voltage across the series winding, but are not meant as a protection from line to ground.

**Lightning Protection:** For better protection of both regulator and line, install a lightning arrester of the proper rating between line and ground. For best results, install lightning arresters on the mounting lugs located between the source and load bushing and the source and neutral bushing at the top of the tank. Ground the arrester and the regulator tank solidly to the same ground connection with the shortest lead possible.

**Fusing:** When fuses are used with single phase regulators, place in source line leads only, never in the neutral or common lead. Fuse manufacturers have standard fuses for protection of circuits of various ampere and voltage ratings. Manufacturers' recommendations should be followed.




Fig. 1 Cutaway view of typical JFR regulator identifying internal and external components.

### CAUTION

The regulator outline drawing, furnished with each regulator shipped, should be reviewed to verify it is built for pole mounting (hanger brackets) or platform mounting.

**WARNING** — Before connecting regulators on the line: Check nameplate for control and motor voltages and markings on main cover for proper bushing location.


[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

**LOCATION**

Siemens-Allis regulators are designed to permit indoor or outdoor installation, on platforms or on poles. There are limitations that should be considered prior to installation:

1. The regulators should not be located in an air locked room or enclosure because they need circulating air for cooling.
2. The regulators should have adequate clearance to permit complete inspection and maintenance.

**Fig. 2** When regulators are used at altitudes above 3300 feet, operating kVA should be reduced as specified in ANSI Standards. This chart indicates reduction in kVA rating for increase in altitude at which the regulator is to be operated.



**Installation Diagrams**

**Single Phase**

Fig. 3 Connection of one phase of a three phase regulator to a single phase system.

**Open Delta**

Fig. 4 Connection of two phase of a three phase regulator to an open delta three phase system.

**Closed Delta**

Fig. 5 Connection of three phase regulator in closed delta to a three phase ungrounded system providing three regulation.

**Wye Connected**

Fig. 6 Connection of three phase regulator in wye connected to a three phase system.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# Straight Design




Fig. 7 Wiring diagram of typical regulator showing both external and internal connections.




Fig. 8 Schematic diagram of typical JFR regulator with separate potential source for control.

\* Note: Other typical motor supply winding configurations.




Fig. 9 Typical arrangement of windings and connections of JFR regulators.

**NOTE:** Straight Design units may or may not be equipped with balance winding. Refer to regulator nameplate.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# Connection Diagrams

## Inverted Design




Fig. 10 Wiring diagram of typical regulator showing both external and internal connections.




Fig. 11 Schematic diagram of JFR regulator utilizing single potential source for motor and control circuit.




Fig. 12 Typical arrangement of windings and connections of JFR regulator.

**NOTE:** Inverted Design units may or may not be equipped with balance winding. Refer to regulator nameplate.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

## CAUTION

Before regulator is energized, refer to nameplate to be sure that all connections to terminal block on cover and, where applicable, to terminal block in control are correct for the line voltage.

### BANDWIDTH CHECK

The bandwidth may be checked with the regulator energized and control supplied by the built-in regulator power supply. This method requires no external power source and may be used even when the regulator is carrying load.

1. Connect an ac voltmeter to the voltmeter test terminals.
2. Set the "R" and "X" compensation to zero.
3. Set the voltage source switch to "Normal" and the panel transfer switch to "Auto".
4. Set the voltage level dials to the value which most nearly corresponds to the voltage that is read at the voltmeter test terminals. The band indicator hand should center to the "IN" position.
5. Set the bandwidth dial at the position to be checked.
6. Gradually decrease the voltage level setting in one volt increments until the band indicating meter hand deflects. It will move to the UPPER limit when the voltage level has been decreased by an amount equal to  $\frac{1}{2}$  the bandwidth setting.
7. The LOWER LIMIT may be checked similarly by increasing the voltage level setting in one volt increments until the band indicator hand deflects.

The regulator source voltage should not fluctuate during this test. If it does the bandwidth limits can not be accurately determined using this method.

If necessary, the band limits may be checked by an alternate means using a variable 120V-ac external source. The external source should be connected to the control panel in the same manner as described in the preceding paragraph on "EXTERNAL POWER SUPPLY."

Adjust the variable voltage source until the voltmeter connected to the voltmeter test terminals reads the same voltage as set on the voltage level control dials. Place the transfer switch to the "AUTO" position and set the bandwidth dial to the position to be checked.

The band indicating meter hand should be centered on the "IN" position, indicating that the applied voltage is within the preset band limits. Gradually increase the supply voltage until the band indicator deflects to the UPPER LIMIT indicating the voltage has exceeded the upper bandwidth limit. This should occur when the supply voltage has been increased by an amount equal to  $\frac{1}{2}$  the bandwidth setting.

The lower limit can be similarly checked with the exception that the supply voltage is decreased until the band meter hand moves to the LOWER LIMIT.

### VOLTAGE LEVEL CHECK

The voltage level setting is equal to the average of the upper and lower bandwidth settings as determined by the above test.

Note: Accuracy of many portable indicating voltmeters is adversely affected by low temperatures.




Fig. 16 Calibrating test points and calibration rheostat.

- \* 1 Calibrating rheostat
- \* 2 Test point (8)
- \* 3 Test point (0)
- 4 Control breather
- 5 Time delay selection knob
- \* Reference IJ-2 Instruction Manual pages 10 & 11.

**CAUTION:** The *Accu/Stat* control is pre-calibrated at the factory. These calibrations should not be changed.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)




Fig. 17 Typical IJ-2 regulator control.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# Wiring Diagrams




Fig. 18 Typical IJ-2A regulator control.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)




Fig. 19 Schematic diagram of a typical regulator IJ-2 control.

**NOTE: PANEL FUSING**

For panel, use MDL 4/10A or 313-3AG 4/10. For motor, use AGX 4A or 362-8AG 4.




Fig. 20 Schematic diagram of a typical IJ-2A control.

NOTE: For connection of P and P<sub>14</sub> see nameplate.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

## INTRODUCTION

*Accu/Stat* control panels consist basically of a static sensing device, a line drop compensator, and a static voltage integrator time delay relay. The entire *Accu/Stat* control is self contained and can be installed or removed from the control box as one unit. Each is interchangeable with the SJ-6, SJ-5, SJ-4 and UJ-5A control panels.

*Accu/Stat* control is completely calibrated at the factory, and all adjustments can be made directly by turning the calibrated control knobs to the desired setting. No instruments or tools are necessary to make any of the settings. All necessary control knobs are securely locked by a thumb screw on each knob. The control does not require any warm-up time and will hold better than accuracy class I over a wider ambient temperature range than required by standards.

*Note:* Before turning any control knobs, loosen the knob lock by turning the thumb screw on knob approximately three turns counterclockwise. Refer to Figure 21 for control knob locations.

## VOLTAGE LEVEL

The voltage level setting consists of a coarse and a fine adjustment of two knobs located on the face of the *Accu/Stat* control panel. A combination of these adjustments yields a voltage level range from 105 volts to 134 volts in one-volt steps.

## BANDWIDTH

Bandwidth is adjusted by turning a calibrated knob on the face of the *Accu/Stat* panel and total bandwidth can be set from 1½ to 6 volts.

## TIME DELAY

*Accu/Stat* controls are shipped from the factory set for a time delay of 45 seconds. To change the time delay setting, loosen the thumb screw on the left hand side of the panel face and open the face plate. A calibrated time delay selection knob is on the top of the printed circuit board. See (Figure 16). Standard type *Accu/Stat* controls allow continuous time delay settings of 15 thru 120 seconds.

## SETTING LINE DROP COMPENSATOR

The Line Drop Compensator is set to compensate for the line drop between the regulator and the load center. In other words, it adjusts the voltage supplied to the control circuit to duplicate the voltage appearing at the load center, or at some point out on the line.

The increase in voltage at the voltage regulator produced by line drop compensation is a function of the resistance (R) and reactance (X) settings on the control panel and the amount of line current flowing through the regulator. There are several different meth-

ods used to determine the actual line drop compensation settings on the control panel. Two of the more common methods are the Load Center Method and the Average Increase Method.

## LOAD CENTER METHOD

Using the Tables on Page 16, the resistance and reactance settings can easily be determined as follows:

1. In Table I, locate the Conductor Size column, resistance of the line per mile, and under the Conductor Center Distance column ("D"), the reactance of the line per mile.
2. Find the appropriate compensator multiplier from Table II.
3. Multiply the resistance or reactance found in Step 1 by the compensator multiplier, and by the distance in miles to the load center to obtain the line drop compensator setting.

### EXAMPLE: LOAD CENTER METHOD

*Name Plate:* 76.2 kVA, line voltage 7200 volts, control voltage 120 volts.

*C.T. primary rating* 100 amps.

*Connection:* 3 single phase units in wye on a three phase line.

*Conductor:* No. 0000 stranded copper, 36" symmetrical triangular spacing.

*Distance to Load Center:* 2 miles.

*Regulator Rated Load:* 100 amps.

From Table I, the resistance is 0.303 ohms per mile and the reactance is 0.630 ohms per mile.

From Table II, the multiplier is 1.67. Multiplying 0.630 by 1.67 gives a setting of 1.05 volts per mile. Multiply by 2 miles to get reactance setting of 2.10 volts or 2 volts.

The actual resistance setting is found in similar manner.

## AVERAGE INCREASE METHOD

Many times voltage regulators are placed on electrical circuits when a specific "Load Center" does not exist. It is often desirable in those situations to adjust the line drop compensation settings to produce a predetermined increase above rated voltage at periods of heavy loading.

Using the Tables on Page 16, the resistance and reactance settings can be easily determined as follows:

1. In Table 1, locate the conductor size column, resistance of the line per mile, and under the conductor center distance column (D), the reactance of the line per mile.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

- Determine the percent increase in line voltage desired at peak load and multiply that percent by the control panel voltage to determine the actual voltage increase desired.

**Note:** The vector summation of the resistance and reactance values must equal the increase in voltage desired. Therefore, the R and X values become two legs of a right triangle with the hypotenuse being the increase in voltage desired.

- Determine an angle  $\theta$  which is the tan of the ratio of reactance to resistance.
- To calculate the resistance value desired, multiply the desired voltage increase by  $\cos\theta$ . The reactance value is determined by multiplying the desired voltage increase by  $\sin\theta$ .
- Find the primary current rating of the regulator C.T. This is shown on the regulator nameplate.
- Determine the peak load current in the circuit.
- Multiply the resistance value by the ratio of the regulator C.T. primary to the peak load current, round off to the nearest volt and this becomes the resistance setting. Do the same with the reactance value to determine the reactance setting.

EXAMPLE:

**AVERAGE INCREASE METHOD**

**Name Plate:** 76.2 kVA, line voltage 7200 volts, control voltage 120 volts. C.T. primary rating 100 amps.

**Connection:** 3 single phase units in wye on a three phase line.

**Conductor:** No. 0000 stranded copper, 36" symmetrical triangular spacing.


**Distance to Load Center:** 2 miles.

**Peak Load:** 80 amps.

**Regulator Rated Load:** 100 amps.

From Table I, the resistance is 0.303 ohms per mile and the reactance is 0.630 ohms per mile.

The actual voltage increase desired at peak load is 6 volts.



$$\tan \theta = \frac{R_X}{R_R} = \frac{0.630}{0.303} = 2.079$$

$$\theta = \text{Arc Tan } 2.079 = 64.3^\circ$$

$$R_X = (126\text{v}-120\text{v}) (\sin \theta) \times \frac{\text{CT primary rating}}{\text{peak load amps}}$$

$$= (6\text{v}) (\sin 64.3^\circ) \times \left( \frac{100 \text{ amps}}{80 \text{ amps}} \right)$$

$$= (6\text{v}) (0.901) (1.25)$$

$$R_X = 6.75\text{v or } 7 \text{ volts}$$

$$R_R = (126\text{v}-120\text{v}) (\cos \theta) \times \frac{\text{CT primary rating}}{\text{peak load amps}}$$

$$= (6\text{v}) (\cos 64.3^\circ) \times \frac{100 \text{ amps}}{80 \text{ amps}}$$

$$= (6\text{v}) (.433) (1.25)$$

$$R_R = 3.25\text{v or } 3.0 \text{ volts}$$

For single phase or three phase four wire connections, set the values obtained directly on the compensator controls and set the compensator polarity switch on +R+X. For open or closed delta systems follow the procedure below:

When single phase distribution regulators are connected in open or closed delta, no interconnection between control panels is necessary. With closed delta connected regulators, the current either leads or lags the regulator voltage of all three units 30 degrees, depending on the regulator connections. With ABC phase rotation, if the regulator which has its "L" bushing connected to phase A has its "SL" bushing connected to phase C, the connections are leading. If the same regulator has its "SL" bushing connected to phase B, the connections are lagging. The resistance and reactance settings are found as outlined above.

These settings, however, must be corrected because of the phase shift between the line current and control voltage. Corrected compensator settings for leading or lagging regulators (in either closed or open delta) are obtained from the following formulas:

$$R_1 = 0.866R - 0.5X \quad X_1 = 0.866X + 0.5R$$

$$R_2 = 0.866R + 0.5X \quad X_2 = 0.866X - 0.5R$$

R & X = the resistance and reactance drop as found on Page 16 or 17.

$R_1$  &  $X_1$  = the resistance and reactance setting of lagging regulator.

$R_2$  &  $X_2$  = the resistance and reactance settings of leading regulator.

Compensator settings can also be found in Table III on Page 17.

EXAMPLE:

With a line reactance drop of 10 volts and a line resistance drop of 8 volts, the corrected settings obtained from Table III are:

lagging regulator: R setting = 2 volts, X setting = 13 volts.

leading regulator: R setting = 12 volts, X setting = 5 volts.

Negative settings are made by means of the compensator polarity switch on the control panel set to the appropriate position.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

### TEST FOR DETERMINING LEADING AND LAGGING REGULATOR (OPEN DELTA)

To determine the phase relationship on a three phase system the following method may be used. This method is applicable only with two regulators connected in open delta on a three phase system. There must be sufficient load on the line at the time of the test to activate the line drop compensator sufficiently to give good positive results.

1. Set the voltage level control on both panels to the same value, i.e. 120 volts.
2. Turn the resistance (R) compensation to zero on both units.
3. Turn reactance (X) compensation on both panels to the same value, i.e. 12 volts.
4. Set the transfer switch to AUTO.

After the regulators come to rest, the regulator with the higher output voltage, nearer maximum raise position, is the lagging regulator and the other regulator is the leading regulator.

### FURTHER RESULTS OF TEST

If the power factor of the load is anywhere between .81 lag and .91 lead:

- a. The lagging regulator will raise its output voltage.
- b. The leading regulator will lower its output voltage.

If the power factor of the load is lower than .81 lag:

- a. Both regulators will raise their output voltage.
- b. The lagging regulator will have the higher output voltage.

If the power factor of the load is lower than .91 lead:

- a. Both regulators will lower their output voltages.
- b. The lagging regulator will still have the higher output voltage.

- 1 External Source Connection Terminals
- 2 Voltage Source Switch
- 3 Fuses
- 4 Bandwidth Adjustment
- 5 Neutral Indicating Light (*Neutralite*)
- 6 Electrical Reset Button for Drag Hands
- 7 Resistance Compensator
- 8 Polarized Jack Plug
- 9 Reactance Compensator (Coarse)
- 10 Reactance Compensator (Fine)
- 11 Compensator Polarity Switch
- 12 Voltage Level Adjustment (Coarse)
- 13 Voltage Level Adjustment (Fine)
- 14 Automatic-Manual Transfer Switch
- 15 Operation Counter
- 16 Band Indicator
- 17 Voltmeter Test Terminals
- 18 Breather

Regardless of load power factor the output voltages of the lagging regulator will always be higher. Within the range of .81 lag to .91 lead (which will take in almost all feeders) the indication is more positive because the regulators will move in opposite directions.

### SETTING COMPENSATOR WITH CAPACITORS ON THE LINE

The line drop compensator is designed to give proper compensation when the power factor at the load center and at the regulator is equal. When the compensator settings are adjusted to match the impedance of the line, the correct load center voltage will be maintained.

If capacitors are installed at the regulator source side or installed at the load center, a regulator control will give proper compensation.

Sometimes, of course, it is desirable to install capacitors beyond the regulator but not at the load center. This will, of course, upset the load center voltage, but usually the regulator can be adjusted to give satisfactory results. This may be done by increasing voltage level setting of voltage control relay. The easiest solution is by trial and error. A few sketches of the vector diagram for existing conditions may help in obtaining the correct setting.




Fig. 21 Front view of JFR regulator control.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

**TABLE I DISTRIBUTION LINE RESISTANCE AND REACTANCE**  
OHMS PER CONDUCTOR PER MILE AT 60 Hz

COPPER — HAND DRAWN										ALUMINUM — STEEL REINFORCED									
CON- DUCTOR SIZE	RESISTANCE AT 50°C	REACTANCE* DISTANCE "D" BETWEEN CENTERS OF CONDUCTOR								CON- DUCTOR SIZE	RESISTANCE AT 50°C	REACTANCE* DISTANCE "D" BETWEEN CENTERS OF CONDUCTOR							
		18"	24"	30"	36"	42"	48"	54"	60"			18"	24"	30"	36"	42"	48"	54"	60"
MCM										MCM									
1000	.0685	.449	.484	.511	.533	.552	.568	.593	.595	1272.0	.0851	.421	.456	.483	.505	.524	.540	.555	.567
750	.0888	.466	.501	.529	.550	.569	.585	.600	.612	954.0	.1128	.439	.474	.501	.523	.542	.553	.573	.585
600	.1095	.481	.516	.543	.565	.584	.600	.615	.627	795.0	.1373	.450	.485	.512	.534	.553	.569	.584	.596
500	.1303	.492	.527	.554	.576	.595	.611	.626	.638	556.5	.1859	.469	.504	.531	.553	.572	.588	.603	.615
400	.1619	.507	.542	.569	.591	.610	.626	.641	.653	477.0	.216	.479	.514	.541	.563	.582	.598	.613	.625
350	.1845	.515	.550	.577	.599	.618	.634	.649	.661	397.5	.259	.490	.525	.555	.574	.593	.609	.624	.636
300	.215	.525	.560	.587	.609	.628	.644	.659	.671	336.4	.306	.500	.535	.562	.584	.603	.619	.634	.646
250	.257	.536	.571	.598	.620	.639	.655	.670	.682	266.8	.385	.514	.549	.576	.598	.617	.633	.648	.660
AWG										AWG									
4/0	.303	.546	.581	.603	.630	.649	.665	.630	.692	4/0	.592	.630	.665	.692	.714	.733	.749	.764	.776
3/0	.382	.554	.589	.616	.638	.657	.673	.688	.700	3/0	.723	.670	.705	.732	.754	.773	.789	.804	.816
2/0	.481	.581	.616	.643	.665	.684	.700	.715	.727	2/0	.895	.690	.725	.752	.774	.793	.809	.824	.836
1/0	.607	.595	.630	.657	.679	.698	.714	.729	.741	1/0	1.12	.705	.740	.767	.789	.808	.824	.839	.851
1	.757	.609	.644	.671	.693	.712	.728	.743	.755	2	1.69	.714	.749	.776	.798	.817	.833	.848	.860
2	.964	.623	.658	.685	.707	.726	.742	.757	.769	4	2.57	.708	.743	.770	.792	.811	.827	.842	.854
4	1.518	.648	.683	.710	.732	.751	.767	.782	.794	6	3.98	.722	.757	.784	.806	.825	.841	.856	.868
6	2.41	.677	.712	.739	.761	.780	.796	.811	.823										
8	3.80	.714	.749	.776	.798	.817	.833	.848	.860										

\*60 Hertz reactance in ohms per mile of each conductor of a single phase, or of a three phase, symmetrical triangular spacing. For other arrangements of conductors see below. The reactance for other frequencies is F/60 times the table values. Reactance values are for concentric stranded copper conductors and are approximately correct for aluminum cable conductors.

**TABLE II COMPENSATOR MULTIPLIER TABLE**

Regulator Operating Data (See nameplate)		Circuit Connection*			Regulator Operating Data (See nameplate)		Circuit Connection*			
Regulator Operating Kv and (Potential Trans. Ratio)	Regulator Current Rating	Single	Delta	Wye	Regulator Operating Kv and (Potential Trans. Ratio)	Regulator Current Rating	Single	Delta	Wye	
19.9 (166/1)	50	.60	.52	.30	5.0 (40/1)	100	5.00	4.33	2.50	
	100	1.20	1.04	.60		150	7.50	6.49	3.75	
	167	2.40	2.08	1.20		200	10.00	8.66	5.00	
	200	2.40	2.08	1.20		250	17.50	15.15	8.75	
14.4 (120/1)	50	.83	.72	.42	334	17.50	15.15	8.75		
	100	1.67	1.44	.83	500	35.00	30.30	17.50		
	200	3.34	2.88	1.67	625	35.00	30.30	17.50		
	300	5.01	4.32	2.49	668	35.00	30.30	17.50		
	400	6.68	5.76	2.52	835	35.00	30.30	17.50		
	13.8 (115/1)	50	.87	.75	.44	4.16 (34.7/1)	100	5.76	4.98	2.88
100		1.74	1.50	.87	150		8.64	7.48	4.32	
150		2.61	2.25	1.31	200		11.53	9.97	5.76	
200		3.48	3.00	1.74	250		20.20	17.48	10.10	
7.62 (63.5/1)		50	1.57	1.36	.79		334	20.20	17.48	10.10
		75	2.36	2.04	1.18		500	40.40	34.96	20.20
	100	3.15	2.72	1.57	625	40.40	34.96	20.20		
	150	4.72	4.08	2.36	668	40.40	34.96	20.20		
	219	7.87	6.82	3.94	835	40.40	34.96	20.20		
	328	12.60	10.90	6.30	2.5 (20/1)	200	20.00	17.30	10.00	
438	12.60	10.90	6.30	300		30.00	25.96	15.00		
548	12.60	10.90	6.30	400		40.00	34.60	20.00		
7.2 (60/1)	50	1.67	1.44	.83		500	70.00	60.55	35.00	
	75	2.50	2.16	1.25		668	70.00	60.55	35.00	
	100	3.34	2.89	1.67		1000	140.00	121.10	70.00	
	150	5.00	4.33	2.50	1250	140.00	121.10	70.00		
	219	8.34	7.22	4.17	1332	140.00	121.10	70.00		
	328	13.33	11.55	6.67	1665	140.00	121.10	70.00		
438	13.33	11.55	6.67							
548	13.33	11.55	6.67							

\*Above multipliers are based on regulator C.T. ratings (see nameplate). C.T. rating is not always the same as regulator rating. To compute compensator multiplier for ratings not given above the basic formula is (C.T. Primary rating) ÷ (Reg. KV ÷ Control operating volts) or P.T. ratio expressed on a line to neutral basis  
 1. Single phase (C.T. rating ÷ P.T. ratio) x 2.  
 2. Delta connected = (C.T. rating ÷ P.T. ratio) x 1.73.  
 3. Wye connected = (C.T. rating ÷ P.T. ratio) x 1.0.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

TABLE III LINE DROP COMPENSATOR SETTINGS FOR REGULATORS CONNECTED IN DELTA

		LINE REACTANCE (X)																								
		0	1	2	3	4	5	6	7	8	9	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
0	$\Delta R_1$	0	-1	-1	-2	-2	-3	-3	-4	-4	-5	-6	-6	-7	-7	-8	-8	-9	-9	-10	-10	-11	-11	-12	-12	
	$\Delta X_1$	0	1	2	3	3	4	5	6	7	8	10	10	11	12	13	14	15	16	16	17	18	19	20	21	
	$R_2$	0	1	1	2	2	3	3	4	4	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	
	$X_2$	0	1	2	3	3	4	5	6	7	8	10	10	11	12	13	14	15	16	16	17	18	19	20	21	
1	$\Delta R_1$	1	0	0	-1	-1	-2	-2	-3	-3	-4	-5	-5	-6	-6	-7	-7	-8	-8	-9	-9	-10	-10	-11	-11	
	$\Delta X_1$	1	1	2	3	4	5	6	7	7	8	10	11	12	13	13	14	15	16	17	18	19	20	20	21	
	$R_2$	1	1	2	2	3	3	4	4	5	5	6	7	7	8	8	9	9	10	10	11	11	12	12	13	
	$X_2$	-1	0	1	2	3	4	5	6	6	7	9	10	11	12	12	13	14	15	16	17	18	19	19	20	
2	$\Delta R_1$	2	1	1	0	0	-1	-1	-2	-2	-3	-4	-4	-5	-5	-6	-6	-7	-7	-8	-8	-9	-9	-10	-10	
	$\Delta X_1$	1	2	3	4	4	5	6	7	8	9	11	11	12	13	14	15	16	17	17	18	19	20	21	22	
	$R_2$	2	2	3	3	4	4	5	5	6	6	7	8	8	9	9	10	10	11	11	12	12	13	13	14	
	$X_2$	-1	0	1	2	2	3	4	5	6	7	9	9	10	11	12	13	14	15	16	17	18	19	20	20	
3	$\Delta R_1$	3	2	2	1	1	0	0	-1	-1	-2	-3	-3	-4	-4	-5	-5	-6	-6	-7	-7	-8	-8	-9	-9	
	$\Delta X_1$	2	2	3	4	5	6	7	8	8	9	11	12	13	14	15	16	17	18	19	20	21	21	22	22	
	$R_2$	3	3	4	4	5	5	6	6	7	7	8	9	9	10	10	11	11	12	12	13	13	14	14	15	
	$X_2$	-2	-1	0	1	2	3	4	5	5	6	8	9	10	11	11	12	13	14	15	16	17	18	18	19	
4	$\Delta R_1$	3	3	2	2	1	1	0	0	-1	-1	-2	-2	-3	-3	-4	-4	-5	-5	-6	-6	-7	-7	-8	-8	
	$\Delta X_1$	2	3	4	5	5	6	7	8	9	10	12	12	13	14	15	16	17	18	18	19	20	21	22	23	
	$R_2$	3	4	4	5	5	6	6	7	7	8	9	10	10	11	11	12	12	13	13	14	14	15	15	15	
	$X_2$	-2	-1	0	1	1	2	3	4	5	6	8	8	9	10	11	12	13	14	14	15	16	17	18	19	
5	$\Delta R_1$	4	4	3	3	2	2	1	1	0	0	-1	-2	-2	-3	-3	-4	-4	-5	-5	-6	-6	-7	-7	-8	
	$\Delta X_1$	3	3	4	5	6	7	8	9	9	10	12	13	14	15	16	17	18	19	20	21	22	22	23	23	
	$R_2$	4	5	5	6	6	7	7	8	8	9	10	11	11	12	12	13	13	14	14	15	15	16	16	16	
	$X_2$	-3	-2	-1	0	1	2	3	4	4	5	7	8	9	10	10	11	12	13	14	15	16	17	17	18	
6	$\Delta R_1$	5	5	4	4	3	3	2	2	1	1	0	-1	-1	-2	-2	-3	-3	-4	-4	-5	-5	-6	-6	-7	
	$\Delta X_1$	3	4	5	6	6	7	8	9	10	11	13	13	14	15	16	17	18	19	20	21	22	23	24	24	
	$R_2$	5	6	6	7	7	8	8	9	9	10	11	12	12	13	13	14	14	15	15	16	16	17	17	17	
	$X_2$	-3	-2	-1	0	0	1	2	3	4	5	7	7	8	9	10	11	12	13	13	14	15	16	17	18	
7	$\Delta R_1$	6	6	5	5	4	4	3	3	2	2	1	0	0	-1	-1	-2	-2	-3	-3	-4	-4	-5	-5	-6	
	$\Delta X_1$	4	4	5	6	7	8	9	10	10	11	13	14	15	16	17	18	19	20	21	22	23	23	24	24	
	$R_2$	6	7	7	8	8	9	9	10	10	11	12	13	13	14	14	15	15	16	16	17	17	18	18	18	
	$X_2$	-4	-3	-2	-1	0	1	2	3	3	4	6	7	8	8	9	10	11	12	13	14	15	16	17	18	
8	$\Delta R_1$	5	5	4	4	3	3	2	2	1	1	0	0	-1	-1	-2	-2	-3	-3	-4	-4	-5	-5	-6	-6	
	$\Delta X_1$	3	4	5	6	7	8	9	9	10	11	13	14	15	16	17	18	19	20	21	22	23	24	24	24	
	$R_2$	5	6	6	7	7	8	8	9	9	10	11	12	12	13	13	14	14	15	15	16	16	17	17	17	
	$X_2$	-3	-2	-1	0	0	1	2	3	4	5	7	7	8	9	10	11	12	13	13	14	15	16	17	18	
9	$\Delta R_1$	8	7	7	6	6	5	5	4	4	3	3	2	2	1	1	0	0	-1	-1	-2	-2	-3	-3	-4	-4
	$\Delta X_1$	5	5	6	7	8	9	10	11	11	12	13	14	15	16	17	18	19	20	21	22	23	24	24	24	
	$R_2$	8	8	9	9	10	10	11	11	12	12	13	14	15	16	17	18	19	20	21	22	23	24	24	24	
	$X_2$	-5	-4	-3	-2	-1	0	1	2	2	3	4	5	6	7	8	8	9	10	11	12	13	14	15	15	16
10	$\Delta R_1$	9	8	8	7	7	6	6	5	5	4	4	3	3	2	2	1	1	0	0	-1	-1	-2	-2	-3	-3
	$\Delta X_1$	5	6	7	8	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	24	24	24	
	$R_2$	9	9	10	10	11	11	12	12	13	13	14	15	16	17	18	19	20	21	22	23	24	24	24	24	
	$X_2$	-5	-4	-3	-2	-2	-1	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	15	16	
11	$\Delta R_1$	10	9	9	8	8	7	7	6	6	5	5	4	4	3	3	2	2	1	1	0	0	-1	-1	-2	-2
	$\Delta X_1$	6	6	7	8	9	10	11	12	12	13	14	15	16	17	18	19	20	21	22	23	24	24	24	24	
	$R_2$	10	10	11	11	12	12	13	13	14	14	15	16	17	18	19	20	21	22	23	24	24	24	24	24	
	$X_2$	-6	-5	-4	-3	-2	-1	0	1	1	2	3	4	5	6	7	7	8	9	10	11	12	13	14	14	15
12	$\Delta R_1$	10	10	9	9	8	8	7	7	6	6	5	5	4	4	3	3	2	2	1	1	0	0	-1	-1	-2
	$\Delta X_1$	6	7	8	9	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	24	24	24	24	
	$R_2$	10	11	11	12	12	13	13	14	14	15	16	17	18	19	20	21	22	23	24	24	24	24	24	24	
	$X_2$	-6	-5	-4	-3	-3	-2	-1	0	1	2	3	4	4	5	6	7	8	9	10	10	11	12	13	14	15
13	$\Delta R_1$	11	11	10	10	9	0	8	8	7	7	6	6	5	5	4	4	3	3	2	2	1	1	0	0	-1
	$\Delta X_1$	7	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	24	24	24	24	24	
	$R_2$	11	12	13	13	14	15	16	17	18	19	20	21	22	23	24	24	24	24	24	24	24	24	24	24	
	$X_2$	-7	-6	-5	-4	-3	-2	-1	0	0	1	2	3	4	5	6	6	7	8	9	10	11	12	13	13	14
* 14	$\Delta R_1$	12	12	11	11	10	10	9	9	8	8	7	7	6	6	5	5	4	4	3	3	2	2	1	1	0
	$\Delta X_1$	7	8	9	10	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	24	24	24	24	24	
	$R_2$	12	13	13	14	14	15	16	17	18	19	20	21	22	23	24	24	24	24	24	24	24	24	24	24	
	$X_2$	-7	-6	-5	-4	-4	-3	-2	-1	0	1	2	3	3	4	5	6	7	8	9	9	10	11	12	13	14

$\Delta R_1$  } Compensator settings of lagging regulator       $R_2$  } Compensator settings of leading regulator  
 $\Delta X_1$  }  
 $X_2$  }

\*For values of R greater than 14 refer to formula Page 17

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

## PERIODIC INSPECTION

Operation of the regulator can be checked without removing it from service. Simply run the mechanism with the transfer switch until the voltage output is outside the bandwidth as set on the panel. By putting the regulator back on automatic control, the operation of the voltage integrator and mechanism can be checked. After the predetermined time delay, the motor switch will close to operate the motor. The quick break mechanism makes a "click" when a step is made. These "clicks" occur uniformly at about 4 second intervals. Check both directions of travel.

Test the limit switches by operating the mechanism to number 16 raise and lower to make sure that the limit switches open the circuit on the two extreme positions. If the limit switch fails to open the circuit, the motor will be stalled against the mechanical stop. The motor is so designed that it can be stalled continuously without damage.

Never, under any circumstances, energize the regulator unless it is filled with oil to the proper level. It should always be kept filled to the proper level as indicated on the oil sight gauge. Use ASTM D-3487 Type II insulating oil.

Check the dielectric strength of the oil from time to time while the regulator is in service, and if found to test below 22 kV, filter immediately.

## ACCU/STAT CONTROL MAINTENANCE

All parts and circuits of the *Accu/Stat* static control are accessible for ease of inspection and maintenance.

Once the *Accu/Stat* control settings have been made, no further adjustments are required. Should trouble develop, it is necessary only to disconnect the jack plug and remove the control. All parts are then accessible for inspection and tests.

An IJ-2, IJ-2A, SJ-6, SJ-5, or SJ-4 *Accu/Stat* control can be attached or a type UJ-5 voltage regulating relay control can be installed until repairs can be made. A Siemens-Allis Instruction and Service Manual (for IJ-2A and IJ-2, Book 21X4992; SJ-6, Book 21X4410; SJ-3, SJ-4, SJ-5, Book 21X3197) would be of further assistance in trouble shooting the control panel. Readings should be made with a good multimeter or individual good quality meters. If the trouble cannot be determined, contact your Siemens-Allis representative.

## REMOVING THE REGULATOR FROM SERVICE

To remove the regulator from service without interrupting the load, proceed as follows:

1. Run the regulator to the "NEUTRAL" position. (When regulators are in closed delta, Figure 5, all three units must be run to neutral.)

2. Turn transfer switch and voltage source switch on the control panel to "OFF" (all three if in delta.)
3. Close the by-pass switch 1, Fig. 7, 10, 13, thus shunting the regulator.
4. Open disconnect switch 3, Fig. 7, 10, 13, on load side.
5. Open disconnect switch 2, Fig. 7, 10, 13, on source side.

## UNTANKING

An inspection jack is available to untank the mechanism portion of the regulator for inspection. This can be done at the installation site by partially untanking without draining the oil.

To untank JFR regulator proceed as follows:

1. Remove the three mounting bolts holding the *Accu/Stat* control panel onto the main tank.
2. Loosen all cover bolts and turn 180 degrees.
3. The regulator can now be pulled from the main tank by the lifting hooks provided on the main cover, or it can be raised with the inspection jack as shown in Fig. 22.

Time intervals between Internal inspections will depend upon frequency of operation and loads being carried. Regulators subjected to numerous overloads and a high load factor may require more frequent inspections than those carrying normal loads. While internal inspection is not a necessity, preventive maintenance inspections will pay dividends in uninterrupted service.

When inspecting, make sure all nuts, bolts, and connections are tight. The results of the first inspection should determine the best inspection program to follow for the type of service involved.

### CAUTION

*Do not make internal inspection while the regulator is energized.*

## OVERLOADING REGULATOR

Regulators can be overloaded as prescribed in proposed ANSI Guide C57.95. *Caution:* Before overloading, check the guides for loading limits.

**Short Circuit:** Standard regulators are designed to withstand 25 times base current for a period of 2 seconds and 40 times base current for 0.8 second without injury per ANSI C57.15. Refer to Siemens-Allis Service and Engineering Manual 2860.233 for greater short circuit capacities.

### CAUTION

*WHEN REPLACING AN IJ-2 OR EARLIER CONTROL WITH AN IJ-2A, connect leads "P" and "P<sub>14</sub>" from the sensing transformer to terminal "20" on the IJ-2A control.*

*WHEN REPLACING AN IJ-2A WITH AN IJ-2 OR EARLIER CONTROL, the voltage level knobs must be set equal to the "Control and Motor" volts (E-P<sub>2</sub>) shown on the nameplate.*

*WHEN REPLACING AN IJ-2A WITH AN IJ-2A, be sure to connect the "P" and "P<sub>14</sub>" leads from the control sensing transformer to the proper terminals corresponding to the operating voltage. Refer to the regulator nameplate for these connections.*

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# SPECIAL FEATURES

## POLARIZED JACK PLUG AND HINGED PANEL

The *Accu/Stat* control panel is hinged and may be removed completely from the regulator control box by removing the wing nuts on the polarized jack plug and pulling the jack from its fixed portion. This will automatically de-energize the entire panel and will also short circuit the secondary of the current transformer.

## VARI-AMP POSITION INDICATOR

The *Vari-Amp* feature provides a method of operating the regulator at increased load by decreasing the range of operation. It provides greater flexibility by allowing the regulating range to be decreased in 1¼ percent increments. The various regulation ranges together with the corresponding current capacities are listed on Table V, Page 21 for standard regulators. All that is necessary to adjust the range of regulation anywhere from ± 5 percent to ± 10 percent is to turn the adjusting knobs until the proper range of regulation is shown on the side of the position indicator. The upper and lower limits need not be the same. *(It is not necessary to remove the regulator from service to make this adjustment. Do not adjust the Vari-Amp selector switch while the tap changer motor is energized.)*

## MOUNTING

The *Accu/Stat* control may be remotely mounted and since its voltage sensing circuit has no moving parts, operation of the control is not affected by mounting position.

## OPERATION AT LESS THAN RATED VOLTAGE

JFR regulators can be provided with potential transformer with taps to permit operation at less than rated voltage. The transformer taps provide proper voltage for the control and motor circuits. When this feature is supplied, reconnect the potential transformer leads





Fig. 22 Untanking JFR regulator with portable inspection jack.

through the terminal block located under the terminal block cover as shown on the regulator name plate.

When operating the regulator at reduced voltage, it is necessary that the regulator be operated at reduced capacity. *The current rating of the regulator must not be exceeded except as noted in Table V, Page 21.*



[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

## Special Features

### UNIDIRECTIONAL BREATHER

The unidirectional breather is standard equipment on all regulators employing the open breathing system.

A unidirectional breather, which differs from ordinary breathers, protects the regulator and reduces the number of times filtering is necessary. Near perfect ventilation lowers the possibility of moisture condensation and rust formation, by providing a continuous flow of warm air over the oil.

The breather consists of a pipe with a screened opening near the bottom of the regulator tank, extending up through and projecting above the surface of the oil. On the top of the tank is a screened gooseneck breather outlet. Air enters the lower breather, is warmed by the hot oil in the regulator, rises in the pipe, flows across the air space, and out the upper breather. Movement of the air effectively reduces condensation and keeps the tank walls dry and free from rust.

### RESET DRAG HAND

To reset drag hand on position indicator, press the drag hand reset button on the control panel. Drag hands will reset automatically.

TABLE IV SYSTEM OPERATING VOLTAGES

2160	3750	4320	6480	6860	7200	10800	12420	12960	17928	108
2280	3960	4560	6840	7240	7600	11400	13110	13680	18924	114
2400	4160	4800	7200	7620	8000	12000	13800	14400	19920	120
2500	4330	5000	7500	7940	8330	12500	14375	15000	20750	125
2640	4580	5280	7920	8380	8800	13200	15180	15840	21912	132




Fig. 24 Circulation of air through unidirectional breather.

TABLE V REGULATING RANGES AND CURRENT CAPACITIES

VOLTS	50	100	150	200	250	300	350
2500	50 75 100 167 250 333 416.3	200 300 400 668 1000 1332 1665	220 330 440 668 1000 1332 1665	240 360 480 668 1000 1332 1665	270 405 540 668 1000 1332 1665	320 480 640 668 1000 1332 1665	320 480 640 668 1000 1332 1665
5000	50 100 167 250 333 416.3	100 200 334 500 668 835	110 220 367 550 668 835	120 240 401 600 668 835	135 270 451 668 668 835	160 320 534 668 668 835	160 320 534 668 668 835
7620	38.1 57.2 76.2 114.3 *167.0 *250.0 *333.0 *416.3 509.0 *667.0 *877.0	50 75 100 150 219/282 328/347 437/463 548/570 668 875/926 1151/1218	55 83 110 165 241/255 361/381 482/509 602/635 668 875/926 1151/1218	60 90 120 180 263/278 304/416 526/556 658/668 668 875/926 1151/1218	68 102 135 203 296/313 443/468 598/625 668/668 668 875/926 1151/1218	80 120 160 240 351/371 585/555 668/668 668/668 668 875/926 1151/1218	80 160 267 320 536 600

13800	69 138 207 276	50 100 150 200	55 110 165 220	60 120 180 240	68 135 203 270	80 160 240 320
14400	72 144 288 333 432 576 720 833	50 100 200 231 300 400 500 578	55 110 220 254 330 440 550 636	60 120 240 277 360 480 600 668	68 135 270 312 405 540 668 668	80 160 320 370 480 640 668 668
19900	100 200 333 400 667 833	50 100 167 200 335 418	55 110 184 220 368 459	60 120 200 240 402 551	68 135 225 270 452 600	80 160 267 320 536 600

\*Regulators rated 167kVA and above at 7620/13200 Y volts are capable of carrying current corresponding to rated kVA when operated at 7200/12470 volts.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

## FORCED AIR COOLING

For forced air cooling, fans are mounted on radiators and are usually automatically controlled by means of changes in oil temperature (see Connection Diagram.)

The thermometer located in the top transformer oil contains two identical switches which control fan operation when fan control switch is in "Auto" position.

The switches are normally set to start the fans at 65° C and to stop them at 55° C top oil temperature, but may be adjusted plus or minus 5° C.

A thermal overload relay is mounted on each fan motor. With this arrangement any fan that develops trouble will be automatically disconnected from the line without affecting the other fans of the system. One fan can be removed from the radiators without affecting the operation of the others. When fans are out of service, care must be exercised to prevent overloading the regulator. Fans should be removed and replaced carefully to prevent damage to the radiators.

The fans used for cooling require a minimum of attention. Fans with plain sleeve bearings or Oil-Lite sleeve bearings should be oiled at least once a year with a good grade of SAE 10-W mineral engine oil which does not thicken in cold weather. Oil must be added to sleeve bearings before starting the motor for the first time after installation.

Fans equipped with ball bearing motors are packed with grease before shipment and should be greased at least once a year with a soda soap ball bearing grease of medium consistency furnished by a reliable supplier.

For fans that are seldom used, the frequency of greasing or oiling may be less than outlined above, but it is recommended that this lubrication be placed on a yearly schedule. It is often possible to determine by inspection whether lubrication is required.




Fig. 25 Control circuit forced air cooling.

## REMOTE MOUNTING OF CONTROL EQUIPMENT

When the JFR regulator is pole mounted, the *Accu/Stat* control compartment may be remotely mounted with the use of a remote control kit. This kit consists of oil and moisture resistant color coded wires, which are 20', 25', or 30' in length. These wires are enclosed in a steel flexible conduit covered with a plastic coating to prevent moisture from entering.

**Installation of the Remote Mounting Kit:** Remove the *Accu/Stat* control panel, steel conduit, and control wires from regulator. Then connect the remote mounting kit to the cover and connect the control leads to the terminal block on top of the cover. After the kit has been connected to the regulator, connect the other end of the remote mounting kit to the control panel and then fasten the leads to the polarized jack plug inside the control compartment. When this is completed, the regulator is then suitable for operation with the control panel remotely mounted.



Fig. 26 Remote mounted control compartment.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

## Optional Features

### METER SOCKETS

A voltage regulator contains both a potential transformer and a current transformer as inputs for the control panel. These same transformers can be used to provide various inputs for metering equipment. Meter sockets can be provided from the factory to accommodate a variety of specific meters including the following:


Current Demand Ammeter (Sangamo Type ADS or equal)

Max-Min Voltmeter (Sangamo Type V4s or equal)


KW-kVAR Meter (Sangamo Type CCW/CCVAR or equal)

The meter socket will be provided with a 0-0.2 amp current input and a 120 volt potential input from the polarized jack plug as standard, depending on which is required. Specific wiring arrangements are shown below. An auxiliary 0.2-5.0 amp current transformer may also be provided to effectively provide a 0-5.0 amp input to the meter socket.


Meter Socket — Current Demand Meter




Meter Socket — kW/kVAR Meter



Meter Socket — Max-Min Voltmeter



Meter Socket — Demand Meter with Auxiliary Current Transformer



[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)





## Major Components

### INSTRUCTIONS FOR ORDERING PARTS


When ordering parts, give the quantity of parts required, the regulator serial number, parts list item number, complete description, and method of shipping. State whether for emergency repair, maintenance, spare parts, etc.

All shipments will be made F.O.B. Factory.



Accu/Stat control panel door is hinged at bottom of weathertight compartment and opens to provide a workshelf. (See parts list description on Pages 24, 25).



Component Parts	Page
Accu/Stat Control Panel	
Type IJ-2 .....	25
Type IJ-2A .....	25
Quick Break Mechanism	
Type TLG .....	27
Type TLF .....	29
Dial Switch	
Type TLG .....	26
Type TLF .....	28
Bushing Assembly	
15 kV, 38.1-167 kVA .....	30
15 & 23 kV, 72-833 kVA .....	31
By-Pass Arrester Assembly	
1.5 kV .....	30
3 & 6 kV .....	31



[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# Accu/Stat Control Panel

## Types IJ-2, IJ-2A



Accu/Stat control equipment is mounted in compact, easily accessible cabinet. Entire unit can be lifted from its hinges for shop testing.


Accu/Stat Control Panel Complete  
 Accu/Stat Control Panel (Less Cabinet)  
 Printed Circuit Board Complete  
 Motor Relay  
 Line Drop Compensator Reactor TR-3  
 Auxiliary Current Transformer TR-2  
 Terminal Block — 4 Pole (IJ-2)  
 Terminal Block — 9 Pole (IJ-2A)  
 Reactance Rotary Switch (Fine)  
 Reactance Rotary Switch (Coarse)  
 Resistance Rheostat  
 Compensator Polarity Switch  
 Voltage Level Switch (Fine)  
 Voltage Level Switch (Coarse)  
 Transfer Switch  
 Voltage Source Switch  
 Panel Faceplate  
 4-Amp Motor Fuse  
 4/10 Amp S/Io-B/o Panel Fuse  
 Control Knob (Transfer Switch)  
 Control Knob (Black) Bandwidth Adjustment  
 Control Knob (Black) Voltage Level  
 Control Knob — Compensator Polarity Switch  
 Control Knob (Red) Resistance Rheostat  
 Control Knob (Red) Line Drop Compensator Switch  
 4 Amp Fuse Holder — for 1659B Fuse  
 4/10 Amp Fuse Holder — for 1659C Fuse  
 Control Knob — Time Delay Rheostat  
 Snap-in Breather Plug  
 Operation Counter  
 Drag Hand Reset Button and Switch  
 Neutral Light — Bulb Only  
 Neutral Light — Socket

Bandwidth Indicator  
 Terminal Posts — Specify Color  
 Bandwidth Adjustment Rheostat  
 Sensing Transformer (IJ-2)  
 Sensing Transformer (IJ-2A)  
 C-2, C-3 Capacitor  
 C-4 Capacitor  
 C-5, C-6 Capacitor  
 C-7 Capacitor  
 C-9 Capacitor  
 C-11 Capacitor  
 C-12, C-13 Capacitor  
 C-14 Capacitor  
 D-1 thru D-8, D-10, D-15, D-26, D-27 Diodes  
 D-9, D-11 thru D-14, D-20, D-21, D-23, D-24 Diodes  
 Z-1 Zener Diode  
 Z-2 Zener Diode  
 Z-3, Z-4 Zener Diode  
 T-1, T-4, T-6, T-7, T-8, T-11, T-12, T-13 Transistors  
 T-2, T-5, T-10 Transistors  
 T-9 Transistor  
 IC-1 Voltage Regulator  
 IC-2 Operation Amplified  
 RH-2 Potentiometer  
 RH-4 Potentiometer  
 FR, GR Reed Relay  
 C-1 Capacitor  
 C-15 Capacitor  
 T-3 Transistor  
 Insulating Heatsink for T-1, T-3 Transistors  
 C-16 Capacitor  
 Gasket — Control Cabinet  
 Terminal Block — 10 Pole  
 Control Cabinet

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# Dial Switch

## Type TLG



204661-A1

Bakelite Panel  
 Glass Polyester Panel  
 Reversing Main Shaft  
 Main Stationary Contacts  
 Reversing Stationary Contact R.H.  
 Reversing Stationary Contact L.H.  
 Neutral Stationary Contact  
 Collector Ring  
 Collector Hub  
 Reversing Switch Arm


Reversing Switch Finger Assembly  
 Reversing Switch Hub Finger Assembly  
 Drive Arm — Bakelite  
 Drive Arm — Glass Polyester  
 Hub Finger Support  
 Ring Finger Support  
 Main Moving Finger Assembly  
 Hub Finger Assembly  
 Ring Finger Assembly  
 Phenolic Drive Pin

\*Indicate S/N when ordering.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# Clutch Break Mechanism

## Type TLG



Mounting Frame Assembly  
 Motor  
 Drive Spring Assembly  
 Latch Assembly  
 Latch Spring (not shown)  
 Latch Pin (not shown)  
 Reversing Switch Drive Arm — Bakelite  
 Reversing Switch Drive Arm — Bakelite  
 Rev. Switch Drive Arm —  
 Glass Polyester  
 Interlock Disc and Drive Assembly  
 Main Shaft w/Sleeve Bearing  
 Motor Mounting Bracket  
 Operation Counter Switch Assembly  
 Roller Chain Position Indicator  
 Reversing Switch Shaft


Reversing Switch Assembly  
 Spring  
 Spring Tube  
 Position Indicator Drive Mechanism  
 Neutral Switch  
 Index Plate  
 Motor Sprocket  
 Capacitor for Motor  
 Sprocket Assembly  
 Main Drive Chain Assembly  
 Drive Pin  
 Phenolic Spacer  
 Flexible Shaft

\*Indicate S/N when ordering.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# Dial Switch

## Type TLF



Bakelite Panel  
 Stationary Contact  
 Neutral Stationary Contact  
 Stationary Contact — L.H.  
 Stationary Contact — R.H.  
 Collector Ring  
 Shaft Assembly  
 Main Finger Assembly (each)  
 Contact Finger Assembly Collector Ring  
 Contact Finger Assembly Collector Hub

Drive Plate  
 Contact Finger Assembly — Rev. Switch  
 Contact Support Assembly  
 Reversing Drive Pin  
 Reversing Shaft  
 Reversing Shaft  
 Spacer  
 Contact Finger Support  
 Contact Finger Support  
 Reversing Switch Stop


\*Indicate S/N when ordering.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# Quick Break Mechanism

## Type TLF

www.electricalparts.com



580328-73

- Counter Switch Assembly
- Neutral Switch\*
- Mounting Frame
- Motor
- Drive Spring Tube
- Drive Spring
- Spacer
- Notched Index Plate
- Latch
- Latch Spring
- Latch Pin
- Reversing Switch Drive Arm

- Interlock Disc and Drive Sprocket Assembly
- Quick Break Mechanism Shaft
- Actuating Arm Assembly
- Phenolic Spacer
- A-Frame
- Drive Chain for Position Indicator
- Motor Sprocket
- Motor Capacitor
- Actuating Disc and Sprocket
- Main Drive Chain
- Position Indicator Drive Mechanism
- Reversing Switch Spring Assembly
- Flexible Shaft

\*Indicate S/N when ordering.



[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

**DISMOUNTING AND BY-PASS ARRESTERS**

**BUSHINGS\***

Bushing Assembly for 15 kV	50	5000
	38.1 thru 76.2	7620
	69 thru 138	13,800
Bushing Assembly for 15 kV	50	2500
	100	5000
	114.3 thru 167	7620
Bushing Assembly for 15 kV	75	2500
Bushing Porcelain for 15 kV	50	5000
	38.1 thru 76.2	7620
	69 thru 138	13,800
Bushing Porcelain for 15 kV	50	2500
	100	5000
	114.3 thru 167	7620
	75	2500
Bushing Porcelain for 15 kV		
Clamping Ring for 5400P and R Ratings		
Clamping Ring for 5400S Rating		
Cushion Spring		
Cap Screw		
Bushing Cap Line Terminal for 5400P Rating		
Bushing Cap Line Terminal for 5400R and S Ratings		
Gasket		
Gasket		

\*Indicate Regulator Serial Number.



**BY-PASS ARRESTER\***


By-Pass Arrester Assembly 1.5 kv	2500, 5000, 7620
By-Pass Arrester Crystal 1.5 kv	
Mounting Bracket Assembly	

\*Indicate Regulator Serial Number.

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)

# Bushings and By-Pass Arresters

com




## BUSHING\*

Bushing Assembly, 15 kV	100 thru 167	2500
	167	5000
	250 thru 509	7620
Bushing Assembly, 15 kV	207	13,800
Bushing Assembly, 23 kV	72 thru 144	14,400
	100 thru 200	19,920
Bushing Assembly, 15 kV	333 thru 416.3	2500
	333 thru 416.3	5000
Bushing Assembly, 23 kV	576 thru 833	14,400
Bushing Assembly, 23 kV	288	14,400
	333 thru 400	19,920
Bushing Assembly, 15 kV	333	12,000
Bushing Assembly, 23 kV	333 thru 432	14,400
Bushing Assembly, 23 kV	667 thru 833	19,920
Bushing Porcelain, 15 kV	100 thru 167	2500
	167	5000
	250 thru 509	7620
Bushing Porcelain, 15 kV	207	13,800
Bushing Porcelain, 23 kV	72 thru 144	14,400
	100 thru 200	19,920
Bushing Porcelain, 15 kV	333 thru 416.3	2500
	333 thru 416.3	5000
Bushing Porcelain, 23 kV	576 thru 833	14,400
Bushing Porcelain, 23 kV	288	14,400
	333 thru 400	19,920
Bushing Porcelain, 15 kV	333	12,000
Bushing Porcelain, 23 kV	333 thru 432	14,400
Bushing Porcelain, 23 kV	667 thru 833	19,920
Clamping Ring for 5400T X, Z and AB Ratings		
Clamping Ring for 5400U V, W. (SL Bushing only), Y and YY Ratings		
Clamping Ring for 5400W Rating S and L Bushings only		
Cushion Spring		
Gasket		
Gasket		
Gasket		
Bushing Cap Line Terminal† for 5400T, X, YY and AB Ratings		
Bushing Cap Line Terminal† for 5400U, Y and Z Ratings		
Bushing Cap Line Terminal† for 5400V Rating		
Cap Screw		

†Units rated 250 kVA and above, 2500 and 5000 volts are not supplied with line terminals.

\*Indicate Regulator Serial Number.



3 kv By-Pass Arrester and 6 kv By-Pass Arrester

## BY-PASS ARRESTER\*

By-Pass Arrester Assembly, 3 kV	12,000-13,800-14,400
By-Pass Arrester Crystal, 3 kV	
Mounting Bracket Assembly	
By-Pass Arrester Assembly, 6 kV	19,920
By-Pass Arrester Crystal, 6 kV	
Mounting Bracket Assembly	

\*Indicate Regulator Serial Number

[www.ElectricalPartManuals.com](http://www.ElectricalPartManuals.com)