


INSTRUCTIONS

Switchgear

AIR CIRCUIT BREAKERS



**Type AK-1-50-1
Manually Operated**

GENERAL  **ELECTRIC**

CONTENTS

| | PAGE |
|--|------|
| INTRODUCTION | 3 |
| RECEIVING, HANDLING, AND STORAGE | 3 |
| INSTALLATION | 3 |
| LOCATION | 3 |
| MOUNTING | 3 |
| CONNECTIONS | 3 |
| OPERATION | 4 |
| MAINTENANCE | 4 |
| INSPECTION | 4 |
| REPAIR AND REPLACEMENT | 4 |
| TROUBLE SHOOTING | 5 |
| BASIC BREAKER COMPONENTS | 5 |
| ARC QUENCHER | 5 |
| POLE UNIT ASSEMBLY | 5 |
| OPERATING MECHANISM | 9 |
| AUXILIARY SWITCH | 10 |
| PROTECTIVE DEVICES | 10 |
| TIME DELAY UNDERVOLTAGE TRIPPING DEVICE | 10 |
| INSTANTANEOUS UNDERVOLTAGE TRIPPING DEVICE | 11 |
| SERIES OVERCURRENT TRIPPING DEVICE | 12 |
| REVERSE CURRENT TRIPPING DEVICE | 14 |
| MISCELLANEOUS | 15 |
| SHUNT TRIPPING DEVICE | 15 |
| BELL ALARM AND LOCKOUT DEVICE | 17 |
| DISCONNECTS | 17 |
| RENEWAL PARTS | 17 |

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

AIR CIRCUIT BREAKER

TYPE AK-1-50-1, MANUALLY OPERATED

INTRODUCTION

Before unpacking, installing, or attempting to operate the Type AK-1-50-1 Air Circuit Breaker described herein, these instructions should be described thoroughly and carefully read.

The ratings for the AK-1-50-1 are as follows:

| Continuous Current Rating | Interrupting Rating | Voltage | |
|---------------------------|---------------------|---------|-----|
| RMS Amperes | RMS Amperes | AC | DC |
| 15* to 1600 | 50,000 | 600 | 250 |

*The interrupting rating is limited on the lower rated coils.

These circuit breakers are generally used for protection and control of apparatus and branch circuits, including equipment in buildings, industries, power stations and for marine applications within the ratings designated.

The AK-1-50-1 breaker for D.C. applications differs from the breaker used for A.C. applications. The difference in D.C. breaker is an extra arcing contact per pole with a corresponding difference in the upper stud and interrupter.

These instructions apply to breakers used for both D.C. and A.C. applications.

RECEIVING, HANDLING AND STORAGE

Immediately upon receipt of the circuit breaker, an examination should be made for any damage or loss sustained in transit. If injury or rough handling is evident, a damage claim should be filed at once with the transportation company and the nearest General Electric Sales Office should be promptly notified.

The circuit breaker should be unpacked as soon as possible after being received as difficulty may be experienced in making claim for damage, not evident upon receipt, if delayed. Care should be used in unpacking to avoid damaging any of the breaker parts. Be sure that no loose parts are

missing or left in the packing material. Blow out any dirt or particles of packing material that may have accumulated on the breaker parts.

If the circuit breaker is not installed at once, it should be stored in a clean dry place and preferably placed in a vertical position. It should be supported to prevent bending of studs or damage to the breaker parts. It is advisable not to cover the breaker with any packing or other material that absorbs moisture which may cause corrosion of breaker parts. A covering of paper will prevent dust from settling on the breaker parts.

INSTALLATION

LOCATION

The Air Circuit Breaker should be installed in a clean dry place where it is readily accessible for operation, inspection and proper maintenance. Special enclosures are available for the installation of circuit breakers which may be subjected to dust and moisture or other unfavorable locations.

MOUNTING

Dead front circuit breakers are designed for mounting in a switchboard or an enclosing case. The mounting of dead front breakers consists of placing the breakers within the enclosed structure and connecting the power buses or cables and making the necessary control connections. The standard mounting depth from the back surface of the breaker base to the back side of the front panel

is 16". The front cover of dead front breakers consists either of a hinged door with cut-out or a plate bolted to the panel.

The structural surface to which the breaker is bolted must be flat throughout and the supporting structure must be of sufficient strength to hold the breaker firmly in place. Minimum cutout dimensions must be maintained in order to have proper electrical clearance.

CONNECTIONS

The connections to the circuit breaker studs should be firmly clamped or bolted in place to prevent excessive heating. The connecting cables or bus bars should have a current-carrying capacity specified to limit their temperature rise to that specified for the breakers. If these connecting

cables or bus bars are not of sufficient size, heat will be conducted from them to the breaker so that the breaker cannot carry normal current without exceeding the specified temperature rise.

Connecting cables or bus bars should be supported so that the breaker studs will not be subjected to unnecessary strains.

OPERATION

The circuit breaker is closed manually by an operating handle. To close the breaker the operating mechanism must be reset, this is accomplished by rotating the operating handle 165° counter clockwise. The breaker is then closed by rotating the operating handle 165° clockwise. The breaker may

be tripped manually by pushing a trip button located in the front escutcheon, or automatically by any tripping device with which the breaker is equipped. After the breaker is tripped it cannot be closed again until the operating mechanism is reset.

MAINTENANCE

INSPECTION

BEFORE INSPECTION OR ANY MAINTENANCE WORK IS DONE, BE SURE THAT THE BREAKER IS IN THE OPEN POSITION. ALL ELECTRICAL POWER, BOTH PRIMARY AND CONTROL SOURCES, SHOULD ALSO BE DISCONNECTED.

Periodic inspection of the circuit breaker is recommended at least once a year. More frequent inspections are recommended, if severe load conditions, dust, moisture or other unfavorable conditions exist. A complete inspection of the breaker, including contacts and arc quenchers, should always be made after the breaker has opened a severe short circuit.

After the breaker has been installed, as well as at the regular inspection periods, slowly operate it manually several times as described above and observe whether the contacts line up properly and make sure that all parts move freely without binding or excessive friction.

If the breaker remains open or closed for a period of six months or more it is recommended that arrangements be made to open and close it several times in succession, preferably under load.

If overheating, not caused by overcurrent, is observed, a complete inspection of the breaker should be made including connections, contacts and flexible connectors.

At all times it is important not to allow pencil lines, paint, oil or other foreign materials on the insulating surfaces of the breaker as they may cause low resistance between points of different potential and result in eventual electrical breakdown.

The contacts should be inspected at the regular inspection periods and always after a known

severe short circuit has been opened, to ascertain whether the contacts are badly worn or pitted, in which case they should be dressed or replaced. It is necessary to remove the arc quenchers in order to properly inspect the contacts.

LUBRICATION

In general, the circuit breaker requires little lubrication. Bearing points and sliding surfaces should be lubricated at the regular inspection periods with a thin film of G.E. Lubricant D50H15. Hardened grease and dirt should be removed from latch and bearing surfaces by using kerosene. **ALL EXCESS LUBRICANT SHOULD BE REMOVED WITH A CLEAN CLOTH IN ORDER TO AVOID ANY ACCUMULATION OF DIRT OR DUST.**

The use of cotton waste to wipe bearing surfaces should be avoided, as the cotton ravelings might become entangled under the bearing surfaces and destroy the surface of the bearing.

REPAIR AND REPLACEMENT

In order to replace contacts, operating mechanism or series overcurrent tripping devices, the front frame must be separated from the back frame. To separate the two frames proceed as follows:

1. The breaker must be open.
2. Remove the two opening springs from the outside pole units.
3. Remove the clevis pin, (14) Fig. 2.
4. Remove the four bolts from the back frame by using a socket wrench with an extension. The two frames can now be separated.

NOTE: It is recommended that the breaker be fastened to a suitable mounting base with a sling or hook to hold the front frame as the bolts are being removed.

TROUBLE SHOOTING

| <u>TROUBLE</u> | <u>PROBABLE CAUSE</u> | <u>REMEDY</u> |
|-----------------------------|---|---|
| Overheating | Contacts not aligned. Contacts dirty, greasy or coated with dark film. Contacts badly burned or pitted. Current carrying surfaces dirty. Bolts and nuts of points at terminal connection not tight. Current in excess of breaker rating. Excessive ambient temperature. | Adjust contacts. Clean contacts. Replace contacts. Clean surfaces of current carrying parts. Tighten, but do not exceed elastic limit of bolts or fittings. Decrease load, rearrange circuit or install larger breaker. Provide adequate ventilation. |
| Failure to Trip | Travel of tripping device does not permit positive release of tripping latch. Worn or damaged trip unit parts. | Re-adjust or replace device. Replace Trip Unit. |
| False Tripping | Binds in overload device. | Replace overload device. |
| Failure to close and latch. | Binding in attachments preventing resetting of latch. Chipped or worn latch. Latch out of adjustment. Latch return spring too weak or broken Hardened or gummy lubricant | Re-align and adjust attachments. Replace latch. Adjust latch. Replace spring. Clean bearing and latch surfaces. |

BASIC BREAKER COMPONENTS

ARC QUENCHER

The arc quenchers should be inspected at the regular inspection period and if the barriers are cracked or eroded, they should be replaced.

REPLACEMENT

1. Remove the channel shaped retaining bar by removing two screws.
2. Lift the quencher clear of the movable arcing contacts.
3. During replacement be careful not to overtighten the screws which secure the channel shaped retaining bar. Overtightening the screws will bow the bar and leave the center arc quencher loose.

INSPECTING INNER, SLIDE, AND POCKET BARRIERS, FIG. 1.

1. Remove arc quenchers (see above).
2. Remove screws holding spacer block (8).
3. Remove spacer block, steel backplate (7) and compound support (6).
4. Slide muffler (5) from slot and remove. The inner barriers (4) can now be removed for inspection.
5. Remove nut and withdraw stud from cap (1).
6. Remove cap (1). The side (2) and pocket (3) barriers can now be removed.
7. Re-assemble and replace the arc quenchers in the reverse order. Tighten all fastenings after replacement.

POLE UNIT ASSEMBLY

Each pole unit assembly consists of a set of arcing contacts, a set of main contacts, the operating linkage and the mounting base. See Fig. 2.




Fig. 1 Dis-Assembly of Arc Quencher to Inspect, Inner, Side and Pocket Barriers

The stationary arcing contact consists of a set of parallel contact fingers (2), pin (3), and compression springs (22), which provide continuous contact pressure for the full travel of the contacts. Flexible braid leads shunt the pivot pin to prevent possible pitting at the pivot point when interrupting high currents.

The movable arcing contact assembly consists of parallel contact arms (4) carried on two movable pivot pins (8) and (19). The arcing contacts interleaf the main contacts and pivot with them about pin (19). This relative motion is obtained by linkages from the upper pin (7) to the breaker mechanism.


The stationary main contact assembly includes main contacts and intermediate contacts. The intermediate contact surface extends beyond the main contacts and will, therefore, make before the main contacts and break after the main contacts. The number of contacts for each rating is given in Table I.

The movable main contacts pivot around a stationary pin (18), which holds them to the lower block, motion is obtained from a second pin (7), connected by an insulated link (12) to the breaker mechanism. Steel springs (17) force the contacts against the pin to prevent pitting at the pivot point. The movable main contact assembly also contains main and intermediate contacts.

TABLE I

| Breaker Type | Main Contacts | | | Intermediate Contacts | | | Arcing Contacts | | |
|--------------------|-----------------|---------------|----------------|-----------------------|---------------|----------------|-----------------|---------------|----------------|
| | No. of Contacts | Pressure lbs. | Wipe in Inches | No. of Contacts | Pressure lbs. | Wipe in Inches | No. of Contacts | Pressure lbs. | Wipe in Inches |
| AK-1-50-1 For D.C. | 3 | 55-65 | 1/16-3/32 | 1 | 55-65 | * | 3 | 25-35 | 5/16-7/16 |
| AK-1-50-1 For A.C. | 3 | 55-65 | 1/16-3/32 | 1 | 55-65 | * | 2 | 25-35 | 5/16-7/16 |

* The intermediate contact wipe should be at least 1/16" more than the main contact wipe.



- | | | |
|----------------------------|---------------------------------|--------------------------------|
| 1. Screw | 10. Pin (Insulating Link) | 19. Pin (Movable Arcing Cont.) |
| 2. Sta. Arcing Contact | 11. Pin (Side Link) | 20. Side Link |
| 3. Pin (Sta. Arcing Cont.) | 12. Link | 21. Spring (Sta. Main Cont.) |
| 4. Movable Arcing Contact | 13. Clevis | 22. Spring (Sta. Arcing Cont.) |
| 5. Braid | 14. Clevis Pin | 23. Upper Stud |
| 6. Movable Main Contact | 15. Lower Stud | 24. Pin (Sta. Main Cont.) |
| 7. Shouldered Pin | 16. Pole Unit Base | 25. Stationary Main Contact |
| 8. Pin (Arcing Cont. Link) | 17. Spring (Main Movable Cont.) | 26. Screw |
| 9. Insulating Link | 18. Pin (Movable Main Cont.) | 27. Screw |

Fig. 2 Pole Unit Assembly

In order to function properly, a definite amount of contact pressure and contact wipe must exist between the movable and stationary contacts. Table I gives the figures for contact wipe and contact pressure. Both wipe and pressure should be checked during the regular inspection period.

MEASURING CONTACT PRESSURE, FIG. 2

1. Remove arc quenchers, (see replacements under "Arc Quenchers").
2. With the breaker open, measure the "B" dimension of the stationary arcing contact with the spring (22) full compressed.
3. Place a push-type scale against the stationary arcing contact and push the contact backward until the "B" dimension is 1/16" more than the measurement taken in item 2. The scale should then be read.

MEASURING CONTACT WIPE, FIG. 2

1. Remove the arc quencher.
2. With the breaker open, measure the horizontal distance from the edge of the contact to the surface behind it. ("B" and "C" dimensions).
3. Close the breaker and repeat item 2. The difference between the readings in item "2 and 3" determines the wipe of the contacts. For safety reasons be extremely careful not to trip the breaker.

ADJUSTING CONTACT WIPE AND PRESSURE, FIG. 2

1. With the breaker open, measure dimension "A".
2. Remove the clevis pin (14) and increase dimension "A" to increase the wipe, and decrease dimension "A" to decrease the wipe by turning the clevis (13).

NOTE: If the proper contact pressure does not exist when the contact wipe is within its limits, the stationary contact springs should be replaced.

REPLACEMENT, FIG. 2

1. Remove the upper plate by removing two screws (1).
2. Remove screw from braid (5).
3. Remove pin (3) allowing the stationary contacts and spring (22) to fall free.
4. Install new springs and stationary arcing contacts in reverse order.
5. Adjust contact wipe and pressure (see "Adjusting Contact Wipe and Pressure").

MOVABLE ARCING CONTACTS (4)

The movable arcing contacts should be replaced when the stationary arcing contacts are replaced.

1. Separate the front frame from the pole unit frame (see "Repair and Replacement").

1. Stationary Arcing Contact
2. Movable Arcing Contact
3. Stationary Main Contact
4. Contact Stop
5. Movable Main Contact
6. Cross Bar
7. Series Overcurrent Device
8. Movable Intermediate Contact
9. Stationary Intermediate Contact




Fig. 3 Front View of Back Frame Assembly

2. Remove pins (8) and (19) and withdraw the contacts.
3. Re-assemble parts in the reverse order.

STATIONARY INTERMEDIATE CONTACTS (9), FIG. 3

1. Remove screws (27) and remove bracket which holds pin (24) in place. See Fig. 2.
2. Remove clamp which holds lower part of stationary contact.
3. Remove pin (24) and screws (26).
4. Lift out the intermediate contacts.
5. Replace the contacts remembering to match the intermediate contacts on each pole.
6. Re-assemble in the reverse order.

MOVABLE INTERMEDIATE CONTACTS (8), FIG. 3.

1. Remove the movable arcing contacts as described above.
2. Loosen spring (17). See Fig. 2.
3. Slide link (12) to the side and off of pin (7).
4. Slide pins (18) and (7) far enough to the side to allow the movable intermediate contact to be replaced.
5. Reassemble parts in reverse order.

Always check the contact wipe and pressure following contact replacement.

OPERATING MECHANISM

The operating mechanism is supported in a

"U" shaped steel frame in front of the center pole unit. It consists of a cam (5), linkage (6), prop (7), roller latch (10), trip latch and shaft (11). Refer to Fig. 4.

The breaker is closed by rotating the operating handle 165° counter-clockwise which allows cam reset spring (17) to pull the cam (5) into the reset position. The handle is then turned 165° clockwise thereby causing roller (4) to engage cam (5) thus causing the linkage to straighten, which moves the cross bar (6) Fig. 3, and movable contacts to the closed position.

The breaker mechanism is tripped by rotating the trip shaft and releasing trip latch (11) which causes the linkage to collapse, allowing the opening springs to pull the cross bar and movable contacts to the open position. The mechanism does not reset until the operating handle is rotated 165° counter-clockwise. Latch stop (12) limits the rotation of the trip shaft and thus determines the amount of latch engagement.

ADJUSTMENTS, FIG. 4

With the breaker open the latch adjustments are as follows:

Latch clearance -

1. Reset the mechanism by turning the operating handle 165° counter-clockwise.




Fig. 4 Operating Mechanism

Fig. 4 (2150146)

2. The vertical clearance between the trip latch (11) and roller (10) should be $1/64''$ to $1/32''$.
3. To obtain this clearance the adjusting screw (8) is turned. Be certain the nut is tightened on the adjusting screw (8) after obtaining proper clearance.

Latch engagement -

1. Mechanism in reset position.
2. Form stop (12) until center line of trip latch (11) passes through the center of roller (10).

REPLACEMENTS, FIG. 4

Prop reset spring (9) - unhook and replace.
Cam reset spring (17) - unhook and replace.





Fig. 5 Rear View of Front Frame Assembly

AUXILIARY SWITCH

The auxiliary switch is used to make and break various control circuits as the circuit breaker is opened and closed.

The auxiliary switch, refer to Fig. 6, is mounted on the left side of the front frame. As



- | | | |
|---------------------|--------------------|---------------------|
| 1. Plate | 7. Indicator | 12. Operating Rod |
| 2. Auxiliary Switch | 8. Adjusting Plate | 13. Bracket |
| 3. Spring | 9. Cross Bar | 14. Link |
| 4. Indicator | 10. Bolt | 15. Operating Shaft |
| 5. Pivot Pin | 11. Extension | 16. Bolt |
| 6. Frame | | |

Fig. 6 Auxiliary Switch Linkage

the cross bar (9) moves, with the contacts, to the open or closed position it operates a rectangular link (14) through an operating rod (12). The rectangular link rotates the operating shaft (15) of the auxiliary switch, which, through cams located on this shaft opens and closes the auxiliary switch contacts. The top terminals of the switch are "a" contacts (open when the breaker is open) and the bottom terminals are "b" contacts (closed when the breaker is open).

REPLACEMENT, FIG. 6



1. Disconnect all leads to auxiliary switch.
2. Remove two mounting bolts (16).
3. Disengage auxiliary switch shaft (15) from the rectangular link (14).
4. Set arrow on new auxiliary switch shaft as shown in Fig. 6.
5. Push auxiliary switch shaft (15) into square hole in link (breaker open).
6. Replace mounting hardware and wiring.

PROTECTIVE DEVICES

TIME DELAY UNDERVOLTAGE TRIPPING DEVICE

This device is mounted to a bracket on the left side of the operating mechanism (looking from the front). The purpose of this device is to trip

the breaker for undervoltage. For rated voltage, the armature (3) is attracted by magnet (14). If the voltage falls below the rated value the magnet (14) releases the armature (3). Spring (4) then pulls armature (3) upward against the restraining force of the oil in cylinder (10); this action causes a time delay. When the spring overcomes the restraining



STAGE OF SWITCH SHOWING
BREAKER IN OPEN POSITION

- | | | | |
|------------------|-----------------|-------------------|-------------------|
| 1. Mounting Bolt | 5. Bottom Cover | 9. Contact Spring | 13. 'b' Contacts |
| 2. Tie Bolt | 6. End Plate | 10. Rocker Arm | 14. 'b' Terminals |
| 3. Shaft | 7. Top Cover | 11. Pin | 15. 'a' Terminals |
| 4. Screw | 8. 'a' Contacts | 12. Can | 16. Barrier |

Fig. 7 Rotary Auxiliary Switch

force of the oil, the armature engages screw (20) thus rotating the trip shaft and opening the breaker. (For parts reference refer to Fig. 8).

ADJUSTMENTS, FIG. 8

An adjusting screw (20) in the trip lever is used to allow from 1/32 to 1/16 inch overtravel after tripping the breaker.

Adjusting screw (2) is used to adjust the armature so that it will pick-up at 80% of normal voltage and drop out between 30% and 60% of normal voltage.

Adjusting nut (8) on connecting rod (11) is intended for a minimum amount of adjustment of the time delay setting.

From 1/4 to 3/8 inch of oil should be maintained in the cylinder at all times. In order to make an inspection of the oil, the cylinder may be unscrewed from the cap. G.E. silicone oil 9981LT4 NV or similar grade should be used in the cylinder.

REPLACEMENTS, - - Time Delay Undervoltage Device, Fig. 8

1. Disconnect coil leads
2. Remove two screws from bracket (1).

(Bracket is omitted when instantaneous undervoltage device is used).

3. Remove four mounting screws (21) and remove device.
4. Install new device in reverse order.


Coil (15)

1. Disconnect leads to coil.
2. Remove two screws (16).
3. Remove magnet and coil assembly.
4. Straighten laminations around shading ring (5).
5. Remove shading ring and straighten lower end of coil clamp (13).
6. Remove coil. Install new coil in reverse order.

INSTANTANEOUS UNDER VOLTAGE TRIPPING DEVICE

The undervoltage tripping device is constructed similarly to the time delay undervoltage tripping device with the exception that the cylinder (10), plunger (12), connecting rod (11), clevis (7), bracket (1) and adjusting nut (8), as shown in Fig. 8 are omitted.

The adjustments and replacement for this device are also the same as those for the time delay undervoltage tripping device.



- | | | |
|--------------------------|--------------------|-------------------------|
| 1. Bracket | 8. Adjusting Nut | 16. Screws |
| 2. Adjusting Screw & Nut | 9. Cap | 17. Pin |
| 3. Armature | 10. Cylinder | 18. Adjusting Screw |
| 4. Spring | 11. Connection Rod | 19. Locking Wire |
| 5. Shading Ring | 12. Plunger | 20. Adjusting Screws |
| 6. Pin | 13. Clamp | 21. Mounting Screws |
| 7. Clevis | 14. Magnet | 22. Trip Paddle & Clamp |
| | 15. Coil | |

Fig. 8 Time Delay Undervoltage Tripping Device

SERIES OVERCURRENT TRIPPING DEVICE

Each series overcurrent tripping device is enclosed in a molded case and mounted by three screws and a bracket to the lower part of the pole unit base.

The device can be provided with the following tripping combinations:

1. Long time delay, short time delay and instantaneous tripping.
2. Long time and short time delay tripping only.
3. Long time delay and instantaneous tripping.
4. Short time delay and instantaneous tripping.
5. Short time delay tripping only.
6. Instantaneous tripping.
 - (a) Adjustable
 - (b) Nonadjustable

Short Time Delay Tripping, Fig. 9

The armature (7) is retained by calibrating spring (8). After the magnetic force, produced by and overcurrent condition, overcomes this restraining force, the armature movement is further retarded by an escapement mechanism which produces an inverse time delay characteristic. The mechanism is shown on Fig. 9a.

Long Time Delay Tripping, Fig. 9


The armature (10) is retained by the calibration spring (11). After the magnetic force, produced by an overcurrent condition, overcomes this restraining force, the armature movement is further retarded by the flow of silicone oil in a dashpot, which produces an inverse time delay characteristic. The mechanism is shown on Fig. 9b.

Instantaneous Tripping, Fig. 9

- (a) Adjustable instantaneous tripping takes place after the magnetic force produced by an overcurrent condition, overcomes the restraining force of the calibration spring which can be adjusted by the calibration clamp nut (14).
- (b) Nonadjustable instantaneous tripping takes place after the magnetic force produced by an overcurrent condition overcomes the restraining force of a nonadjustable spring.

Selective tripping is obtained when the breakers in the electrical distribution system are arranged on the basis of a progressive series of time and current pickup. This will allow the breaker having the shorter time setting and the lower pickup to trip before the breaker having the longer time setting and the higher current pickup, provided the fault is on the part of the line protected by the breaker having the lower setting. Hence, if a fault

Fig. 9 (P-6423678)



- 1. Series Coil
- 2. Magnet
- 3. Pallet
- 4. Pinion
- 5. Escape Wheel
- 6. Driving Segment
- 7. S.T.D. Armature

- 8. S.T.D. Calibration Spring
- 9. Trip Arm
- 10. L.T.D. Armature
- 11. L.T.D. Calibration Spring
- 12. Instantaneous Trip Spring
- 13. Spring Holder
- 14. Calibration Clamp Nut

- 15. Plunger
- 16. Cylinder
- 17. Calibration Plate
- 18. Trip Paddle
- 19. Trip Paddle Adjusting Screw
- 20. Clamping Bracket

Fig. 9 Series Overcurrent Tripping Device

GEH-1799 Type AK-1-50-1 Air Circuit Breaker

occurs in any part of the electrical system, only the breaker nearest the fault will trip.

In order to reduce the possibility of damaging the equipment and to provide maximum safety to the operator, the overload caused by a fault is removed in a minimum amount of time by selective tripping. Overloads producing current up to 5 or 10 times the breaker rating are removed in a matter of a few seconds while currents in excess of this value are removed in a fraction of a second.

For the exact characteristics and setting of each breaker in a selective system, reference should be made to the coordination chart furnished for the particular system.

ADJUSTMENTS, FIG. 9

Calibration clamping nuts (14) are used to set the desired pickup for the adjustable elements.

To adjust for approximately $1/32$ " overtravel of trip arm (9) after tripping:

1. Check trip latch engagement. See "Adjustments - Operating Mechanism".
2. Loosen the locknut and turn the adjusting screw (19) on the trip arm (9). The screw should not touch the trip paddle when the breaker is "open" and the latch is reset, but should have a clearance not exceeding $1/32$ ".
3. Tighten the adjusting screw locknut on the trip arm.

REPLACEMENT

1. Remove front frame (See "Repair and Replacement").
2. Remove the bolts holding the coil to the lower stud.
3. Remove bracket and mounting screws.
4. Before installing a new device, check the travel of the trip arm with a rod or wire and push the armature solidly against the magnet (see Fig. 10). The trip arm should move at least $5/32$ ". If there appears to be insufficient movement of the trip arm, or if the armature appears to be binding, the device should not be used.
5. Replace new device in reverse order.
6. Adjust device as described above.

NOTE: No component parts of the overcurrent tripping device are replaced. It will be necessary to install a new device when parts are worn or damaged.

REVERSE CURRENT TRIPPING DEVICE

The device is enclosed in a molded case and is mounted on the right pole base similarly to the series overcurrent tripping device.




Fig. 10 Checking Travel Distance Of Trip Arm On Overcurrent Trip Device

The reverse current tripping device consists of a series coil (2) with an iron core mounted between two pole pieces (9), also a potential coil (7) connected across a constant source of voltage and mounted around a rotary-type armature (10). Calibration spring (6) determines the armature pick-up when a reversal of current occurs.

As long as the flow of current through the breaker is in the normal direction, the magnetic flux of the series coil and the magnetic flux of the potential coil produce a torque which tends to rotate the armature counter-clockwise. The calibration spring also tends to rotate the armature in the same direction. This torque causes the armature to rest against the stop screw (12) attached to a bearing plate on the right side of the device.

If the current through the series coil (2) is reversed, the armature (10) tends to move in the clockwise direction against the restraint of the calibration spring (6). When the current reversal exceeds the calibration setting, the armature revolves clockwise causing the trip rod (3) to move upward engaging the trip paddle (1), thereby tripping the breaker.

ADJUSTMENTS

No adjustments should be made in the field with the exception of checking for overtravel of the trip rod. Proper overtravel of the trip rod is provided, if the trip rod advances the trip paddle between $1/32$ " to $3/64$ " beyond the point where the breaker trips. To adjust for this amount of overtravel, lift the trip rod as high as possible after backing off the adjusting nut on the trip rod (3) so that it will not touch the trip paddle (1). Advance adjusting nut on the trip rod until you can just trip the breaker by lifting the trip rod (3) as far as it will go. Then advance this same adjusting nut an additional $1-1/2$ turns, thereby assuring positive

FIG. 11 (2150180)




FIG. 11A
LONG-TIME AND INSTANTANEOUS
TRIPPING CHARACTERISTIC




FIG. 11B
LONG-TIME AND SHORT-TIME
TRIPPING CHARACTERISTIC

Fig. 11 Typical Time-Current Characteristic

tripping. Lock adjusting nut.

Be extremely cautious not to have hands near moving parts of the breaker when making this adjustment.

REPLACEMENT

After removing the wiring for the potential coil the reverse current device can be removed and replaced by following the procedure outlined for replacing the series overcurrent device. For wiring, see Fig. 12.

MISCELLANEOUS


SHUNT TRIPPING DEVICE

The shunt tripping device (refer to Fig. 13) is mounted on a bracket attached to the left side of the operating mechanism (looking from the front).

A remote switch or relay contacts are used to close the circuit of the device causing the arma-

ture (9) to engage the trip paddle (11), thereby tripping the breaker. The spring (2) is used to return the armature to the neutral position after the breaker trips.

To prevent overheating, the coil (7) is cut off by contacts of the auxiliary switch which are open when the breaker is open.



- | | | |
|--------------------------|--------------------|--------------------|
| 1. Trip Paddle | 6. Spring | 11. Counter Weight |
| 2. Series Coil | 7. Potential Coil | 12. Stop Screw |
| 3. Trip Rod | 8. Calibration Nut | 13. Mounting Screw |
| 4. Trip Crank | 9. Pole Pieces | 14. Screw |
| 5. Setting Sealing Screw | 10. Armature | |

Fig. 12 Reverse Current Tripping Device




Fig. 13 Shunt Tripping Device

ADJUSTMENTS

From 1/32" to 1/16" overtravel of the armature is required when the breaker is tripped. If any adjustment is necessary to provide this amount of overtravel, the trip lever is bent in or out accordingly.

REPLACEMENT - COIL (7)

1. Disconnect leads to coil.
2. Remove magnet (6) and coil from frame (3).
3. Bend lower end of clamp (8) straight and remove.
4. Remove coil and install new coil in reverse order.

BELL ALARM AND LOCKOUT DEVICE

Refer to Fig. 14. When the breaker is tripped by an overload device, auxiliary shaft (9) rotates counter clockwise causing latch (8) to move off of latch arm (5). The breaker opens causing prop (3) to rotate clockwise allowing switch (2) to close. The switch then rotates latch arm (5) which, in turn, allows catch (11) to move downward thereby locking latch arm (5) in the rotated position. When in the rotated position the latch arm keeps the trip shaft and prop (3) in the trip-free position, thus keeping the breaker from being closed until the lockout mechanism is reset by means of reset button (1). When the switch is closed it sounds an alarm. If the breaker is tripped by any device other than an overload device, latch (8) keeps latch arm (5)

from rotating and therefore stops the bell alarm and lockout device mechanism from operating.

ADJUSTMENTS

1. With the breaker mechanism and lockout mechanism in the reset position adjusting screw (13) should be set so that auxiliary shaft (9) just touches the overload paddles on the trip shaft.
2. With the front frame assembled to the back frame the adjusting screws in the series overcurrent tripping devices should be adjusted so that there is approximately 1/16 inch to 3/32 inch clearance between screw and auxiliary shaft (9).

DISCONNECTS

The disconnects are attached to the circuit breaker studs at the rear of the breaker.

Each disconnect consists of eight contact fingers (5), four retainers (7), two spacers (4), two screws (1), one retaining ring (6), four washers (2) and four springs (3). The parts are assembled as shown in Fig. 16.

ADJUSTMENTS, FIG. 16

Tighten the nuts on screw (1) compressing springs (3) so that the spring length from retainer to washer does not exceed 1-1/32 inches. GREASE CONTACT FINGERS (5) WITH GREASE G.E. SPECIFICATION D50H28.

RENEWAL PARTS

When ordering renewal parts, address the nearest Sales Office of the General Electric Company, specifying the quantity required. The parts should be described and the complete nameplate data of the breaker should be given.

Renewal parts, which are furnished, may not be identical with the original parts since improvements are made from time to time. Parts which are furnished will be interchangeable.




Fig. 14 Bell Alarm And Lockout Device





Fig. 15 Rear View Of Breaker, Showing Secondary Disconnects



1. Screw 3. Spring 5. Contact 6. Retaining Ring
 2. Washer 4. Spacer Finger 7. Retainer

Fig. 16 Secondary Disconnect

Fig. 14 (24 583)

Fig. 15 (8014675)

Fig. 16 (2678294)

www.ElectricalPartManuals.com

WHEN YOU NEED SERVICE

IF YOU NEED TO REPAIR, recondition, or rebuild any electric apparatus, a G-E service shop near you is available day and night, seven days a week, for work in the shops or on your premises. Latest factory methods and genuine G-E renewal parts are used to maintain the original performance of your G-E equipment. For full information about these services, contact the nearest service shop or sales office listed below:

APPARATUS SERVICE SHOPS

Allentown, Pa. 672-676 E. Highland St.
 Appleton, Wisc. Midway Industrial Area,
 County Trunk, "P"
 Atlanta—Chamblee, Ga. 4639 Peachtree
 Indus. Blvd.
 Baltimore 30, Md. 920 E. Fort Ave.
 Boston—Medford 55, Mass. Mystic Valley Pkwy.
 Buffalo 11, N. Y. 318 Urban St.
 Charleston 28, W. Va. 306 MacCorkle Ave., S.E.
 Charlotte, N. C. 2328 Thrift Road
 Chicago 32, Ill. 4360 W. 47th St.
 Cincinnati 2, Ohio 444 W. Third St.
 Cleveland 4, Ohio 4966 Woodland Ave.
 Columbus 23, Ohio 2128 Eakin Rd.
 Corpus Christi, Texas 115 Busse St.
 Dallas 19, Texas 3202 Manor Way
 Davenport—Bettendorf, Ia. 1039 State St.
 Decatur, Ill. 2225 E. Logan St.
 Denver 5, Colo. 3353 Larimer St.
 Detroit 2, Mich. 5950 Third Ave.
 Houston 20, Texas 5534 Harvey Wilson Drive
 Indianapolis 22, Ind. 1740 W. Vermont St.
 Johnstown, Pa. 841 Oak St.
 Kansas City, Mo. 3525 Gardner Ave.
 Los Angeles 1, Calif. 6900 Stanford Ave.
 Louisville, Ky. 2014 New Main St.
 Midland, Tex. 3404 Bankhead Hwy.
 Milwaukee 3, Wisc. 940 W. St. Paul Ave.
 Minneapolis 12, Minn. 2025 49th Ave., N.
 New Orleans, La. 2815 N. Robertson St.
 New York—N. Bergen, N. J. 6001 Tonnelle Ave.
 Oakland, Calif. 1525 Peralta St.
 Philadelphia 24, Pa. 1040 E. Erie Ave.
 Pittsburgh 6, Pa. 6519 Penn Ave.
 Portland 10, Oregon 2727 N.W. 29th Ave.
 Richmond 24, Va. 1403 Ingram Ave.
 Roanoke, Va. 115 Albermarle St.
 Sacramento, Calif. 99 N. 17th St.
 St. Louis 10, Mo. 1115 East Road
 Salt Lake City 4, Utah 301 S. Seventh West St.
 San Francisco 3, Calif. 1098 Harrison St.
 Seattle 4, Wash. 3422 First Ave., S.
 Southington, Conn. 53 Railroad Ave.
 Spokane 3, Wash. S. 155 Sherman St.
 Tampa 1, Fla. P.O. Box 1245,
 Naval Indus. Res. Shipyard
 Toledo 4, Ohio 1 So. St. Clair St.
 Wheeling, W. Va. 2050 National Rd.
 York, Pa. 54 N. Harrison St.
 Youngstown 5, Ohio 272 E. Indianola Ave.

APPARATUS SALES OFFICES

Abilene, Texas 442 Cedar St.
 Akron 8, Ohio 335 S. Main St.
 Albany 7, N. Y. 90 State St.
 Albuquerque, N. Mex. 323 Third St., S.W.
 Alexandria, La. 720 Murray St.
 Allentown, Pa. 1132 Hamilton St.
 Amarillo, Texas Amarillo Bldg.
 Appleton, Wisc. 531 W. College Ave.
 Atlanta 3, Ga. 1860 Peachtree Rd., N.W.
 Augusta, Ga. Masonic Bldg.
 Augusta, Me. 152 State St.
 Baltimore 1, Md. 111 Park Ave.
 Bangor, Maine 77 Central St.
 Baton Rouge 6, La. 3170 Florida Blvd.
 Battle Creek, Mich. 25 W. Michigan Ave.
 Beaumont, Texas 1385 Calder Ave.
 Billings, Mont. Rm. 816, 303 No. Broadway
 Binghamton, N. Y. 19 Chenango St.

Birmingham 3, Ala. 1804 Seventh Ave., N.
 Bismarck, N. Dak. 418 Rosser Ave.
 Bluefield, W. Va. 704 Bland St.
 Appalochian Bldg.
 Boise, Idaho 1524 Idaho St.
 Boston 1, Mass. 140 Federal St.
 Buffalo 3, N. Y. 535 Washington St.
 Butte, Mont. P.O. Box 836, 103 N. Wyoming St.
 Canton 2, Ohio 700 Tuscarawas St., W.
 Cedar Rapids, Iowa 210 Second St., S.E.
 Charleston 28, W. Va. 306 MacCorkle Ave., S.E.
 Charlotte 1, N. C. 112 S. Tryon St.
 Chattanooga 2, Tenn. 832 Georgia Ave.
 Chicago 80, Ill. P.O. Box 5970A, 840 S. Canal St.
 Cincinnati 2, Ohio 215 W. Third St.
 Cleveland 4, Ohio 4966 Woodland Ave.
 Columbia 1, S.C., P.O. Box 1434, 1420 Lady St.
 Columbus 15, Ohio 40 S. Third St.
 Corpus Christi, Texas 205 N. Chaparral
 Dallas 2, Texas 1801 N. Lamar St.
 Davenport—Bettendorf, Ia. 1039 State St.
 Dayton 2, Ohio 11 W. Monument Bldg.
 Dayton 9, Ohio Avia. & Def.,
 2600 Far Hills Ave.
 Denver 2, Colo. 650 Seventeenth St.
 Des Moines 9, Iowa 505 W. Fifth Ave.
 Detroit 2, Mich. 700 Antoinette St.
 Duluth 2, Minn. 14 W. Superior St.
 Elmira, N. Y. Main and Woodlawn Aves.
 El Paso, Texas 215 No. Stanton
 Erie, Pa. 1001 State St.
 Eugene, Ore. Cascade Bldg., 1170 Pearl St.
 Evansville 19, Ind. 123 N.W. Fourth St.
 Fairmont, W. Va. 310 Jacobs Bldg.,
 P.O. Box 1626
 Fergus Falls, Minn. 108N. Court Ave. P.O. Box 197
 Flint 3, Mich. 653 S. Saginaw St.
 Fort Wayne 6, Ind. 3606 So. Calhoun St.
 Fort Worth 2, Tex. 408 W. Seventh St.
 Fort Worth, Tex. Avia. & Def.,
 6200 Camp Bowie Blvd.
 Fresno 1, Calif. 407 Patterson Bldg.
 Tulare and Fulton St.
 Grand Rapids 2, Mich. 425 Cherry St., SE
 Greensboro, N. C. 301 S. Elm St.
 Greenville, S. C. 108 W. Washington St.
 Gulfport, Miss. 207 Ja-Fran Bldg.
 Hagerstown, Md. Professional Arts Bldg.
 Hartford 5, Conn. 764 Asylum Ave.
 Houston 1, Texas 1312 Live Oak St.
 Indianapolis 4, Ind. 110 N. Illinois St.
 Jackson, Mich. 120 W. Michigan Ave.
 Jackson 1, Miss. 203 W. Capital St.
 Jacksonville 2, Fla. 700 E. Union St.
 Jamestown, N. Y. P.O. Box 548, 2 Second St.
 Johnstown, Pa. 841 Oak St.
 Joplin, Mo. P.O. Box 948, 220½ W. Fourth St.
 Kalamazoo 3, Mich. 112 Parkway Ave.
 Kansas City 6, Mo. 106 W. Fourteenth St.
 Knoxville 16, Tenn. 1301 Hannah Ave.
 Lake Charles, La. 422 Seventh St.
 Lansing 8, Mich. 306 Michigan National Tower
 Lexington, Ky. First National Bank Bldg.
 Lincoln 8, Nebr. Sharpe Bldg., 206 S. 13th St.
 Little Rock, Ark. 103 W. Capitol Ave.
 Los Angeles 54, Calif. 212 N. Vignes St.
 Louisville 2, Ky. 455 S. Fourth St.
 Lubbock, Texas 3302 Avenue "A"
 Macon, Ga. 682 Cherry St.
 Madison 3, Wisc. 16 N. Carroll St.
 Manchester, N. H. 875 Elm St.

Medford, Ore., P.O. Box 1349, 107 E. Main St.
 Memphis 3, Tenn. 8 N. Third St.
 Miami 32, Fla. 25 S.E. Second Ave.
 Midwest City, Okla. Avia. & Def.,
 207 Post Off. Bldg.
 Milwaukee 3, Wisc. 940 W. St. Paul Ave.
 Minneapolis 3, Minn. 12 S. Sixth St.
 Mobile 13, Ala. 54 St. Joseph St.
 Nashville 3, Tenn. 234 Third Ave., N.
 Newark 2, N. J. 744 Broad St.
 New Haven 6, Conn. 129 Church St.
 New Orleans 12, La. 837 Gravier St.
 New York 22, N. Y. 570 Lexington Ave.
 New York Avia. & Def., Fed. Bldg.,
 N. Y. International Airport, Jamaica 30, N. Y.
 Niagara Falls, N. Y. 253 Second St.
 Norfolk 10, Va. 229 W. Bute St.
 Oakland 12, Calif. 409 Thirteenth St.
 Oklahoma City 2, Okla. 119 N. Robinson St.
 Omaha 2, Nebr. 409 S. Seventeenth St.
 Pasco, Wash. 824 W. Lewis St.
 Peoria 2, Ill. 309 Jefferson Bldg.
 Philadelphia 2, Pa. 1405 Locust St.
 Phoenix, Ariz. P.O. Box 4037, 303 Luhrs Tower
 Pittsburgh 22, Pa. The Oliver Bldg., Mellon Sq.
 Portland 7, Ore. 920 S.W. Sixth Ave.
 Providence 3, R. I. Industrial Trust Bldg.
 Raleigh, N. C. Room 401, 16 W. Martin St.
 Reading, Pa. 31 N. Sixth St.
 Richmond 17, Va. 700 E. Franklin St.
 Riverside, Calif. 3570 Ninth St.
 Roanoke 16, Va. 920 S. Jefferson St.
 Rochester 4, N. Y. 89 E. Ave.
 Rockford, Ill. 110 S. First St.
 Rutland, Vt. 38½ Center St.
 Sacramento 14, Calif. 626 Forum Bldg.
 Saginaw, Mich. Second National Bank Bldg.
 St. Louis 1, Mo. 818 Olive St.
 Salt Lake City 9, Utah 200 S. Main St.
 San Antonio 5, Texas 434 So. Main Ave.
 San Diego 1, Calif. 1240 Seventh Ave.
 San Francisco 6, Calif. 235 Montgomery St.
 San Jose 10, Calif. 460 Park Ave.
 Savannah, Ga. 4 E. Bryan St.
 Seattle 4, Wash. 710 Second Ave.
 Seattle 8, Wash. Avia. & Def., 220 Dawson St.
 Shreveport, La. 206 Beck Bldg.
 Sioux City 13, Iowa 572 Orpheum Electric Bldg.
 South Bend 1, Ind. 112 W. Jefferson Blvd.
 Spokane 4, Wash. S. 162 Post St.
 Springfield, Ill. 607 E. Adams St.
 Springfield 3, Mass. 1387 Main St.
 Stockton, Calif. 11 So. San Joaquin St.
 Syracuse 6, N. Y. 3532 James St.
 Tacoma 1, Wash. 1202 Washington Bldg.
 Tampa 6, Fla. 1206 North A St.
 Toledo 4, Ohio 420 Madison Ave.
 Trenton 8, N. J. 214 E. Hanover St.
 Tucson, Ariz. P.O. Box 710, 650 N. Sixth Ave.
 Tulsa 3, Okla. 320 S. Boston Ave.
 Utica 2, N. Y. 258 Genesee St.
 Washington 5, D. C. 777-14th St., N.W.
 Waterloo, Iowa 206 W. 4th St.
 Wenatchee, Wash. 328 N. Wenatchee Ave.
 Wheeling, W. Va. 40 Fourteenth St.
 Wichita 2, Kan. 200 E. First St.
 Williamston, N. C. 115 E. Main St.
 Worcester 5, Mass. 288 Grove St.
 York, Pa. 56 N. Harrison St.
 Youngstown 5, Ohio 272 E. Indianola Ave.