



POWERLOGIC DIGITAL RELAY  
TIME-CURRENT CURVES NO. 3030-06  
DEFINITE TIME (DT)

t = PH TD

t = Tripping time  
I = Trip current  
PH CS = Phase current setting  
PH TD = Phase overcurrent time delay

Time-Current Curve equations are the same for ground fault. Substitute GF CS and GF TD for PH CS and PH TD.

