

TYPE MA-250C Stored Energy Operated Air Circuit Breaker  
1200 Amperes - 2400/4160 Volts



RECOMMENDED  
SPARE PARTS

MARCH 1970

Reference Instruction Book BWX-6731			QUANTITY		NET PRICE
Fig. / Item No.	Description	Drawing Number	1-5 Bkrs.	5 or more	
3-9	Arcing Contact (Stationary)	71-112-966-502	1	3	<b>REFER TO FACTORY</b>
3-28	Arcing Contact (RH Moving)	71-112-913-502	1	3	
3-27	Arcing Contact (LH Moving)	71-112-913-503	1	3	
3-11	Main Contact (One Finger)	71-112-903-501	6	18	
3-19	Main Contact (RH Moving) Disconnect Arm	71-208-255-509	1	3	
3-18	Main Contact (LH Moving) Disconnect Arm	71-208-255-510	1	3	
2A-23	Barrier Stack	71-208-818-502	1	3	
3-25	Washer Hinge Contact (Main)	71-177-196-003	2	6	
3-17	Washer Hinge Contact (Arcing)	71-114-701-001	3	12	
1B-3	Primary Contact Finger Assembly	71-201-738-502	1	6	
1B-21	"Y" Relay (Give Voltage)	Breaker serial number applies*	1	2	
	Closing Spring Release Solenoid Coil (Give Voltage)	71-200-745-	1	2	
4B-17	Trip Solenoid Coil (Give Voltage)	71-209-234-	1	2	
8-6	88 Switch	72-220-125-001	1	2	
4B-48	Motor (Give Voltage)	71-210-046	1	2	
5/page 25	Reset Relay (Give Voltage)	72-200-053		1	
5/page 25	Power Supply (For Relay if A-C Close)	72-200-051-501		1	

SUPPLEMENTARY INFORMATION

71-132-122-03-406

Prices: FOB Factory - Subject to change without notice

Terms: NET CASH - 30 days

Minimum Order: 15 dollars

Estimated Delivery: 8 to 10 weeks

Export Pricing: Refer to Factory

It is recommended that if there are 5 or more identical breakers, a spare removable breaker element should be purchased in addition to the recommended parts specified above.

\* When ordering renewal or spare parts always give complete nameplate data including the breaker serial number.

TYPE MA-250C Stored Energy Operated Air Circuit Breaker  
2000 Amperes - 2400/4160 Volts



RECOMMENDED  
SPARE PARTS

MARCH 1970

Reference Instruction Book Number BWX-6731			QUANTITY		NET PRICE
Fig. / Item No.	Description	Drawing Number	1-5 Bkrs.	5 or more	
3-9	Arcing Contact (Stationary)	71-112-966-502	1	3	
3-28	Arcing Contact (RH Moving)	71-112-913-502	1	3	
3-27	Arcing Contact (LH Moving)	71-112-913-503	1	3	
3-11	Main Contact (One Finger)	71-112-903-501	6	18	
3-19	Main Contact (RH Moving) Disconnect Arm	71-208-255-511	1	2	
3-18	Main Contact (LH Moving) Disconnect Arm	71-208-255-512	1	3	
2A-23	Barrier Stack	71-208-818-502	1	3	
3-25	Washer Hinge Contact (Main)	71-177-196-003	2	6	REFER TO FACTORY
3-17	Washer Hinge Contact (Arcing)	71-114-701-001	3	12	
1B-3	Primary Contact Finger Assembly	71-201-458-502	1	6	
1B-21	"Y" Relay (Give Voltage)	Breaker serial number applies*	1	2	
	Closing Spring Release Solenoid Coil	71-200-745	1	2	
4B-17	Trip Solenoid Coil (Give Voltage)	71-209-234	1	2	
8-6	88 Switch	72-220-125-001	1	2	
4B-48	Motor (Give Voltage)	71-210-046	1	2	
5/page 25	Reset Relay (Give Voltage)	72-200-053		1	
5/page 25	Power Supply (For Relay if A-C Close)	72-200-051-501		1	

SUPPLEMENTARY INFORMATION

71-132-122-03-406

Prices: FOB Factory - Subject to change without notice

Terms: NET CASH - 30 days

Minimum Order: 15 dollars

Estimated Delivery: 8 to 10 weeks

Export Pricing: Refer to Factory

It is recommended that if there are 5 or more identical breakers, a spare removable breaker element should be purchased in addition to the recommended parts specified above.

\* When ordering renewal or spare parts always give complete nameplate data including the breaker serial number.