



Setting the 700 Series Relays

The 700 Series relays are easy to set by following this simple procedure:

1. Using the UP and DOWN keys, find the setting to be changed.
2. Press ENTER twice to display three Ls.
3. Press ENTER once to display two Ls.
4. Using the UP and DOWN keys, select the required value.
5. Press ENTER.
6. Repeat steps 1 and 3-5 to change the other settings.
7. Using the UP and DOWN keys, return to position 0.
8. Ensure that you are at position 0 and press ENTER.

Pressing the ACK key will cancel the settings entered. The ACK key is used to acknowledge an alarm when the relay has operated and not to confirm the entered settings.

Pressing the ENTER key can have one of three functions depending on what the user is doing at the time:

While entering a value----- Enters the value and returns to the menu
While scrolling through the menu, but not at position 0 ----- Cancels the entered settings
After scrolling through the menu and returned to position 0 --- Confirms the entered settings