



April, 1987
Supersedes Descriptive Bulletin 34-251,
pages 1-60, dated September, 1980 and
Technical Data 34-221, pages 1-4, dated
January, 1980
Mailed to: E, D, C/34-000A

600 Volts, 8 Ampere
300 Volts, 20 Ampere
Continuous Capacity
UL Recognized

Instrument and Control Switches Type W-2

Application

The Type W-2 switch is designed for use as an instrument, control or general purpose switch. It is compact, yet of sufficient size to provide long, trouble-free service when applied within the specified ratings.

Design flexibility of internal parts and contacting, plus external jumpering of the contact studs affords almost limitless switching combinations for relatively few standard components. The design flexibility is provided in the basic switch styles. A complete switch is made up of a basic switch, one of several styled handles, external jumper, (when required) and a nameplate.

The W-2 switch may be ordered as a single style unit where such a style meets a specific application. Where a single listed style does not meet a specific application, the desired switch may be ordered by specifying the required styled components. As separate items or by completing Contact Tabulation Form 34219-A.


The style numbers shown in this bulletin apply to switches for mounting on 1/8 to 1/4 inch thick panels. Switches for thicker panels (up to two inches) are available on special order. Refer to the factory.

Instrument Switches: Maintained contact type for use with all classes of electrical instruments, relays, meters, and for performing various circuit combinations. Designed for panel mounting and equipped with handles for manual operation.

Control Switches: Are designed as spring return to the original or neutral position. They are used for circuit breaker control and other types of electrically controlled apparatus where momentary contact is required. They are designed for panel mounting and equipped with a handle for manual operation.

Advantages

- Small Size
- Variable Circuitry by "You Wire It"
- More Contacts per Unit Volume
- Roller-Wipe Spring Actuated Contacting
- Momentary and Maintained Contact Designs, or in Combination
- Affords almost limitless switching combinations
- Identification for Automated Wiring or Application Changes in Field
- Double Break Contacts per Stage
- UL recognized



Index	Page	Index	Page
Application	1	Ordering Information	9
Advantages	1	Outline Dimensions	19
Auxiliary Switches	18	Protective Covers	16
Basic Switches and General Application	20	Switches (Numerical Sequence)	9
Basic Switches in Numerical Sequence	11	Switches (Specific Application)	21
Construction	5	Terminal Connectors	12
Contact Interpretation	4	Tumbler Pin Key Lock	17
Design Features	2		
Handles	2		
Interrupting Ratings	3		
Key Interlocking	17		
Materials	8		
Nameplates	13		
Operation	3		



Design Features

General Construction

The W-2 switch consists essentially of an operating handle, face plate, control housing, contact frame assembly and rotor assembly. It can be built up in any number of stages from 1 to 8, which stages are clamped together and to the control housing by two tie bolts. A steel operating shaft ties the contact rotors together. A metal cover on the rear holds the position stop pins, retains the shaft and provides switch identification. For push or pull switches, the metal cover is replaced by a polycarbonate cover which houses the pull-out mechanism.

Switch Positions

The Type W-2 switch has a minimum of two and a maximum of twelve rotary positions with a 30° throw between positions, irrespective of the number. Each rotary position coincides precisely with the nameplate markings. The degree of throw between positions is fixed and cannot be changed. The number of positions of each switch can be altered by removing the rear cover and changing the position of the "stop" pin or pins located in the rear housing spacer. In addition to rotary motion, the W-2 switch can be provided with a lateral movement (push-pull) of the handle and shaft.

Contact Frames

Two contact frame sizes are available; the half frame with six sets of contacts; three sets on the top at 11, 12 and 1 o'clock positions and three sets on the bottom at 5, 6 and 7 o'clock positions. The full frame with 12 sets of contacts, each set located at 30° intervals around its perimeter as are the numbers on a clock. The contact frames are made of glass polyester insulating material.

Contacts

Switches are usually referred to as "so many stages long". For a W-2 switch, a stage of contacts consists of a contact frame (either 6 or 12 contact sets) and a rotor.

At every position location on the frame, there are two contact terminal studs in line (a set) per stage. Each of these studs is one piece, made of bronze alloy and silver plated.

Rotors

The rotors are standard in design and hold the roller contacts. Each rotor, made of glass polyester insulating material, rotates independently between the stage spacer plates. The rotor assembly is equipped with one to six rollers (as determined by the required circuitry) each of which makes contact with two adjacent

stationary terminal studs to complete a circuit and so affording a double, series break contact. The silver-plated bronze alloy roller contacts provide a rolling, wiping action, are self-aligning on assembly and require no adjustment of contact pressure for the life of the switch. Contact springs do not carry current.


Contact Flexibility

Basic "you wire it" flexibility is available in the Type W-2 switch. While the internal contacting is standardized for each basic type of switch; such as ammeter, voltmeter, circuit breaker, etc., by using available insulated jumpers, connections between external switch terminals can be made to obtain the desired circuitry for a specific application. This minimizes the number of basic styled switches that otherwise would be required.

Switch Dial

The Type W-2 switch dial consists of two parts; i.e., a dial plate and a nameplate.

The standard control switch dial plate is die cast aluminum, with red and green target parts, where required, and serves as the base for mounting the nameplate. The nameplate is made of a white Cycolac ABS material on which is engraved in black the desired position markings.





Handles

Handles for the Type W-2 switch are made of a phenolic insulating material designed to afford a smooth, easy, and comfortable grip of pleasing appearance. Each handle has a recessed arrow molded into it as a visual aid in positioning.

The handles are made in six shapes: Oval, round, pistol grip, large pistol grip, finger tip and mini-slim DS.

They can be obtained in the fixed type or the removable key type. All handles are fastened to the shaft by a screw through the front of the handle.

There is also available a combination removable key type handle in the pistol grip shape that can be used to operate both the Type W-2 and the Type W switches designed for removable key operation.

Switches using mini-slim or finger tip handles require a shorter shaft extension than do the shank type handles. Therefore mini-slim and finger tip handles are not interchangeable with the other 4 shank type handles.

Operation

The Type W-2 switch is a rotary roller action switch. Rotation of the shaft causes the rotor rollers to roll from one set of stationary contacts to another. The number of roller contacts can vary from 1 to 6 depending on the number of rotary positions required for the switch application. Each roller contact, moving radially, is held in and guided by a slot in the rotor arm. The rollers are pushed outward by spring pressure. Between roller and spring there is an insulated spring seat to reduce friction and wear. On standard potential contacts, an insulated wheel is used on both ends of the roller contact which wheels roll inside the switch stator frame. This arrangement reduces the friction of the spring-loaded roller in riding up on the stationary contact and also results in an increased air gap and faster contact separation.

Overlapping contacts are obtained by increasing the diameter of the contact rollers of the shorting bar. At mid-position the roller spans the space between the stationary contacts. Such rollers provide a make-before-break contact in going from one position to an adjacent position.

The Type W-2 switch is available in both the maintained and the spring return types. Both types use a common housing that is $\frac{7}{8}$ " deep, located between the back surface of the dial plate and the frame-rotor unit. This feature permits easy conversion from one type to another with a minimum of parts, time and experience.

Maintained Type: On a switch of this type, the switch is held in each rotary position by a starwheel mechanism. The mechanism consists of a pointed notched, molded wheel rotating between two metal rollers mounted on spring loaded arms. This arrangement provides a positive snap action as the handle is turned.

Interrupting Ratings

Voltage	Amperes			
	General Purpose	Pilot Duty 35% P.F. Normal	Inrush	2 Contacts in Series General Purpose
Standard Contact				
600 Volts Ac	8	2.4	12	20
240 Volts Ac	20	6	30	40
110 Volts Ac	30	10	60	60
250 Volts Dc	1.65	1.1	..	9.5
125 Volts Dc	5	2.2	..	20


Note: Adjacent poles (contacts in same chamber) must be connected at same polarity

Slip Contacts

600 Volts Ac	8	2.4	12	...
240 Volts Ac	20	6	30	...
110 Volts Ac	30	10	60	...
250 Volts Dc	1	55
125 Volts Dc	3.5	1.1

Note: 2 adjacent side pole double throw contacts (in same chamber or stage) must be connected at same polarity

Pull and ammeter contacts are not given ratings as they do not interrupt loads. Normally closed ammeter contact has a continuous rating of 10 amperes



Contact Interpretation

The contacts of the Type W-2 Switch are identified by the combination of Bands and Rows.

Rows

Viewing the switch from the handle end (front), it is noted the terminals are arranged in rows from front to back. The rows are set 30 degrees apart as is the face of a clock. On the six contact frame, the top three rows are identified as 11, 12 and 1 o'clock. The three rows at the bottom of the stage are 5, 6 and 7 o'clock. On the twelve contact frame, the rows are set as per each number on the face of a clock.

Bands

As the switch is viewed from the side, bands of terminals are readily seen around the outer perimeter of the stage frame. Such bands are lettered. The band nearest the handle end is band "A", the second band is band "B", etc. Bands "A" and "B" constitute stage one, bands "C" and "D" constitute stage two, etc.

The row numbers and band letters are then combined to form full terminal identification as shown above and in the contact tabulations shown in this bulletin.





Figure 1: Methods of Identifying Contact Terminal Letter of Bands, Numbered Rows.

Contacts

The stationary contact (terminal) is a solid one piece forging. The moving (roller) contact is a solid bar.

To complete a circuit the roller contact internally bridges the stationary terminals in adjacent bands in the same row, for example, bands A & B in row twelve (A12-B12) etc.



Each Type W-2 switch is shipped with hardware packet containing one nut for each switch terminal to facilitate field wiring.



Construction Details




Figure 2: Exploded View of Typical Control Switch.

Construction Details of Important Sub-assemblies




Figure 3①

Figure 4①

Figure 5①

Figure 6①


Figure 7①

Figure 8①


① Subassemblies listed above are available in spare parts kits.
Refer to Instruction Leaflet 34-251.




Stage Frame Construction




12 Contact Frame With Overlapping Contact Roller
(Make Before Break)




6 Contact Frame With Overlapping Contact Roller
(Make Before Break)



6 Contact Frame With Standard Potential Contact Roller
(Break Before Make)



6 Contact Frame With Push-Pull Rotor



6 Contact Frame With Slip Contact Rotor

**Rotor Construction**


Contacting of the Type W-2 Switch is derived from the varied assembly of fully standard parts. The stators (stage frames) are of the 6-contact and 12-contact designs per stage. The number of contacts per position and the number of required positions determine the rotor configuration. The stage frames remain unaltered, but the rotors are assembled to suit the application.

In the following is illustrated the contact tabulation derived from a particular rotor configuration. All illustrations are for a single stage. The Type W-2 Switch can be made up of several duplicate stages or a combination of varied compatible stages.


The following illustrations are intended to permit a fuller understanding of the internal construction and flexibility of the Type W-2 Switch.

Rotor Configurations Used With The Six Contact Frame



Rotor Configuration	Resulting Contact Operation	Position Available	Function
---------------------	-----------------------------	--------------------	----------





Two Contacts Closed in Each of Three Positions





One Contact Closed in Each of Six Positions




Two Contacts Closed in Twelve O'clock Position-Four Contacts Closed in One O'clock Position



Four Contacts Closed in Twelve O'clock Position-Two Contacts Closed in One O'clock Position


**Slip Rotor Used With The Six Contact Frame**

Slip Rotor:
Top Portion-One Contact Closed in Each of Three Positions. Lower Portion-Two Contacts Closed in Each of Two Positions.








Rotor Configurations Used With The Twelve Contact Frame




Rotor Configuration	Resulting Contact Operation	Position Available	Function																										
	<table border="1"> <thead> <tr> <th>CONTACT</th><th>POSITION</th></tr> </thead> <tbody> <tr><td>A12-B12</td><td>1 2 3 4 5 6 7 8 9 10 11</td></tr> <tr><td>A1-B1</td><td>X</td></tr> <tr><td>A2-B2</td><td>X</td></tr> <tr><td>A3-B3</td><td>X</td></tr> <tr><td>A4-B4</td><td>X</td></tr> <tr><td>A5-B5</td><td>X</td></tr> <tr><td>A6-B6</td><td>X</td></tr> <tr><td>A7-B7</td><td>X</td></tr> <tr><td>A8-B8</td><td>X</td></tr> <tr><td>A9-B9</td><td>X</td></tr> <tr><td>A10-B10</td><td>X</td></tr> <tr><td>A11-B11</td><td>X</td></tr> </tbody> </table>	CONTACT	POSITION	A12-B12	1 2 3 4 5 6 7 8 9 10 11	A1-B1	X	A2-B2	X	A3-B3	X	A4-B4	X	A5-B5	X	A6-B6	X	A7-B7	X	A8-B8	X	A9-B9	X	A10-B10	X	A11-B11	X		One Contact Closed in Each of Twelve Positions
CONTACT	POSITION																												
A12-B12	1 2 3 4 5 6 7 8 9 10 11																												
A1-B1	X																												
A2-B2	X																												
A3-B3	X																												
A4-B4	X																												
A5-B5	X																												
A6-B6	X																												
A7-B7	X																												
A8-B8	X																												
A9-B9	X																												
A10-B10	X																												
A11-B11	X																												
	<table border="1"> <thead> <tr> <th>CONTACT</th><th>POSITION</th></tr> </thead> <tbody> <tr><td>A10-B10</td><td>1 2 3</td></tr> <tr><td>A11-B11</td><td>X</td></tr> <tr><td>A12-B12</td><td>X</td></tr> <tr><td>A1-B1</td><td>X</td></tr> <tr><td>A2-B2</td><td>X</td></tr> <tr><td>A3-B3</td><td>X</td></tr> <tr><td>A4-B4</td><td>X</td></tr> <tr><td>A5-B5</td><td>X</td></tr> <tr><td>A6-B6</td><td>X</td></tr> <tr><td>A7-B7</td><td>X</td></tr> <tr><td>A8-B8</td><td>X</td></tr> <tr><td>A9-B9</td><td>X</td></tr> </tbody> </table>	CONTACT	POSITION	A10-B10	1 2 3	A11-B11	X	A12-B12	X	A1-B1	X	A2-B2	X	A3-B3	X	A4-B4	X	A5-B5	X	A6-B6	X	A7-B7	X	A8-B8	X	A9-B9	X		Two Contacts Closed in Each of Six Positions
CONTACT	POSITION																												
A10-B10	1 2 3																												
A11-B11	X																												
A12-B12	X																												
A1-B1	X																												
A2-B2	X																												
A3-B3	X																												
A4-B4	X																												
A5-B5	X																												
A6-B6	X																												
A7-B7	X																												
A8-B8	X																												
A9-B9	X																												
	<table border="1"> <thead> <tr> <th>CONTACT</th><th>POSITION</th></tr> </thead> <tbody> <tr><td>A11-B11</td><td>X</td></tr> <tr><td>A12-B12</td><td>X</td></tr> <tr><td>A1-B1</td><td>X</td></tr> <tr><td>A2-B2</td><td>X</td></tr> <tr><td>A3-B3</td><td>X</td></tr> <tr><td>A4-B4</td><td>X</td></tr> <tr><td>A5-B5</td><td>X</td></tr> <tr><td>A6-B6</td><td>X</td></tr> <tr><td>A7-B7</td><td>X</td></tr> <tr><td>A8-B8</td><td>X</td></tr> <tr><td>A9-B9</td><td>X</td></tr> <tr><td>A10-B10</td><td>X</td></tr> </tbody> </table>	CONTACT	POSITION	A11-B11	X	A12-B12	X	A1-B1	X	A2-B2	X	A3-B3	X	A4-B4	X	A5-B5	X	A6-B6	X	A7-B7	X	A8-B8	X	A9-B9	X	A10-B10	X		Three Contacts Closed in Each of Four Positions
CONTACT	POSITION																												
A11-B11	X																												
A12-B12	X																												
A1-B1	X																												
A2-B2	X																												
A3-B3	X																												
A4-B4	X																												
A5-B5	X																												
A6-B6	X																												
A7-B7	X																												
A8-B8	X																												
A9-B9	X																												
A10-B10	X																												
	<table border="1"> <thead> <tr> <th>CONTACT</th><th>POSITION</th></tr> </thead> <tbody> <tr><td>A11-B11</td><td>X</td></tr> <tr><td>A12-B12</td><td>X</td></tr> <tr><td>A1-B1</td><td>X</td></tr> <tr><td>A2-B2</td><td>X</td></tr> <tr><td>A3-B3</td><td>X</td></tr> <tr><td>A4-B4</td><td>X</td></tr> <tr><td>A5-B5</td><td>X</td></tr> <tr><td>A6-B6</td><td>X</td></tr> <tr><td>A7-B7</td><td>X</td></tr> <tr><td>A8-B8</td><td>X</td></tr> <tr><td>A9-B9</td><td>X</td></tr> <tr><td>A10-B10</td><td>X</td></tr> </tbody> </table>	CONTACT	POSITION	A11-B11	X	A12-B12	X	A1-B1	X	A2-B2	X	A3-B3	X	A4-B4	X	A5-B5	X	A6-B6	X	A7-B7	X	A8-B8	X	A9-B9	X	A10-B10	X		Four Contacts Closed in Each of Three Positions
CONTACT	POSITION																												
A11-B11	X																												
A12-B12	X																												
A1-B1	X																												
A2-B2	X																												
A3-B3	X																												
A4-B4	X																												
A5-B5	X																												
A6-B6	X																												
A7-B7	X																												
A8-B8	X																												
A9-B9	X																												
A10-B10	X																												
	<table border="1"> <thead> <tr> <th>CONTACT</th><th>POSITION</th></tr> </thead> <tbody> <tr><td>A11-B11</td><td>X</td></tr> <tr><td>A12-B12</td><td>X</td></tr> <tr><td>A1-B1</td><td>X</td></tr> <tr><td>A2-B2</td><td>X</td></tr> <tr><td>A3-B3</td><td>X</td></tr> <tr><td>A4-B4</td><td>X</td></tr> <tr><td>A5-B5</td><td>X</td></tr> <tr><td>A6-B6</td><td>X</td></tr> <tr><td>A7-B7</td><td>X</td></tr> <tr><td>A8-B8</td><td>X</td></tr> <tr><td>A9-B9</td><td>X</td></tr> <tr><td>A10-B10</td><td>X</td></tr> </tbody> </table>	CONTACT	POSITION	A11-B11	X	A12-B12	X	A1-B1	X	A2-B2	X	A3-B3	X	A4-B4	X	A5-B5	X	A6-B6	X	A7-B7	X	A8-B8	X	A9-B9	X	A10-B10	X		Six Contacts Closed in Each of Two Positions
CONTACT	POSITION																												
A11-B11	X																												
A12-B12	X																												
A1-B1	X																												
A2-B2	X																												
A3-B3	X																												
A4-B4	X																												
A5-B5	X																												
A6-B6	X																												
A7-B7	X																												
A8-B8	X																												
A9-B9	X																												
A10-B10	X																												



Push-Pull Rotors



Six Contact Stage With Pull Rotor-Two Pull to Break and Two Pull Make Contacts



Twelve Contact Stage With Pull Rotor-Six Pull to Break and Six Pull to Make Contacts



Circuit Breaker Control

Type W-2 Switch Materials

Handle	Moldarta, General Purpose
Nameplate	Cycloc, ABS Molded Composition
Dial Plate	Aluminum Die Cast
Housing	Aluminum Die Cast
Stage Frame	Glass Polyester
Rotor	Glass Polyester
Stationary Contact	Silicon Bronze, Silver Plated
Roller Contact	Silicon Bronze, Silver Plated
Springs	Silicon Bronze, Silver Plated
Locking Spacer Window	Stainless Steel
Starwheel	Polysulfone
Pull Cover and Guide	Nylon
Shaft	Polycarbonate
	Stainless Steel

**Ordering Instructions**

All type W-2 switches must be ordered by style number. If the style number is unknown, Form 34219-A, (refer to page 61) must be completed and sent to:

Westinghouse Electric Corporation
Route 9, P.O. Box 555D
Marketing Department
London, KY 40741

The London division will assign and advise style number. Contact tabulation form 34219-A is available from either the Westinghouse Printing Division, Trafford, PA or from the London division.

The type W-2 switch can be furnished in either of two ways;

- 1) as a complete unit consisting of the switch unit, handle, nameplate and external jumpers when required (as listed in Table 1, pages 9 and 10) or
- 2) as a basic switch with all desired components being ordered as separate items (as listed in Table 2, page 11).

Switches requiring external jumpers in order to perform a specific function and which are ordered as a complete switch from Table 1, will be furnished with the jumpers installed. Basic switches ordered from Table 2, are not furnished with jumpers installed.

The rear end cap of each switch will be marked with the style number of the switch as ordered, whether a complete unit or basic switch.

Style numbers of switches to be operated by a removable key handle do not include the handle. The switch and key handle must be identified and ordered as separate items.

The style numbers shown in this bulletin apply to switches for mounting on 1/8 to 1/4 inch thick panels. Switches for thicker panels (up to two inches) are available on special order (refer to factory).

Each type W-2 switch, complete or basic, is shrink packed in a carton with a contact tabulation sheet, and packets of terminal nuts sufficient for connecting to each switch terminal. Type W-2 switches shipped as complete units also include a nameplate, dial-plate, and handle hardware.

Additional ordering information can be found including:	
Nameplates	Pages 13, 14, 15
Handles	Pages 2, 3
Terminal Connectors	Page 12
Tumbler Pin Key Lock	Page 17
Key Interlocking	Page 17
Protective Covers	Page 16
Auxiliary Switch	Page 18

Note: Switches listed are only a minute percentage of switches actually available.

Table 1: Complete Switches, Continued

Complete switches are those with nameplates, handles, and external jumpers (where required) except that switches to be operated by a removable key handle do not include the key handle. All removable key handles must be ordered as separate items. (All for 1/8- 1/4 inch thick panel mounting.)

Style	Figure	Application
505A700G01	1	Ammeter - 2 Phase
505A701G01	2A	Ammeter - 3 Phase - 3 CT's - Independent Circuits
505A701G02	2	Ammeter - 3 Phase - 2 CT's
505A701G05	3	Ammeter - 3 Phase - 3 CT's - No "OFF" Position
505A702L02	103	1 or 2 Pole with OFF
505A702L03	92	OFF - ON
505A702G01	20	Voltmeter - 2 Phase - AC - 3 Wire
505A702G02	21	Voltmeter - 2 Circuit - DC - 2 Wire
505A702G03	22	Voltmeter - 3 Wire DC
505A702G04	23	Voltmeter - 3 Phase - 3 Wire
505A702G05	24	Voltmeter - 3 Phase - 4 Wire
505A703G01	38	Voltage Control
505A703G02	62	Speed Control
505A703G06	38	Voltage Control
505A703G07	62	Speed Control
505A703G51	103	2 Pole - 2 Throw
505A704G01	25	Voltmeter - 4 Circuit
505A705G01	26	Voltmeter - 3 Phase and Phase-to-Neut.
505A705G02	27	Voltmeter - Two 3-Phase Circuits
505A705G03	28	Voltmeter - 6 Circuit
505A706G01	91	OFF - ON
505A706G02	91	OFF - ON
505A706G03	91	OFF - ON
505A706G55	97	1 or 2 Pole - 2 Throw
505A709G01	85	Temperature - 4 RTD - Accurate Lead Compensation
505A711G01①	86	Temperature - 4 RTD - Accurate Lead Compensation
505A711G03	86	Temperature Removable Key Handle
505A712G01	57	Regulator Cutout
505A712G90	44	Wattmeter
505A712G91	53	Power Factor
505A712G92	106	4 Pole - 2 Throw
505A713G01	63	Circuit Breaker Control
505A713G02	64	Circuit Breaker Control
505A713G03	63	Circuit Breaker Control
505A714G01	65	Circuit Breaker Control
505A714G02	65	Circuit Breaker Control
505A715G01	39	Voltage Control
505A715G05	39	Voltage Control
505A715G32	106	4 Pole - 2 Throw
505A716G01	40	Voltage Control
505A716G02	59	Electrode Control
505A716G03	60	Motor Control
505A716G04	59	Electrode Control
505A716G05	60	Motor Control
505A717G01	68	Circuit Breaker Control
505A717G03	68	Circuit Breaker Control
505A718G01	66	Circuit Breaker Control
505A718G15	67	Circuit Breaker Control
505A720G01	69	Circuit Breaker Control
505A720G03	69	Circuit Breaker Control
505A722G01	95	OFF - ON
505A722G02	95	OFF - ON
505A722G03	95	OFF - ON
505A723G01	91	OFF - ON
505A723G02	91	OFF - ON
505A723G03	91	OFF - ON
505A725G01	95	OFF - ON
505A725G06	95	OFF - ON
505A725G11	95	OFF - ON
505A726G14	107	6 Pole - 2 Throw
505A727G15	107	6 Pole - 2 Throw
505A733G01	93	OFF - ON
505A733G17	98	1 Pole - 4 Throw
505A733G18	99	1 Pole - 5 Throw
505A734G09	45	Wattmeter

① Switch requires removable key handle which is not included with switch style - switch and removable key handle must be ordered as separate items.



Table 1: Complete Switches, Continued

Complete switches are those with nameplates, handles, and external jumpers (where required) except that switches to be operated by a removable key handle do not include the key handle. All removable key handles must be ordered as separate items. (All for $\frac{1}{8}$ - $\frac{1}{4}$ inch thick panel mounting.)

Style	Figure	Application	Style	Figure	Application
505A738G07	75	Circuit Breaker Control	508A496G03	54	Power Factor Meter
505A740G06	47	Watt Meter	661A208G01①	2A	Ammeter - 3 Phase, 3 Ct's.
505A740G07	48	Watt Meter	661A210G01	89	Temperature - 10 RTD - Accurate Lead Compensation
505A745G01	94	OFF - ON	661A210G06	87	Temperature - 6 RTD - Accurate Lead Compensation
505A745G17	100	1 Pole - 7 Throw	663A245G06	61	Motor Control
505A745G18	101	1 Pole - 8 Throw	663A454G01①	90	Temperature, 10 RTD - Accurate Lead Compensation
505A745G19	102	1 Pole - 10 Throw	781A252G01	11	Ammeter, Two 3 Phase Circuits
505A747G01	19	Voltmeter - Single Phase	781A254G01	84	Temperature, 1 RTD, Accurate Lead Compensation
505A747G02	19	Voltmeter Removable Key Handle	781A489G01①	88	Temperature, 6 RTD, Accurate Lead Compensation
505A748G01①	21	Voltmeter - 2 Circuit - DC - 2 Wire	787A976G01	4	Ammeter, 3 Phase, 3 Ct's., End of Circuit
505A748G02	21	Voltmeter - Removable Key Handle	787A976G02	5	Ammeter, 3 Phase, 2 Ct's., End of Circuit
505A749G01①	23	Voltmeter - 3 Phase, 3 Wire	787A976G03	6	Ammeter, 3 Phase, 3 Ct's., End of Circuit
505A749G02	23	Removable Key Handle	787A976G04	7	Ammeter, 3 Phase, 2 Ct's., End of Circuit
505A752G01①	50	Wattmeter	787A977G01	36	Voltmeter/Ammeter/3 Phase - 4 Wire, 3 Ct's., 3 Pt's./End of Circuit
505A752G02	50	Removable Key Handle	787A977G02	37	Voltmeter/Ammeter/3 Phase - 3 Wire, 3 Ct's., 2 Pt's./End of Circuit
505A753G01①	51	Power Factor Meter	787A984G01	12	Ammeter, 3 Phase - 2 Ct's., End of Circuit
505A753G02	51	Removable Key Handle	787A984G02	13	Ammeter, 3 Phase - 2 Ct's., End of Circuit
505A754G01①	52	Power Factor Meter	787A984G03	14	Ammeter, 3 Phase - 3 Ct's., End of Circuit
505A754G02	52	Removable Key Handle	787A984G04	15	Ammeter, 3 Phase - 3 Ct's., End of Circuit
505A754G03	55	Removable Key Handle	787A984G05	16	Ammeter, ON - OFF, 1 Ct., End of Circuit
505A754G04①	46	Wattmeter	787A984G06	17	Ammeter, 3 Phase - 2 Ct's., End of Circuit
505A755G01①	41	Synchroscope - Machine to Bus	787A984G07	18	Ammeter, 3 Phase - 3 Ct's., End of Circuit
505A755G02	41	Removable Key Handle	800A426G01①	4	Ammeter, 3 Phase - 3 Ct's., End of Circuit
505A757G01①	42	Synchroscope - Between Machines	800A426G02①	5	Ammeter, 3 Phase - 2 Ct's., End of Circuit
505A757G02	42	Removable Key Handle - Running	802A231G01	76	Circuit Breaker Control
505A757G03	42	Removable Key Handle - Incoming	802A469G01	80	Circuit Breaker Control
505A762G01①	24	Voltmeter - 3 Phase, 4 Wire	802A470G01①	55	Power Factor Meter
505A762G02	24	Removable Key Handle	3562A01G01	29	Voltmeter - 3 Phase; 3 Wire, End of Circuit
505A779G05①	49	Wattmeter	3562A01G02	30	Voltmeter - 3 Phase; 3 Wire, End of Circuit
505A781G03	96	OFF - ON	3562A01G03	31	Voltmeter - 3 Phase; 4 Wire, End of Circuit
505A782G01	96	OFF - ON	3562A01G04	32	Voltmeter - 3 Phase; 4 Wire, End of Circuit
505A797G02	46	Removable Key Handle	3562A01G05	33	Voltmeter - 3 Phase; 3 Wire, End of Circuit
508A207G02	77	Circuit Breaker Control	3669A41G01①	2	Ammeter - 3 Phase; 2 Ct's.
508A218G07	78	Circuit Breaker Control			
508A224G02	58	Regulator Cutout			
508A229G01	79	Circuit Breaker Control			
508A244G01	70	Circuit Breaker Control			
508A244G02	70	Circuit Breaker Control			
508A247G02	49	Removable Key Handle			
508A255G03	83	Circuit Breaker Control			
508A262G01	71	Circuit Breaker Control			
508A262G03	71	Circuit Breaker Control			
508A264G01	72	Circuit Breaker Control			
508A264G02	72	Circuit Breaker Control			
508A281G02	73	Circuit Breaker Control			
508A284G01	74	Circuit Breaker Control			
508A298G02	4	Removable Key Handle			
508A299G03	34	Voltmeter/Ammeter/3 Phase, 3 Wire/3 Ct's., 2 Pt's.			
508A299G09	35	Voltmeter/Ammeter/3 Phase, 3 Wire/3 Ct's., 2 Pt's.			
508A423G16	104	2 Pole - 8 Throw			
508A423G17	105	2 Pole - 12 Throw			
508A463G04	8	Ammeter - 3 Ct's. and Neutral			
508A463G05	9	Ammeter - 4 Ct's.			
508A467G01①	43	Frequency Meter			
508A467G02	43	Removable Key Handle			
508A468G01	56	Pilot Wire Test			
508A474G02	2	Removable Key Handle			
508A480G01	81	Circuit Breaker Control			
508A480G08	82	Circuit Breaker Control			
508A481G01	10	Ammeter - 6 Ct's. Independent			

① Switch requires removable key handle which is not included with switch style - switch and removable key handle must be ordered as separate items.

**Table 2: Basic Switches**

Basic switches **DO NOT** include handle, nameplate or jumpers which should be ordered separately from pages 2, 3, 12, 13, 14 and 15. (All for $\frac{1}{8}$ - $\frac{1}{4}$ inch Thick Panel Mounting)

Symbols

Fixed Handle (F or unmarked)
Removable key handle (R)
Momentary Contacts (MO)
Maintained Contacts (MA)
Switch includes target (T)

Style Number	Handle	Contacts	Stages	Figure	Style Number	Handle	Contacts	Stages	Figure
505A600G01	F	MA	1	116	508A128G01	F	MO	2	121
505A601G01	F	MA	2	2	508A129G01	F	MO	2	121
505A602G01	F	MA	1	115	508A133G01	F	MO	2	122
505A603G01	F	MO	1	115	508A143G01	F	MO	2	123
505A604G01	F	MA	2	25	508A144G01	F	MO	2	123
505A605G01	F	MA	2	26	508A145G01	F	MO	3	124
505A606G01	F	MA	1	108	508A146G01	R	MA	3	124
505A607G01	F	MO	1	111	508A161G01	F	MO	3	125
505A612G01	F	MA	2	118	508A162G01	F	MO	3	126
505A613G01	F	MO	1	63	508A163G01	F	MO	3	127
505A614G01	F	MO	1	65	508A164G01	F	MO	3	127
505A615G01	F	MO	2	118	508A166G01	F	MA	3	129
505A616G01	F	MO	2	59	508A167G01	F	MO	3	129
505A617G01	F	MO	2	68	508A173G01	R	MA	5	133
505A618G01	F	MO	2	66	508A175G01	R	MA	4	130
505A619G01	F	MO	3	128	508A181G01	F	MO	4	131
505A620G01	F	MO	2	122	508A183G01	F	MO	4	132
505A621G01	F	MA	2	113	508A184G01	F	MO	4	132
505A622G01	F	MA	2	112	508A189G01	F	MO	3	125
505A623G01	F	MO	1	108	508A196G01	F	MA	6	134
505A624G01	F	MO	2	113	508A199G01	F	MA	3	135
505A625G01	F	MO	2	112	508A300G01	R	MA	3	135
505A626G01	F	MA	3	124	508A301G01	R	MA	1	136
505A627G01	F	MO	3	124	508A302G01	F	MA	1	137
505A628G01	F	MA	3	114	508A303G01	R	MA	1	137
505A630G01	F	MO	4	130	508A307G01	F	MA	3	139
505A631G01	F	MA	5	133	508A308G01	R	MA	3	139
505A632G01	F	MO	5	133	508A310G01	F	MA	3	140
505A633G01	F	MA	1	136	508A311G01	R	MA	3	140
505A634G01	F	MA	1	111	508A314G01	F	MA	4	141
505A635G01	F	MO	2	5	508A317G01	F	MA	6	142
505A638G01	F	MO	1	117	508A320G01	R	MA	2	143
505A644G01	F	MA	1	154	508A323G01	F	MA	4	144
505A645G01	F	MA	2	143	508A326G01	F	MA	6	145
505A647G01	R	MA	1	108	508A334G01	F	MA	2	149
505A649G01	R	MA	1	115	508A342G01	F	MO	2	151
505A650G01	F	MA	1	146	508A343G01	F	MA	1	152
505A651G01	F	MO	1	146	508A344G01	F	MO	1	152
505A652G01	R	MA	2	50	508A351G01	F	MA	1	153
505A653G01	R	MA	2	51	508A363G01	F	MA	3	138
505A654G01	R	MA	1	111	508A364G01	R	MA	3	138
505A655G01	R	MA	1	41	508A368G01	F	MA	3	56
505A657G01	R	MA	1	115	508A370G01	R	MA	4	141
505A659G01	F	MA	2	147	508A396G01	F	MA	1	110
505A660G01	F	MA	1	148	658A578G01	F	MO	1	148
505A661G01	F	MO	1	150	658A594G01	F	MA	2	122
505A664G01	F	MA	4	130	661A105G01	R	MA	1	116
505A667G01	F	MA	1	109	661A150G01	R	MA	2	147
505A668G01	F	MO	1	109	661A152G01	R	MA	1	146
505A669G01	R	MA	1	109	663A175G01	R	MA	2	149
505A670G01	R	MA	2	112	663A176G01	R	MA	1	148
505A672G01	R	MA	2	113	663A177G01	R	MO	1	108
505A684G01	F	MO	3	114	663A195G01	R	MO	1	115
505A685G01	R	MA	3	114	663A340G01	R	MA	1	154
508A107G01	F	MO	1	115	781A123G01	R	MA	1	152
508A108G01	R	MA	1	115	781A167G01	R	MA	6	134
508A110G01	F	MO	1	116	781A181G01	R	MA	4	144
508A111G01	F	MO	1	117	781A377G01	F	MA	1	117
508A112G01	R	MA	1	117					
508A118G01	F	MO	2	118					
508A119G01	R	MA	2	118					
508A124G01	F	MA	2	119					
508A125G01	F	MO	2	119					
508A126G01	F	MA	2	120					
508A127G01	F	MO	2	120					




Terminal Connectors

Additional flexibility of the type W-2 switch is gained with the use of terminal connectors (jumpers) applied to the switch terminals.

Complete type W-2 switches ordered for specific applications where the circuitry requires jumpers, are applied at the factory.


When basic switches are used and when field changes of existing switches becomes necessary, terminal connectors (jumpers) may be obtained from the factory. The following charts will aid in identifying the terminal connectors. These charts identify the terminals to be connected and the connectors by number to accomplish such connection.




Style No.	Dim. "A"
677C782G01	3.50
677C782G02	4.25
677C782G03	5.00
677C782G04	5.50

Terminal Connectors

The terminal connectors listed below are those to be selected and ordered separately. These connectors may be applied to the general application switches shown in Figures 108 through 154.



Style Number	Dim. "A"
677C519H08	.89
677C519G01	1.59
677C519G05	1.59
677C519G07	1.22
677C782G01	3.50
677C782G02	4.25
677C782G03	5.00
677C782G04	5.50
677C782G05	6.00
677C782G06	7.25
677C782G07	9.75
677C782G08	10.50





Ordering Nameplates

Nameplates can be ordered:


- 1) Blank
- 2) Blank to be Engraved
- 3) Preengraved

Each request is specifically outlined.


Blank Nameplates

The nameplates listed below are inclusive of the entire stock of blank nameplates available at the factory. To order select the style number to meet application.


Note: Radial lines etched on blank nameplates will not be blackened in.




692C707H01
(Fixed Handle)




692C707H02
(Fixed Handle)




692C707H03
(Removable Key)




692C707H04
(Fixed Handle)




692C707H05
(Removable Key)




692C707H06
(Fixed Handle)




692C707H08
(Fixed Handle)




692C707H09
(Removable Key)




692C707H10
(Fixed Handle)




692C707H12
(Fixed Handle)



692C707H13
(Removable Key)



692C707H14
(Fixed Handle with
Target)



692C707H16
(Fixed Handle)




Blank Nameplates to be Ordered

Refer to Page 13 and select style number of blank nameplate. Refer to Table 3 and specify required markings to be engraved. Required markings must be less than or equal to the number of letter spaces allowed per line.

Note: Letter spacing allowance shown in Table 3 is also applicable to Removable Key style nameplates.


Table 3

Number of Letter Spaces per Line




Name Plate Engraving Locations

Number of Letter Spaces per Line




Name Plate Engraving Locations

Number of Letter Spaces per Line




Name Plate Engraving Locations


Example 1



Example 2



Example 3



Similar to 692C707H03
EXCEPT
nameplate to read;

15 = TEMPERATURE
16 = INDICATOR
11 = OFF
12 = CAL
1 = 1
2 = 2
3 = 3
4 = 4

Similar to 692C707H04
EXCEPT
nameplate to read;

15 = PORT POWER
16 = SELECTOR
9 = 70
10 = 80
11 = 90
12 = 100
1 = 110


Similar to 692C707H14
EXCEPT
nameplate to read;

7 = LOCKOUT
8 = TO
9 = PULL
11 = STOP
12 = AUTO
1 = START


**Preengraved Nameplates**

The nameplates listed below are inclusive of the entire stock of preengraved nameplates available at the factory. Any desired name-


plate markings deviating from the outline below must be ordered as a blank nameplate to be engraved. To order select the style number to meet the application.




677C524H01




677C524H02




677C524H03




677C524H04




677C524H06




677C524H09




677C524H10




677C524H11




677C524H13




677C524H14




677C524H15




677C524H16




677C524H17




677C524H18




677C524H19




677C524H20




677C525H01




677C525H02



677C525H03



791A737H01




791A737H02




Protective Covers, Type W-2 Switch

Designed to totally enclose all contact terminals. Made of high density black Polyethylene. Provides no conduit connection. Wiring enters through opening between panel and front opening of enclosure. Secured in position by switch tie bolts. Switch identification remains visible.

Switch Stage	A
1	2.88
2	4.38
3	5.88
4	7.38
5	8.88
6	10.38
7	11.88
8	13.38




Typical Mounting



Drilling Plan

Note:
For Removable Key Designs Panel Hole Must be 1.28 Diameter.
For Fixed Handle Designs Hole May be Reduced to .43 Diameter.





Tumbler Pin Key Lock

The Type W-2 switch can be supplied with either 1, 2, or 3 locks. In the case of one lock, it can be mounted either at the top or to the left or to the right of the switch handle. For one lock, top mounting is considered the standard. When two locks are required, the normal mounting is one lock to the left and one lock to the right of the switch handle.

Where several switches are supplied with locks, they may be keyed alike or differently as required.

When a single switch is furnished with more than one lock, such locks may be keyed alike or keyed differently as the application may require.

The above considers that key interlocking with other equipment is not required and that the switch only is to be locked and in which cases we would supply Yale lock cylinders from factory stock. When ordering, specify in what position(s) the switch is to be locked. Key(s) may be removable in switch locked position(s) only.

To order tumbler pin key locks the following questions apply:

1) Identify how many locks are needed.

- A) 1
- B) 2
- C) 3

2) Specify location of the lock.

- A) Above the handle
- B) To the left of the handle
- C) To the right of the handle

3) Specify what position(s) the key is to be removed.

- A) 12 o'clock position
- B) 1 o'clock position
- C) 2 o'clock position

Etc.



4) If more than a quantity of one switch is ordered specify if the locks are to be;

- A) Keyed differently
- B) Keyed alike

5) If one switch is furnished with more than one lock specify if the locks are to be;

- A) Keyed differently
- B) Keyed alike

For Handle and Switch Dimensions, Refer to Standard Outline Drawings



Drilling Plan (Key Lock)



Key Interlocking

When key interlocking with other equipment is required, Kirk locks would be specially ordered by the customer from Brown Boveri Company separately, but mounted by Westinghouse. Contact:

Westinghouse Electric Corporation
Marketing Department
London, Kentucky 40741

When ordering Type W-2 switches with key interlocking, i.e., switches to be furnished with locks having keys which are to be used in locks applied to other apparatus such as circuit breakers, disconnect switches, etc., the customer needs to furnish the following information:

- 1) Customer's purchase order number and field sales office general order number on which lock switches were originally ordered.
- 2) Lock numbers and mounting instructions. (Lock number referred to style and mounting location.)
- 3) Locks need to be sent to the attention of: Westinghouse Electric Corp.
% Production Department
Daniel Boone Parkway
London, Kentucky 40741



Key interlocking can be furnished on Type W-2 switches utilizing either 1, 2, or 3 locks with keying as required.

The drilling plan shown is a composite drilling for three (3) locks. If less than three locks are used, apply the appropriate portion of the drilling plan.

For further classification and specific reference:

Assembly #1 – one lock mounted above handle

Assembly #2 – one lock mounted to left of handle.



Assembly #3 – one lock mounted to right of handle.

Assembly #4 – three locks—including assemblies 1, 2 and 3.



Auxiliary Switch, Type W-2

The type W-2 auxiliary switch is designed around the six contact stage frame and rotor of the type W-2 instrument and control switch. This switch is a two position device and can be supplied with an overtravel lever or without lever. Levers are available with adjustable linkage (serrated styles) or non-adjustable (solid lever with pin). Nameplates are not supplied with auxiliary switches.



Contacting of one stage may take the form of either Figure #1 or Figure #2.

For multiple stages contacting may take the form of Figure #1 or Figure #2 or a combination of both as shown in Figure #3.

Switch Position Tabulations

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

Figure 1

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

Figure 2

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

Figure 3



Outline Dimensions

Six and Twelve Contact Frame Pull Out and Non-Pull Out



2.06 (For Figures 4, 5 and 6)
.84 (For Figure 8), .81 (For Figure 9)

Figure 3








Figure 3

Non-Pull Out

Line No.	No. of Stages	A	Description	Net Weight Pounds 6 Contact Frame	12 Contact Frame
1	1	2.97	STD.	1.12	1.50
2	2	4.47	STD.	1.50	2.12
3	3	5.97	STD.	1.85	2.70
4	4	7.47	STD.	2.35	3.25
5	5	8.97	STD.	2.75	3.80
6	6	10.47	STD.	3.12	4.50
7	7	11.97	STD.	3.60	5.00
8	8	13.47	STD.	4.00	5.60
21	1	3.85	2-Mech HSG.	1.52	1.90
22	2	5.35	2-Mech HSG.	1.90	2.52
23	3	6.85	2-Mech HSG.	2.25	3.10
24	4	8.35	2-Mech HSG.	2.75	3.65
25	5	9.85	2-Mech HSG.	3.15	4.20
26	6	11.35	2-Mech HSG.	3.52	4.90
27	7	12.85	2-Mech HSG.	4.00	5.40
28	8	14.35	2-Mech HSG.	4.40	6.00

With Pull Out

Line No.	No. of Stages	B	Description	Line No.	Panel THK	Net Weight Pounds 6 Contact Frame	12 Contact Frame
31	1	3.81	STD.	51	.125 to .250	1.25	1.65
32	2	5.31	STD.	52	.250	1.60	2.60
33	3	6.81	STD.	53	.300	2.00	2.80
34	4	8.31	STD.	54	.38	2.50	3.40
35	5	9.81	STD.	55	.50	3.85	4.00
36	6	11.31	STD.	56	1.00	4.25	4.60
37	7	12.81	STD.	57	1.00	5.12	5.70
38	8	14.31	STD.	58	1.00	4.12	5.70
41	1	4.69	2-Mech HSG.	59	2.00	1.65	2.05
42	2	6.19	2-Mech HSG.	60	2.25	2.00	3.00
43	3	7.69	2-Mech HSG.			2.40	3.20
44	4	9.19	2-Mech HSG.			2.90	3.80
45	5	10.69	2-Mech HSG.			3.25	4.40
46	6	12.19	2-Mech HSG.			3.65	5.00
47	7	13.69	2-Mech HSG.			4.10	5.52
48	8	15.19	2-Mech HSG.			4.52	6.10



Removable Key Dimension

Figure A

1	2.62
2	2.62
3	2.62
4	4.12
5	1.40
6	1.37



Standard Application Switches, Style Numbers

Application	Style Number	Handle Shape	Contact Type	Figure Number	Application	Style Number	Handle Shape	Contact Type	Figure Number
Ammeter									
2 Phase	505A700G01	Round	MA	1	3 Phase, 3 Wire System (3 Circuits and 2 PT's)	508A299G03	Round	MA	34
3 Phase, 2 CT's	505A701G02	Round	MA	2	3 Phase, 4 Wire System (3 CT's and 3 PT's)	508A299G09	Round	MA	35
3 Phase, 2 CT's (Use Removable Key)	3669A41G01	(Key)*	MA	2	3 Phase, 4 Wire System (3 CT's and 3 PT's) End of Circuit Connection	787A977G01	Round	MA	36
3 Phase, 3 CT's (Independent Circuit)	505A701G01	Round	MA	2A	3 Phase, 3 Wire System (3 CT's and 2 PT's) End of Circuit Connection	787A977G02	Round	MA	37
3 Phase, 3 CT's (Independent Circuit) Use Removable Key	661A208G01	(Key)*	MA	2A					
3 Phase, 3 CT's (No OFF Position)	661A208G03	(Key)*	MA	3					
3 Phase, 3 CT's (No OFF Position)	505A701G05	Round	MA	3					
3 Phase, 3 CT's (End of Circuit)	787A976G01	Round	MA	4					
3 Phase, 3 CT's (End of Circuit)	800A426G01	(Key)*	MA	4					
3 Phase, 3 CT's (End of Circuit) Use Removable Key	508A298G02	(Key)*	MA	5					
3 Phase, 2 CT's (End of Circuit)	787A976G02	Round	MA	5					
3 Phase, 2 CT's (End of Circuit) Use Removable Key	800A426G02	(Key)*	MA	5					
3 Phase, 3 CT's (End of Circuit) No OFF Position	508A298G02	(Key)*	MA	6					
3 Phase, 3 CT's (End of Circuit) No OFF Position	787A976G03	Round	MA	6					
3 Phase, 2 CT's (End of Circuit) No OFF Position	787A976G04	Round	MA	7					
3 CT's and Neutral	508A463G04	Round	MA	8					
4 CT's	508A463G05	Round	MA	9					
6 CT's Independently on One Meter	508A481G01	Round	MA	10					
2 Three Phase CT's	658A615G02	Round	MA	11					
3 Phase, 2 CT's (End of Circuit)	787A984G01	Mini-Slim	MA	12					
3 Phase, 2 CT's (End of Circuit)	787A984G02	Mini-Slim	MA	13					
3 Phase, 3 CT's (End of Circuit)	787A984G03	Mini-Slim	MA	14					
3 Phase, 3 CT's (End of Circuit)	787A984G04	Mini-Slim	MA	15					
ON-OFF, 1 CT's (End of Circuit)	787A984G05	Mini-Slim	MA	16					
3 Phase, 2 CT's (End of Circuit)	787A984G06	Mini-Slim	MA	17					
3 Phase, 3 CT's	787A984G07	Mini-Slim	MA	18					
Voltmeter									
Single Phase (Use Removable Key)	505A747G01	(Key)*	MA	19	OFF-ON (Removable Key)	505A753G01	(Key)*	MA	51
2 Phase, Ac, 3 Wire	505A702G01	Round	MA	20	OFF-ON (Removable Key)	505A753G02	(Key)*	MA	51
2 Circuit, Dc, 2 Wire	505A702G02	Round	MA	21	W-OFF-RVA	505A754G01	(Key)*	MA	52
2 Circuit, Dc, 2 Wire (Use Removable Key)	505A748G01	(Key)*	MA	21	OFF-ON	505A754G02	(Key)*	MA	52
3 Wire, Dc	505A702G02	Round	MA	22	OFF-ON	505A754G01	(Key)*	MA	53
3 Phase, 3 Wire	505A702G04	Round	MA	23	W-OFF-RVA	505A712G91	Round	MA	54
3 Phase, 3 Wire (Use Removable Key)	505A749G01	(Key)*	MA	23	OFF-ON	508A496G03	Round	MA	54
3 Phase, 4 Wire	505A749G02	Round	MA	24	OFF-ON	802A470G01	(Key)*	MA	55
3 Phase, 4 Wire (Use Removable Key)	505A702G05	Round	MA	24	(Removable Key)	505A754G03	(Key)*	MA	55
4 Circuit	505A762G01	Round	MA	25					
3 Phase and Neutral	505A705G01	Round	MA	26	Pilot Wire Test	508A468G01	Round	MO	56
Two 3 Phase Circuits	505A705G02	Round	MA	27	Regulator Cutout	505A712G01	Round	MA	57
6 Circuits	505A705G03	Round	MA	28	Regulator Cutout	508A224G02	Round	MA	58
3 Phase, 3 Wire (End of Circuit)	3562A01G01	Mini-Slim	MA	29	Electrode Control	505A716G02	Oval	MO	59
3 Phase, 3 Wire (End of Circuit)	3562A01G02	Mini-Slim	MA	30	Electrode Control	505A716G04	Pistol	MO	59
3 Phase, 4 Wire (End of Circuit)	3562A01G03	Mini-Slim	MA	31	Motor Control	505A716G03	Oval	MO	60
3 Phase, 4 Wire (End of Circuit)	3562A01G04	Mini-Slim	MA	32	Motor Control	505A716G05	Pistol	MO	60
3 Phase, 3 Wire (End of Circuit)	3562A01G05	Mini-Slim	MA	33	Speed Control	663A245G06	Pistol	MO	61

**Standard Application Switches, Style Numbers, *Continued*****Circuit Breaker Control**

Style Number	Handle Shape	Handle Operation	Figure ^② Number
505A713G01	Pistol	MO	63
505A713G03	Oval	MO	63
505A713G02	Pistol	MO	64
505A714G01	Pistol	MO	65
505A714G02	Oval	MO	65
505A718G01	Pistol	MO	66
505A718G15	Pistol	MO	67
505A717G01	Pistol	MO	68
505A717G03	Oval	MO	68
505A720G01	Pistol	MO	69
505A720G03	Oval	MO	69
508A244G01	Pistol	MO	70
508A244G02	Oval	MO	70
508A262G01	Pistol	MO	71
508A262G03	Oval	MO	71
508A264G01	Oval	MO	72
508A264G02	Pistol	MO	72
508A281G02	Pistol	MO	73
508A284G01	Pistol	MO	74
505A738G07	Pistol	MO	75
802A231G01	Pistol	MO	76
508A207G02	Pistol	MO	77
508A218G07	Pistol	MO	78
508A229G01	Pistol	MO	79
802A469G01	Pistol	MO	80
508A480G01	Pistol	MO	81
508A480G08	Pistol	MO	82
508A255G03	Pistol	MO	83

① All circuit breaker control switches listed are momentary operation, i.e., spring return to neutral.

② Figures 63 to 74 include a "Pull-to-Lock" or "Pull-Lamp Cutout" Feature. Figures 75 to 83 do not include a "Pull-out" feature.

Temperature Switches

All Type W-2 Temperature Switches Furnished by Westinghouse Have Gold Plated Contacts.

Number of Thermocouples	Style Number	Handle	Handle Shape	Figure Number
Accurate Lead Compensation				
One	781A254G01	Fixed	Round	84
Four	505A709G01	Fixed	Round	85
	505A711G01	Key	Round	86
Six	661A210G06	Fixed	Round	87
	781A489G01	Key	Round	88
Ten	661A210G01	Fixed	Round	89
	663A454G01	Key	Round	90
		505A711G03		

OFF-ON Switches and Selector Switches

Style Number	Handle Operation	Figure Number
505A706G01	MA	91
505A706G02	MA	91
505A706G03	MA	91
505A723G01	MO	91
505A723G02	MO	91
505A723G03	MO	91
505A702L03	MA	92
505A733G01	MA	93
505A745G01	MA	94
505A722G01	MA	95
505A722G02	MA	95
505A722G03	MA	95
505A722G01	MO	95
505A725G06	MO	95
505A722G01	MA	95
505A722G02	MA	95
505A725G01	MO	95
505A725G11	MO	95
505A781G03	MA	96
505A782G01	MO	96

General Application Switches


Style Number	Application	Handle Operation	Figure Number
505A706G55	1 or 2 Pole-2 Throw	MA	97
505A733G17	1 Pole-4 Throw	MA	98
505A733G18	1 Pole-5 Throw	MA	99
505A745G17	1 Pole-7 Throw	MA	100
505A745G18	1 Pole-8 Throw	MA	101
505A745G19	1 Pole-10 Throw	MA	102
505A702L02	1 or 2 Pole with OFF	MA	103
505A703G51	2 Pole-2 Throw	MO	103
508A423G16	2 Pole-8 Throw	MA	104
508A423G17	2 Pole-12 Throw	MA	105
505A712G92	4 Pole-2 Throw	MA	106
505A715G32	4 Pole-2 Throw	MO	106
505A726G14	6 Pole-2 Throw	MA	107
505A727G15	6 Pole-2 Throw	MO	107



Position Tabulations

All Wiring Diagrams Contained in This Bulletin are to be Considered as "TYPICAL."

1



Ammeter

2 Phase

Style No. 505A700G01

Handle: Round Fixed


Contacts: Maintained

Stages: 2, Six Contact Frame


Mounting: 1/8-1/4

Target: No

CONTACT	POSITION	1	-	OFF	-	2
A11-B11	X X					
A12-B12	X X	X	X			
A1-B1		X	X			
A5-B5	X X					
A6-B6	X X	X	X			
A7-B7	X X	X	X	X	X	



2A



Ammeter

3 Phase-3 CT's

Style No. 505A701G01

Handle: Round Fixed


Contacts: Maintained

Stages: 2, Six Contact Frame


Mounting: 1/8-1/4

Target: No

(R) Switch: S#661A208G01
Removable Key Handle: S#661A208G03
Key Removable in OFF Position Only
S=30°



2



Ammeter

3 Phase-2 CT's

Style No. 505A701G02

Handle: Round Fixed

Contacts: Maintained


Stages: 2, Six Contact Frame

Mounting: 1/8-1/4


Target: No

CONTACT	POSITION	1	-	2	-	3
A11-B11	0 - 1 - 2 - 3	X	X	X	X	
A12-B12		X	X	X	X	
A1-B1		X	X			
A5-B5	X X					
A6-B6	X X	X	X			
A7-B7	X X	X	X	X	X	
C11-D11	X X	X	X	X	X	X
C12-D12	X X	X	X	X	X	X
C1-D1	X X	X	X	X	X	X
C5-D5	X X	X	X	X	X	X
C6-D6	X X	X	X	X	X	X
C7-D7	X X	X	X	X	X	X

(R) Switch: S#3669A41G01
Removable Key Handle: S#787A989G02
Key Removable in OFF Position Only.
S=240°



3



Ammeter

3 Phase-3 CT's

Style No. 505A701G05

Handle: Round Fixed


Contacts: Maintained

Stages: 2, Six Contact Frame

Mounting: 1/8-1/4

Target: No

CONTACT	POSITION	1	-	2	-	3
A11-B11	X X					
A12-B12		X	X	X		
A1-B1					X	X
A5-B5	X X	X	X			
A6-B6	X X		X	X	X	
A7-B7	X X				X	X
C11-D11	X X	X	X	X	X	X
C12-D12	X X	X	X	X	X	X
C1-D1	X X	X	X	X	X	X
C5-D5	X X	X	X	X	X	X
C6-D6	X X	X	X	X	X	X
C7-D7	X X	X	X	X	X	X




Notes:

"S" Angle Refers to Key Bearing Setting for Switches With Removable Key Handles.

"R" = Removable Key Switch.

Position Tabulations, *Continued*

4



Ammeter

3 Phase-3 CT's (End of Circuit)

Style No. 787A976G01

Handle Round Fixed

Contacts Maintained

Stages 1, Six Contact Frame

Mounting 1-8-1 4

Target: No


(R) Switch: S#800A426G01

Removable Key Handle: S#508A298G02


Key Removable in OFF Position Only

S-O

CONTACT	OFF	-	1	-	2	-	3
A11-B11	X	X	X	X	X	X	X
A12-B12	X	X	X	X	X	X	X
A1-B1	X	X	X	X	X	X	X
A5-B5	X	X	X	X	X	X	X
A6-B6				X	X	X	
A7-B7						X	X



7



Ammeter

3 Phase-2 CT's (End of Circuit)

Style No. 787A976G04

Handle Round Fixed

Contacts Maintained

Stages 1, Six Contact Frame

Mounting 1-8-1 4

Target: No


(R) Switch: S#800A426G01

Removable Key Handle: S#508A298G02


Key Removable in OFF Position Only

S-O

CONTACT	1	-	2	-	3
A11-B11	X	X	X	X	X
A12-B12	X	X	X	X	X
A1-B1	X	X	X	X	X
A5-B5	X	X	X	X	X
A6-B6			X	X	X
A7-B7				X	X



5



Ammeter

3 Phase-2 CT's (End of Circuit)

Style No. 787A976G02

Handle Round Fixed

Contacts Maintained

Stages 1, Six Contact Frame

Mounting 1-8-1 4

Target: No


(R) Switch: S#800A426G02

Removable Key Handle: S#508A298G02


Key Removable in OFF Position Only

S-O

CONTACT	OFF	-	1	-	2	-	3
A11-B11	X	X	X	X	X	X	X
A12-B12	X	X	X	X	X	X	X
A1-B1	X	X	X	X	X	X	X
A5-B5	X	X	X	X	X	X	X
A6-B6			X	X	X		
A7-B7				X	X	X	



6



Ammeter

3 Phase-3 CT's (End of Circuit)

Style No. 787A976G03

Handle Round Fixed

Contacts Maintained

Stages 1, Six Contact Frame

Mounting 1-8-1 4

Target: No


(R) Switch: S#800A426G03

Removable Key Handle: S#508A298G03


Key Removable in OFF Position Only

S-O

CONTACT	1	-	2	-	3
A11-B11	X	X	X	X	X
A12-B12	X	X	X	X	X
A1-B1	X	X	X	X	X
A5-B5	X	X			
A6-B6			X	X	X
A7-B7				X	X



8



Ammeter

Style No. 508A463G04

Handle Round Fixed


Contacts Maintained

Stages 3, Six Contact Frame

Mounting 1-8-1 4

Target: No


CONTACT	OFF	-	1	-	2	-	3	-	N
A11-B11									
A12-B12	X	X							
A1-B1		X	X	X	X				
A5-B5									
A6-B6								X	X
A7-B7								X	X
C11-D11	X	X	X	X	X	X	X	X	X
C12-D12	X	X	X	X	X	X	X	X	X
C1-D1	X	X	X	X	X	X	X	X	X
C5-D5	X	X	X	X	X	X	X	X	X
C6-D6	X	X	X	X	X	X	X	X	X
C7-D7	X	X	X	X	X	X	X	X	X
E11-F11									
E12-F12	X	X							
E5-F5			X	X	X				
E6-F6					X	X	X		
E7-F7						X	X		





Position Tabulations. Continued

9




Ammeter

Style No. 508A463G05
Handle: Round Fixed
Contacts: Maintained
Stages: 3, Six Contact Frame
Mounting: 1/8-1/4
Target: No

CONTACT	POSITION														
	-	-	-	OFF	-	-	1	-	2	-	-	3	-	-	4
A11-B11	X	X													
A12-B12		X	X	X											
A1-B1			X	X	X										
A5-B5						X	X	X							
A6-B6								X	X	X					
A7-B7											X	X			
C11-D11	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C12-D12	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C1-D1	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C5-D5	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C6-D6	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C7-D7	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
E11-F11	X	X													
E12-F12		X	X	X											
E1-F1			X	X	X										
E5-F5						X	X	X							
E6-F6								X	X	X					
E7-F7										X	X				



10



Ammeter

Style No. 508A481G01
Handle: Round Fixed
Contacts: Maintained
Stages: 3, Six Contact Frame
Mounting: 1/8-1/4
Target: No


CONTACT	POSITION						BUS1														
	BUS1	BUS2	BUS1	BUS2	BUS1	BUS2	BUS1	BUS2	BUS1	BUS2	BUS1	BUS2	BUS1	BUS2							
A11-B11	O	O	O	-	1	-	2	-	3	-	0	0	0	-	3	-	2	-	-	1	-
A12-B12		X	X	X																	
A1-B1			X	X	X						X	X	X								
A5-B5						X	X	X													
A6-B6							X	X	X												
A7-B7										X	X	X									
C11-D11	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C12-D12	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C1-D1	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C5-D5	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C6-D6	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C7-D7	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
E11-F11	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
E12-F12		X	X	X							X	X	X								
E1-F1			X	X	X						X	X	X								
E5-F5						X	X	X						X	X	X					
E6-F6							X	X	X					X	X	X					
E7-F7									X	X				X	X	X					



Balance of
Incoming
Connections
are Similar.

Position Tabulations, *Continued*


11




Ammeter

Style No 658A615G02
Handle: Round Fixed
Contacts: Maintained
Stages: 2, Six Contact Frame
Mounting: 1 8-1 4
Target: No

CONTACT	POSITION						POSITION							
	BUS 2	0	0	0	-1	-2	-3	BUS 1	0	0	0	-3	-2	-1
A11-B11	X	X	X	X	X	X	X							
A12-B12														
A1-B1														
A5-B5														
A6-B6														
A7-B7														
C11-D11	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C12-D12	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C1-D1	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C5-D5	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C6-D6	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C7-D7	X	X	X	X	X	X	X	X	X	X	X	X	X	X



12




Ammeter


3 Phase-2 CT's (End of Circuit)
Style No 787A984G01
Handle: Fixed, Mini-Slim DS
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1 8-1 4
Target: No

CONTACT	POSITION						
	OFF	-	1	-	2	-	3
A11-B11	X	X	X	X	X	X	X
A12-B12	X	X	X	X	X	X	X
A1-B1	X	X	X	X	X	X	X
A5-B5							
A6-B6							
A7-B7							

Note:
Switch Mounted 90° From Standard.



13



Ammeter

3 Phase-2 CT's (End of Circuit)
Style No 787A984G02
Handle: Fixed, Mini-Slim DS
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1 8-1 4
Target: No

CONTACT	POSITION						
	OFF	-	1	-	2	-	3
A11-B11	X	X	X	X	X	X	X
A12-B12	X	X	X	X	X	X	X
A1-B1	X	X	X	X	X	X	X
A5-B5							
A6-B6							
A7-B7							

Note:
Switch Mounted 90° From Standard.

Ammeter

3 Phase-3 CT's (End of Circuit)
Style No 787A984G03
Handle: Fixed, Mini-Slim DS
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1 8-1 4
Target: No

CONTACT	POSITION						
	OFF	-	1	-	2	-	3
A11-B11	X	X	X	X	X	X	X
A12-B12	X	X	X	X	X	X	X
A1-B1	X	X	X	X	X	X	X
A5-B5							
A6-B6							
A7-B7							

Note:
Switch Mounted 90° From Standard.

Ammeter

3 Phase-3 CT's (End of Circuit)
Style No 787A984G04
Handle: Fixed, Mini-Slim DS
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1 8-1 4
Target: No


CONTACT	POSITION						
	OFF	-	1	-	2	-	3
A11-B11	X	X	X	X	X	X	X
A12-B12	X	X	X	X	X	X	X
A1-B1	X	X	X	X	X	X	X
A5-B5							
A6-B6							
A7-B7							

Note:
Switch Mounted 90° From Standard.



Position Tabulations, Continued

16




CONTACT	POSITION	OFF	ON
A11-B11	X X	X	X
A5-B5	X X	X	X

Note:
Switch Mounted 90° From Standard


Ammeter

3 Phase-1 CT

Style No 787A984G05
Handle: Mini-Slim, Fixed
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: No



17




CONTACT	POSITION	OFF	1	2	3
A11-B11	X X	X	X X	X X	X X
A12-B12	X X X X	X X X X	X X X X	X X X X	X X X X
A1-B1	X X X X	X X X X	X X X X	X X X X	X X X X
A5-B5	X X X X	X X X X	X X X X	X X X X	X X X X
A6-B6	X X X X	X X X X	X X X X	X X X X	X X X X
A7-B7	X X X X	X X X X	X X X X	X X X X	X X X X

Note:
Switch Mounted 90° From Standard.


Ammeter

3 Phase-2 CT's (End of Circuit)

Style No. 787A984G06
Handle: Mini-Slim DS, Fixed
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: No



18




CONTACT	POSITION	OFF	1	2	3
A11-B11	X X X X	X X X X	X X X X	X X X X	X X X X
A12-B12	X X X X X X X X	X X X X X X X X	X X X X X X X X	X X X X X X X X	X X X X X X X X
A1-B1	X X X X X X X X	X X X X X X X X	X X X X X X X X	X X X X X X X X	X X X X X X X X
A5-B5	X X X X X X X X	X X X X X X X X	X X X X X X X X	X X X X X X X X	X X X X X X X X
A6-B6	X X X X X X X X	X X X X X X X X	X X X X X X X X	X X X X X X X X	X X X X X X X X
A7-B7	X X X X X X X X	X X X X X X X X	X X X X X X X X	X X X X X X X X	X X X X X X X X

Note:
Switch Mounted 90° From Standard.


Ammeter

3 Phase-3 CT's (End of Circuit)

Style No. 787A984G07
Handle: Mini-Slim DS, Fixed
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: No




19



CONTACT	POSITION	OFF	ON
A11-B11	X	X	
A12-B12	X	X	

CONTACT	POSITION	OFF	ON
A11-B11	X	X	
A12-B12	X	X	

20



CONTACT	POSITION	OFF	1	2
A11-B11	X	X		
A12-B12	X	X		


CONTACT	POSITION	OFF	1	2
A11-B11	X	X		
A12-B12	X	X		

Voltmeter


Single Phase

(R) Switch: S#505A747G01
Removable Key Handle S# 505A747G02
Key Removable in OFF Position Only
S=0°

Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: No



21



CONTACT	POSITION	OFF	1	2
A11-B11	X	X		
A12-B12	X	X		

CONTACT	POSITION	OFF	1	2
A11-B11	X	X		
A12-B12	X	X		

Voltmeter

2 Phase-Ac-3 Wire

Style No. 505A702G01


Handle: Round Fixed

Contacts: Maintained

Stages: 1, Six Contact Frame

Mounting: 1/8-1/4


Target: No





Position Tabulations, Continued

22



Voltmeter

Dc-3 Wire

Style No. 505A702G03

Handle: Round Fixed


Contacts: Maintained

Stages: 1, Six Contact Frame


Mounting: 1/8-1/4

Target: No

CONTACT	POSITION	OFF	1	2
A11-B11	X			
A12-B12	X			
A1-B1	X			
A5-B5	X			
A6-B6	X			
A7-B7	X			



23



Voltmeter

3 Phase-3 Wire

Style No. 505A702G04

Handle: Round Fixed

(R) Switch Only: S#505A749G01

Removable Key Handle: S# 505A749G02

Key Removable in OFF Position Only
S=60*

Contacts: Maintained

Stages: 1, Six Contact Frame

Mounting: 1/8-1/4


Target: No

CONTACT	POSITION	OFF	1	2	3
A11-B11	X				
A12-B12	X				
A1-B1	X				
A5-B5	X				
A6-B6	X				
A7-B7	X				

Tabulation of Switch as Jumpered

A1-B11	X	X
A1-B12	X	
A5-B5	X	
A5-B7		X X

24



Voltmeter

3 Phase-4 Wire

Style No. 505A702G05

Handle: Round Fixed

(R) Switch Only: S#505A762G01

Removable Key Handle: S# 505A762G02

Key Removable in OFF Position Only.
S=315*

Contacts: Maintained

Stages: 1, Six Contact Frame

Mounting: 1/8-1/4



Target: No

CONTACT	POSITION	OFF	1	2	3	N
A11-B11	X					
A12-B12	X					
A1-B1	X					
A5-B5	X					
A6-B6	X					
A7-B7	X					

Tabulation of Switch as Jumpered

A1-B11	X	
A1-B12	X	
A1-B1		X
A5-B5	X	X X

25



Voltmeter

4 Circuit

Style No. 505A704G01


Handle: Round Fixed

Contacts: Maintained



Stages: 2, Six Contact Frame

Mounting: 1/8-1/4

Target: No



26



Voltmeter

Phase to Neutral and Phase to Phase

Style No. 505A705G01



Handle: Round Fixed

Contacts: Maintained

Stages: 2, Six Contact Frame

Mounting: 1/8-1/4


Target: No





Position Tabulations, Continued

27




Voltmeter


Two 3 Phase Circuits

Style No. 505A705G02
Handle Round Fixed
Contacts Maintained
Stages: 2, Six Contact Frame
Mounting: 1-8-1-4
Target No.

CONTACT	POSITION											
	0	0	0	1	2	3	0	0	0	3	2	1
A11-B11	X											
A12-B12		X										
A1-B1			X									
A5-B5				X								
A6-B6					X							
A7-B7						X						
C11-D11							X					
C12-D12								X				
C1-D1									X			
C5-D5										X		
C6-D6											X	
C7-D7												X



29



Voltmeter

3 Phase-3 Wire

Style No. 3562A01G01
Handle: Mini-Slim DS, Fixed
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1-8-1-4
Target No.

CONTACT	POSITION					
	0	1	2	3		
A1-B11	X					
A12-B12		X				
A1-B1			X			
A5-B5				X		
A6-B6					X	
A7-B7						X


Tabulation of Switch With Extra Connectors Added.

CONTACT	POSITION					
	0	1	2	3		
A1-B11	X					
A12-B12		X				
A1-B1			X			
A5-B5				X		
A6-B6					X	
A7-B7						X

Note:

Switch Mounted 90° From Standard.
Nameplate Arrow Down.

30



Voltmeter

3 Phase-3 Wire

Style No. 3562A01G01
Handle: Mini-Slim DS, Fixed
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1-8-1-4
Target No.

CONTACT	POSITION					
	0	1	2	3		
A11-B11	X					
A12-B12		X				
A1-B1			X			
A5-B5				X		
A6-B6					X	
A7-B7						X


Tabulation of Switch With Extra Connectors Added.

CONTACT	POSITION					
	0	1	2	3		
A1-B11	X					
A12-B12		X				
A1-B1			X			
A5-B5				X		
A6-B6					X	
A7-B7						X

Note:

Switch Mounted 90° From Standard,
Nameplate Arrow Up.

31



Voltmeter

3 Phase-4 Wire

Style No. 3562A01G03
Handle: Mini-Slim DS, Fixed
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1-8-1-4
Target No.

CONTACT	POSITION					
	0	1	2	3		
A11-B11	X					
A12-B12		X				
A1-B1			X			
A5-B5				X		
A6-B6					X	
A7-B7						X

Tabulation of Switch With Extra Connectors Added.

CONTACT	POSITION					
	0	1	2	3		
A1-B11	X					
A12-B12		X				
A1-B1			X			
A5-B5				X		
A6-B6					X	
A7-B7						X


Note:

Switch Mounted 90° From Standard,
Nameplate Arrow Down.



Position Tabulations, Continued

32




Voltmeter

3 Phase-4 Wire

Style No. 3562A01G04
Handle: Mini-Slim DS, Fixed
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: No

CONTACT	POSITION	0	1	2	3
A1-B11		X			
A12-B12			X		
A1-B1				X	
A5-B5			X		
A6-B6				X	
A7-B7				X	X




Tabulation of Switch With Extra Connectors Added.

CONTACT		X		
A1-B11			X	
A1-B12		X		
A1-B1			X	

Note:
Switch Mounted 90° From Standard.
Nameplate Arrow Up.

33




Voltmeter

3 Phase-3 Wire

Style No. 3562A01G05
Handle: Mini-Slim DS, Fixed
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: No

CONTACT	POSITION	0	1	2	3
A11-B11		X			
A12-B12			X		
A1-B1				X	
A5-B5			X		
A6-B6				X	
A7-B7				X	X




Tabulation of Switch With Extra Connectors Added.

CONTACT		X		X
A1-B11			X	
A1-B12		X		
A5-B5			X	
A5-B7			X	X

Note:
Switch Mounted 90° From Standard


34



Ammeter/Voltmeter

Style No. 508A299G03
Handle: Round Fixed
Contacts: Maintained
Stages: 3, Six Contact Frame
Mounting: 1/8-1/4
Target: No


CONTACT	POSITION	0	1	2	3
A11-B11		X	X	X	
A12-B12			X	X	X
A1-B1				X	X
A5-B5			X	X	X
A6-B6				X	X
A7-B7				X	X
C11-D11		X	X	X	X
C12-D12		X	X	X	X
C1-G1		X	X	X	X
C5-D5		X	X	X	X
C6-D6		X	X	X	X
C7-D7		X	X	X	X
E11-F11			X		
E12-F12				X	
E1-F1					X
E5-F5			X		
E6-F6				X	
E7-F7					X





Position Tabulations, Continued

35




Ammeter/Voltmeter

Style No. 508A299G09
Handle Round Fixed
Contacts Maintained
Stages 3, Six Contact Frame
Mounting 1-8-1/4
Target No.

CONTACT	POSITION							
	0	-	1	-	-	2	-	-
A11-B11	X	X	X					
A12-B12				X	X	X		
A1-B1						X	X	
A5-B5	X	X	X					
A6-B6				X	X	X		
A7-B7						X	X	
C11-D11	X	X	X	X	X	X	X	
C12-D12	X	X	X	X	X	X	X	
C1-D1	X	X	X	X	X	X	X	
C5-D5	X	X	X	X	X	X	X	
C6-D6	X	X	X	X	X	X	X	
C7-D7	X	X	X	X	X	X	X	
E11-F11		X						
E12-F12			X					
E1-F1				X				
E5-F5	X							
E6-F6			X					
E7-F7				X				

36





Ammeter/Voltmeter

Ammeter/Voltmeter

3 Phase-4 Wire-3 CT's and 3 PT's
(End of Line Application)

Style No. 787A977G01
Handle Round Fixed
Contacts Maintained
Stages 2, Six Contact Frame
Mounting 1-8-1/4
Target No.


CONTACT	POSITION							
	OFF	-	-	1	-	2	-	-
A11-B11	X	X	X		X	X	X	X
A12-B12	X	X	X	X	X	X	X	X
A1-B1	X	X	X	X	X	X	X	X
A5-B5		X	X	X				
A6-B6				X	X	X		
A7-B7						X	X	
C11-D11		X						
C12-D12			X					
C1-D1				X				X
C5-D5					X			
C6-D6						X		
C7-D7							X	





Position Tabulations, Continued

37




Ammeter/Voltmeter


3 Phase-Wire-3 CT's and 3 PT's
(End of Line Application)

Style No. 787A977G02
Handle: Round Fixed
Contacts: Maintained
Stages: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: No

CONTACT	POSITION	OFF	1	2	3
A11-B11	X X X X X X X X X X X X	X	X	X	X
A12-B12	X X X X X X X X X X X X	X	X	X	X
A1-B1	X X X X X X X X X X X X	X	X	X	X
A5-B5	X X X X X X X X X X X X	X	X	X	X
A6-B6	X X X X X X X X X X X X		X	X	X
A7-B7	X X X X X X X X X X X X			X	X
C11-D11	X X X X X X X X X X X X				X
C12-D12	X X X X X X X X X X X X			X	
C1-D1	X X X X X X X X X X X X				X
C5-D5	X X X X X X X X X X X X				X
C6-D6	X X X X X X X X X X X X		X		
C7-D7	X X X X X X X X X X X X				X



38




Voltage Control

Style No. 505A703G01
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: No


Oval Fixed Handle
Switch: S# 505A703G06

CONTACT	POSITION	R	O	L
A11-B11	X	X		
A12-B12		X	X	
A1-B1		X		X
A5-B5	X			
A6-B6	X			
A7-B7			X	X

Note:
Spring Return to OFF Position.



39



Voltage Control

Style No. 505A715G01
Handle: Oval Fixed
Contacts: Momentary
Stages: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: No


Oval Fixed Handle
Switch: S# 505A715G05

CONTACT	POSITION	R	O	L
A11-B11	X	X		
A12-B12		X	X	
A1-B1		X		X
A5-B5				
A6-B6				
A7-B7			X	X
C11-D11				
C12-D12				
C1-D1				
C5-D5				
C6-D6			X	
C7-D7				X

Note:
Spring Return to OFF Position.

Voltage Control

Style No. 505A716G01
Handle: Oval Fixed
Contacts: Momentary
Stages: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: No




Note:

Spring Return to OFF Position.
Maintained In Pull Out at OFF.



Position Tabulations, Continued


59



Electrode Control


Switch S#505A716G02
(Oval Fixed Handle)
Switch S#505A716G04
(Pistol Grip Fixed Handle)
Contacts Momentary
Stages 2, Six Contact Frame
Mounting 1 8-1 4
Target No

CONTACT	R	O	P	L	POSITION
A11-B11	X				0
A12-B12	X	X			
A1-B1		X			
A5-B5	X				
A6-B6	X	X			
A7-B7		X			
C12-C1		X			
D12-D1	X	X	X		
C6-C7		X			
D6-D7	X	X	X		



Note:
Maintained in Pull Out at OFF


60



Motor Control


Switch S#505A716G03
(Oval Fixed Handle)
Switch S#505A716G05
(Pistol Grip Fixed Handle)
Contacts Momentary
Stages 2, Six Contact Frame
Mounting 1 8-1 4
Target No

CONTACT	S	O	P	R	POSITION
A11-B11	X				0
A12-B12	X	X			
A1-B1		X			
A5-B5	X				
A6-B6	X	X			
A7-B7		X			
C12-C1		X			
D12-D1	X	X	X		
C6-C7		X			
D6-D7	X	X	X		



Note:
Spring Return to OFF Position.
Maintained in Pull Out at OFF Position.

61



Motor Control


Style No. 663A245G06
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 1, Six Contact Frame
Mounting: 1 8-1 4
Target: Yes

CONTACT	STOP	N	SP1	POSITION
A11-B11	X			
A12-B12		X		
A1-B1			X	
A5-B5	X			
A6-B6	X	X	X	*
A7-B7		X	X	

* Note:
Adjacent Overlap Contacts
are Electrically Connected
Together During Transfer.

Note:
Spring Return to Center (N) Position


62



Speed Control


Switch S#505A703G02
(Pistol Grip Fixed Handle)
Switch S#505A703G07
(Oval Fixed Handle)
Contacts: Momentary
Stages: 1, Six Contact Frame
Mounting: 1 8-1 4
Target: No

CONTACT	R	O	P	L	POSITION
A11-B11	X				0
A12-B12	X	X			
A1-B1		X			
A5-B5	X				
A6-B6	X	X			
A7-B7		X			
C12-C1		X			
D12-D1	X	X	X		
C6-C7		X			
D6-D7	X	X	X		




Position Tabulations, *Continued*

Interpretation of position designations for Figures 63 through 83 and other switches using slip and/or pull contacts.



63




CONTACT	P	T	O	C
A11-B11	X	X		
A12-B12		X	X	
A1-B1			X	
A5-B5	X	X	X	
A6-B6			X	X
A7-B7			X	


Circuit Breaker Control

Switch S#505A713G01
(Pistol Grip Fixed Handle)
Switch S#505A713G03
(Oval Fixed Handle)

Contacts: Momentary
Stages: 1, Six Contact Frame
Mounting: 1-8-1-4
Target: Yes




64



CONTACT	P	T	O	C
A11-B11	X	X		
A12-B12		X	X	
A1-B1			X	
A5-B5	X	X	X	
A6-B6			X	X
A7-B7			X	

Circuit Breaker Control


Style No. 505A713G02
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 1, Six Contact Frame
Mounting: 1-8-1-4
Target: Yes





Position Tabulations, Continued


65




Circuit Breaker Control

Switch S#505A714G01
(Pistol Grip Fixed Handle)
Switch S#505A714G02
(Oval Fixed Handle)
Contacts: Momentary
Stages: 1. Six Contact Frame
Mounting: 1/8-1/4
Target: Yes

CONTACT	POSITION					
	P	T	OFF	OFF	C	T
	AFT	AFT			T	C
A11-B11	X	X				
A12-B12		X	X			
A1-B1			X			
A5-A6	X	X	X			
A6-A7			X	X		
B5-B6	X	X	X			
B6-B7			X	X		




66




Circuit Breaker Control
Style No 505A718G01
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 2. Six Contact Frame
Mounting: 1/8-1/4
Target: Yes

CONTACT	POSITION					
	P	T	OFF	OFF	C	T
	AFT	AFT			T	C
A11-B11	X	X				
A12-B12		X	X			
A1-B1			X			
A5-B5	X	X				
A6-B6			X	X		
A7-B7			X	X		
C11-D11	X	X				
C12-D12			X	X		
C1-D1			X	X		
C5-C6	X	X	X			
C6-C7			X	X		
D5-D6	X	X	X			
D6-D7			X	X		



67



Circuit Breaker Control

Style No 505A718G15
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 2. Six Contact Frame
Mounting: 1/8-1/4
Target: Yes


CONTACT	POSITION					
	P	T	OFF	OFF	C	T
	AFT	AFT			T	C
A11-B11	X	X				
A12-B12		X	X			
A1-B1			X			
A5-B5	X	X				
A6-B6			X	X		
A7-B7			X	X		
C11-D11	X	X				
C12-D12			X	X		
C1-D1			X	X		
C5-C6	X	X	X			
C6-C7			X	X		
D5-D6	X	X	X			
D6-D7			X	X		

Note:
Connectors Added to
Obtain Contact A1-B1
Closed in Close, Trip
and Trip Pull Out
Positions

Top
5 6 7 A
5 6 7 B
5 6 7 C
5 6 7 D

Bottom
5 6 7 A
5 6 7 B
5 6 7 C
5 6 7 D

68




Circuit Breaker Control

Switch S#505A717G02
(Pistol Grip Fixed Handle)

Switch S#505A717G03
(Oval Fixed Handle and No Connectors)


Contacts: Momentary
Stages: 2. Six Contact Frame
Mounting: 1/8-1/4
Target: Yes

CONTACT	POSITION					
	P	T	OFF	OFF	C	T
	AFT	AFT			T	C
A11-B11	X	X				
A12-B12		X	X			
A1-B1			X			
A5-A6	X	X				
A6-A7			X	X		
B5-B6	X	X	X			
B6-B7			X	X		
C11-D11	X	X				
C12-D12			X	X		
C1-D1			X	X		
C5-C6	X	X	X			
C6-C7			X	X		
D5-D6	X	X	X			
D6-D7			X	X		



Position Tabulations, *Continued*

69



CONTACT	P	T	O	C
A11-B11	X	X		
A12-B12		X	X	
A1-B1			X	X
A5-B5	X	X		
A6-B6			X	X
A7-B7			X	X
C12-C1	X			
D12-D1		X	X	X
C6-C7	X			
D6-D7	X	X	X	X

Circuit Breaker Control

Switch S#505A720G01 (Pistol Grip Fixed Handle)

Switch S#505A720G03 (Oval Fixed Handle)


Contacts: Momentary

Stages: 2, Six Contact Frame

Mounting: 1-8-1-4

Target: Yes

No Connectors Furnished



70

CONTACT	P	T	O	C
	T	OFF	OFF	C
A11-B11	X	X		
A12-B12		X	X	
A1-B1			X	X
A5-A6	X	X	X	
A6-A7			X	X
B5-B6	X	X	X	
B6-B7			X	X
C12-C1	X			
D12-D1		X	X	X
C6-C7	X			
D6-D7	X	X	X	X

Circuit Breaker Control

Switch S#508A244G01 (Pistol Grip Fixed Handle)


Switch S#508A244G02 (Oval Fixed Handle)

Contacts: Momentary

Stages: 2, Six Contact Frame

Mounting: 1-8-1-4

Target: Yes



71

CONTACT	P	T	O	C
	T	OFF	OFF	C
A11-B11	X	X		
A12-B12		X	X	
A1-B1			X	X
A5-A6	X	X	X	
A6-A7			X	X
B5-B6	X	X	X	
B6-B7			X	X
C11-D11	X	X		
C12-D12		X	X	
C1-D1			X	X
C5-C6	X	X		
C6-C7			X	X
D5-D6	X	X	X	
D6-D7		X	X	X
E12-E1	X			
F12-F1		X	X	X
E6-E7	X			
F6-F7		X	X	X

Circuit Breaker Control

Switch S#508A262G01 (Pistol Grip Fixed Handle)


Switch S#508A262G03 (Oval Fixed Handle)

Contacts: Momentary

Stages: 3, Six Contact Frame

Mounting: 1-8-1/4


Target: Yes



72

CONTACT	P	T	OFF	OFF	C
	T	OFF	OFF	C	
A11-B11	X	X			
A12-B12			X	X	
A1-B1					X
A5-B5	X	X			
A6-B6			X	X	
A7-B7					X
C11-D11	X	X			
C12-D12			X	X	
C1-D1					X
C5-C6	X	X			
C6-C7			X	X	
D5-D6	X	X			
D6-D7			X	X	
E12-E1	X				
F12-F1		X	X	X	
E6-E7	X				
F6-F7		X	X	X	

73



Circuit Breaker Control

Switch S#508A264G02 (Pistol Grip Fixed Handle)


Switch S#508A264G01 (Oval Fixed Handle)

Contacts: Momentary

Stages: 3, Six Contact Frame

Mounting: 1-8-1/4

Target: Yes



Circuit Breaker Control

Style No. 508A281G02

Handle: Pistol Grip Fixed

Contacts: Momentary

Stages: 4, Six Contact Frame

Mounting: 1-8-1/4

Target: Yes

Top	1	12	11 A
	1	12	11 B
	1	12	11 C
	1	12	11 D
	1	12	11 E
	1	12	11 F
	1	12	11 G
	1	12	11 H
Bottom	5	6	7 A
	5	6	7 B
	5	6	7 C
	5	6	7 D
	5	6	7 E
	5	6	7 F
	5	6	7 G
	5	6	7 H




Position Tabulations. Continued

74


CONTACT	POSITION				C
	PULL	T	N	N	C
	T		ATF	ATF	
A11-B11	X	X			
A12-B12			X	X	
A1-B1					X
A5-A6	X	X	X		
A6-A7				X	X
B5-B6	X	X	X		
B6-B7				X	X
C11-D11	X	X			
C12-D12			X	X	
C1-D1					X
C5-C6	X	X	X		
C6-C7				X	X
D5-D6	X	X	X		
D6-D7				X	X
E11-F11	X	X			
E12-F12			X	X	
E1-F1					X
E5-E6	X	X	X		
E6-E7				X	X
F5-F6	X	X	X		
F6-F7				X	X
G12-G1	X				
H12-H1		X	X	X	X
G6-G7	X				
H6-H7		X	X	X	X

Circuit Breaker Control

Style No. 508A284G01
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 4, Six Contact Frame
Mounting: 1/8-1/4
Target: Yes




75



CONTACT	POSITION			
	T	N	N	C
	ATF		ATF	
A11-B11	X			
A12-B12		X	X	
A1-B1			X	
A5-A6	X	X		
A6-A7			X	X
B5-B6	X	X		
B6-B7			X	X

Circuit Breaker Control


Style No. 505A738G07
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: Yes



Tabulation of Switch With Extra Connectors Added.

A11-B11	X			
A1-B1			X	
A5-A6	X	X		
A6-A7			X	X
A12-B5	X			
A12-B7			X	


76




CONTACT	POSITION			
	T	N	N	C
	ATF		ATF	
A11-B11	X	X		
A12-B12		X	X	
A1-B1			X	
A5-B5		X		
A6-B6			X	X
A7-B7	X			

Circuit Breaker Control

Style No. 802A231G01
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: Yes



77




CONTACT	POSITION		
	T	O	C
A11-B11	X		
A12-B12		X	
A1-B1			X
A5-B5	X		
A6-B6		X	
A7-B7		X	

Circuit Breaker Control

Style No. 508A207G02
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: Yes


78




CONTACT	POSITION		
	T	N	C
A11-B11	X		
A12-B12		X	
A1-B1			X
A5-B5	X		
A6-B6		X	
A7-B7		X	

Circuit Breaker Control

For Operating Two Breakers
Style No. 508A218G07
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: Yes



79




CONTACT	POSITION			
	T	N	N	C
	ATF		ATF	
A11-B11	X			
A12-B12		X	X	
A1-B1			X	
A5-B5	X			
A6-B6		X	X	
A7-B7		X	X	

Circuit Breaker Control

Style No. 508A229G01
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: Yes

Position Tabulations, *Continued*


80




CONTACT	POSITION			
	T	N	N	C
	NT	NT	NT	
A11-B11	X			
A12-B12		X	X	
A1-B1			X	
A5-B5			X	
A6-B6			X	
A7-B7	X			
C11-D11	X			
C12-D12		X	X	
C1-D1			X	
C5-C6	X	X		
C6-C7		X	X	
D5-D6	X	X		
D6-D7			X	X

Circuit Breaker Control

Style No. 8116A39G01
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: Yes




82




CONTACT	POSITION			
	T	N	N	C
	NT	NT	NT	
A11-B11	X			
A12-B12		X	X	
A1-B1			X	
A5-A6	X	X		
A6-A7		X	X	
B5-B6	X	X		
B6-B7		X	X	
C11-D11	X			
C12-D12		X	X	
C1-D1			X	
C5-C6	X	X		
C6-C7		X	X	
D5-D6	X	X		
D6-D7		X	X	

Circuit Breaker Control

Style No. 508A480G08
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: Yes




81




CONTACT	POSITION			
	T	W	OFF	C
	NT	NT	NT	
A11-B11	X			
A12-B12		X	X	
A1-B1			X	
A5-A6	X	X		
A6-A7		X	X	
B5-B6	X	X		
B6-B7		X	X	
C11-D11	X			
C12-D12		X	X	
C1-D1			X	
C5-C6	X	X		
C6-C7		X	X	
D5-D6	X	X		
D6-D7		X	X	

Circuit Breaker Control

Style No. 508A480G01
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: Yes




83



CONTACT	POSITION			
	T	N	N	C
	NT	NT	NT	
A11-B11	X			
A12-B12		X	X	
A1-B1			X	
A5-B5	X			
A6-B6		X	X	
A7-B7			X	
C11-D11	X			
C12-D12		X	X	
C1-D1			X	
C5-C6	X	X		
C6-C7		X	X	
D5-D6	X	X		
D6-D7		X	X	
E11-F11	X			
E12-F12		X	X	
E1-F1			X	
E5-E6	X	X		
E6-E7		X	X	
F5-F6	X	X		
F6-F7		X	X	

Circuit Breaker Control


Style No. 508A255G03
Handle: Pistol Grip Fixed
Contacts: Momentary
Stages: 3, Six Contact Frame
Mounting: 1/8-1/4
Target: Yes





Position Tabulations, Continued

84



Temperature

Accurate Lead Compensation

Style No. 781A254G01

Handle: Round, Fixed


Contacts: Maintained

Stages: 2, Six Contact Frame


Mounting: 1/8-1/4

Target: No

CONTACT	POSITION				
	O	-	C	-	1
A11-B11	X	X			
A12-B12		X	X	X	
A1-B1			X	X	
A5-B5	X	X			
A6-B6		X	X	X	
A7-B7			X	X	
C11-D11	X				
C12-D12		X			
C1-D1				X	
C5-D5	X				
C6-D6		X			
C7-D7			X		



85



Temperature

Accurate Lead Compensation

Style No. 505A709G01

Handle: Round, Fixed


Contacts: Maintained

Stages: 3, Six Contact Frame


Mounting: 1/8-1/4

Target: No

CONTACT	POSITION										
	O	-	C	-	1	-	2	-	3	-	4
A11-B11	X	X									
A12-B12		X	X	X							
A1-B1			X	X							
A5-B5								X	X	X	
A6-B6								X	X	X	
A7-B7								X	X	X	
C11-D11	X										
C12-D12		X									
C1-D1					X						
C5-D5	X										
C6-D6		X									
C7-D7			X								



* Note: Adjacent Overlap Contacts
are Electrically Connected
Together During Transfer

Position Tabulations, *Continued***86****Temperature****Accurate Lead Compensation**

(R) Style No. 505A711G01

Handle Removable Key

Contacts Maintained

Stages 4, Six Contact Frame

Mounting 1 8 1 4


Targe! No

Key Handle Removable in OFF Position Only

Ref to Removable Key Handle S#505A711G03

S 90

CONTACT	POSITION				
	-	1	2	3	4
A11-B11	X X				
A12-B12	X X X				
A1-B1	X X X X				
A5-B5		X X X			
A6-B6			X X X		
A7-B7				X X	
C11-D11	X X				
C12-D12	X X X X				
C1-D1	X X X X				
C5-D5		X X X X			
C6-D6			X X X X		
C7-D7				X X X	
E11-F11	X				
E12-F12	X				
E1-F1		X			
E5-F5			X		
E6-F6				X	
E7-F7					X
G11-H11	X X				
G12-H12	X X X X				
G1-H1	X X X X				
G5-H5		X X X X			
G6-H6			X X X X		
G7-H7				X X X	




*Note: Adjacent Overlap Contacts
are Electrically Connected
Together During Transfer.



Position Tabulations, Continued

87




Temperature

Accurate Lead Compensation

Style No. 661A210G06

Handle: Round, Fixed
Contacts: Maintained
Stages: 6, Six Contact Frame
Mounting: 1/8-1/4
Target: No.


CONTACT	O	-	C	-	1	-	2	1	3	-	4	-	5	-	6
A12-B12	X														
A1-B1		X													
A5-B5									X						
A6-B6											X				
A7-B7												X			
C11-D11				X											
C12-D12					X										
C1-D1						X									
E12-F12	X	X													
E1-F1		X	X	X											
E5-F5							X	X	X						
E6-F6								X	X	X					
E7-F7									X	X					
G11-H11			X	X	X										
G12-H12				X	X	X									
G1-H1						X	X	X							
I12-J12	X	X													
I1-J1		X	X	X	X										
I5-J5						X	X	X							
I6-J6							X	X	X						
I7-J7									X	X					
K11-L11			X	X	X										
K12-L12				X	X	X									
K1-L1						X	X	X							





Position Tabulations, *Continued*

88




Temperature

Accurate Lead Compensation

(R) Style No. 781A489G01
Handle Removable Key
Contacts Maintained
Stages 6, Six Contact Frame
Mounting: 1/8-1/4
Target: No

Note:


Key Handle Removable in OFF Position Only.
Key Handle Not Furnished With Switch.
Ref. to Key Handle S#505A765G03 (Round)
S=240





Position Tabulations, Continued

89



Temperature

Accurate Lead Compensation

Style No. 661A210G01

Handle: Round, Fixed


Contacts: Maintained

Stages: 6, Six Contact Frame

Mounting: 1/8-1/4

Target: No


CONTACT	0	C	1	2	3	4	5	6	7	8	9	10	X
A11-B11													
A12-B12	X												
A1-B1			X										
A5-B5				X									
A6-B6					X								
A7-B7						X							
C11-D11			X										
C12-D12				X									
C1-D1					X								
C5-D5						X							
C6-D6							X						
C7-D7								X					
E11-F11								X					
E12-F12	X	X							X	X	X		
E1-F1		X	X	X									
E5-F5					X	X	X						
E6-F6						X	X	X					
E7-F7							X	X	X				
G11-H11		X	X	X									
G12-H12		X	X	X									
G1-H1			X	X	X								
G5-H5						X	X	X					
G6-H6							X	X	X				
G7-H7								X	X	X			
I11-J11								X	X	X			
I12-J12	X	X							X	X	X		
I1-J1		X	X	X									
I5-J5					X	X	X						
I6-J6						X	X	X					
I7-J7							X	X	X				
K11-L11		X	X	X	X								
K12-L12			X	X	X								
K1-L1				X	X	X							
K5-L5						X	X	X					
K6-L6							X	X	X				
K7-L7								X	X	X			



* Note: Adjacent Overlap Contacts
are Electrically Connected
Together During Transfer.

Position Tabulations, *Continued*

90



Temperature

Accurate Lead Compensation

(R) Style No. 663A454G01

Handle: Removable Key

Contacts: Maintained

Stages: 7, Six Contact Frame

Mounting: 1-8-1/4


Target: No.

Note:

Key Removable in OFF Position Only
Ref. to Removable Key Handle S#505A711G03
S-120^o

CONTACT	0	1	2	3	4	5	6	7	8	9	10
A11-B11	X										
A12-B12		X									
A1-B1			X								
A5-B5				X							
A6-B6					X						
A7-B7						X					
C11-D11		X									
C12-D12			X								
C1-D1				X							
C5-D5					X						
C6-D6						X					
C7-D7							X				
E11-F11								X	X	X	
E12-F12	X	X									X
E1-F1		X	X	X							
E5-F5				X	X	X					
E6-F6					X	X	X				
E7-F7						X	X	X			
G11-H11		X	X	X							
G12-H12			X	X	X						
G1-H1				X	X	X					
G5-H5					X	X	X				
G6-H6						X	X	X			
G7-H7							X	X	X		


1st Stage
2nd Stage
3rd Stage
Shown 5th-7th Duplicate
4th Stage
Shown 6th Duplicate





Position Tabulations, Continued

91



OFF-ON Switch

Fixed Handle	Maintained	Momentary
Oval	505A706G01	505A723G01
Pistol Grip	505A706G02	505A723G02
Round	505A706G03	505A723G03


Stage: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: No

CONTACT	POSITION	OFF	ON
A11-B11		X	
A12-B12		X	
A1-B1		X	
A5-B5		X	
A6-B6		X	
A7-B7		X	

- Top**
 1 2 11 A
 1 2 11 B

Bottom
 5 6 7 A
 5 6 7 B

92



Selector Switch

Style No. 505A702L03
Handle: Oval Fixed
Contacts: Maintained


Style No. 3745A75G23
Handle: Oval Fixed
Contacts: Momentary
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: No

CONTACT	POSITION	1	2	3
A11-B11		X		
A12-B12		X		
A1-B1			X	
A5-P5		X		
A6-B6		X		
A7-B7			X	

- Top**
 1 2 11 A
 1 2 11 B

Bottom
 5 6 7 A
 5 6 7 B

93



Selector Switch


Style No. 505A733G01
Handle: Oval Fixed
Contacts: Maintained
Stages: 1, Six Contact Frame
Mounting: 1/8-1/4
Target: No

CONTACT	POSITION	1	2	3	4	5	6
A11-B11		X					
A12-B12		X					
A1-B1			X				
A5-B5				X			
A6-B6					X		
A7-B7						X	

- Top**
 1 2 11 A
 1 2 11 B

Bottom
 5 6 7 A
 5 6 7 B

94



Selector Switch


Style No. 505A745G01
Handle: Oval Fixed
Contacts: Maintained
Stages: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: No

CONTACT	POSITION										
	11	12	1	2	3	4	5	6	7	8	9
A11-B11	X										
A12-B12		X									
A1-B1			X								
A5-B5				X							
A6-B6					X						
A7-B7						X					
C11-D11						X					
C12-D12							X				
C1-D1								X			
C5-D5									X		
C6-D6										X	
C7-D7											X

- Top**
 1 2 11 A
 1 2 11 B
 1 2 11 C
 1 2 11 D

Bottom
 5 6 7 A
 5 6 7 B
 5 6 7 C
 5 6 7 D

95



OFF-ON Switch


Fixed Handle	Maintained	Momentary
Oval	505A722G01	505A725G06
Pistol Grip	505A722G02	505A725G01
Round	505A722G03	505A725G11

Stage: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: No.

CONTACT	POSITION					
	OFF	1	2	3	4	5
A11-B11	X					
A12-B12		X				
A1-B1			X			
A5-B5				X		
A6-B6					X	
A7-B7						X

- Top**
 1 2 11 A
 1 2 11 B
 1 2 11 C
 1 2 11 D

Bottom
 5 6 7 A
 5 6 7 B
 5 6 7 C
 5 6 7 D

Position Tabulations, *Continued***96****OFF-ON Switch**

Style No. 505A781G03

Handle: Oval Fixed

Contacts: Maintained

Style No. 505A782G01

Handle: Oval Fixed

Contacts: Momentary

Stages: 3, Six Contact Frame

Mounting: 1/8-1/4

Target: No

CONTACT	POSITION OFF	POSITION ON
A11-B11	X	
A12-B12	X	
A1-B1	X	
A5-B5	X	
A6-B6	X	
A7-B7	X	
C11-D11	X	
C12-D12	X	
C1-D1	X	
C5-D5	X	
C6-D6	X	
C7-D7	X	
E11-F11	X	
E12-F12	X	
E1-F1	X	
E5-F5	X	
E6-F6	X	
E7-F7	X	

97**General Application Switch****1 and 2 Pole - 2 Throw**

Style No. 505A706G55

Handle: Oval Fixed



Contacts: Maintained

Stages: 1, Six Contact Frame

Mounting: 1/8-1/4

Target: No

CONTACT	POSITION 1	POSITION 2
A11-B11	X	
A12-B12	X	
A1-B1	X	
A5-B5	X	
A6-B6	X	
A7-B7	X	

**98****General Application Switch****1 Pole - 4 Throw**

Style No. 505A733G17

Handle: Oval Fixed




Contacts: Maintained

Stages: 1, Six Contact Frame

Mounting: 1/8-1/4

Target: No

CONTACT	POSITION 1	POSITION 2	POSITION 3	POSITION 4
A11-B11	X			
A12-B12	X			
A1-B1		X		
A5-B5			X	

**99****99****General Application Switch****1 Pole - 5 Throw**

Style No. 505A733G18

Handle: Oval Fixed




Contacts: Maintained

Stages: 1, Six Contact Frame

Mounting: 1/8-1/4

Target: No

CONTACT	1	2	3	4	5
A11-B11	X				
A12-B12		X			
A1-B1			X		
A5-B5				X	
A6-B6					X

**100****100****General Application Switch****1 Pole - 7 Throw**

Style No. 505A745G17

Handle: Oval Fixed



Contacts: Maintained

Stages: 2, Six Contact Frame

Mounting: 1/8-1/4

Target: No

CONTACT	1	2	3	4	5	6	7
A11-B11	X						
A12-B12		X					
A1-B1			X				
C11-D11				X			
C12-D12					X		
C6-D6	X						
C7-D7		X					

**98****General Application Switch****1 Pole - 4 Throw**

Style No. 505A733G17


Handle: Oval Fixed

Contacts: Maintained

Stages: 1, Six Contact Frame

Mounting: 1/8-1/4


Target: No






Position Tabulations, Continued

101



CONTACT	POSITION							
	1	2	3	4	5	6	7	8
A11-B11			X					
A12-B12				X				
A1-B1					X			
C11-D11						X		
C12-D12							X	
C1-D1								X
C6-D6	X							
C7-D7		X						

102



CONTACT	POSITION									
	1	2	3	4	5	6	7	8	9	10
A11-B11			X							
A12-B12				X						
A1-B1					X					
C11-D11						X				
C12-D12							X			
C1-D1								X		
A5-B5									X	
C5-D5	X									
C6-D6		X								
C7-D7			X							

General Application Switch

1 Pole - 8 Throw

Style No. 505A745G18

Handle: Oval Fixed


Contacts: Maintained

Stages: 2, Six Contact Frame

Mounting: 1/8-1/4

Target: No

103



CONTACT	POSITION							
	1	2	3	4	5	6	7	8
A11-B11			X					
A12-B12				X				
A1-B1					X			
A5-B5						X		
A6-B6							X	
A7-B7								X

General Application Switch

1 Pole or 2 Pole With OFF

Style No. 505A702L02

Handle: Oval Fixed

Contacts: Maintained

Style No. 505A703G51


Handle: Oval Fixed

Contacts: Momentary


Stages: 1, Six Contact Frame

Mounting: 1/8-1/4

Target: No



104



CONTACT	POSITION									
	1	2	3	4	5	6	7	8	9	10
A11-B11			X							
A12-B12				X						
A1-B1					X					
C11-D11						X				
C12-D12							X			
C1-D1								X		
A5-B5									X	
C5-D5	X									
C6-D6		X								
C7-D7			X							

General Application Switch

2 Pole - 8 Throw

Style No. 508A423G16


Handle: Oval Fixed


Contacts: Maintained

Stages: 4, Six Contact Frame

Mounting: 1/8-1/4


Target: No



Position Tabulations, *Continued***105****General Application Switch****2 Pole - 12 Throw**

Style No. 508A423G17
Handle: Oval Fixed
Contacts: Maintained
Stages: 4, Six Contact Frame
Mounting: 1/8-1/4
Target: No

CONTACT	12	1	2	3	4	5	6	7	8	9	10	11	POSITION
A11-B11	X												
A12-B12		X											
A1-B1			X										
A5-B5				X									
A6-B6					X								
A7-B7						X							
C11-D11				X									
C12-D12					X								
C1-D1						X							
C5-D5							X						
C6-D6								X					
C7-D7									X				
E11-F11	X												
E12-F12		X											
E1-F1			X										
E5-F5				X									
E6-F6					X								
E7-F7						X							
G11-H11				X									
G12-H12					X								
G1-H1						X							
G5-H5							X						
G6-H6								X					
G7-H7									X				

106**General Application Switch****4 Pole - 2 Throw**

Style No. 505A712G92
Handle: Oval Fixed
Contacts: Maintained

Style No. 505A715G32
Handle: Oval Fixed
Contacts: Momentary
Stages: 2, Six Contact Frame
Mounting: 1/8-1/4
Target: No

CONTACT	1	OFF	2	POSITION
A11-B11	X			
A12-B12		X		
A1-B1			X	
A5-B5	X			
A6-B6		X		
A7-B7			X	
C11-D11	X			
C12-D12		X		
C1-D1			X	
C5-D5	X			
C6-D6		X		
C7-D7			X	

Top
1 [2] 11 A
1 [2] 11 B
1 [2] 11 C
1 [2] 11 D
Bottom
5 [6] 7 A
5 [6] 7 B
5 [6] 7 C
5 [6] 7 D
5 [6] 7 E
5 [6] 7 F



Basic Switches-Style Numbers

Basic switches DO NOT include handle, nameplate nor external jumpers; these items may be ordered separately. For handles see page 2, nameplates see page 9 and external jumpers see page 9. For complete switch style including handle, nameplate and jumpers, refer to the Distribution and Control Business Unit, London Division.

Momentary Contacts (Control Switch)				Maintained Contacts (Instrument Switch)			
Figure	Basic Switch	Target	Handle Type	Figure	Basic Switch	Target	Handle Type
108	505A623G01①	No	Fixed	108	505A606G01	No	Fixed
108	663A177G01①	No	Removable Key ②	108	505A647G01②	No	Removable Key ②
109	505A668G01①	No	Fixed	109	505A667G01	No	Fixed
111	505A607G01①	No	Fixed	109	505A669G01②	No	Removable Key ②
112	505A625G01①	No	Fixed	110	508A396G01	No	Fixed
113	505A624G01①	No	Fixed	111	505A634G01	No	Fixed
114	505A684G01①	No	Fixed	111	505A654G01②	No	Removable Key ②
115	505A603G01	No	Fixed	112	505A622G01	No	Fixed
115	508A107G01①	Yes	Fixed	112	505A670G01②	No	Removable Key ②
115	663A195G01①	No	Removable Key ②	113	505A621G01	No	Fixed
116	508A110G01①	No	Fixed	113	505A672G01②	No	Removable Key ②
117	508A111G01①	No	Fixed	114	505A628G01	No	Fixed
117	505A638G01①	Yes	Fixed	114	505A685G01②	No	Removable Key ②
118	505A615G01①	No	Fixed	115	505A602G01	No	Fixed
118	508A118G01①	Yes	Fixed	115	508A108G01②	No	Removable Key ②
119	508A125G01①	No	Fixed	116	505A600G01	No	Fixed
120	508A127G01①	No	Fixed	116	661A105G01②	No	Removable Key ②
121	508A128G01①	No	Fixed	117	781A377G01	Yes	Fixed
121	508A129G01①	Yes	Fixed	117	508A112G01②	No	Removable Key ②
122	508A133G01①	No	Fixed	118	505A612G01	No	Fixed
122	505A620G01①	Yes	Fixed	118	508A119G01②	No	Removable Key ②
123	508A143G01①	No	Fixed	119	508A124G01	No	Fixed
123	508A144G01①	Yes	Fixed	120	508A126G01	No	Fixed
124	505A627G01①	No	Fixed	122	658A594G01	Yes	Fixed
124	508A145G01①	Yes	Fixed	124	505A626G01	No	Fixed
125	508A189G01①	No	Fixed	124	508A146G01②	No	Removable Key ②
125	508A161G01①	Yes	Fixed	129	508A166G01	No	Fixed
126	508A162G01①	Yes	Fixed	130	505A664G01	No	Fixed
127	508A163G01①	No	Fixed	133	505A631G01	No	Fixed
127	508A164G01①	Yes	Fixed	133	508A173G01②	No	Removable Key ②
128	505A619G01①	Yes	Fixed	134	508A196G01	No	Fixed
129	508A167G01①	Yes	Fixed	134	781A167G01③	No	Removable Key ③
130	505A630G01①	No	Fixed				
131	508A181G01①	Yes	Fixed				
132	508A183G01①	No	Fixed				
132	508A184G01①	Yes	Fixed				
133	505A632G01①	No	Fixed				
146	505A651G01①	No	Fixed				
147	658A542G01①	No	Fixed				
148	658A578G01	No	Fixed				
150	505A661G01①	Yes	Fixed				
151	508A342G01①	Yes	Fixed				
152	508A344G01①	No	Fixed				

① Spring return to "12" position.

② If key is desired, the following must be specified:
(a) Shape of handle.

(b) If to be interchangeable with other keys, specify the position or positions in which the key is to be removable and the style of the existing switch.

(c) If the key is to be removable in a different position than indicated for the basic switch, or is to be non-interchangeable with other key handles, order the basic switch as "similar to" a style number and give specific requirements.

③ Key removable in "12" position.

④ Key removable in "11" position.

⑤ Key removable in "10" position.



Additional Position Tabulations

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
E1-F1	X
E5-F5	X
E6-F6	X
E7-F7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-A6	X X
A6-A7	X X X
B5-B6	X X X
B6-B7	X X X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
E1-F1	X
E5-F5	X
E6-F6	X
E7-F7	X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-A6	X X X
A6-A7	X X X
B5-B6	X X X
B6-B7	X X X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-C6	X X
C6-C7	X X
C7-D7	X X
D6-D7	X X X

* Adjacent overlap contacts are electrically connected together during transfer.

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X
C12-C1	X
D12-D1	X X X
C6-C7	X X
D6-D7	X X X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-A7	X X X
B5-B6	X X X
B6-B7	X X X
C11-D11	X X
C12-D12	X X X
C1-D1	X X X
C5-C6	X X X
C6-C7	X X X
D6-D7	X X X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X
C12-C1	X X X
D12-D1	X X X
C1-D1	X X X
C5-C6	X X X
C6-C7	X X X
D6-D7	X X X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X
C12-C1	X X X
D12-D1	X X X
C1-D1	X X X
C5-C6	X X X
C6-C7	X X X
D6-D7	X X X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X
C12-C1	X X X
D12-D1	X X X
C1-D1	X X X
C5-C6	X X X
C6-C7	X X X
D6-D7	X X X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X
C12-C1	X X X
D12-D1	X X X
C1-D1	X X X
C5-C6	X X X
C6-C7	X X X
D6-D7	X X X

* Adjacent overlap contacts are electrically connected together during transfer.

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-A7	X X X
B5-B6	X X X
B6-B7	X X X
C11-D11	X X
C12-D12	X X X
C1-D1	X X X
C5-C6	X X X
C6-C7	X X X
D6-D7	X X X

CONTACT	POSITION
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X



Additional Position Tabulations, *Continued*

CONTACT	POSITION		
	11	12	P
A11-B11	X		
A12-B12		X	X
A1-B1			X
A5-B5	X		
A6-B6		X	X
A7-B7			X
C11-D11	X		
C12-D12		X	X
C1-D1			X
C5-D5	X		
C6-D6		X	X
C7-D7			X
E12-E1			X
F12-F1	X	X	X
E6-E7			X
F6-F7	X	X	X

CONTACT	POSITION		
	I	I1	I2
A11-B11	X		
A12-B12		X	
A1-B1			X
A5_B5	X		
A6_B6		X	
A7_B7			X
C11-D11	X		
C12-D12		X	
C1-D1			X
C5_D5	X		
C6_D6		X	
C7_D7			X
E11-F11	X		
E12-F12		X	
E1_F1			X
E5_F5	X		
E6_F6		X	
E7_F7			X
G11-H11	X		
G12-H12		X	
G1_H1			X
G5_H5	X		
G6_H6		X	
G7_H7			X

CONTACT	POSITION				
	P	H	I	2A	I
A11-B11	X	X			
A12-B12			X	X	
A1-B1					X
A5-B5	X	X			
A6-B6			X	X	
A7-B7					X
C11-D11	X	X			
C12-D12			X	X	
C1-D1					X
C5-C6	X	X	X		
C6-C7				X	X
D5-D6	X	X	X		
D6-D7					X
E11-F11	X	X			
E12-F12			X	X	
E1-F1					X
E5-E6	X	X	X		
E6-E7				X	X
F5-F6	X	X	X		
F6-F7				X	X
G12-G1	X				
H12-H1		X	X	X	X
G6-G7	X				
H6-H7	X	X	X	X	X

CONTACT		POSITION			
P	I	I	I	I	I
A11-B11		X	X		
A12-B12			X	X	
A1-B1					X
A5-A6	X	X	X		
A6-A7				X	X
B5-B6	X	X	X		
B6-B7					X
C11-D11	X	X			
C12-D12			X	X	
C1-D1					X
C5-C6	X	X	X		
C6-C7					X
D5-D6	X	X	X		
D6-D7				X	X
E11-F11	X	X			
E12-F12			X	X	
E1-F1					X
E5-E6	X	X	X		
E6-E7				X	X
F5-F6	X	X	X		
F6-F7				X	X
G12-G1	X				
H12-H1	X	X	X	X	
G6-G7	X				
H6-H7	X	X	X	X	

CONTACT	POSITION	
	I	II
A11-B11	X	
A12-B12		X
A1-B1		X
A5-B5	X	
A6-B6		X
A7-B7		X
C11-D11	X	
C12-D12		X
C1-D1		X
C5-D5	X	
C6-D6		X
C7-D7		X
E11-F11	X	
E12-F12		X
E1-F1		X
E5-F5	X	
E6-F6		X
E7-F7		X
G11-H11	X	
G12-H12		X
G1-H1		X
G5-H5	X	
G6-H6		X
G7-H7		X
J11-J11	X	
J12-J12		X
J1-J1		X
J5-J5	X	
J6-J6		X
J7-J7		X

CONTACT	POSITION	
	I-1	I-2
A11-B11	X	
A12-B12		X
A1-B1		X
A5-B5	X	
A6-B6		X
A7-B7		X
C11-D11	X	
C12-D12		X
C1-D1		X
C5-D5	X	
C6-D6		X
C7-D7		X
E11-F11	X	
E12-F12		X
E1-F1		X
E5-F5	X	
E6-F6		X
E7-F7		X
G11-H11	X	
G12-H12		X
G1-H1		X
G5-H5	X	
G6-H6		X
G7-H7		X
I11-J11	X	
I12-J12		X
I1-J1		X
I5-J5	X	
I6-J6		X
I7-J7		X
K11-L11	X	
K12-L12		X
K1-L1		X
K5-L5	X	
K6-L6		X
K7-L7		X

CONTACT	POSITION				
	I	O	-	I	-
A11-B11	X	X	X		
A12-B12				X	X
A1-B1					X
A5-B5	X	X	X		
A6-B6				X	X
A7-B7					X
C11-D11	X	X	X	X	X
C12-D12	X	X	X	X	X
C1-D1	X	X	X	X	X
C5-D5	X	X	X	X	X
C6-D6	X	X	X	X	X
C7-D7	X	X	X	X	X
E11-F11			X		
E12-F12				X	
E1-F1					X
E5-F5		X			
E6-F6					X
E7-F7					X

136	CONTACT	POSITION				
		1	2	3	4	
A11-B11	X					
A12-B12		X				
A1-B1			X			
A5-B5				X		
A6-B6					X	
A7-B7						X

* Adjacent overlap contacts are electrically connected together during transfer.

137	CONTACT	POSITION
	i	- 1 2 - 1 - 2 - 3 - 4
A11-B11	X	
A12-B12	X X	
A1-B1	X X X	
A5-B5		X X X
A6-B6		X X X
A7-B7		X X

CONTACT	POSITION									
	1	1	2	1	1	2	1	1	2	1
A11-B11	X	X								
A12-B12		X	X	X						
A1-B1				X	X	X				
A5-B5							X	X	X	
A6-B6								X	X	X
A7-B7										X
C11-D11	X	X	X	X	X	X	X	X	X	X
C12-D12	X	X	X	X	X	X	X	X	X	X
C1-D1	X	X	X	X	X	X	X	X	X	X
C5-D5	X	X	X	X	X	X	X	X	X	X
C6-D6	X	X	X	X	X	X	X	X	X	X
C7-D7	X	X	X	X	X	X	X	X	X	X
E11-F11	X	X								
E12-F12		X	X	X						
E1-F1				X	X	X				
E5-F5					X	X	X			
E6-F6							X	X	X	
E7-F7								X	X	X

CONTACT	POSITION			
	1	1	2	3
A11-B11	X			
A12-B12		X		
A1-B1			X	
A5-B5				X
A6-B6				X
A7-B7				X
C11-D11	X			
C12-D12		X		
C1-D1			X	
C5-D5				X
C6-D6				X
C7-D7				X
E11-F11	X			
E12-F12		X		
E1-F1			X	
E5-F5				X
E6-F6				X
E7-F7				X

CONTACT	POSITION										
	11	-	12	-	1	-	2	-	3	-	4
A11-B11	X	X									*
A12-B12		X	X								*
A1-B1			X	X	X						*
A5-B5					X	X	X				*
A6-B6							X	X	X		*
A7-B7									X	X	*
C11-D11	X	X									*
C12-D12		X	X	X							*
C1-D1			X	X	X						*
C5-D5					X	X	X				*
C6-D6							X	X	X		*
C7-D7									X	X	*
E11-F11	X	X									*
E12-F12		X	X	X							*
E1-F1			X	X	X						*
E5-F5					X	X	X				*
E6-F6							X	X	X		*
E7-F7								X	X	X	*

Additional Position Tabulations, *Continued*

CONTACT	POSITION				
	1	2	3	4	
A11-B11	X				
A12-B12	X				
A1-B1		X			
A5-B5	X				
A6-B6	X				
A7-B7	X				
C11-D11		X			
C12-D12		X			
C1-D1			X		
C5-D5	X				
C6-D6		X			
C7-D7		X			
E11-F11	X				
E12-F12	X				
E1-F1		X			
E5-F5	X				
E6-F6	X				
E7-F7	X				
G11-H11		X			
G12-H12		X			
G1-H1			X		
G5-H5	X				
G6-H6		X			
G7-H7		X			

CONTACT	POSITION									
	1	2	3	4	5	6	7	8	9	10
A11-B11	X									
A12-B12	X									
A1-B1		X								
A5-B5			X							
A6-B6				X						
A7-B7					X					
C11-D11		X								
C12-D12		X								
C1-D1			X							
C5-D5				X						
C6-D6					X					
C7-D7						X				
E11-F11							X			
E12-F12								X		
E1-F1								X		
E5-F5									X	
E6-F6										X
E7-F7										
G11-H11										X
G12-H12										
G1-H1										
G5-H5										
G6-H6										
G7-H7										

CONTACT	POSITION				
	1	2	3	4	
A11-B11	X				
A12-B12	X				
A1-B1		X			
A5-B5	X				
A6-B6	X				
A7-B7	X				
C11-D11		X			
C12-D12		X			
C1-D1			X		
C5-D5		X			
C6-D6		X			
C7-D7		X			
E11-F11	X				
E12-F12	X				
E1-F1		X			
E5-F5	X				
E6-F6	X				
E7-F7	X				
G11-H11		X			
G12-H12		X			
G1-H1			X		
G5-H5		X			
G6-H6		X			
G7-H7		X			
J11-J12	X				
J1-J2		X			
J5-J6	X				
J6-J7	X				
J7-J8	X				
K11-L11		X			
K12-L12		X			
K1-L1			X		
K5-L5	X				
K6-L6		X			
K7-L7		X			

CONTACT	POSITION									
	1	2	3	4	5	6	7	8	9	10
A11-B11	X									
A12-B12	X									
A1-B1		X								
A5-B5			X							
A6-B6				X						
A7-B7					X					
C11-D11		X								
C12-D12		X								
C1-D1			X							
C5-D5				X						
C6-D6					X					
C7-D7						X				
E11-F11							X			
E12-F12								X		
E1-F1								X		
E5-F5									X	
E6-F6										X
E7-F7										
G11-H11										X
G12-H12										
G1-H1										
G5-H5										
G6-H6										
G7-H7										

CONTACT	POSITION									
	1	2	3	4	5	6	7	8	9	10
A11-B11	X									
A12-B12	X									
A1-B1		X								
A2-B2		X								
A3-B3			X							
A4-B4				X						
A5-B5					X					
A6-B6						X				
A7-B7							X			
A8-B8								X		
A9-B9									X	
A10-B10										X

CONTACT	POSITION									
	1	2	3	4	5	6	7	8	9	10
A11-B11	X									
A12-B12	X									
A1-B1		X								
A2-B2		X								
A3-B3			X							
A4-B4				X						
A5-B5					X					
A6-B6						X				
A7-B7							X			
A8-B8								X		
A9-B9									X	
A10-B10										X

CONTACT	POSITION									
	1	2	3	4	5	6	7	8	9	10
A11-B11	X									
A12-B12	X									
A1-B1		X								
A2-B2		X								
A3-B3			X							
A4-B4				X						
A5-B5					X					
A6-B6						X				
A7-B7							X			
A8-B8								X		
A9-B9									X	
A10-B10										X



Additional Position Tabulations, *Continued*

CONTACT	POSITION		
	1	2	1
A11-B11	x		
A12-B12	x		
A1-B1	x	x	
A2-B2	x		
A3-B3	x		
A4-B4	x	x	
A5-B5	x		
A6-B6	x		
A7-B7	x	x	
A8-B8	x		
A9-B9	x		
A10-B10	x	x	
C11-D11	x		
C12-D12	x		
C1-D1	x		
C2-D2	x		
C3-D3	x		
C4-D4		x	
C5-D5	x		
C6-D6	x		
C7-D7	x	x	
C8-D8	x		
C9-D9	x		
C10-D10	x	x	

CONTACT	POSITION		
P	1	1	2
	1	1	A
A11-B11	x	x	
A12-B12		x	x
A1-B1		x	x
A2-B2	x	x	
A3-B3		x	x
A4-B4	x	x	
A5-A6	x	x	x
A6-A7	x	x	x
B5-B6	x	x	x
B6-B7		x	x
A8-A9	x	x	x
A9-A10	x	x	x
B8-B9	x	x	x
B9-B10		x	x
C12-C1	x		
D12-D1	x	x	x
C2-C3	x		
D2-D3	x	x	x
C4-C5	x		
D4-D5	x	x	x
C6-C6	x		
D6-D7	x	x	x
C8-C9	x		
D8-D9	x	x	x
C10-C11	x		
D10-D11	x	x	x

CONTACT	POSITION		
P	1	1	2
	1	1	A
A11-B11	x	x	
A12-B12		x	x
A1-B1		x	x
A2-B2	x	x	
A3-B3		x	x
A4-B4	x	x	
A5-A6	x	x	x
A6-A7	x	x	x
B5-B6	x	x	x
B6-B7		x	x
A8-A9	x	x	x
A9-A10	x	x	x
B8-B9	x	x	x
B9-B10		x	x
C12-C1	x		
D12-D1	x	x	x
C2-C3	x		
D2-D3	x	x	x
C4-C5	x		
D4-D5	x	x	x
C6-C6	x		
D6-D7	x	x	x
C8-C9	x		
D8-D9	x	x	x
C10-C11	x		
D10-D11	x	x	x

CONTACT	POSITION		
P	1	1	2
	1	1	A
A11-B11	x		
A12-B12		x	
A1-B1		x	
A2-B2		x	
A3-B3	x		
A4-B4	x		
A5-B5		x	
A6-B6		x	
A7-B7	x		
A8-B8		x	
A9-B9	x		
A10-B10		x	

CONTACT	POSITION		
O	1	1	2
	1	1	2
A10-B10	x		
A11-B11	x		
A12-B12		x	
A1-B1		x	
A2-B2		x	
A3-B3	x		
A4-B4	x		
A5-B5		x	
A6-B6		x	
A7-B7	x		
A8-B8		x	
A9-B9	x		
A10-B10		x	

CONTACT	POSITION								
	1	2	3	4	5	6	7	8	9
A12-B12	x								
A1-B1		x							
A2-B2			x						
A3-B3				x					
A4-B4					x				
A5-B5						x			
A6-B6							x		
A7-B7								x	
A8-B8									x
A9-B9									x
A10-B10									x
A11-B11									x




This form is available from the Westinghouse Printing Division, Trafford, PA. Reference Form 34219-A.

Form 34219-A (For ordering switches not covered in this publication or to outline desired modifications.)

SWITCH POSITION TABULATION

**TYPE W2 SWITCH - REFER TO DESCRIPTIVE BULLETIN 34-251
WESTINGHOUSE FORM 34219-A**

CONNECTORS ON SW. TERMINALS AS FOLLOWS.



STAMP N P AS FOLLOWS:

CONTACTS: Momentary - Maintained

HANDLE: Fixed - Removable Key


Oval - Round - Pistol Grip

MOUNTING: 1/8 - 1/4 - 1 - 1 1/2 - 2, Thick Panel

TARGET: Yes - No

STAGE CONTACTS: 6 - 12

1 =	_____	10 =	_____
2 =	_____	11 =	_____
3 =	_____	12 =	_____
4 =	_____	13 =	_____
5 =	_____	14 =	_____
6 =	_____	15 =	_____
7 =	_____	16 =	_____
8 =	_____	17 =	_____
9 =	_____	18 =	_____



FACEPLATE (F.V.)
SPECIFY MARKINGS



Westinghouse Electric Corporation
Distribution and Control Business Unit
London, Kentucky, U.S.A. 40741

Westinghouse

**Instrument and Control Switches, Type W-2**600 Volts, 20 Ampere
Continuous Capacity**Application**

The Type W-2 switch is designed for use as an instrument, control or general purpose switch. It is compact, yet of sufficient size to provide long, trouble-free service when applied within the specified ratings.

Design flexibility of internal parts and contacting, plus external jumpering of the contact studs affords almost limitless switching combinations for relatively few standard components. The design flexibility is provided in the basic switch styles. A complete switch is made up of a basic switch style, one of several styled handles, a nameplate connector diagram style and a nameplate.


The W-2 switch may be ordered as a single style unit where such a style meets a specific application. Where a single listed style does not meet a specific application, the desired switch may be ordered by specifying the required styled components.

Instrument Switches: Maintained contact type for use with all classes of electrical instruments, relays, meters, and for performing various circuit combinations. Designed for panel mounting and equipped with handles for manual operation.

Control Switches: Momentary contact type being spring return to the original or "off" position. For use with circuit breakers and other electrically controlled apparatus. Panel mounting. Handles for manual operation.

The Type W-2 switch can be furnished with a tumbler pin keylock. Such lock can be assembled either to the right or to the left of the switch unit on the horizontal center line, or, as is considered standard, above the switch unit on the vertical center line as shown in the illustration. The unit is so designed as to permit locking the switch in any one or in each of several positions. The position or positions in which a switch is to be locked must be specified on order.

The style numbers shown in this bulletin apply to switches for mounting on $\frac{1}{8}$ - $\frac{1}{4}$ inch thick panels only. Switches for mounting on thicker panels may be ordered as "similar to" a desired style except for thick panel.

**Advantages**

Small Size

Variable Circuitry by "You Wire It"

More Contacts per Unit Volume

Roller-Wipe Spring Actuated Contacting

Momentary and Maintained Contact Designs, or in Combination

Greater Availability of Contacts with Terminal Identification for Automated Wiring or Application Changes in Field, See Page 23

Double Break Contacts per Stage

In This Bulletin

	Instrument and Control Switches	Page
Application	1	
Design Features	2	
Operation	3	
Construction Details	4	
Standard Switches	5	
Position Tabulations	6-17	
Basic Switches	18	
Additional Position Tabulations	19-22	
Dimensions	22	
Ordering Information	23-24	

Westinghouse



Design Features

General Construction

The W-2 switch consists essentially of an operating handle, face plate, control housing, contact frame assembly and rotor assembly. It can be built up in any number of stages from 1 to 9, which stages are clamped together and to the control housing by two tie bolts. A steel operating shaft ties the contact rotors together. A metal cover on the rear holds the position stop pins, retains the shaft and provides basic switch identification. For push or pull switches, the metal cover is replaced by a polycarbonate cover which houses the pull-out mechanism.

Switch Positions

Each switch has a minimum of two and a maximum of twelve rotary positions with a 30° throw between positions, irrespective of the number. Each rotary position coincides precisely with the nameplate markings. The degree of throw between positions is fixed and cannot be changed. The number of positions of each switch can be altered by removing the rear cover and changing the position of the "stop" pin or pins located in the rear housing spacer. In addition to rotary motion, the W-2 switch can be provided with a lateral movement (push-pull) of the rotor.

Contact Frames

Two contact frame sizes are available; the half frame with six sets of contacts; three sets on the top at 11, 12 and 1 o'clock positions and three sets on the bottom at 5, 6 and 7 o'clock positions. The full frame with 12 sets of contacts, each set located at 30° intervals around its perimeter as are the numbers on a clock. The contact frames are made of glass polyester insulating material.

Contacts

Switches are usually referred to as "so many stages long". For a W-2 switch, a stage of contacts consists of a contact frame (either 6 or 12 contact sets) and a rotor.

At every position location on the frame, there are two contact terminal studs in line (a set) per stage. Each of these studs is one piece, made of bronze alloy and silver plated.

Rotors

The rotors are standard in design and hold the roller contacts. Each rotor, made of glass polyester insulating material, rotates independently between the stage spacer plates. The rotor assembly is equipped with one to six rollers (as determined by the required circuitry) each of which makes contact with two adjacent stationary terminal studs to complete a circuit and so affording a double, series break contact. The silver-plated bronze

alloy roller contacts provide a rolling, wiping action, are self-aligning on assembly and require no adjustment of contact pressure for the life of the switch.

Contact Flexibility

Basic "you wire it" flexibility is available in the Type W-2 switch. While the internal contacting is standardized for each basic type of switch; such as ammeter, voltmeter, circuit breaker, etc., by using available insulated jumpers, connections between external switch terminals can be made to obtain the desired contacting for a specific application. This minimizes the number of basic styled switches that otherwise would be required.

Switch Dial

The Type W-2 switch dial consists of two parts; i.e., a dial plate and a nameplate.







The standard control switch dial plate is die cast aluminum, with red and green target parts, where required, and serves as the base for mounting the nameplate. The nameplate is made of a white ABS material on which is stamped in black the desired position markings.

Handles

Handles for the Type W-2 switch are made of a phenolic insulating material designed to afford a smooth, easy, and comfortable grip of pleasing appearance. Each handle has a recessed arrow molded into it as a visual aid in positioning.

The handles are made in four shapes, i.e., oval, round, pistol grip, and large pistol grip. Each of the shapes can be obtained in the fixed type or the removable key type. The fixed handles are fastened to the switch shaft by a screw through the front of the handle.

There is also available a combination removable key type handle in the pistol grip shape that can be used to operate both the Type W-2 and the Type W switches designed for removable key operation.



Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity

Operation

The Type W-2 switch is a rotary roller action switch. Rotation of the shaft causes the rotor rollers to roll from one set of stationary contacts to another. The number of roller contacts can vary from 1 to 6 depending on the number of rotary positions required for the switch application. Each roller contact, moving radially, is held in and guided by a slot in the rotor arm. The rollers are pushed outward by spring pressure. Between roller and spring there is an insulated spring seat to reduce friction and wear. On standard potential contacts, an insulated wheel is used on both ends of the roller contact which wheels roll inside the switch stator frame. This arrangement reduces the friction of the spring-loaded roller in riding up on the stationary contact and also results in an increased air gap as a result of faster contact separation.

Overlapping contacts are obtained by increasing the diameter of the contact rollers of the shorting bar. At mid-position the roller spans the space between the stationary contacts. Such rollers provide a make-before-break contact in going from one position to an adjacent one.

The Type W-2 switch is available in both the maintained and the spring return types. Both types use a housing that is $\frac{3}{8}$ " deep, located between the back surface of the dial plate and the frame-rotor unit. This feature permits conversion from one type to another with a minimum of parts, time and experience.

Maintained Type: On a switch of this type, the switch is held in rotary position by a starwheel mechanism. The mechanism consists of a notched, molded wheel rotating between two metal rollers mounted on spring loaded arms. This arrangement provides a positive snap action as the handle is turned.

Momentary Type: This type uses a rotor that is returned to its original position by a double coil wound spring. The spring offers minimum opposition to movement of the switch handle, but is sufficiently strong to operate the rotor for all required contacting.

For current circuits, there is available an assembly of normally closed contact between front and rear terminals at each position on a stage. The assembly consists of a shorting bar across the two terminals and held closed by spring pressure. Turning the switch handle causes a cam to push the shorting bar away from the two terminals. Operating simultaneously with this contact assembly, in a different stage, are regular rollers designed and arranged so that they make a parallel circuit just prior to opening of the normally closed contact. This arrange-

ment permits overlapping transition in current metering of circuits.

On three-position switches, slip contacts are available. These contacts close when the switch operating handle is turned to the right position and remain closed after the operating handle has returned to the center position. The contacts open when the operating handle is turned to the left position and remain open upon return of the handle to the center position.

In addition to rotary motion, the W-2 switch can be provided with lateral movement (push-pull). Spring actuated roller contacts are mounted in a wafer housing fastened to the operating shaft by "E" rings. The wafer housing can only be moved by a push or pull movement. The roller contact spans two adjacent terminals on a band and it moves back and forth between two bands in a stage.

Interrupting Ratings


Voltage

Voltage	Amperes			
	Single Contact		Two Contacts in Series	
	Non-Inductive Load	Inductive Load .2 Henry	Non-Inductive Load	Inductive Load .2 Henry
110V 60 Cy.	60.0	30.0
220V 60 Cy.	30.0	20.0	60.0	...
440V 60 Cy.	25.0	10.0	40.0	...
660V 60 Cy.	15.0	8.0	25.0	...
48V D.C.	40.0	5.0
125V D.C.	8.0	2.4	28.0	5.0
250V D.C.	1.8	1.1	9.5	3.3
550V D.C.	.6	.5	2.0	1.2


Westinghouse




Exploded View of Typical Control Switch




Construction Details of Important Sub-assemblies

Frame
6 contacts

1. Hex nut
2. Window-locking spacer
3. Stationary terminal contact

Rotor
Pull contact


1. Roller contact
2. Spring seat
3. Spring

Rotor
Standard
4 roller
potential contacts

1. Standard roller contact
2. Contact wheel
3. Spring seat
4. Spring

Rotor
Standard
6 roller
overlap contacts

1. Overlap roller contact
2. Spring seat
3. Spring

Control housing
with maintained
contact mechanism

1. Starwheel spring
2. Starwheel lever
3. Starwheel roller
4. Starwheel

Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity

Standard Switches – Style Numbers

Figure	Switch Description	Complete Switch	Handle Type	Contact Type
1	Ammeter – 2 phase	505A700G01	R	MA
2	Ammeter – 3 phase – 2 CT's	505A701G02	R	MA
2A	3 phase – 3 independent circuits	505A701G01	R	MA
3	Voltmeter – 1 phase	505A747G01+	...	MA
3A	Frequency Meter	508A467G01+	...	MA
3B	Synchronizing – machine to bus	505A755G01+	...	MA
4	Voltmeter – 2 phase – 3 wire	505A702G01	R	MA
4A	2 circuit dc – 2 wire	505A702G02	R	MA
4A	2 circuit dc – 2 wire	505A748G01+	...	MA
4B	Dc – 3 wire	505A702G03	R	MA
4C	3 phase – 3 wire	505A702G04	R	MA
4C	3 phase – 3 wire	505A749G01+	...	MA
4D	3 phase – 4 wire	505A702G05	R	MA
4D	3 phase – 4 wire	505A762G01+	...	MA
5	Voltmeter – 4 circuit	505A704G01	R	MA
6	Voltmeter			
	3 phase and phase-to-neutral			
6A	two 3 phase circuits	505A705G01	R	MA
6B	6 circuit	505A705G02	R	MA
		505A705G03	R	MA
7	Wattmeter	505A752G01+	...	MA
8	Power Factor Meter	505A753G01+	...	MA
9	Power Factor Meter current transfer only	505A754G01+	...	MA
10	Synchronizing between machines	505A757G01+	...	MA
11	Temperature approximate lead compensation	658A667G01	R	MA
12	Temperature approximate lead compensation	663A488G01	R	MA
13	Temperature accurate lead compensation	787A936G01	R	MA
14	Temperature accurate lead compensation	661A210G01	R	MA
15	Temperature approximate lead compensation	663A452G01+	...	MA
16	Temperature accurate lead compensation	661A287G03+	...	MA
17	Temperature approximate lead compensation	663A453G01+	...	MA

Figure	Switch Description	Complete Switch	Handle Type	Contact Type
18	Temperature accurate lead compensation	663A454G01+	...	MA
19	Regulator Cutout	505A712G01	R	MA
20	Regulator Cutout	508A224G02	R	MA
21	Circuit Breaker	505A713G01	P	MO
21A	Circuit Breaker	505A713G02	P	MO
21	Circuit Breaker	505A713G03	O	MO
22	Circuit Breaker	505A714G01	P	MO
	Circuit Breaker	505A714G02	O	MO
23	Circuit Breaker	505A717G01	P	MO
	Circuit Breaker	505A717G03	O	MO
24	Circuit Breaker	505A718G01	P	MO
25	Circuit Breaker	505A720G01	P	MO
	Circuit Breaker	505A720G03	O	MO
26	Circuit Breaker	508A244G01	P	MO
	Circuit Breaker	508A244G02	O	MO
27	Circuit Breaker	508A262G01	P	MO
	Circuit Breaker	508A262G03	O	MO
28	Circuit Breaker	508A264G01	O	MO
	Circuit Breaker	508A264G02	P	MO
29	Voltage Control	505A703G01	P	MO
	Voltage Control	505A703G06	O	MO
29A	Speed Control	505A703G02	P	MO
	Speed Control	505A703G07	O	MO
30	Voltage Control	505A715G01	P	MO
	Voltage Control	505A715G05	O	MO
31	Voltage Control	505A716G01	O	MO
	Electrode Control	505A716G02	O	MO
31A	Electrode Control	505A716G04	P	MO
	Motor Control	505A716G03	O	MO
31B	Motor Control	505A716G05	P	MO
32	Pilot Wire Test	508A468G01	P	MA
33	OFF-ON	505A706G01	O	MA
		505A706G02	P	MA
		505A706G03	R	MA

Handle Type: R = Round Fixed

P = Pistol Grip Fixed

O = Oval Fixed

MA = Maintained Contacts


MO = Momentary Contacts

+ Switch requires but does not include removable key handle. Order as separate item, the number of keys desired, specifying style as shown in referenced figure.

Westinghouse

**Position Tabulations**



All wiring diagrams contained in this bulletin are to be considered as "TYPICAL."



CONTACT	POSITION	1	-	OFF	2
A11-B11		X	X	X	
A12-B12		X	X	X	X
A1-B1				X	X
A5-B5		X	X		
A6-B6		X	X	X	X
A7-B7				X	X

Ammeter



2 Phase
Round Fixed Handle
Switch S# 505A700G01



CONTACT	POSITION	1	-	OFF	ON
A11-B11				X	
A12-B12				X	
A1-B1				X	
A5-B5				X	
A6-B6				X	
A7-B7				X	

Voltmeter



Single Phase
Switch S# 505A747G01
Removable Key Handle S# 505A747G02
Key removable in off position only




CONTACT	POSITION	0	-	1	-	2	-	3
A11-B11		X	X	X				
A12-B12			X	X	X			
A1-B1						X	X	
A5-B5		X	X	X				
A6-B6			X	X	X			
A7-B7						X	X	
C11-D11		X	X	X	X	X	X	X
C12-D12		X	X	X	X	X	X	X
C1-D1		X	X	X	X	X	X	X
C5-D5		X	X	X	X	X	X	X
C6-D6		X	X	X	X	X	X	X
C7-D7		X	X	X	X	X	X	X

Ammeter



3Phase-2CT's
Round Fixed Handle
Switch S# 505A701G02

**Frequency Meter**


Switch S# 508A467G01
Removable Key Handle S# 508A467G02
Key removable in off position only

**Ammeter**

3 Phase - 3 Independent Circuits
Round Fixed Handle
Switch S# 505A701G01


**Synchronizing**

Machine to Bus
Switch S# 505A755G01
Removable Key Handle S# 505A755G02
Key removable in off position only




Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity




Voltmeter

2 Phase—Ac—3 Wire
Round Fixed Handle
Switch S# 505A702G01




CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X




Voltmeter

3 Phase—3 Wire
Round Fixed Handle
Switch S# 505A702G04
Switch Only S# 505A749G01
Removable Key Handle S# 505A749G02
Key removable in off position only





Voltmeter

2 Circuit—Dc—2 Wire
Round Fixed Handle
Switch S# 505A702G02
Switch Only S# 505A748G01
Removable Key Handle S# 505A748G02
Key removable in off position only




Voltmeter—Dc—3 Wire

Round Fixed Handle
Switch S# 505A702G03




Voltmeter



3 Phase—4 Wire
Round Fixed Handle
Switch S# 505A702G05
Switch Only S# 505A762G01
Removable Key Handle S# 505A762G02
Key removable in off position only








Westinghouse

**Position Tabulations Continued**

CONTACT	POSITION	1	2	3	4	-
A11-B11	X					
A12-B12	X					
A1-B1		X				
A5-B5	X					
A6-B6		X				
A7-B7		X				
C11-D11			X			
C12-D12			X			
C1-D1				X		
C5-D5				X		
C6-D6				X		
C7-D7				X		


Voltmeter**4 Circuit**Round Fixed Handle
Switch S# 505A704G01

CONTACT	POSITION											
	OFF	OFF	OFF	1	2	3	N	OFF	OFF	1	2	3
A11-B11	X											
A12-B12		X										
A1-B1			X									
A5-B5				X								
A6-B6					X							
A7-B7						X						
C11-D11							X					
C12-D12								X				
C1-D1									X			
C5-D5										X		
C6-D6											X	
C7-D7												X

Voltmeter**3 Phase and Phase to Neutral**
Round Fixed Handle
Switch S# 505A705G01**Voltmeter****Two 3 Phase Circuits**
Round Fixed Handle
Switch S# 505A705G02**Voltmeter****6 Circuit**
Round Fixed Handle
Switch S# 505A705G03



Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity




Wattmeter

Switch Only S# 505A752G01
Removable Key Handle S# 505A752G02
Key removable in off position only




Synchronizing Between Machines

Switch Only S# 505A757G01
Running Key S# 505A757G02
Incoming Key S# 505A757G03
Key removable in off position only





CONTACT	POSITION	OFF	ON
A11-B11		X	
A12-B12	X		
A1-B1		X	
A5-B5		X	
A6-B6	X		
A7-B7		X	
C11-D11	X	X	
C12-D12	X	X	
C1-D1		X	X
C5-D5	X	X	
C6-D6	X	X	
C7-D7		X	X





Power Factor Meter

Switch Only S# 505A753G01
Removable Key Handle S# 505A753G02
Key removable in off position only




Temperature

Approximate Lead Compensation
Round Fixed Handle
Switch S# 658A667G01



Power Factor Meter

Current Transfer Only
Switch Only S# 505A754G01
Removable Key Handle S# 505A754G02
Key removable in off position only




CONTACT	POSITION	OFF	ON
A11-B11		X	X
A12-B12	X	X	
A1-B1		X	X
A5-B5		X	X
A6-B6	X	X	
A7-B7		X	X

Westinghouse





Position Tabulations *Continued*



Temperature

Approximate Lead Compensation
Round Fixed Handle
Switch S# 663A488G01


CONTACT	POSITION																					
	O	-	C	-	I	-	2	-	3	-	4	-	5	-	6	-	7	-	8	-	9	-
A11-B11																						X
A12-B12	X																					
A1-B1		X																				
A5-B5											X											
A6-B6												X										
A7-B7													X									
C11-D11			X																			
C12-D12				X																		
C1-D1					X																	
C5-D5						X												X				
C6-D6							X												X			
C7-D7								X												X		
E11-F11																				X	X	X
E12-F12	X	X																				X
E1-F1	X	X	X																			X
E5-F5								X	X	X												
E6-F6									X	X	X											
E7-F7										X	X	X										
G11-H11		X	X	X																		
G12-H12				X	X	X																
G1-H1					X	X	X															
G5-H5												X	X	X								
G6-H6													X	X	X							
G7-H7														X	X	X						




Temperature

Accurate Lead Compensation
Round Fixed Handle
Switch S# 787A936G01


CONTACT		POSITION								
	BT	C	-	I	-	2	-	3	-	4
A11-B11	X									
A12-B12			X							
A1-B1					X					
A5-B5							X			
A6-B6								X		
A7-B7										X
C11-D11	X									
C12-D12	X	X	X	X						
C1-D1			X	X	X					
C5-D5						X	X			
C6-D6								X	X	X
C7-D7									X	X
E11-F11	X									
E12-F12		X	X	X						
E1-F1			X	X	X					
E5-F5					X	X	X			
E6-F6							X	X	X	
E7-F7								X	X	X



**Instrument and Control
Switches, Type W-2**

 600 Volts, 20 Ampere
Continuous Capacity
**Temperature**
Accurate Lead Compensation
 Round Fixed Handle
 Switch S# 661A210G01


CONTACT	0	C	I	2	3	4	5	6	7	8	9	10	X
A11-B11													
A12-B12	X												
A1-B1			X										
A5-B5													
A6-B6													
A7-B7													
C11-D11													
C12-D12													
C1-B1													
C5-D5													
C6-D6													
C7-D7													
E11-F11	X	X	X	X									
E12-F12		X	X	X									
E1-F1													
E5-F5													
E6-F6													
E7-F7													
G11-H11			X	X	X								
G12-H12			X	X	X								
G1-H1													
G5-H5													
G6-H6													
G7-H6													
I11-J11													
I12-J12	X	X	X	X									
I1-J1													
I5-J5													
I6-J6													
I7-J7													
K11-L11			X	X	X								
K12-L12			X	X	X								
K1-L1													
K5-L5													
K6-L6													
K7-L7													



Westinghouse



Position Tabulations *Continued*





Temperature

Approximate Lead Compensation

**Switch Only S# 663A452G01
Removable Key Handle S# 505A765G03
Key removable in off position only**

CONTACT	OFF	-	C	-	I	-	2	-	3	-	4	POSITION
A11-B11	X											
A12-B12			X									
A1-B1					X							
A5-B5							X					
A6-B6										X		
A7-B7											X	
C11-D11	X	X										
C12-D12	X	X	X									
C1-D1			X	X	X							
C5-D5							X	X	X			
C6-D6								X	X	X		
C7-D7											X	X
E11-F11	X	X										
E12-F12	X	X	X									
E1-F1			X	X	X							
E5-F5							X	X	X			
E6-F6								X	X	X		
E7-F7										X	X	
G11-H11	X	X										
G12-H12	X	X	X									
G1-H1			X	X	X							
G5-H5							X	X	X			
G6-H6								X	X	X		
G7-H7									X	X	X	




Temperature

Accurate Lead Compensation


Switch Only S# 661A287G03
Removable Key Handle S# 505A711G02
Key removable in off position only

CONTACT		POSITION					
	OFF	C	I	-1	-2	-3	-4
A11-B11	X						
A12-B12			X				
A1-B1				X			
A5-B5					X		
A6-B6						X	
A7-B7							X
C11-D11	X	X					
C12-D12		X	X	X			
C1-D1			X	X	X		
C5-D5				X	X	X	
C6-D6						X	X
C7-D7							X
E11-F11	X	X					
E12-F12		X	X	X			
E1-F1			X	X	X		
E5-F5				X	X	X	
E6-F6						X	X
E7-F7							X
G11-H11	X	X					
G12-H12		X	X	X			
G1-H1			X	X	X		
G5-H5				X	X	X	
G6-H6						X	X
G7-H7							X



Instrument and Control Switches, Type W-2


600 Volts, 20 Ampere
Continuous Capacity



Temperature

Approximate Lead Compensation
Switch Only S# 663A453G01
Removable Key Handle S# 505A765G03
Key removable in off position only



CONTACT	POSITION																				
	O	C	-	1	2	-	3	-	4	-	5	-	6	-	7	-	8	-	9	-	X
A11-B11																					
A12-B12	X																				
A1-B1		X																			
A5-B5																					
A6-B6																					
A7-B7																					
C11-D11				X																	
C12-D12					X																
C1-D1						X															
C5-D5							X														
C6-D6								X													
C7-D7									X												
E11-F11										X											
E12-F12	X	X		X	X																
E1-F1			X	X	X																
E5-F5						X	X	X													
E6-F6							X	X	X												
E7-F7								X	X	X											
G11-H11			X	X	X																
G12-H12				X	X	X															
G1-H1					X	X	X														
G5-H5						X	X	X													
G6-H6							X	X	X												
G7-H7								X	X	X											




Temperature

Accurate Lead Compensation
Switch Only S# 663A454G01
Removable Key Handle S# 505A711G03
Key removable in off position only

CONTACT	POSITION																				
	O	C	-	1	2	-	3	-	4	-	5	-	6	-	7	-	8	-	9	-	X
A11-B11																					
A12-B12	X																				
A1-B1		X																			
A5-B5																					
A6-B6																					
A7-B7																					
C11-D11				X																	
C12-D12					X																
C1-D1						X															
C5-D5							X														
C6-D6								X													
C7-D7									X												
E11-F11									X												
E12-F12	X	X		X	X																
E1-F1			X	X	X																
E5-F5						X	X	X													
E6-F6							X	X	X												
E7-F7								X	X	X											
G11-H11			X	X	X																
G12-H12				X	X	X															
G1-H1					X	X	X														
G5-H5						X	X	X													
G6-H6							X	X	X												
G7-H7								X	X	X											





Westinghouse

Position Tabulations *Continued*

CONTACT	POSITION	M	O	A
A11-B11	X			
A12-B12		X		
A1-B1			X	
A5-B5	X			
A6-B6		X		
A7-B7			X	
C11-D11	X			
C12-D12		X		
C1-D1			X	
C5-D5	X			
C6-D6		X	X	
C7-D7			X	X

Regulator Cutout



Round Fixed Handle
Switch S# 505A712G01



CONTACT	POSITION	M	O	I	R
A11-B11	X	X			
A12-B12	X	X	X		
A1-B1			X		
A5-B5	X	X			
A6-B6		X	X		
A7-B7			X		
C11-D11	X	X			
C12-D12	X	X	X		
C1-D1			X		
C5-D5	X	X			
C6-D6		X	X		
C7-D7			X	X	

Regulator Cutout



Round Fixed Handle
Switch S# 508A224G02



CONTACT	POSITION	P	T	O	C
A11-B11		X	X		
A12-B12		X	X	X	
A1-B1			X		
A5-B5	X	X			
A6-B6		X	X		
A7-B7			X		

Circuit Breaker Control


Pistol Grip Fixed Handle
Switch S# 505A713G01
Oval Fixed Handle
Switch S# 505A713G03



CONTACT	POSITION	P	T	O	C
A11-B11		X	X		
A12-B12		X	X	X	
A1-B1			X		
A5-B5	X	X			
A6-B6		X	X		
A7-B7			X		

Circuit Breaker Control

Pistol Grip Fixed Handle
Switch S# 505A713G02




Interpretation of position designations for Figures 21 through 28, and other switches using slip and/or pull contacts.

CONTACT	P	T	O	C
A11-B11	X	X		
A12-B12	X	X	X	
A1-B1			X	
A5-A6	X	X	X	
A6-A7			X	X
B5-B6	X	X		
B6-B7			X	X
C11-D11	X	X		
C12-D12			X	X
C1-D1			X	
C5-C6	X	X	X	
C6-C7			X	X
D5-D6	X	X	X	
D6-D7			X	X

- (11 O'clock) Handle Pulled Out at Trip Position } Pull-Out at Trip Position }
- (11 O'clock) Trip
- (12 O'clock) Off after Trip (Reverse Slip)
Handle at Off (Neutral) Position after Rotation to Trip Position
- (12 O'clock) Off after Close (Standard Slip)
Handle at Off (Neutral) Position after Rotation to Close Position
- (1 O'clock) Close

Instrument and Control Switches, Type W-2


600 Volts, 20 Ampere
Continuous Capacity




Circuit Breaker Control

Pistol Grip Fixed Handle
Switch S# 505A714G01

Oval Fixed Handle
Switch S# 505A714G02




CONTACT	POSITION			
	P	T	OFF	C
		AFT	AFT	
A11-B11	X	X		
A12-B12		X	X	
A1-B1			X	
A5-A6	X	X	X	
A6-A7			X	X
B5-B6	X	X	X	
B6-B7			X	X




Circuit Breaker Control

Pistol Grip Fixed Handle
Switch S# 505A717G01

Oval Fixed Handle
Switch S# 505A717G03




CONTACT	POSITION			
	P	T	OFF	C
		AFT	AFT	
A11-B11	X	X	/	
A12-B12		X	X	
A1-B1			X	
A5-A6	X	X	X	
A6-A7			X	X
B5-B6	X	X	X	
B6-B7			X	X
C11-D11	X	X		
C12-D12		X	X	
C1-D1			X	
C5-C6	X	X	X	
C6-C7			X	X
D5-D6	X	X	X	
D6-D7			X	X



Circuit Breaker Control

Pistol Grip Fixed Handle
Switch S# 505A718G01




CONTACT	POSITION			
	P	T	OFF	C
		AFT	AFT	
A11-B11	X	X		
A12-B12		X	X	
A1-B1			X	
A5-B5	X	X		
A6-B6			X	
A7-B7			X	
C11-D11	X	X		
C12-D12		X	X	
C1-D1			X	
C5-C6	X	X	X	
C6-C7			X	X
D5-D6	X	X	X	
D6-D7			X	X

Circuit Breaker Control

Pistol Grip Fixed Handle
Switch S# 505A720G01

Oval Fixed Handle
Switch S# 505A720G03




CONTACT	POSITION			
	P	T	OFF	C
		AFT	AFT	
A11-B11	X	X		
A12-B12		X	X	
A1-B1			X	
A5-B5	X	X		
A6-B6			X	
A7-B7			X	
C12-C1	X			
D12-D1		X	X	X
C6-C7	X			
D6-D7		X	X	X

CONTACT	POSITION			
	P	T	OFF	C
		AFT	AFT	
A11-B11	X	X		
A12-B12		X	X	
A1-B1			X	
A5-A6	X	X	X	
A6-A7			X	X
B5-B6	X	X	X	
B6-B7			X	X
C12-C1	X	X		
D12-D1		X	X	X
C6-C7	X			
D6-D7		X	X	X

Circuit Breaker Control

Pistol Grip Fixed Handle
Switch S# 508A244G01

Oval Fixed Handle
Switch S# 508A244G02



Westinghouse



**Position Tabulations *Continued***

CONTACT	P	T	OFF	ON	C
A11-B11	X	X			
A12-B12		X	X		
A1-B1			X		
A5-A6	X	X	X		
A6-A7			X	X	
B5-B6	X	X	X		
B6-B7			X	X	
C11-D11	X	X			
C12-D12		X	X		
C1-D1			X		
C5-C6	X	X	X		
C6-C7			X	X	
D5-D6	X	X	X		
D6-D7			X	X	
E12-E1	X				
F12-F1	X	X	X	X	
E6-E7	X				
F6-F7	X	X	X	X	

Circuit Breaker Control


Pistol Grip Fixed Handle
Switch S# 508A262G01

Oval Fixed Handle
Switch S# 508A262G03

**Voltage Control**

Pistol Grip Fixed Handle
Switch S# 508A703G01

Oval Fixed Handle
Switch S# 505A703G06





CONTACT	P	T	OFF	ON	C
A11-B11	X	X			
A12-B12		X	X		
A1-B1			X		
A5-B5	X	X			
A6-B6		X	X		
A7-B7			X	X	
C11-D11	X	X			
C12-D12		X	X		
C1-D1			X		
C5-C6	X	X	X		
C6-C7			X	X	
D5-D6	X	X	X		
D6-D7			X	X	
E12-E1	X				
F12-F1	X	X	X	X	
E6-E7	X				
F6-F7	X	X	X	X	

Circuit Breaker Control



Oval Fixed Handle
Switch S# 508A264G01

Pistol Grip Fixed Handle
Switch S# 508A264G02

**Speed Control**

Pistol Grip Handle
Switch S# 505A703G02

Oval Fixed Handle
Switch S# 505A703G07




CONTACT	R	O	L
A11-B11	X		
A12-B12		X	
A1-B1		X	
A5-B5	X		
A6-B6		X	
A7-B7		X	
C11-D11	X		
C12-D12		X	
C1-D1		X	
C5-D5	X		
C6-D6		X	
C7-D7		X	

Voltage Control


Pistol Grip Handle
Switch S# 505A715G01

Oval Fixed Handle
Switch S# 505A715G05





Instrument and Control Switches, Type W-2

**600 Volts, 20 Ampere
Continuous Capacity**





Voltage Control

Oval Fixed Handle
Switch S# 505A716G01





Electrode Control

Pistol Grip Fixed Handle
Switch S# 505A716G04
Oval Fixed Handle





Motor Control

Oval Fixed Handle
Switch S# 505A716G03



Pilot Wire Test

Pistol Grip Fixed Handle
Switch S# 508A468G01




Off-On Switch

Oval Fixed Handle
Switch S# 505A706G01

Pistol Grip Fixed Handle
Switch S# 505A706G02

Round Fixed Handle
Switch S# 505A706G03



Westinghouse

**Basic Switches – Style Numbers**

Available for Special Application without Nameplate, Handle or Connectors®

Maintained Contacts				Momentary Contacts			
Figure	Basic Switch	Target	Handle+	Figure	Basic Switch	Target	Handle+
34	505A606G01	no	fixed	34	505A623G01	no	fixed
34	505A647G01△	no	removable key▲	34	663A177G01△	no	removable key▲
35	505A667G01	no	fixed	35	505A668G01	no	fixed
35	505A669G01△	no	removable key▲	37	505A607G01	no	fixed
36	508A396G01	no	fixed	38	505A625G01	no	fixed
37	505A634G01	no	fixed	39	505A624G01	no	fixed
37	505A654G01△	no	removable key▲	40	505A684G01	no	fixed
38	505A622G01	no	fixed	41	505A603G01	no	fixed
38	505A670G01△	no	removable key▲	41	508A107G01	yes	fixed
39	505A621G01	no	fixed	41	663A195G01△	no	removable key▲
39	505A672G01△	no	removable key▲	42	508A110G01	no	fixed
40	505A628G01	no	fixed	43	508A111G01	no	fixed
40	505A685G01△	no	removable key▲	43	505A638G01	yes	fixed
41	505A602G01	no	fixed	44	505A615G01	no	fixed
41	508A108G01△	no	removable key▲	44	508A118G01	yes	fixed
42	505A600G01	no	fixed	45	508A125G01	no	fixed
42	661A105G01△	no	removable key▲	46	508A127G01	no	fixed
43	781A377G01	yes	fixed	47	508A128G01	no	fixed
43	508A112G01△	no	removable key▲	47	508A129G01	yes	fixed
44	505A612G01	no	fixed	48	508A133G01	no	fixed
44	508A119G01△	no	removable key▲	48	505A620G01	yes	fixed
45	508A124G01	no	fixed	49	508A143G01	no	fixed
46	508A126G01	no	fixed	49	508A144G01	yes	fixed
48	688A594G01	yes	fixed	50	505A627G01	no	fixed
50	505A626G01	no	fixed	50	508A145G01	yes	fixed
50	508A146G01△	no	removable key▲	51	508A189G01	no	fixed
55	508A166G01	no	fixed	51	508A161G01	yes	fixed
56	505A664G01	no	fixed	52	508A162G01	yes	fixed
59	505A631G01	no	fixed	53	508A163G01	no	fixed
59	508A173G01△	no	removable key▲	53	508A164G01	yes	fixed
60	508A196G01	no	fixed	54	505A619G01	yes	fixed
60	781A167G01△	no	removable key▲	55	508A167G01	yes	fixed
61	508A199G01	no	fixed	56	505A630G01	no	fixed
61	508A300G01□	no	removable key▲	57	508A181G01	yes	fixed
62	505A633G01	no	fixed	58	508A183G01	no	fixed
63	508A302G01	no	fixed	58	508A184G01	yes	fixed
64	508A363G01	no	fixed	59	505A632G01	no	fixed
65	508A307G01	no	fixed	72	505A651G01	no	fixed
65	508A308G01△	no	removable key▲	73	658A542G01	no	fixed
66	508A310G01	no	fixed	74	658A578G01	no	fixed
66	508A311G01△	no	removable key▲	76	505A661G01	yes	fixed
67	508A314G01	no	fixed	77	508A342G01	yes	fixed
67	508A370G01△	no	removable key▲	78	508A344G01◆	no	fixed
68	508A317G01	no	fixed				
69	505A645G01	no	fixed				
69	508A320G01△	no	removable key▲				
70	508A323G01	no	fixed				
70	781A181G01△	no	removable key▲				
71	508A326G01	no	fixed				
72	505A650G01	no	fixed				
72	661A152G01△	no	removable key▲				
73	505A659G01	no	fixed				
73	661A150G01△	no	removable key▲				
74	505A660G01	no	fixed				
74	663A176G01△	no	removable key▲				
75	508A334G01	no	fixed				
75	663A175G01△	no	removable key▲				
78	508A343G01	no	fixed				
78	781A123G01◆	no	removable key▲				
79	508A351G01	no	fixed				
80	505A644G01	no	fixed				
80	663A340G01△	no	removable key▲				

- ◆ = Spring return to "12" position.
 ◇ Select and specify, if desired, nameplate and connectors from Page 23. Handles from the following:
- | | |
|-------------------------|---------------|
| Round Fixed | S #310C624H01 |
| Pistol Grip Fixed | S #310C624H02 |
| Oval Fixed | S #501B787H01 |
| Large Pistol Grip Fixed | S #677C101H01 |
- + Provision only.
 ▲ If key is desired, the following must be specified:
- Shape of handle.
 - If to be interchangeable with other keys, specify the position or positions in which the key is to be removable and the style of the existing switch.
 - If the key is to be removable in a different position than indicated for the basic switch, or is to be non-interchangeable with other key handles, order the basic switch as "similar to" a style number and give specific requirements.
- △ Key removable in "12" position.
 □ Key removable in "10" position.
 ◆ Key removable in "11" position.

Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity

Additional Position Tabulations

CONTACT	POSITION
	I 2 I
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
	I 2 I
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
	I 2 I
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X X
A6-B6	X X
A7-B7	X X X

CONTACT	POSITION
	I 2 I
A11-B11	X X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X
A7-B7	X X X

CONTACT	POSITION
	I 2 I
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
	I 2 I
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
	I 2 I
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
	I 2 I
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
	I 2 I
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
	I 2 - I
A11-B11	X X
A12-B12	X X X
A1-B1	X X
A5-B5	X X
A6-B6	X X X
A7-B7	X X X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
	I 2 - I
A11-B11	X
A12-B12	X X
A1-B1	X X
A5-B5	X X
A6-B6	X X X
A7-B7	X X X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
	I 2 I I
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
	I I - I I
A11-B11	X X
A12-B12	X X X
A1-B1	X X
A5-B5	X X
A6-B6	X X X
A7-B7	X X X
C11-D11	X X
C12-D12	X X X
C1-D1	X X
C5-D5	X X
C6-D6	X X
C7-D7	X X X

CONTACT	POSITION
	I I - I I
A11-B11	X X
A12-B12	X X X
A1-B1	X X
A5-B5	X X
A6-B6	X X X
A7-B7	X X X
C11-D11	X X
C12-D12	X X X
C1-D1	X X
C5-C6	X X
C6-C7	X X
D6-D7	X X X
E12-E1	X
F12-F1	X X X
E6-E7	X
F6-F7	X X X

CONTACT	POSITION
	P I I I I
A11-B11	X X
A12-B12	X X X
A1-B1	X X
A5-B5	X X X
A6-A7	X X X
B5-B6	X X X X
B6-B7	X X X X
C11-D11	X X X
C12-D12	X X X X
C1-D1	X X X
C5-C6	X X X X
C6-C7	X X X X
D6-D7	X X X X
E12-E1	X X X X
F12-F1	X X X X
E6-E7	X X X X
F6-F7	X X X X

CONTACT	POSITION
	P I I I I
A11-B11	X X
A12-B12	X X X
A1-B1	X X
A5-B5	X X X
A6-B6	X X X
A7-B7	X X X
C11-D11	X X X
C12-D12	X X X X
C1-D1	X X X
C5-C6	X X X X
C6-C7	X X X X
D6-D7	X X X X
E12-E1	X X X X
F12-F1	X X X X
E6-E7	X X X X
F6-F7	X X X X

CONTACT	POSITION
	P I I I I
A11-B11	X X
A12-B12	X X X
A1-B1	X X
A5-B5	X X X
A6-B6	X X X
A7-B7	X X X
C11-D11	X X X
C12-D12	X X X X
C1-D1	X X X
C5-C6	X X X X
C6-C7	X X X X
D6-D7	X X X X
E12-E1	X X X X
F12-F1	X X X X
E6-E7	X X X X
F6-F7	X X X X

CONTACT	POSITION
	P I I I I
A11-B11	X X
A12-B12	X X X
A1-B1	X X
A5-B5	X X X
A6-B6	X X X
A7-B7	X X X
C11-D11	X X X
C12-D12	X X X X
C1-D1	X X X
C5-C6	X X X X
C6-C7	X X X X
D6-D7	X X X X
E12-E1	X X X X
F12-F1	X X X X
E6-E7	X X X X
F6-F7	X X X X

*Adjacent overlap contacts
are electrically connected
together during transfer.

Westinghouse

**Additional Position Tabulations *Continued***

CONTACT	POSITION			
	I1	I2	P	I2
A11-B11	X			
A12-B12		X X		
A1-B1			X	
A5-B5	X			
A6-B6		X X		
A7-B7			X X	
C11-D11	X			
C12-D12		X X		
C1-D1			X	
C5-D5	X			
C6-D6		X X		
C7-D7			X	
E12-E1		X		
F12-F1	X X	X X		
E6-E7			X	
F6-F7	X X	X X		

CONTACT	POSITION			
	P	I1	I2	A
A11-B11	X X			
A12-B12		X X		
A1-B1			X	
A5-B5		X X		
A6-A7			X X	
B5-B6	X X	X X		
B6-B7			X X	
C11-D11	X X			
C12-D12		X X		
C1-D1			X	
C5-D5	X			
C6-C6	X X	X X		
C6-C7			X X	
D5-D6	X X	X X		
D6-D7			X X	
E11-F11	X X			
E12-F12		X X		
E1-F1			X	
E5-F5	X			
E6-F6			X	
E7-F7			X X	
G11-H11	X			
G12-H12		X X		
G1-H1			X	
G5-H5	X			
G6-H6		X		
G7-H7		X X		

CONTACT	POSITION			
	I1	I2	I	I
A11-B11	X			
A12-B12		X		
A1-B1			X	
A5-B5	X			
A6-B6		X X		
A7-B7			X	
C11-D11	X X			
C12-D12		X X		
C1-D1			X	
C5-D5	X			
C6-D6		X X		
C7-D7			X X	
E11-F11	X X			
E12-F12		X X		
E1-F1			X	
E5-F5	X			
E6-F6			X	
E7-F7			X X	
G11-H11	X			
G12-H12		X X		
G1-H1			X	
G5-H5	X			
G6-H6		X		
G7-H7		X X		

CONTACT	POSITION			
	P	I1	I2	A
A11-B11	X X			
A12-B12		X X		
A1-B1			X	
A5-B5	X X			
A6-B6		X X		
A7-B7			X X	
C11-D11	X X			
C12-D12		X X		
C1-D1			X	
C5-C6	X X	X X		
C6-C7			X X	
D5-D6	X X	X X		
D6-D7			X X	
E11-F11	X X			
E12-F12		X X		
E1-F1			X X	
E5-F5	X X			
E6-F6			X X	
F6-F7	X X	X X		
G12-G1	X			
H12-H1		X X	X X	
G6-G7	X			
H6-H7		X X	X X	

CONTACT	POSITION			
	I1	I2	I	I
A11-B11	X			
A12-B12		X		
A1-B1			X	
A5-B5		X X		
A6-B6			X X	
A7-B7			X X	
C11-D11	X			
C12-D12		X X		
C1-D1			X X	
C5-D5	X			
C6-D6		X X		
C7-D7			X X	
E11-F11	X			
E12-F12		X X		
E1-F1			X X	
E5-F5			X X	
E6-F6			X X	
E7-F7			X X	

CONTACT	POSITION			
	P	I1	I2	A
A11-B11	X X			
A12-B12		X X		
A1-B1			X X	
A5-B5		X X		
A6-B6			X X	
A7-B7			X X	
C11-D11	X X			
C12-D12		X X		
C1-D1			X X	
C5-D5	X X			
C6-D6		X X		
C7-D7			X X	
E11-F11	X X			
E12-F12		X X		
E1-F1			X X	
E5-F5			X X	
E6-F6			X X	
E7-F7			X X	

CONTACT	POSITION			
	I1	I2	I	I
A11-B11	X			
A12-B12		X		
A1-B1			X	
A5-B5			X	
A6-B6			X	
A7-B7			X	

CONTACT	POSITION			
	I1	-	I2	-
A11-B11	X X			
A12-B12		X X X		
A1-B1			X X X	
A5-B5				X X X
A6-B6				X X X
A7-B7				X X X

CONTACT	POSITION			
	I1	-	I2	-
A11-B11	X X			
A12-B12		X X X		
A1-B1			X X X	
A5-B5				X X X
A6-B6				X X X
A7-B7				X X X
C11-D11	X X			
C12-D12		X X X		
C1-D1			X X X	
C5-D5	X X			
C6-D6		X X X		
C7-D7			X X X	
E11-F11	X X			
E12-F12		X X X		
E1-F1			X X X	
E5-F5			X X X	
E6-F6			X X X	
E7-F7			X X X	

CONTACT	POSITION			
	I1	-	I2	-
A11-B11	(X X)			
A12-B12		(X X X)		
A1-B1			(X X X)	
A5-B5				(X X X)
A6-B6				(X X X)
A7-B7				(X X X)
C11-D11	(X X)			
C12-D12		(X X X)		
C1-D1			(X X X)	
C5-D5				(X X X)
C6-D6				(X X X)
C7-D7				(X X X)
E11-F11	(X X)			
E12-F12		(X X X)		
E1-F1			(X X X)	
E5-F5			(X X X)	
E6-F6			(X X X)	
E7-F7			(X X X)	

*Adjacent overlap contacts are electrically connected together during transfer.

Instrument and Control Switches, Type W-2

**600 Volts, 20 Ampere
Continuous Capacity**

CONTACT	POSITION				
	I	I2	I	2	3
A11-B11	X				
A12-B12		X			
AI-BI			X		
A5-B5	X				
A6-B6		X			
A7-B7			X		
C11-D11				X	
C12-D12					X
CI-D1					X
C5-D5			X		
C6-D6				X	
C7-D7					X
E11-F11	X				
E12-F12		X			
E1-F1			X		
E5-F5	X				
E6-F6		X			
E7-F7			X		
G11-H11				X	
G12-H12					X
G1-H1					X
G5-H5			X		
G6-H6				X	
G7-H7					X

CONTACT	POSITION	
	I2	I
A11-B11		X
A12-B12	X	
A1-B1		X
A2-B2	X	
A3-B3		X
A4-B4	X	
A5-B5		X
A6-B6	X	
A7-B7		X
A8-B8	X	
A9-B9		X
A10-B10	X	

CONTACT	POSITION				
	I	I2	I	2	3
A11-B11	X				
A12-B12		X			
A1-B1			X		
A5-B5	X				
A6-B6		X			
A7-B7			X		
C11-D11				X	
C12-D12					X
C1-D1					X
C5-D5			X		
C6-D6				X	
C7-D7					X
E11-F11	X				
E12-F12		X			
E1-F1			X		
E5-F5	X				
E6-F6		X			
E7-F7			X		
G11-H11				X	
G12-H12					X
G1-H1					X
G5-H5			X		
G6-H6				X	
G7-H7					X
I11-J11	X				
I12-J12		X			
I1-J1			X		
I5-J5	X				
I6-J6		X			
I7-J7			X		
K11-L11				X	
K12-L12					X
K1-L1					X
K5-L5			X		
K6-L6				X	
K7-L7					X

CONTACT	POSITION													
	1	2	3	4	5	6	7	8	9	10	11	12	13	
A11-B11	X	X												X
A12-B12		X	X	X										
A1-B1			X	X	X									
A5-B5							X	X	X					
A6-B6								X	X	X				
A7-B7									X	X	X			
C11-D11	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C12-D12	X	X		X	X	X	X	X	X	X	X	X	X	X
C1-D1	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C5-D5	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C6-D6	X	X	X	X	X	X	X	X	X	X	X	X	X	X
C7-D7	X	X	X	X	X	X	X	X	X	X	X	X	X	X
E11-F11	X	X												X
E12-F12		X	X	X										
E1-F1			X	X	X									
E5-F5								X	X	X				
E6-F6									X	X	X			
E7-F7										X	X	X		
G11-H11			X	X	X									
G12-H12					X	X	X							
G1-H1						X	X	X						
G5-H5										X	X	X		
G6-H6											X	X	X	
G7-H7												X	X	X
I11-J11	X	X	X	X	X	X	X	X	X	X	X	X	X	X
I12-J12	X	X	X	X	X	X	X	X	X	X	X	X	X	X
I1-J1	X	X	X	X	X	X	X	X	X	X	X	X	X	X
I5-J5	X	X	X	X	X	X	X	X	X	X	X	X	X	X
I6-J6	X	X	X	X	X	X	X	X	X	X	X	X	X	X
I7-J7	X	X	X	X	X	X	X	X	X	X	X	X	X	X
K11-L11			X	X	X									
K12-L12				X	X	X								
K1-L1					X	X	X							
K5-L5						X	X	X						
K6-L6							X	X	X					
K7-L7								X	X	X				

CONTACT	POSITION	
	I	2
A12-B12	X	
A1-B1		X
A2-B2	X	
A3-B3		X
A4-B4	X	
A5-B5		X
A6-B6	X	
A7-B7		X
A8-B8	X	
A9-B9		X
A10-B10	X	
A11-B11		X
C12-D12	X	
C1-D1		X
C2-D2	X	
C3-D3		X
C4-D4	X	
C5-D5		X
C6-D6	X	
C7-D7		X
C8-D8	X	
C9-D9		X
C10-D10	X	
C11-D11		X

CONTACT	POSITION		
	I	I	I
A11-B11	X		
A12-B12		X	
A1-B1			X
A2-B2	X		
A3-B3		X	
A4-B4			X
A5-B5	X		
A6-B6		X	
A7-B7			X
A8-B8	X		
A9-B9		X	
A10-B10			X

Westinghouse



Additional Position Tabulations *Continued*

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A2-B2	X
A3-B3	X
A4-B4	X
A5-B5	X
A6-B6	X
A7-B7	X
A8-B8	X
A9-B9	X
A10-B10	X
C11-D11	X
C12-D12	X
C1-D1	X
C2-D2	X
C3-D3	X
C4-D4	X
C5-D5	X
C6-D6	X
C7-D7	X
C8-D8	X
C9-D9	X
C10-D10	X


CONTACT	POSITION				
	P	I	I	I	I
A1-B1	X	X			
A1-B12			X	X	
A1-B1					X
A2-B2		X	X		
A3-B3				X	X
A4-B4					X
A5-A6	X	X	X		
A6-A7				X	X
B5-B6	X	X	X		
B6-B7					X
A8-A9	X	X	X		
A9-A10				X	X
B8-B9	X	X	X		
B9-B10				X	X

CONTACT	POSITION			
	P	112 A	12 A	I
A11-B11	X	X		
A12-B12			X	X
A1-B1				X
A2-B2	X	X		
A3-B3			X	X
A4-B4				X
A5-A6	X	X	X	
A6-A7				X
B5-B6	X	X	X	
B6-B7				X
A8-A9	X	X	X	
A9-A10				X
B8-B9	X	X	X	
B9-B10				X
C12-C1	X			
D12-D1		X	X	X
C2-C3	X			
D2-D3		X	X	X
C4-C5	X			
D4-D5		X	X	X
C6-C6	X			
D6-D7		X	X	X
C8-C9	X			
D8-D9		X	X	X
C10-C11	X			
D10-D11		X	X	X

CONTACT	POSITION		
	11	12	1
A11-B11	X		
A12-B12		X	
A1-B1			X
A2-B2			X
A3-B3	X		
A4-B4		X	
A5-B5			X
A6-B6			X
A7-B7	X		
A8-B8		X	
A9-B9			X
A10-B10			X


CONTACT	POSITION				
	10	11	12	1	2
A10-B10	X				
A11-B11		X			
A12-B12			X		
A1-B1				X	
A2-B2					X
A3-B3					X
A4-B4	X				
A5-B5		X			
A6-B6			X		
A7-B7				X	
A8-B8					X
A9-B9					X

Dimensions in Inches




* The above Dimensions Apply to Switches Having Either Momentary or Maintained Contacts. On Switches Requiring both Momentary and Maintained Contacts, add .88 Inch to The First Stage Only.

Typical Arrangement of Type W-2 Switch with Type EZC Indicating Lamps.




Switch Contact Frame Size	Number of Lamps Above Each Switch		Horizontal Distance Inches
	Sw. 1	Sw. 2	
6	0	0	3
12	0	0	5½
6	2	2	3
12	2	2	5½
6	3	3	4¼
12	3	3	5½
6	2	3	3½
12	2	3	5½

Note 1—Vertical Distance Between Switches
With Lamps and N. P. 7 Inches.
Without Lamps/with N. P. 5½ Inches.
Without Lamps or N. P. 5½ Inches.



Drilling Plan
Key Interlock



Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity

How to Order Stamped Dial Nameplates

- NP 502A054H01 (Fixed Handle) Fig. 1
- NP 502A054H03 (Removable Key) Fig. 1
- NP 502A054H02 (Fixed Handle with Target) Fig. 2
- NP 502A054H04 (Fixed Handle) Fig. 3
- NP 502A054H05 (Removable Key) Fig. 3

Select figure number meeting nameplate requirement. Specify the required blank nameplate style as given for the selected figure number and the desired markings at location numbers shown on the figures.

Example: Figure 2 – NP 502A054H02
Stamp 11 = Trip, 1 = Close, 15 = Circuit Breaker, 16 = Control.

Number of Letter Spaces per Line




Fig. 1

Number of Letter Spaces per Line




Fig. 2

Number of Letter Spaces per Line






Fig. 3

Method of Identifying Contact Terminals Lettered Bands, Numbered Terminals




6-Contact Stage Connector Connector Style No.

1	677C519H08
2	677C519G07
3	677C519G05
4	677C519G01
5	677C782G01
6	677C782G02
7	677C782G03
8	677C782G04




Connectors in Same Band




Connectors between Adjacent Bands

12-Contact Stage Connector Connector Style No.

1	677C519H08
2	677C519G07
3	677C519G05
4	677C519G01
5	677C782G01
6	677C782G02
7	677C782G03
8	677C782G04



Connectors in Same Band



Connector between Adjacent Bands

Instrument and Control Switches, Type W-2

**600 Volts, 20 Ampere
Continuous Capacity**

Form 34219 – For Ordering Special Switches

SWITCH STYLE NO.		PURCHASER		G.O. NO.		ENG.		DATE			
505A717G02		John Doe		A2XZY							
SWITCH POSITION TABULATION (Front View)											
CONTACT						POSITION					
	PULL	TRIP	OFF	AFT	CLOSE						
	T	T	C								
<i>A11-B11</i>	X	X									
<i>A12-B12</i>			X	X							
<i>A1-B1</i>					X						
<i>A5-A6</i>	X	X	X								
<i>A6-A7</i>				X	X						
<i>B5-B6</i>	X	X	X								
<i>B6-B7</i>				X	X						
<i>C11-D11</i>	X	X									
<i>C12-D12</i>			X	X							
<i>C1-D1</i>					X						
<i>C5-C6</i>	X	X	X								
<i>C6-C7</i>				X	X						
<i>D5-D6</i>	X	X	X								
<i>D6-D7</i>				X	X						
TOP	1	12	11	A							
	1	12	11	B							
BOTTOM	5	6	7	A							
	5	6	7	B							
PLAN VIEW											
TYPICAL 6 CONTACT STAGE		TOP		A				Remarks or Additional Data:			
		3		2	1	12	11	10	9		
		3		2	1	12	11	10	9		
BOTTOM		4		5	6	7	8	A			
		4		5	6	7	8	B			
PLAN VIEW											
TYPICAL 12 CONTACT STAGE		TOP		A							
		3		2	1	12	11	10	9		
		3		2	1	12	11	10	9		
BOTTOM		4		5	6	7	8	A			
		4		5	6	7	8	B			
CIRCUIT BREAKER CONTROL											
TRIP											
PULL OUT											
CLOSE											
FACEPLATE (F.V.) SPECIFY MARKINGS											

CONTACTS: Momentary - Maintained
 HANDLE: Fixed - Removable Key
 - Oval - Round - Pistol Grip
 MOUNTING: 1/8 - 1/4 - 1 - 1 1/2 - 2, Thick Panel
 TARGET: Yes - No
 STAGE CONTACTS: 6 - 12

Westinghouse Electric Corporation
Switchgear Division, East Pittsburgh, Pa. 15112
Printed in USA

Westinghouse



Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity

Application

The Type W-2 switch is designed for use as an instrument, control or general purpose switch. It is compact, yet of sufficient size to provide long, trouble-free service when applied within the specified ratings.

Design flexibility of internal parts and contacting, plus external jumpering of the contact studs affords almost limitless switching combinations for relatively few standard components. The design flexibility is provided in the basic switch styles. A complete switch is made up of a basic switch style, one of several styled handles, a nameplate connector diagram style and a nameplate.


The W-2 switch may be ordered as a single style unit where such a style meets a specific application. Where a single listed style does not meet a specific application, the desired switch may be ordered by specifying the required styled components.

Instrument Switches: Maintained contact type for use with all classes of electrical instruments, relays, meters, and for performing various circuit combinations. Designed for panel mounting and equipped with handles for manual operation.

Control Switches: Momentary contact type being spring return to the original or "off" position. For use with circuit breakers and other electrically controlled apparatus. Panel mounting. Handles for manual operation.

The Type W-2 switch can be furnished with a tumbler pin keylock. Such lock can be assembled either to the right or to the left of the switch unit on the horizontal center line, or, as is considered standard, above the switch unit on the vertical center line as shown in the illustration. The unit is so designed as to permit locking the switch in any one or in each of several positions. The position or positions in which a switch is to be locked must be specified on order.

The style numbers shown in this bulletin apply to switches for mounting on $\frac{1}{8}$ - $\frac{1}{4}$ inch thick panels only. Switches for mounting on thicker panels may be ordered as "similar to" a desired style except for thick panel.



Advantages

Small Size

Variable Circuitry by "You Wire It"

More Contacts per Unit Volume

Roller-Wipe Spring Actuated Contacting

Momentary and Maintained Contact Designs, or in Combination

Greater Availability of Contacts with Terminal Identification for Automated Wiring or Application Changes in Field, See Page 23

Double Break Contacts per Stage

In This Bulletin

Instrument and Control Switches

Page

Application	1
Design Features	2
Operation	3
Construction Details	4
Standard Switches	5
Position Tabulations	6-17
Basic Switches	18
Additional Position Tabulations	19-22
Dimensions	22
Ordering Information	23-24

Westinghouse



Design Features

General Construction

The W-2 switch consists essentially of an operating handle, face plate, control housing, contact frame assembly and rotor assembly. It can be built up in any number of stages from 1 to 9, which stages are clamped together and to the control housing by two tie bolts. A steel operating shaft ties the contact rotors together. A metal cover on the rear holds the position stop pins, retains the shaft and provides basic switch identification. For push or pull switches, the metal cover is replaced by a polycarbonate cover which houses the pull-out mechanism.

Switch Positions

Each switch has a minimum of two and a maximum of twelve rotary positions with a 30° throw between positions, irrespective of the number. Each rotary position coincides precisely with the nameplate markings. The degree of throw between positions is fixed and cannot be changed. The number of positions of each switch can be altered by removing the rear cover and changing the position of the "stop" pin or pins located in the rear housing spacer. In addition to rotary motion, the W-2 switch can be provided with a lateral movement (push-pull) of the rotor.

Contact Frames

Two contact frame sizes are available; the half frame with six sets of contacts; three sets on the top at 11, 12 and 1 o'clock positions and three sets on the bottom at 5, 6 and 7 o'clock positions. The full frame with 12 sets of contacts, each set located at 30° intervals around its perimeter as are the numbers on a clock. The contact frames are made of glass polyester insulating material.

Contacts

Switches are usually referred to as "so many stages long". For a W-2 switch, a stage of contacts consists of a contact frame (either 6 or 12 contact sets) and a rotor.

At every position location on the frame, there are two contact terminal studs in line (a set) per stage. Each of these studs is one piece, made of bronze alloy and silver plated.

Rotors

The rotors are standard in design and hold the roller contacts. Each rotor, made of glass polyester insulating material, rotates independently between the stage spacer plates. The rotor assembly is equipped with one to six rollers (as determined by the required circuitry) each of which makes contact with two adjacent stationary terminal studs to complete a circuit and so affording a double, series break contact. The silver-plated bronze

alloy roller contacts provide a rolling, wiping action, are self-aligning on assembly and require no adjustment of contact pressure for the life of the switch.

Contact Flexibility

Basic "you wire it" flexibility is available in the Type W-2 switch. While the internal contacting is standardized for each basic type of switch; such as ammeter, voltmeter, circuit breaker, etc., by using available insulated jumpers, connections between external switch terminals can be made to obtain the desired contacting for a specific application. This minimizes the number of basic styled switches that otherwise would be required.

Switch Dial

The Type W-2 switch dial consists of two parts; i.e., a dial plate and a nameplate.


The standard control switch dial plate is die cast aluminum, with red and green target parts, where required, and serves as the base for mounting the nameplate. The nameplate is made of a white ABS material on which is stamped in black the desired position markings.

Handles

Handles for the Type W-2 switch are made of a phenolic insulating material designed to afford a smooth, easy, and comfortable grip of pleasing appearance. Each handle has a recessed arrow molded into it as a visual aid in positioning.

The handles are made in four shapes, i.e., oval, round, pistol grip, and large pistol grip. Each of the shapes can be obtained in the fixed type or the removable key type. The fixed handles are fastened to the switch shaft by a screw through the front of the handle.

There is also available a combination removable key type handle in the pistol grip shape that can be used to operate both the Type W-2 and the Type W switches designed for removable key operation.



Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity

Operation

The Type W-2 switch is a rotary roller action switch. Rotation of the shaft causes the rotor rollers to roll from one set of stationary contacts to another. The number of roller contacts can vary from 1 to 6 depending on the number of rotary positions required for the switch application. Each roller contact, moving radially, is held in and guided by a slot in the rotor arm. The rollers are pushed outward by spring pressure. Between roller and spring there is an insulated spring seat to reduce friction and wear. On standard potential contacts, an insulated wheel is used on both ends of the roller contact which wheels roll inside the switch stator frame. This arrangement reduces the friction of the spring-loaded roller in riding up on the stationary contact and also results in an increased air gap as a result of faster contact separation.

Overlapping contacts are obtained by increasing the diameter of the contact rollers of the shorting bar. At mid-position the roller spans the space between the stationary contacts. Such rollers provide a make-before-break contact in going from one position to an adjacent one.

The Type W-2 switch is available in both the maintained and the spring return types. Both types use a housing that is $\frac{3}{8}$ " deep, located between the back surface of the dial plate and the frame-rotor unit. This feature permits conversion from one type to another with a minimum of parts, time and experience.

Maintained Type: On a switch of this type, the switch is held in rotary position by a starwheel mechanism. The mechanism consists of a notched, molded wheel rotating between two metal rollers mounted on spring loaded arms. This arrangement provides a positive snap action as the handle is turned.

Momentary Type: This type uses a rotor that is returned to its original position by a double coil wound spring. The spring offers minimum opposition to movement of the switch handle, but is sufficiently strong to operate the rotor for all required contacting.

For current circuits, there is available an assembly of normally closed contact between front and rear terminals at each position on a stage. The assembly consists of a shorting bar across the two terminals and held closed by spring pressure. Turning the switch handle causes a cam to push the shorting bar away from the two terminals. Operating simultaneously with this contact assembly, in a different stage, are regular rollers designed and arranged so that they make a parallel circuit just prior to opening of the normally closed contact. This arrange-

ment permits overlapping transition in current metering of circuits.



On three-position switches, slip contacts are available. These contacts close when the switch operating handle is turned to the right position and remain closed after the operating handle has returned to the center position. The contacts open when the operating handle is turned to the left position and remain open upon return of the handle to the center position.

In addition to rotary motion, the W-2 switch can be provided with lateral movement (push-pull). Spring actuated roller contacts are mounted in a wafer housing fastened to the operating shaft by "E" rings. The wafer housing can only be moved by a push or pull movement. The roller contact spans two adjacent terminals on a band and it moves back and forth between two bands in a stage.


Interrupting Ratings

Voltage	Amperes			
	Single Contact		Two Contacts in Series	
	Non-Inductive Load	Inductive Load .2 Henry	Non-Inductive Load	Inductive Load .2 Henry
110V 60 Cy.	60.0	30.0
220V 60 Cy.	30.0	20.0	60.0	...
440V 60 Cy.	25.0	10.0	40.0	...
660V 60 Cy.	15.0	8.0	25.0	...
48V D.C.	40.0	5.0
125V D.C.	8.0	2.4	28.0	5.0
250V D.C.	1.8	1.1	9.5	3.3
550V D.C.	.6	.5	2.0	1.2


Westinghouse

**Exploded View of Typical Control Switch****Construction Details of Important Sub-assemblies**Frame
6 contacts

1. Hex nut
2. Window locking spacer
3. Stationary terminal contact

Rotor
Pull contact


1. Roller contact
2. Spring seat
3. Spring

Rotor
Standard
4 roller
potential contacts

1. Standard roller contact
2. Contact wheel
3. Spring seat
4. Spring

Rotor
Standard
6 roller
overlap contacts

1. Overlap roller contact
2. Spring seat
3. Spring

Control housing
with maintained
contact mechanism

1. Starwheel spring
2. Starwheel lever
3. Starwheel roller
4. Starwheel

**Instrument and Control
Switches, Type W-2**

 600 Volts, 20 Ampere
Continuous Capacity

Standard Switches – Style Numbers

Figure	Switch Description	Complete Switch	Handle Type	Contact Type
1	Ammeter – 2 phase	505A700G01	R	MA
2	Ammeter – 3 phase – 2 CT's	505A701G02	R	MA
2A	3 phase – 3 independent circuits	505A701G01	R	MA
3	Voltmeter – 1 phase	505A747G01+	...	MA
3A	Frequency Meter	508A467G01+	...	MA
3B	Synchronizing – machine to bus	505A755G01+	...	MA
4	Voltmeter – 2 phase – 3 wire	505A702G01	R	MA
4A	2 circuit dc – 2 wire	505A702G02	R	MA
4A	2 circuit dc – 2 wire	505A748G01+	...	MA
4B	Dc – 3 wire	505A702G03	R	MA
4C	3 phase – 3 wire	505A702G04	R	MA
4C	3 phase – 3 wire	505A749G01+	...	MA
4D	3 phase – 4 wire	505A702G05	R	MA
4D	3 phase – 4 wire	505A762G01+	...	MA
5	Voltmeter – 4 circuit	505A704G01	R	MA
6	Voltmeter			
	3 phase and phase-to-neutral			
6A	two 3 phase circuits	505A705G01	R	MA
6B	6 circuit	505A705G02	R	MA
		505A705G03	R	MA
7	Wattmeter	505A752G01+	...	MA
8	Power Factor Meter	505A753G01+	...	MA
9	Power Factor Meter current transfer only	505A754G01+	...	MA
10	Synchronizing between machines	505A757G01+	...	MA
11	Temperature approximate lead compensation	658A667G01	R	MA
12	Temperature approximate lead compensation	663A488G01	R	MA
13	Temperature accurate lead compensation	787A936G01	R	MA
14	Temperature accurate lead compensation	661A210G01	R	MA
15	Temperature approximate lead compensation	663A452G01+	...	MA
16	Temperature accurate lead compensation	661A287G03+	...	MA
17	Temperature approximate lead compensation	663A453G01+	...	MA

Figure	Switch Description	Complete Switch	Handle Type	Contact Type
18	Temperature accurate lead compensation	653A454G01+	...	MA
19	Regulator Cutout	505A712G01	R	MA
20	Regulator Cutout	508A224G02	R	MA
21	Circuit Breaker	505A713G01	P	MO
21A	Circuit Breaker	505A713G02	P	MO
21	Circuit Breaker	505A713G03	O	MO
22	Circuit Breaker	505A714G01	P	MO
	Circuit Breaker	505A714G02	O	MO
23	Circuit Breaker	505A717G01	P	MO
	Circuit Breaker	505A717G03	O	MO
24	Circuit Breaker	505A718G01	P	MO
	Circuit Breaker	505A720G01	P	MO
		505A720G03	O	MO
25	Circuit Breaker	508A244G01	P	MO
	Circuit Breaker	508A244G02	O	MO
26	Circuit Breaker	508A262G01	P	MO
	Circuit Breaker	508A262G03	O	MO
27	Circuit Breaker	508A264G01	O	MO
	Circuit Breaker	608A264G02	P	MO
28	Circuit Breaker	505A703G01	P	MO
	Circuit Breaker	505A703G06	O	MO
29	Voltage Control	505A703G02	P	MO
	Voltage Control	505A703G07	O	MO
30	Voltage Control	505A715G01	P	MO
	Voltage Control	505A715G05	O	MO
31	Voltage Control	505A716G01	O	MO
	Electrode Control	505A716G02	O	MO
31A	Electrode Control	505A716G04	P	MO
	Motor Control	505A716G03	O	MO
31B	Motor Control	505A716G05	P	MO
32	Pilot Wire Test	508A468G01	P	MA
33	OFF-ON	505A706G01	O	MA
		505A706G02	P	MA
		505A706G03	R	MA

Handle Type: R = Round Fixed

P = Pistol Grip Fixed

O = Oval Fixed

MA = Maintained Contacts


MO = Momentary Contacts

* Switch requires but does not include removable key handle. Order as separate item, the number of keys desired, specifying style as shown in referenced figure.

Westinghouse

**Position Tabulations**



All wiring diagrams contained in this bulletin are to be considered as "TYPICAL."



CONTACT	POSITION
A11-B11	X X
A12-B12	X X X
A1-B1	X X X
A5-B5	X X X
A6-B6	X X X
A7-B7	X X X

Ammeter


2 Phase
Round Fixed Handle
Switch S# 505A700G01



CONTACT	POSITION
A11-B11	X X X
A12-B12	X X X
A1-B1	X X X
A5-B5	X X X
A6-B6	X X X
A7-B7	X X X
C11-D11	X X X X X X X X
C12-D12	X X X X X X X X
C1-D1	X X X X X X X X
C5-D5	X X X X X X X X
C6-D6	X X X X X X X X
C7-D7	X X X X X X X X

Ammeter


3Phase-2CT's
Round Fixed Handle
Switch S# 505A701G02




2A

Ammeter

3 Phase—3 Independent Circuits
Round Fixed Handle
Switch S# 505A701G01




3




CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

Voltmeter**Single Phase**


Switch S# 505A747G01
Removable Key Handle S# 505A747G02
Key removable in off position only




3A

**Frequency Meter**


Switch S# 508A467G01
Removable Key Handle S# 508A467G02
Key removable in off position only



3B

**Synchronizing**


Machine to Bus
Switch S# 505A755G01
Removable Key Handle S# 505A755G02
Key removable in off position only



Instrument and Control Switches, Type W-2


600 Volts, 20 Ampere
Continuous Capacity

4



Voltmeter


2 Phase—Ac—3 Wire
Round Fixed Handle
Switch S# 505A702G01



4A

Voltmeter


2 Circuit—Dc-2 Wire
Round Fixed Handle
Switch S# 505A702G02
Switch Only S# 505A748G01
Removable Key Handle S# 505A748G02
Key removable in off position only




4B

Voltmeter—Dc-3 Wire

Round Fixed Handle
Switch S# 505A702G03




4C



Voltmeter


3 Phase—3 Wire
Round Fixed Handle
Switch S# 505A702G04
Switch Only S# 505A749G01
Removable Key Handle S# 505A749G02
Key removable in off position only



4D

Voltmeter


3 Phase—4 Wire
Round Fixed Handle
Switch S# 505A702G05
Switch Only S# 505A762G01
Removable Key Handle S# 505A762G02
Key removable in off position only




Westinghouse

**Position Tabulations Continued**


5





CONTACT	POSITION	1	2	3	4	-
A11-B11	X					
A12-B12	X					
A1-B1	X					
A5-B5	X					
A6-B6	X					
A7-B7	X					
C11-D11	X					
C12-D12	X					
C1-D1	X					
C5-D5	X					
C6-D6	X					
C7-D7	X					

Voltmeter**4 Circuit**Round Fixed Handle
Switch S# 505A704G01



6




CONTACT	POSITION	1	2	3	N
A11-B11	OFF				
A12-B12	OFF				
A1-B1	OFF				
A5-B5	OFF				
A6-B6	OFF				
A7-B7	OFF				
C11-D11	OFF				
C12-D12	OFF				
C1-D1	OFF				
C5-D5	OFF				
C6-D6	OFF				
C7-D7	OFF				

Voltmeter**3 Phase and Phase to Neutral**
Round Fixed Handle
Switch S# 505A705G01

6A
Voltmeter
Two 3 Phase Circuits
Round Fixed Handle
Switch S# 505A705G02




6B
Voltmeter
6 Circuit
Round Fixed Handle
Switch S# 505A705G03




Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity

7


**Wattmeter**

Switch Only S# 505A752G01
Removable Key Handle S# 505A752G02
Key removable in off position only




CONTACT	POSITION
A11-B11	OFF - X
A12-B12	X - X
A1-B1	X - X
A5-B5	X - X
A6-B6	X - X
A7-B7	X - X
C11-D11	X X
C12-D12	X X
C1-D1	X X
C5-D5	X X
C6-D6	X X
C7-D7	X X

8


**Power Factor Meter**

Switch Only S# 505A753G01
Removable Key Handle S# 505A753G02
Key removable in off position only




CONTACT	POSITION
A11-B11	OFF - X
A12-B12	X - X
A1-B1	X - X
A5-B5	X - X
A6-B6	X - X
A7-B7	X - X
C11-D11	X X
C12-D12	X X
C1-D1	X X
C5-D5	X X
C6-D6	X X
C7-D7	X X

9


**Power Factor Meter**

Current Transfer Only
Switch Only S# 505A754G01
Removable Key Handle S# 505A754G02
Key removable in off position only



CONTACT	POSITION
A11-B11	OFF - X X
A12-B12	X X - X
A1-B1	X X - X
A5-B5	X X - X
A6-B6	X X - X
A7-B7	X X - X

10

**Synchronizing****Between Machines**


Switch Only S# 505A757G01
Running Key S# 505A757G02
Incoming Key S# 505A757G03
Key removable in off position only

CONTACT	R	O	I
A11-B11	X	X	X
A12-B12	X	X	X
A1-B1	X	X	X
A5-B5	X	X	X
A6-B6	X	X	X
A7-B7	X	X	X

CONTACT	R	O	I
A11-B11	X	X	X
A12-B12	X	X	X
A1-B1	X	X	X
A5-B5	X	X	X
A6-B6	X	X	X
A7-B7	X	X	X

Temperature


Approximate Lead Compensation
Round Fixed Handle
Switch S# 658A667G01



Westinghouse


**Position Tabulations *Continued***

12


**Temperature**

Approximate Lead Compensation
Round Fixed Handle
Switch S# 663A488G01


CONTACT	O	-C	-I	-2	-3	-4	-5	-6	-7	-8	-9	-10	-
A11-B11												X	
A12-B12	X												
A1-B1		X											
A5-B5													
A6-B6													
A7-B7													
C11-D11			X										
C12-D12			X										
C1-D1				X									
C5-D5							X						
C6-D6								X					
C7-D7									X				
E11-F11										X	X	X	
E12-F12	X	X											
E1-F1	X	X	X										
E5-F5				X	X	X							
E6-F6					X	X	X						
E7-F7						X	X	X					
G11-H11		X	X	X									
G12-H12		X	X	X									
G1-H1			X	X	X								
G5-H5							X	X	X				
G6-H6								X	X	X			
G7-H7									X	X	X		



13




CONTACT	W	-C	-I	-2	-3	-4
A11-B11	X					
A12-B12			X			
A1-B1		X				
A5-B5						
A6-B6						
A7-B7						
C11-D11	X	X				
C12-D12	X	X	X			
C1-D1		X	X	X		
C5-D5			X	X	X	
C6-D6				X	X	X
C7-D7	X	X				
E11-F11	X	X				
E12-F12		X	X	X		
E1-F1		X	X	X		
E5-F5			X	X	X	
E6-F6				X	X	X
E7-F7					X	X




**Instrument and Control
Switches, Type W-2**

 600 Volts, 20 Ampere
Continuous Capacity


14

**Temperature**
Accurate Lead Compensation
 Round Fixed Handle
 Switch S# 661A210G01

CONTACT	0	-C-	1	-2-	3	-4-	5	-6-	7	-8-	9	-10-	X
A11-B11													
A12-B12	X												
A1-B1		X											
A5-B5				X									
A6-B6					X								
A7-B7						X							
C11-D11		X											
C12-D12			X										
C1-D1				X									
C5-D5								X					
C6-D6									X				
C7-D7										X			
E11-F11											X		
E12-F12	X											X	
E1-F1		X	X	X									
E5-F5				X	X	X							
E6-F6					X	X	X						
E7-F7						X	X	X					
G11-H11		X	X	X									
G12-H12			X	X	X								
G1-H1				X	X	X							
G5-H5							X	X	X				
G6-H6								X	X	X			
G7-H6									X	X	X		
I11-J11										X	X		
I12-J12	X												
I1-J1		X	X	X									
I5-J5				X	X	X							
I6-J6					X	X	X						
I7-J7						X	X	X					
K11-L11							X	X					
K12-L12								X	X				
K1-L1									X	X			
K5-L5										X	X		
K6-L6											X		
K7-L7												X	





Westinghouse

**Position Tabulations Continued****Temperature****Approximate Lead Compensation**


Switch Only S# 663A452G01
Removable Key Handle S# 505A765G03
Key removable in off position only

CONTACT	POSITION	OFF	C	I	2	3	4
A11-B11	X						
A12-B12		X					
A1-B1			X				
A5-B5				X			
A6-B6					X		
A7-B7						X	X
C11-D11	X X						
C12-D12	X X X						
C1-D1	X X X X						
C5-D5	X X X X						
C6-D6		X X X					
C7-D7			X X X				
E11-F11	X X						
E12-F12	X X X X						
E1-F1	X X X X						
E5-F5	X X X X						
E6-F6		X X X X					
E7-F7			X X X X				
G11-H11	X X						
G12-H12	X X X X						
G1-H1	X X X X						
G5-H5		X X X X					
G6-H6			X X X X				
G7-H7				X X X X			

**Temperature****Accurate Lead Compensation**

Switch Only S# 661A287G03
Removable Key Handle S# 505A711G02
Key removable in off position only


CONTACT	POSITION	OFF	C	I	2	3	4
A11-B11	X						
A12-B12		X					
A1-B1			X				
A5-B5				X			
A6-B6					X		
A7-B7						X	X
C11-D11	X X						
C12-D12	X X X						
C1-D1	X X X X						
C5-D5	X X X X						
C6-D6		X X X X					
C7-D7			X X X X				
E11-F11	X X						
E12-F12	X X X X						
E1-F1	X X X X						
E5-F5	X X X X						
E6-F6		X X X X					
E7-F7			X X X X				
G11-H11	X X						
G12-H12	X X X X						
G1-H1	X X X X						
G5-H5		X X X X					
G6-H6			X X X X				
G7-H7				X X X X			



Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity

17



Temperature


Approximate Lead Compensation
Switch Only S# 663A453G01
Removable Key Handle S# 505A765G03
Key removable in off position only

CONTACT


	O	C	-	1	2	3	4	5	6	7	8	9	10	X
A11-B11	X													
A12-B12		X												
A1-B1			X											
A5-B5				X										
A6-B6					X									
A7-B7						X								
C11-D11							X							
C12-D12								X						
C1-D1									X					
C5-D5										X				
C6-D6											X			
C7-D7												X		
E11-F11	X	X												
E12-F12		X	X	X										
E1-F1			X	X	X									
E5-F5				X	X	X	X							
E6-F6					X	X	X	X						
E7-F7						X	X	X						
G11-H11							X	X						
G12-H12								X	X					
G1-H1									X	X				
G5-H5										X	X			
G6-H6											X	X		
G7-H7												X	X	X

POSITION

1st Stage
2nd Stage
3rd Stage
Shown
5th-7th
Duplicate
4th Stage
Shown 6th
Duplicate



18



Temperature


Accurate Lead Compensation
Switch Only S# 663A454G01
Removable Key Handle S# 505A711G03
Key removable in off position only

CONTACT





	O	C	-	1	2	3	4	5	6	7	8	9	10	X
A11-B11	X													
A12-B12		X												
A1-B1			X											
A5-B5				X										
A6-B6					X									
A7-B7						X								
C11-D11							X							
C12-D12								X						
C1-D1									X					
C5-D5										X				
C6-D6											X			
C7-D7												X		
E11-F11	X	X												
E12-F12		X	X	X										
E1-F1			X	X	X									
E5-F5				X	X	X	X							
E6-F6					X	X	X	X						
E7-F7						X	X	X						
G11-H11							X	X						
G12-H12								X	X					
G1-H1									X	X				
G5-H5										X	X			
G6-H6											X	X		
G7-H7												X	X	X

POSITION


1st Stage
2nd Stage
3rd Stage
Shown
5th-7th
Duplicate
4th Stage
Shown 6th
Duplicate




Westinghouse

**Position Tabulations Continued****Regulator Cutout**Round Fixed Handle
Switch S# 505A712G01**Regulator Cutout**Round Fixed Handle
Switch S# 508A224G02


Interpretation of position designations for Figures 21 through 28, and other switches using slip and/or pull contacts.




21




CONTACT	P	T	O	C
A11-B11	X	X		
A12-B12		X		
A1-B1			X	
A5-B5	X	X		
A6-B6		X		
A7-B7			X	

Circuit Breaker ControlPistol Grip Fixed Handle
Switch S# 505A713G01
Oval Fixed Handle
Switch S# 505A713G03

21 A




CONTACT	P	T	O	C
A11-B11	X	X		
A12-B12		X		
A1-B1			X	
A5-B5	X	X		
A6-B6		X		
A7-B7			X	

Circuit Breaker ControlPistol Grip Fixed Handle
Switch S# 505A713G02

Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity


22



Circuit Breaker Control


Pistol Grip Fixed Handle
Switch S# 505A714G01

Oval Fixed Handle
Switch S# 505A714G02



CONTACT	POSITION			
	P	T	W	C
A11-B11	X	X		
A12-B12		X	X	
A1-B1				X
A5-A6	X	X	X	
A6-A7			X	X
B5-B6	X	X	X	
B6-B7			X	X


23



Circuit Breaker Control


Pistol Grip Fixed Handle
Switch S# 505A717G01

Oval Fixed Handle
Switch S# 505A717G03



CONTACT	POSITION			
	P	T	W	C
A11-B11	X	X		
A12-B12		X	X	
A1-B1				X
A5-A6	X	X	X	
A6-A7			X	X
B5-B6	X	X	X	
B6-B7			X	X
C11-D11	X	X		
C12-D12		X	X	
C1-D1				X
C5-C6	X	X	X	
C6-C7			X	X
D5-D6	X	X	X	
D6-D7			X	X


24



Circuit Breaker Control

Pistol Grip Fixed Handle
Switch S# 505A718G01

CONTACT	POSITION			
	P	T	W	C
A11-B11		X	X	
A12-B12		X		
A1-B1				X
A5-B5	X			
A6-B6			X	X
A7-B7				X
C11-D11	X	X		
C12-D12		X	X	
C1-D1				X
C5-C6	X	X	X	
C6-C7			X	X
D5-D6	X	X	X	
D6-D7			X	X




25

CONTACT	POSITION			
	P	T	W	C
A11-B11	X	X		
A12-B12		X		
A1-B1				X
A5-B5	X			
A6-B6			X	
A7-B7				X
C12-C1	X			
D12-D1		X	X	X
C6-C7	X			
D6-D7		X	X	X

Circuit Breaker Control

Pistol Grip Fixed Handle
Switch S# 505A720G01

Oval Fixed Handle
Switch S# 505A720G03




26

CONTACT	POSITION			
	P	T	W	C
A11-B11	X	X		
A12-B12		X	X	
A1-B1				X
A5-A6	X	X		
A6-A7			X	X
B5-B6	X	X		
B6-B7			X	X
C12-C1	X	X		
D12-D1		X	X	X
C6-C7	X			
D6-D7		X	X	X

Circuit Breaker Control

Pistol Grip Fixed Handle
Switch S# 508A244G01

Oval Fixed Handle
Switch S# 508A244G02




Westinghouse

**Position Tabulations Continued**

CONTACT	P	T	M	N	C
A11-B11	X	X			
A12-B12		X	X		
A1-B1			X	X	X
A5-A6	X	X	X		
A6-A7				X	X
B5-B6	X	X	X		
B6-B7				X	X
C11-D11	X	X			
C12-D12		X	X		
C1-D1				X	X
C5-C6	X	X	X		
C6-C7				X	X
D5-D6	X	X	X		
D6-D7				X	X
E12-E1	X				
F12-F1		X	X	X	X
E6-E7	X				
F6-F7	X	X	X	X	X

Circuit Breaker Control


Pistol Grip Fixed Handle
Switch S# 508A262G01
Oval Fixed Handle
Switch S# 508A262G03




CONTACT	P	T	M	N	C
A11-B11	X	X			
A12-B12		X	X		
A1-B1			X	X	X
A5-B5	X	X			
A6-B6		X	X		
A7-B7	X				
C11-D11	X	X			
C12-D12		X	X		
C1-D1			X	X	X
C5-C6	X	X	X		
C6-C7				X	X
D5-D6	X	X	X		
D6-D7				X	X
E12-E1	X				
F12-F1		X	X	X	X
E6-E7	X				
F6-F7	X	X	X	X	X

Circuit Breaker Control


Oval Fixed Handle
Switch S# 508A264G01
Pistol Grip Fixed Handle
Switch S# 508A264G02

**Circuit Breaker Control**

Pistol Grip Fixed Handle
Switch S# 508A262G01
Oval Fixed Handle
Switch S# 508A262G03




29



CONTACT	R	O	L
A11-B11	X		
A12-B12		X	
A1-B1		X	X
A5-B5	X		
A6-B6		X	X
A7-B7	X		X
C11-D11	X	X	
C12-D12		X	X
C1-D1			X
C5-C6	X	X	
C6-C7			X
D5-D6	X	X	
D6-D7			X
E12-E1	X		
F12-F1		X	X
E6-E7	X		
F6-F7	X	X	X


29A




CONTACT	R	O	L
A11-B11	X		
A12-B12		X	
A1-B1		X	X
A5-B5	X		
A6-B6		X	X
A7-B7	X		X
C11-D11	X	X	
C12-D12		X	X
C1-D1			X
C5-C6	X	X	
C6-C7			X
D5-D6	X	X	
D6-D7			X
E12-E1	X		
F12-F1		X	X
E6-E7	X		
F6-F7	X	X	X

Voltage Control


Pistol Grip Fixed Handle
Switch S# 505A703G01
Oval Fixed Handle
Switch S# 505A703G06

**Speed Control**

Pistol Grip Handle
Switch S# 505A703G02
Oval Fixed Handle
Switch S# 505A703G07




30



CONTACT	R	O	L
A11-B11	X		
A12-B12		X	
A1-B1		X	X
A5-B5	X		
A6-B6		X	X
A7-B7	X		X
C11-D11	X	X	
C12-D12		X	X
C1-D1			X
C5-C6	X	X	
C6-C7			X
D5-D6	X	X	
D7-D7			X
E12-E1	X		
F12-F1		X	X
E6-E7	X		
F6-F7	X	X	X

Voltage Control


Pistol Grip Handle
Switch S# 505A715G01
Oval Fixed Handle
Switch S# 505A715G05




Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity


31




Voltage Control
Oval Fixed Handle
Switch S# 505A716G01




31A




Electrode Control
Pistol Grip Fixed Handle
Switch S# 505A716G04
Oval Fixed Handle
Switch S# 505A716G02




31B



Motor Control
Pistol Grip Fixed Handle
Switch S# 505A716G05
Oval Fixed Handle
Switch S# 505A716G03




32



CONTACT	R	O	N	P	L	C	L
A11-B11	X						
A12-B12		X	X				
A1-B1				X	X		
A5-B5	X						
A6-B6		X	X				
A7-B7			X	X			

Pilot Wire Test

Pistol Grip Fixed Handle
Switch S# 508A468G01



Off-On Switch

Oval Fixed Handle
Switch S# 505A706G01
Pistol Grip Fixed Handle
Switch S# 505A706G02
Round Fixed Handle
Switch S# 505A706G03

CONTACT	OFF	ON
A11-B11	X	
A12-B12	X	
A1-B1	X	
A5-B5	X	
A6-B6	X	
A7-B7	X	

Westinghouse

**Basic Switches – Style Numbers**

Available for Special Application without Nameplate, Handle or Connectors®

Maintained Contacts				Momentary Contacts			
Figure	Basic Switch	Target	Handle+	Figure	Basic Switch	Target	Handle+
34	505A606G01	no	fixed	34	505A623G01	no	fixed
34	505A647G01△	no	removable key▲	34	663A177G01△	no	removable key▲
35	505A667G01	no	fixed	35	505A668G01	no	fixed
35	505A669G01△	no	removable key▲	37	505A607G01	no	fixed
36	508A396G01	no	fixed	38	505A625G01	no	fixed
37	505A634G01	no	fixed	39	505A624G01	no	fixed
37	505A654G01△	no	removable key▲	40	505A684G01	no	fixed
38	505A622G01	no	fixed	41	505A603G01	no	fixed
38	505A670G01△	no	removable key▲	41	508A107G01	yes	fixed
39	505A621G01	no	fixed	41	663A195G01△	no	removable key▲
39	505A672G01△	no	removable key▲	42	508A110G01	no	fixed
40	505A628G01	no	fixed	43	508A111G01	no	fixed
40	505A685G01△	no	removable key▲	43	505A638G01	yes	fixed
41	505A602G01	no	fixed	44	505A615G01	no	fixed
41	508A108G01△	no	removable key▲	44	508A118G01	yes	fixed
42	505A600G01	no	fixed	45	608A125G01	no	fixed
42	661A105G01△	no	removable key▲	46	508A127G01	no	fixed
43	781A377G01	yes	fixed	47	508A128G01	no	fixed
43	508A112G01△	no	removable key▲	47	508A129G01	yes	fixed
44	505A612G01	no	fixed	48	508A133G01	no	fixed
44	508A119G01△	no	removable key▲	48	505A620G01	yes	fixed
45	508A124G01	no	fixed	49	508A143G01	no	fixed
46	508A126G01	no	fixed	49	508A144G01	yes	fixed
48	658A594G01	yes	fixed	50	505A627G01	no	fixed
50	505A626G01	no	fixed	50	508A145G01	yes	fixed
50	508A146G01△	no	removable key▲	51	508A189G01	no	fixed
55	508A166G01	no	fixed	51	508A161G01	yes	fixed
56	505A664G01	no	fixed	52	508A162G01	yes	fixed
59	505A631G01	no	fixed	53	508A163G01	no	fixed
59	508A173G01△	no	removable key▲	53	508A164G01	yes	fixed
60	508A196G01	no	fixed	54	505A619G01	yes	fixed
60	781A167G01△	no	removable key▲	55	508A167G01	yes	fixed
61	508A199G01	no	fixed	56	505A630G01	no	fixed
61	508A300G01□	no	removable key▲	57	508A181G01	yes	fixed
62	505A633G01	no	fixed	58	508A183G01	no	fixed
63	508A302G01	no	fixed	58	508A184G01	yes	fixed
64	508A363G01	no	fixed	59	505A632G01	no	fixed
65	508A307G01	no	fixed	72	505A651G01	no	fixed
65	508A308G01△	no	removable key▲	73	658A542G01	no	fixed
66	508A310G01	no	fixed	74	658A578G01	no	fixed
66	508A311G01△	no	removable key▲	76	505A661G01	yes	fixed
67	508A314G01	no	fixed	77	508A342G01	yes	fixed
67	508A370G01△	no	removable key▲	78	508A344G01◆	no	fixed
68	508A317G01	no	fixed				
69	505A645G01	no	fixed				
69	508A320G01△	no	removable key▲				
70	508A323G01	no	fixed				
70	781A181G01△	no	removable key▲				
71	508A326G01	no	fixed				
72	505A650G01	no	fixed				
72	661A152G01△	no	removable key▲				
73	505A659G01	no	fixed				
73	661A150G01△	no	removable key▲				
74	505A660G01	no	fixed				
74	663A176G01△	no	removable key▲				
75	508A334G01	no	fixed				
75	663A175G01△	no	removable key▲				
78	508A343G01	no	fixed				
78	781A123G01◆	no	removable key▲				
79	508A351G01	no	fixed				
80	505A644G01	no	fixed				
80	663A340G01△	no	removable key▲				

- ◆ = Spring return to "12" position.
- Select and specify, if desired, nameplate and connectors from Page 23. Handles from the following:
 - Round Fixed S#310C624H01
 - Pistol Grip Fixed S#310C624H02
 - Oval Fixed S#501B787H01
 - Large Pistol Grip Fixed S#677C101H01
- ◆ Provision only.
- ▲ If key is desired, the following must be specified:
 - (a) Shape of handle.
 - (b) If to be interchangeable with other keys, specify the position or positions in which the key is to be removable and the style of the existing switch.
 - (c) If the key is to be removable in a different position than indicated for the basic switch, or is to be non-interchangeable with other key handles, order the basic switch as "similar to" a style number and give specific requirements.
- △ Key removable in "12" position.
- Key removable in "10" position.
- ◆ Key removable in "11" position.

Instrument and Control Switches, Type W-2

600 Volts, 20 Ampere
Continuous Capacity

Additional Position Tabulations

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-D6	X
C7-D7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-D5	X
C6-C7	X
D6-D7	X
E12-E1	X
F12-F1	X
E5-F5	X
E6-F6	X
E7-F7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-C6	X
C6-C7	X
D6-D7	X
E12-E1	X
F12-F1	X
E5-F5	X
E6-F6	X
E7-F7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-C6	X
C6-C7	X
D6-D7	X
E12-E1	X
F12-F1	X
E5-F5	X
E6-F6	X
E7-F7	X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A5-B5	X
A6-B6	X
A7-B7	X
C11-D11	X
C12-D12	X
C1-D1	X
C5-C6	X
C6-C7	X
D6-D7	X
E12-E1	X
F12-F1	X
E5-F5	X
E6-F6	X
E7-F7	X

*Adjacent overlap contacts
are electrically connected
together during transfer.

Westinghouse

**Additional Position Tabulations *Continued***

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X			
A12-B12	X X			
A1-B1	I	X		
A5-B5	X			
A6-B6	X X			
A7-B7	I	X		
C11-D11	X			
C12-D12	X X			
C1-D1	I	X		
C5-D5	X	I		
C6-D6	X X			
C7-D7	I	X		
E12-E1	X I			
F12-F1	X X	I X		
E6-E7	I X			
F6-F7	X X	I X		

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X			
A12-B12	I X			
A1-B1	I	X		
A5-B5	X			
A6-B6	I X			
A7-B7	I	X		
C11-D11	X I			
C12-D12	I X			
C1-D1	I	X		
C5-D5	X I			
C6-D6	I X			
C7-D7	I X			
E11-F11	X I			
E12-F12	I X			
E1-F1	I	X		
E5-F5	X			
E6-F6	I X			
E7-F7	I X			
G11-H11	X I			
G12-H12	I X			
G1-H1	I X			
G5-H5	X			
G6-H6	I X			
G7-H7	I X			

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X X			
A12-B12	I X X			
A1-B1	I			
A5-B5	X X			
A6-B6	X X			
A7-B7	I X			
C11-D11	X X			
C12-D12	I X X			
C1-D1	I X			
C5-C6	X X	I X X		
C6-C7	I X X			
D5-D6	X X	I X		
D6-D7	I X X			
E11-F11	X X			
E12-F12	I X X			
E1-F1	I X			
E5-E6	X X	I X		
E6-E7	I X X			
F5-F6	X X	I X		
F6-F7	I X X			
G12-G1	X			
H12-H1	X X X			
G6-G7	X			
H6-H7	X X X X			

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X X			
A12-B12	I X X			
A1-B1	I X			
A5-A6	X I X X			
A6-A7	I X X X			
B5-B6	I X X X			
B6-B7	I X X X			
C11-D11	I X X			
C12-D12	I X X			
C1-D1	I X X			
C5-C6	I X X			
C6-C7	I X X			
D5-D6	I X X			
D6-D7	I X X			
E11-F11	I X X			
E12-F12	I X X			
E1-F1	I X X			
E5-E6	I X X			
E6-F6	I X X			
E7-F7	I X X			
G11-H11	I X X			
G12-H12	I X X			
G1-H1	I X X			
G5-H5	I X X			
G6-H6	I X X			
G7-H7	I X X			

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X X			
A12-B12	I X X			
A1-B1	I X			
A5-B5	X X			
A6-B6	X X			
A7-B7	I X			
C11-D11	X X			
C12-D12	I X X			
C1-D1	I X			
C5-C6	X X	I X X		
C6-C7	I X X			
D5-D6	X X	I X		
D6-D7	I X X			
E11-F11	X X			
E12-F12	I X X			
E1-F1	I X			
E5-E6	X X	I X		
E6-E7	I X X			
F5-F6	X X	I X		
F6-F7	I X X			
G12-G1	X			
H12-H1	X X X			
G6-G7	X			
H6-H7	X X X X			

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X X			
A12-B12	I X			
A1-B1	I X			
A5-B5	I X X			
A6-B6	I X X			
A7-B7	I X X			
C11-D11	I X X			
C12-D12	I X X			
C1-D1	I X X			
C5-C6	I X X			
C6-C7	I X X			
D5-D6	I X X			
D6-D7	I X X			
E11-F11	I X X			
E12-F12	I X X			
E1-F1	I X X			
E5-F5	I X X			
E6-F6	I X X			
E7-F7	I X X			
G11-H11	I X X			
G12-H12	I X X			
G1-H1	I X X			
G5-H5	I X X			
G6-H6	I X X			
G7-H7	I X X			

CONTACT	POSITION			
P	I	I	I	I
A11-B11	I X X			
A12-B12	I X X			
A1-B1	I X X			
A5-B5	I X X			
A6-B6	I X X			
A7-B7	I X X			
C11-D11	I X X			
C12-D12	I X X			
C1-D1	I X X			
C5-C6	I X X			
C6-C7	I X X			
D5-D6	I X X			
D6-D7	I X X			
E11-F11	I X X			
E12-F12	I X X			
E1-F1	I X X			
E5-F5	I X X			
E6-F6	I X X			
E7-F7	I X X			
G11-H11	I X X			
G12-H12	I X X			
G1-H1	I X X			
G5-H5	I X X			
G6-H6	I X X			
G7-H7	I X X			

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X X			
A12-B12	I X			
A1-B1	I X			
A5-B5	I X X			
A6-B6	I X X			
A7-B7	I X X			

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X X			
A12-B12	X X X			
A1-B1	I X X X			
A5-B5	I X X X			
A6-B6	I X X X			
A7-B7	I X X X			

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X X			
A12-B12	I X X			
A1-B1	I X X X			
A5-B5	I X X X			
A6-B6	I X X X			
A7-B7	I X X X			
C11-D11	I X X X			
C12-D12	I X X X			
C1-D1	I X X X			
C5-D5	I X X X			
C6-D6	I X X X			
C7-D7	I X X X			
E11-F11	I X X X			
E12-F12	I X X X			
E1-F1	I X X X			
E5-F5	I X X X			
E6-F6	I X X X			
E7-F7	I X X X			

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X I			
A12-B12	I X			
A1-B1	I X			
A5-B5	I X			
A6-B6	I X			
A7-B7	I X			
C11-D11	I X			
C12-D12	I X			
C1-D1	I X			
C5-D5	I X			
C6-D6	I X			
C7-D7	I X			
E11-F11	I X			
E12-F12	I X			
E1-F1	I X			
E5-F5	I X			
E6-F6	I X			
E7-F7	I X			

CONTACT	POSITION			
P	I	I	I	I
A11-B11	X X			
A12-B12	X X			
A1-B1	X X X			
A5-B5	X X X			
A6-B6	X X X			
A7-B7	X X X			
C11-D11	X X X			
C12-D12	X X X			
C1-D1	X X X			
C5-D5	X X X			
C6-D6	X X X			
C7-D7	X X X			
E11-F11	X X X			
E12-F12	X X X			
E1-F1	X X X			
E5-F5	X X X			
E6-F6	X X X			
E7-F7	X X X			

*Adjacent overlap contacts are electrically connected together during transfer.

Instrument and Control Switches, Type W-2

**600 Volts, 20 Ampere
Continuous Capacity**

CONTACT	POSITION			
	1	2	3	4
A11-B11	X			
A12-B12		X		
A1-B1			X	
A5-B5	X			
A6-B6		X		
A7-B7			X	
C11-D11				X
C12-D12				X
C1-O1				X
C5-D5			X	
C6-D6				X
C7-D7				X
E11-F11	X			
E12-F12		X		
E1-F1			X	
E5-F5	X			
E6-F6		X		
E7-F7			X	
G11-H11				X
G12-H12				X
G1-H1				X
G5-H5			X	
G6-H6				X
G7-H7				X

CONTACT	POSITION
A11-B11	X
A12-B12	X
A1-B1	X
A2-B2	X
A3-B3	X
A4-B4	X
A5-B5	X
A6-B6	X
A7-B7	X
A8-B8	X
A9-B9	X
A10-B10	X

CONTACT	POSITION				
	1	1	2	3	4
A11-B11	X				
A12-B12		X			
A1-B1			X		
A5-B5	X				
A6-B6		X			
A7-B7			X		
C11-D11				X	
C12-D12					X
C1-D1					X
C5-D5		X			
C6-D6				X	
C7-D7					X
E11-F11	X				
E12-F12		X			
E1-F1			X		
E5-F5	X				
E6-F6		X			
E7-F7			X		
G11-H11				X	
G12-H12					X
G1-H1					X
G5-H5				X	
G6-H6					X
G7-H7					X
I11-J11	X				
I12-J12		X			
I1-J1			X		
I5-J5	X				
I6-J6		X			
I7-J7			X		
K11-L11				X	
K12-L12					X
K1-L1					X
K5-L5				X	
K6-L6					X
K7-L7					X

CONTACT	POSITION									
	1	2	3	4	5	6	7	8	9	10
A11-B11	X	X								
A12-B12		X	X	X						
A1-B1			X	X	X					
A5-B5						X	X	X		
A6-B6							X	X	X	
A7-B7								X	X	X
C11-D11	I	X	X	X	X	X	X	X	X	X
C12-D12	X	X	X	X	X	X	X	X	X	X
C1-D1	X	X	X	X	X	X	X	X	X	X
C5-D5	X	X	X	X	X	X	X	X	X	X
C6-D6	X	X	X	X	X	X	X	X	X	X
C7-D7	X	X	X	X	X	X	X	X	X	X
E11-F11		X	X							
E12-F12			X	X	X					
E1-F1				X	X	X				
E5-F5							X	X	X	
E6-F6								X	X	X
E7-F7								X	X	X
G11-H11			X	X	X					
G12-H12				X	X	X				
G1-H1					X	X	X			
G5-H5								X	X	X
G6-H6									X	X
G7-H7										X
I11-J11	X	X	X	X	X	X	X	X	X	X
I12-J12	X	X	X	X	X	X	X	X	X	X
J1-J1	X	X	X	X	X	X	X	X	X	X
I5-J5	X	X	X	X	X	X	X	X	X	X
I6-J6	X	X	X	X	X	X	X	X	X	X
I7-J7	X	X	X	X	X	X	X	X	X	X
K11-L11			X	X	X					
K12-L12				X	X	X				
K1-L1					X	X	X			
K5-L5						X	X	X		
K6-L6							X	X	X	
K7-L7								X	X	X

CONTACT	POSITION
A1-2	I
A12-B12	X
A1-B1	X
A2-B2	X
A3-B3	X
A4-B4	X
A5-B5	I
A6-B6	X
A7-B7	I
A8-B8	X
A9-B9	I
A10-B10	X
A11-B11	I
C12-D12	X
Cl-D1	I
C2-D2	X
C3-D3	I
C4-D4	X
C5-D5	I
C6-D6	X
C7-D7	I
C8-D8	X
C9-D9	I
C10-O10	X
C11-D11	I

CONTACT	POSITION	
	I	II
A11-B11		X
A12-B12		X
A1-B1		
A2-B2		X
A3-B3		
A4-B4		
A5-B5		X
A6-B6		X
A7-B7		X
A8-B8		X
A9-B9		X
A10-B10		X

Westinghouse

**Additional Position Tabulations Continued**

CONTACT	POSITION	I	12	I
A11-B11	X			
A12-B12	X			
A1-B1		X		
A2-B2	X	X		
A3-B3	X	X		
A4-B4				
A5-B5	X	X		
A6-B6	X			
A7-B7		X		
A8-B8	X			
A9-B9	X			
A10-B10	X			
C11-D11	X			
C12-D12	X			
C1-D1		X		
C2-D2	X			
C3-D3	X			
C4-D4		X		
C5-D5	X			
C6-D6	X			
C7-D7		X		
C8-D8	X			
C9-D9	X			
C10-D10	X			

CONTACT	POSITION	P	I	12	A	I
A11-B11	X					
A12-B12		X	X			
A1-B1			X	X		
A2-B2	X	X				
A3-B3	X	X				
A4-B4						
A5-A6	X	X	X			
A6-A7	X	X	X			
B5-B6	X	X	X	X		
B6-B7			X	X		
A8-A9	X	X	X			
A9-A10			X	X		
B8-B9	X	X	X	X		
B9-B10						
C12-C1	X					
D12-D1	X	X	X	X		
C2-C3	X	X	X	X		
D2-D3		X	X	X		
C4-C5	X					
D4-D5	X	X	X	X		
C6-C6	X					
D6-D7		X	X	X		
C8-C9	X	X	X	X		
D8-D9						
C10-C11	X	X	X	X		
D10-D11	X	X	X	X		

CONTACT	POSITION	P	I	12	A	I
A11-B11	X					
A12-B12		X	X			
A1-B1			X	X		
A2-B2	X	X				
A3-B3	X	X				
A4-B4						
A5-A6	X	X	X			
A6-A7	X	X	X			
B5-B6	X	X	X	X		
B6-B7			X	X		
A8-A9	X	X	X			
A9-A10			X	X		
B8-B9	X	X	X	X		
B9-B10						
C12-C1	X					
D12-D1	X	X	X	X		
C2-C3	X	X	X	X		
D2-D3		X	X	X		
C4-C5	X					
D4-D5	X	X	X	X		
C6-C6	X					
D6-D7		X	X	X		
C8-C9	X	X	X	X		
D8-D9						
C10-C11	X	X	X	X		
D10-D11	X	X	X	X		

CONTACT	POSITION	I	12	I	2
A11-B11	X				
A12-B12		X			
A1-B1			X		
A2-B2				X	
A3-B3	X				
A4-B4					
A5-B5					
A6-B6					
A7-B7	X				
A8-B8					
A9-B9					
A10-B10					
A11-B11					X

CONTACT	POSITION	I	12	I	2
A10-B10	X				
A11-B11		X			
A12-B12			X		
A1-B1				X	
A2-B2					
A3-B3					
A4-B4					
A5-B5					
A6-B6					
A7-B7					
A8-B8					
A9-B9					

CONTACT	POSITION	12	I	2	3	4	5	6	7	8	9	10	11
A12-B12	X												
A1-B1		X											
A2-B2			X										
A3-B3				X									
A4-B4					X								
A5-B5						X							
A6-B6							X						
A7-B7								X					
A8-B8									X				
A9-B9										X			
A10-B10											X		
A11-B11												X	




Dimensions in Inches**Typical Arrangement of Type W-2 Switch with Type EZC Indicating Lamps**

Table A

Switch Contact Frame Size	Number of Lamps Above Each Switch		Horizontal Distance Inches
	Sw. 1	Sw. 2	
6	0	0	3
12	0	0	5 1/2
6	2	2	3
12	2	2	5 1/2
6	3	3	4 1/4
12	3	3	5 1/2
6	2	3	3 3/4
12	2	3	5 1/2



Instrument and Control Switches, Type W-2

**600 Volts, 20 Ampere
Continuous Capacity**

How to Order Stamped Dial Nameplates

- NP 502A054H01 (Fixed Handle) Fig. 1
NP 502A054H03 (Removable Key) Fig. 1
NP 502A054H02
(Fixed Handle with Target) Fig. 2
NP 502A054H04 (Fixed Handle) Fig. 3
NP 502A054H05 (Removable Key) Fig. 3

Select figure number meeting nameplate requirement. Specify the required blank nameplate style as given for the selected figure number and the desired markings at location numbers shown on the figures.

Example: Figure 2 - NP 502A054H02
Stamp 11 = Trip, 1 = Close, 15 = Circuit
Breaker, 16 = Control.




Fig. 1




Fig 2





Fig. 3


Method of Identifying Contact Terminals Lettered Bands, Numbered Terminals




6-Contact Stage Connector

Connector Style No.

1	677C519H08
2	677C519G07
3	677C519G05
4	677C519G01
5	677C782G01
6	677C782G02
7	677C782G03
8	677C782G04




Connectors in Same Bond




Connectors between Adjacent Bands

12-Contact Stage Connector

Connector	Style No.
1	677C519H08
2	677C519G07
3	677C519G05
4	677C519G01
5	677C782G01
6	677C782G02
7	677C782G03
8	677C782G04



Connectors in Same Band



Connector between Adjacent Bands

Instrument and Control Switches, Type W-2

**600 Volts, 20 Ampere
Continuous Capacity**

Form 34219 – For Ordering Special Switches

Westinghouse Electric Corporation
Switchgear Division, East Pittsburgh, Pa. 15112
Printed in USA

INSTRUMENT AND CONTROL
SWITCHES
TYPE W-2

Supplement to Descriptive Bulletin 34-251

www.ElectricalPartManuals.com

TYPE W-2 SWITCH

The following is presented as an aid in identifying contact terminals of the type W-2 Switch.

Referring to sketch Figure A, consider the radial lines (12 in number) positioned and numbered as the hours on the face of a clock, as being the ROWS of terminals.

Consider the circles of the sketch as BANDS of terminals around the circumference of the switch, the smallest circle representing the front BAND, or the BAND nearest the switch handle. Starting from the front, let the BANDS progressively be identified by the letters A - B - C, etc.

The intersection of the radial lines with the circles are used to locate specific terminals. Identification is by reference to both line and circle designation, i.e., A1, B2, C3, E7, etc.

The sequential grouping from front to back of two BANDS of terminals is designed as a STAGE.

The relationship between ROWS - BANDS - and STAGES is shown by figure A.


Contact positions for the type W-2 Switch are indicated by means of tabulations such as illustrated by Tab. 1. Closed contacts are indicated by X. Designation of closed contacts for the various switch handle positions is by means of the letter-number combinations in the left hand column of the tabulation. For example, with the switch handle in the trip or T position, terminals A11 and B11 are connected each to the other, also terminals A5 and A6, also B5 and B6, etc.

The tabulation used herein is for a circuit breaker control switch, having handle positions PULL TRIP - TRIP - OFF AFTER TRIP - OFF AFTER CLOSE - CLOSE.

Figures B-C-D-E-F are an expansion of tabulation 1, to diagrammatically show the contact positions, both open and close, for the various switch handle movements. (# indicates closed contacts, = indicates open contacts)

CONTACT	POSITION				
	P	T	Off	After	C
	T	T	T	C	C
A11-B11	X	X			
A12-B12			X	X	
A1-B1					X
A5-A6	X	X	X		
A6-A7				X	X
B5-B6	X	X	X		
B6-B7				X	X
C11-D11	X	X			
C12-D12			X	X	
C1-D1					X
C5-C6	X	X	X		
C6-C7				X	X
D5-D6	X	X	X		
D6-D7				X	X
E12-E1	X				
F12-F1		X	X	X	X
E6-E7	X				
F6-F7		X	X	X	X

TAB. 1








FIG. A




Switch handle pulled out in TRIP (T) position.
Breaker is TRIPPED AND indicating LAMPS ARE CUT OUT.

FIG. B.




Switch handle held in TR (T) position.
Handle not pulled out.
Indicating lamps not cut out.


FIG. C



Switch handle
spring returned
to off position
after being moved to
TRIP (T) position.
Indicating
LAMPS NOT CUT
OUT.



Switch handle
spring returned
to off position
after being moved to
CLOSE (C) position.
Indicating
lamps not cut
out.



Switch handle
held in CLOSE
(C) position.
Handle not
pulled out.
Indicating
lamp not cut
out

FIG. F

TYPE W-2 SWITCH
Wiring Diagram

Fig. I is the wiring diagram for a circuit breaker control switch with positions as shown in Tab. 1. Referring to the Figure I, R and G are respectively Red and Green Indicating Lights. Breaker Close and Breaker Trip are respectively the closing and trip mechanisms of the controlled circuit breaker. The breaker A and B contacts are respectively the normal open and closed contacts of the circuit breaker auxiliary switch. Closing are the contacts of the Recloser relay that are in the closing circuit of the circuit breaker.

By comparing contact position table Tab. 1 and the wiring diagram Fig. I, it should be noted that the tabulation shows more contacts closed than are required in the wiring diagram Fig. I. The tabulation shows all the inherently available closed contacts for each position of the switch handle, from which the required wiring diagram can be made. For example, the switch under consideration is provided with two standard roller contacts, four slip roller contacts and two rotor pull contacts. With the handle in the CLOSE position, from Tab. 1, it is noted that eight closed contacts are available of which 2 (A1-B1, C1-D1) are closed in the CLOSE position only; 4 (A6-A7, B6-B7, C6-C7, D6-D7) are closed in the CLOSE and OFF AFTER CLOSE positions; and 2 (F12-F1, F6-F7) are closed in all positions except when the handle is pulled out. Referring to Fig. I, it is shown that the only CLOSE contact required is between A1 and B1; the circuit being from bus P through B1-A1 through breaker close to bus N.

With the handle in the OFF AFTER CLOSE position, eight closed contacts are available of which 2 (A12-B12, C12-D12) are closed in the OFF position only; 4 (A6-A7, B6-B7, C6-C7, D6-D7) are closed in the CLOSE and OFF AFTER CLOSE positions; and 2 (F12-F1, F6-F7) are closed in all positions except when the handle is pulled out.

Referring to Fig. I, only four of the closed contacts are required to complete two circuits, each of which is closed in the OFF AFTER CLOSE position only, and each circuit being obtained by the use of a standard contact and a slip contact in series. One circuit starts at bus P, through C12-D12, through D7-D6, through closing contact of the recloser, through breaker close to bus N. The other circuit starts at bus X, through A12-B12, through C6-C7, through recloser to bus Y.

Similarly other contact requirements and circuits can be identified for corresponding positions of the switch handle.




FIG. I

TYPE W-2 SWITCH
Contact Details





Sketches Fig. G and H were prepared to show how connection is made between the stationary terminal contacts and the roller contacts of the Type W-2 Switch. The figures represent one stage of the half frame stator size. For simplicity, only a single roller contact is diagrammatically shown. Stationary and roller contacts are made of bronze alloy, silver plated. Actual construction of contacts, stators and rotors is shown in Descriptive Bulletin 34-251 Page 4.

Figure G illustrates the standard roller contact, used to connect two adjacent stationary contacts in the same stage and row. In the position shown, the roller connects stationary contact A12 to B12. Turning the switch handle clockwise to its next position, the roller connects stationary contact A1 to B1. The roller is sufficiently small in diameter, so that in being moved from one set of contacts to the next, connection is broken before it is again made; ie, connection with terminals A12 is broken before connection is made with A1; the same being true for contacts B12 and B1. With this small roller, there are provided contact wheels made of glass polyester - an insulating material of high dielectric and mechanical strength. These wheels, riding on the stator frame provides for a smooth transition between stationary contacts and serve to maintain adequate electrical strike distance between roller and stationary contacts during transfer.

Fig. H illustrates the overlap roller contact. This contact differs from the standard roller contact in that it uses a roller of a larger diameter to effect a make - before - break transfer of contacts. Fig. H shows the roller midway in its travel from stationary contact A11 to A12. Contact wheels are not required.

Modification of this overlap roller by use of an insulating shaft between the two roller wheels and mounting it on segmented rotor makes us what is termed a slip contact. This arrangement allows the roller contact to rest between adjacent stationary contacts for certain positions of the switch handle. For example referring to Fig. H, stationary contacts A11 and A12 are connected together, and B11 and B12 are connected together. Due to the insulated roller shaft, there is no electrical connection between A11 and B11 or A12 and B12 stationary contacts when the roller contact is in the position shown.

The rotor pull contact, illustrated on page 4 of Descriptive Bulletin 34-251 is used to connect or disconnect two adjacent stationary terminal contacts in the same band. This is accomplished by the in and out axial movement of the switch handle which causes axial movement of the pull contact rotor and the associated roller contacts. For example, referring to Fig. C, with the switch handle pushed in, the roller bridges contacts F1 and F12. With the switch handle pulled out, Fig. B, the bridging is transferred from F1 - F12 to E1 - E12. When the handle is in the pulled-out position, rotary motion of the handle is not possible.



TYPE W-2 SWITCH
Rotor Construction

Figs. 1 to 10 show the various types of circuit combinations possible per stage with rotor using the standard or overlapping types of contacts. Two rotor moldings are available to make up the illustrated combinations; ie, one using up to four roller contacts and one using up to six roller contacts.

Fig. 1 shows a four roller contact rotor with only one roller in the 12 o'clock position of a six contact frame. A switch with such a rotor assembly is suitable for two or three positions, with one contact closed in each position. The number of positions is controlled by the stop pins at the rear of the switch.

Fig. 2 shows the same rotor with two roller contacts 180 degrees apart. This is same as Fig. 1 except that two contacts are closed in each position. In Figs. 1 and 2 a stop can be utilized at 10 o'clock and, or 2 o'clock positions by locating stop pins at the rear of the switch as desired. This will provide for OFF positions as indicated in Figs. 1 and 2.

Fig. 3 shows the same rotor molding with two roller contacts 90 degrees apart. Such an arrangement permits one contact closed in each of up to six positions. With this arrangement, there would be no OFF position as such, however, one of the six positions could be used as an OFF position, if required, simply by not connecting the external stationary contact terminals in the circuit.


Figs. 6-7-8 also use the four roller contact rotor. The function of these figures is similar to those described above, except for the use of the twelve contact frame.

Fig. 4 illustrates the six roller contact rotor in the six contact frame, with but four "rollers" being used. This arrangement permits four contacts to be closed in one position and two closed in the other position.


Figs. 5-9-10 use the six roller contact rotor in the twelve contact frame in combinations as shown in the figures.

TYPE W-2 SWITCH
Rotor Forms

FOR USE WITH HALF FRAME



FOR USE WITH FULL FRAME




PULL ROTOR

The pull rotor of the Type W-2 Switch is designed to close adjacent contacts in the same band. No other type of contact can be combined in the pull rotor and any requirement for a pull contact constitutes a separate stage.

The pull rotor is designed to remain stationary during any rotary movement of the switch shaft in that the shaft of the switch is free to rotate within the hub of the pull rotor. However, "E" rings are used to lock the pull rotor in position on the shaft, i.e. one E ring in front and one in back of the pull rotor, so that the rotor must follow the shaft when pulled out or pushed in.

The pull rotor is prevented from turning inside the stator frame by means of two projections, 180 degrees apart, on the pull rotor which engage and travel in slots molded into the inside surface of the stage frame.

In the "in" or normal position the rotor contacts will bridge, for example, terminals F12 - F1 at the top and F6 - F7 at the bottom of the stage frame and when the handle and rotor are pulled out, the pull rotor is drawn straight forward, guided by the slots in the stage frame, and the aforementioned contacts open and when pull out is com-



PULL ROTOR CONT'D

leted, contacts E12 - E1 and E6 - E7 are closed.

Here again, depending on how the terminals are wired, these can be either pull-to-open or pull-to-close contacts.

SLIP CONTACTS

The slip contact as used in the Type W-2 Switch is a combination or hinging type of rotor with locations for four roller contacts. In the top two locations are placed standard potential type rollers with wheels. This top portion of the rotor contains the hub that fits onto the switch shaft and is therefore moved to various positions as the handle is rotated.

The lower portion of this rotor is that containing the slip contacts and will accommodate two slip contacts. Such contacts can be either slip or reverse slip depending on how the terminals are wired.

In working up a contact tabulation for the Type W-2 Switch it is important to know that the lower or slip contact has a diameter of inch and rides on an insulated shaft and is designed to bridge adjacent terminals in the same band i.e., A6 - A7 and B6 - B7 when in one position and A5 - A6 and B5 - B6 when in the other position.


By way of illustration, consider a Circuit Breaker control switch where the slip rotor consists of one potential and one slip roller; being spring return, the handle and potential roller move to the neutral or 12 o'clock position. When the handle is rotated to the "CLOSE" (1 o'clock) position the potential roller closes (bridges) terminals A1 - B1 and in the rotating process the lower half of the rotor has been forced to its extreme position where it closes terminals A6 - A7 for one circuit and B6 - B7 for a second circuit.



The slip contact will remain thus so long as the handle is rotated only between neutral and CLOSE.

When the handle is rotated to the TRIP position (11 o'clock) the potential roller will close (bridge) terminals A11 - B11 and in the rotating process the lower half or slip roller has been forced to a position where it rests between terminals A5 - A6 and B5 - B6.

SLIP CONTACT* CONT'D

If reverse slip contacts are desired and if a common connection exists between the slip and reverse slip contacts then the latter four terminals may be wired. If no common connection exists then a separate stage of similar design must be added to obtain reverse slip of independent circuitry.





NORMALLY CLOSED CONTACT

The normally closed contact of the Type W-2 Switch differs from all others in that the actual contact is not on the rotor but is held captive between two stationary contacts.

The stationary contacts of this assembly are "L" shaped and the feet of opposite terminals face each other thus forming a "U". A spring actuated contact bar bridges the gap between the feet of the stationary contacts. The contact is held closed by spring pressure. The rotor used in this assy is of Glass Polyester material and is designed to open as many as four normally closed contacts in each position but is also designed so that certain desired projections can be removed that fewer than four "NC" contacts can be opened in each position.

