



RENEWAL PARTS

SECONDARY SUBSTATION TRANSFORMERS

| <u>Item Number</u> | <u>Description</u> |
|--------------------|----------------------------------|
| 101 | High-Voltage Bushing |
| 102 | Low-Voltage Bushing |
| 103 | Neutral Bushing |
| 104 | Liquid Temperature Indicator |
| 105 | Liquid Level Gage |
| 106 | Pressure-Vacuum Gage |
| 107 | Fan |
| 108 | Fault-Pressure Relay |
| 109 | Gaskets, High-Voltage Bushing |
| 110 | Gaskets, Low-Voltage Bushing |
| 111 | Gaskets, Neutral Bushing |
| 112 | Gaskets, Liquid Temp. Ind. |
| 113 | Gasket, Liquid Level Gage |
| 114 | Gasket, Fault Pressure Relay |
| 115 | Gasket, Drain Valve |
| 116 | Gaskets, Tap Changer |
| 117 | Gasket, Pressure-Relief/Handhole |

Refer to the transformer outline drawing for the location of these parts and for any unlisted items. Note that neutral bushings, fans, and the fault-pressure relay are optional features and may not be included with all transformers.

Orders for Renewal Parts should be placed with the nearest Apparatus Sales Office of the General Electric Company. Specify the quantity required and give the TRANSFORMER SERIAL NUMBER, and DESCRIPTION of the desired parts. If the required items are not identified on this list or the outline drawing, describe the part(s) in detail and include the SERIAL NUMBER of the TRANSFORMER.

MEDIUM TRANSFORMER PRODUCTS DEPARTMENT
GENERAL ELECTRIC COMPANY
ROME, GEORGIA 30161

GENERAL  ELECTRIC