


Type 5HK250  
1200 and 2000 Amperes  
5000 Volts







8




9A




9B



10




11




12


| Description of Part Or Assembly          | Fig. Ref. | Quantity Per Breaker |       |                 |
|------------------------------------------|-----------|----------------------|-------|-----------------|
|                                          |           | 1200A                | 2000A | Ordering Number |
| Puffer Piston Assembly                   | 8         | 3                    | 3     | 193989-T2       |
| Pushrod Assembly (Outer Pole)            | 9A        | 2                    | 2     | 192100-K1       |
| Pushrod Assembly (Center Pole)           | 9B        | 1                    | 1     | 192100-K6       |
| Operating Mechanism Assembly             | 10        | 1                    | 1     | 194111-T3       |
| Spring Charging Motor Assembly           |           |                      |       |                 |
| 48V DC                                   | 11        | 1                    | 1     | 709799-T13      |
| 125V DC                                  | 11        | 1                    | 1     | 709799-T11      |
| 250V DC                                  | 11        | 1                    | 1     | 709799-T12      |
| 110/120V AC                              | 11        | 1                    | 1     | 709799-T11      |
| 208/240V AC                              | 11        | 1                    | 1     | 709799-T12      |
| Close Coil Assembly                      |           |                      |       |                 |
| 48V DC                                   | 12        | 1                    | 1     | 191920-T4       |
| 125V DC                                  | 12        | 1                    | 1     | 191920-T14      |
| 250V DC                                  | 12        | 1                    | 1     | 191920-T3       |
| 110/120V AC                              | 12        | 1                    | 1     | 191920-T5       |
| 208/204V AC                              | 12        | 1                    | 1     | 191920-T6       |
| Trip Coil Assembly                       |           |                      |       |                 |
| 48V DC                                   | 12        | 1                    | 1     | 191920-T4       |
| 125V DC                                  | 12        | 1                    | 1     | 191920-T14      |
| 250V DC                                  | 12        | 1                    | 1     | 191920-T3       |
| 110/120V AC                              | 12        | 1                    | 1     | 191920-T5       |
| 204/240V AC                              | 12        | 1                    | 1     | 191920-T6       |
| Control Device Assembly                  |           |                      |       |                 |
| 48V DC                                   | 13        | 1                    | 1     | 191921-T8       |
| 125V DC                                  | 13        | 1                    | 1     | 191921-T6       |
| 250V DC                                  | 13        | 1                    | 1     | 191921-T7       |
| 110/120V AC                              | 13        | 1                    | 1     | 191921-T10      |
| 204/240V AC                              | 13        | 1                    | 1     | 191921-T11      |
| Motor Disconnect Switch                  | 14        | 1                    | 1     | 703270-A        |
| Electrical Close/Trip Switch (When Used) | 15        | 1                    | 1     | 712780-A        |




14




13




15




16




17




18



19




20




21


| Description of Part Or Assembly          | Fig. Ref. | Quantity Per Breaker |       |                 |
|------------------------------------------|-----------|----------------------|-------|-----------------|
|                                          |           | 1200A                | 2000A | Ordering Number |
| Operation Counter                        | 16        | 1                    | 1     | 180522-C        |
| Auxiliary Switch Assembly (4 Contact)    | 17        | 1                    | 1     | 700034-K1       |
| Undervoltage Trip Device (When Used)     |           |                      |       |                 |
| 48V DC                                   | 18        | 1                    | 1     | 197909-T6       |
| 125V DC                                  | 18        | 1                    | 1     | 197909-T7       |
| 250V DC                                  | 18        | 1                    | 1     | 197909-T8       |
| 110/120V AC                              | 18        | 1                    | 1     | 197909-T9       |
| 204/240V AC                              | 18        | 1                    | 1     | 197909-T10      |
| Latch Check Switch Assembly (When Used)  | 19        | 1                    | 1     | 191924-T3       |
| Latch Check Switch (When Used)           | 20        | 1                    | 1     | 191545-A        |
| Resistor Assembly (When Used)            |           |                      |       |                 |
| 120V AC                                  | 21        | 1                    | 1     | 194124-T15      |
| 240V AC                                  | 21        | 1                    | 1     | 194124-T16      |
| Secondary Disconnect Assembly—Moving     | 22        | 2                    | 2     | 703153-K5       |
| Secondary Disconnect Assembly—Stationary | 23        | 1                    | 1     | 834838-T1       |
| Hardware & Retainer Kit                  | 24        | 1                    | 1     | 709712-T1       |



22




23




24


| Description of Part Or Assembly            | Fig. Ref. | Quantity Per Breaker |       |                 |
|--------------------------------------------|-----------|----------------------|-------|-----------------|
|                                            |           | 1200A                | 2000A | Ordering Number |
| Accessories                                |           |                      |       |                 |
| Accessory Kit                              | 30-34     | 1                    | 1     | 160800-T1       |
| (Order Individual Accessories As Required) |           |                      |       |                 |
| Slow Close Bracket                         | 30        | 1                    | 1     | 194147-T10      |
| Manual Charge Handle                       | 31        | 1                    | 1     | 187912-A        |
| Racking Crank                              | 32        | 1                    | 1     | 160800-T9       |
| 5th Wheel Assembly                         | 33        | 1                    | 1     | 160800-T6       |
| Lifting Yoke Assembly                      | 34        | 1                    | 1     | 160800-T7       |



30




31



32



33



34

---

Notes

www.ElectricalPartManuals.com



**BBC Brown Boveri, Inc.**  
Circuit Breaker Division  
W Columbia, SC 29169

Supersedes Issue A  
Printed in U.S.A. 3M 1286

---

www.ElectricalPartManuals.com