



CLASS	9854
PAGE	1
APRIL, 1969	

FUSE BLOCKS AND FUSE HOLDERS For National Electric Code Fuses

Fuse blocks are fabricated using ebony asbestos bases and a copper chromate finish on current-carrying parts. Terminals on the 30 ampere unit have wire-binding washers; 60 and 100 ampere have solderless connectors and 400 and 600 ampere have terminal screw and nut without lugs.

Fuse holders for front-connection have mounting screws for 1/2" panel thickness on 200-ampere and smaller and for 1" thick panel on 400 and 600 ampere. Back-connection fuse holder terminal studs, on 200 ampere and smaller, fit any panel up to 2" thick. The 400 and 600 ampere holders fit panels from 1" to 2" thick. Fuse holders have a copper chromate finish and are not furnished with terminal lugs.



400 AMPERE,
SINGLE-POLE FUSE BLOCK





FUSE BLOCKS

(Prices Do Not Include Fuses)

Ampere Rating	One Pole			Two Pole			Three Pole			Four Pole		
	Type	Price	Weight	Type	Price	Weight	Type	Price	Weight	Type	Price	Weight
250 VOLT												
30	B-3611	\$ 1.	1/2	B-3621	\$ 4.	2	B-3631	\$ 6.	1 1/2	B-3641	\$ 7.	2
60	B-3612	2.	1	B-3622	7.	2 1/4	B-3632	10.	3	B-3642	14.	4
100	B-3613	4.	2	B-3623	10.	5	B-3633	14.	6 3/4	B-3643	21.	9
200	B-3614	6.	3 1/2	B-3624	21.	8 1/4	B-3634	27.	12 3/4	B-3644	41.	16
400	A-3615	15.	7 3/4	A-3625	49.	17	A-3635	73.	26	A-3645	100.	35
600	A-3616	20.	9 1/2	A-3626	67.	20	A-3636	96.	30	A-3646	134.	40
600 VOLT												
30	B-3651	\$ 2.	3/4	B-3661	\$ 5.	2	B-3671	\$ 8.	3	B-3681	\$ 11.	54
60	B-3652	2.	1 1/2	B-3662	8.	4	B-3672	11.	5 1/2	B-3682	16.	6
100	B-3653	4.	2	B-3663	13.	7 1/2	B-3673	22.	10 3/4	B-3683	28.	14
200	B-3654	6.	5	B-3664	23.	14	B-3674	35.	16	B-3684	47.	24
400	A-3655	17.	8	A-3665	53.	19	A-3675	85.	30	A-3685	117.	40
600	A-3656	22.	11	A-3666	76.	22	A-3676	113.	36	A-3686	154.	48

FUSE HOLDERS

UNMOUNTED, WITHOUT LUGS (Prices Do Not Include Fuses)

Ampere Rating	Front Connected			Ampere Rating	Back Connected		
	Volts	Type	Price		Volts	Type	Price
0-30	250	A-25	\$1.	0-30	250	D-35	\$1.
31-60	250	A-26	1.	31-60	250	D-36	2.
0-30	600	A-27	1.	0-30	600	D-37	2.
31-60	600	A-28	1.	31-60	600	D-38	2.
 0 to 60 Ampere				 0 to 60 Ampere			
61-100	250-600	A-29	\$3.	61-100	250-600	D-39	\$ 3.
101-200	250-600	A-30	4.	101-200	250-600	D-40	6.
201-400	250-600	A-31	6.	201-400	250-600	D-41	10.
401-600	250-600	A-32	8.	401-600	250-600	D-42	16.
 61 to 600 Ampere				 61 to 600 Ampere			

ORDERING INFORMATION REQUIRED

1. Class and Type number.
2. Voltage and ampere rating.
3. Number of poles (for fuse blocks).
4. Front or back-connected (for fuse holders).